

# LANCIA



# LANCIA k

## 2nd Volume

 Service  
Manual

3U05DV

COPYRIGHT Fiat Auto S.p.A.

Reproduction of all or part of the text and illustrations is prohibited.

The information in this publication is intended as a guide and could be superseded by modifications introduced by the Manufacturer at any time for technical and commercial reasons or in accordance with local regulations.



Fiat Auto S.p.A.  
Direzione Marketing Commerciale  
Direzione Post-Vendita - Servizi - Assistenziali  
10134 TURIN (Italy) - Corso E. Giambone, 33  
Print no. 506.475 - Ottobre 1994 - 400  
Printed in Italy - Tip. Europrint - Torino




This manual contains the main instructions for repairing and maintaining the **LANCIA k**

The section **INTRODUCTION AND TECHNICAL DATA (00.)** has the dual function of introducing the model and supporting the remaining part of the manual. This section contains the tables of technical data and specific information relating to the sections in the remaining part of the manual.

**The remaining sections (10. - 18. etc.)** include the descriptions for the repair operations.

This manual contains graphic representations and symbols in place of descriptions for mechanical components, operations and servicing.

For example:



Tighten to torque

**ENGINES** Section 10 contains illustrations of the operations of removing-refitting the power unit, operations on vehicle and the various fuel, lubrication and cooling systems. The procedure for overhauling the engines, is published in separate booklets under the following print numbers:

1995 16v: 504.513/06

Inserted in the Overhauling Petrol Engines Manual Volume 1

1998 20v - 2446 20v: 505.810/02

2959 V6 24v: 505.810/03

} Inserted in the Overhauling Petrol Engines Manual Volume 2

2387 TD: 505.223/02

Inserted in the Overhauling Diesel Engines Manual

**GEARBOXES** Section 21-27 illustrates the operations of removing and refitting the gearbox. The procedure for overhauling the manual gearbox at the bench is published in a separate booklet under the following print number:

505.028/05:

Inserted in the Overhauling gearboxes manual

**THIS PUBLICATION HAS BEEN PRODUCED IN A LOOSE LEAF FORMAT TO FACILITATE THE OPERATION OF UPDATING THE MODEL.**



For the use of chemical products stick closely to the instructions in the safety chart which the supplier must give the consumer (for Italy in accordance with D.M. no. 46/1992)

**The LANCIA k** is a three box saloon with a load carrying structure, a transversely mounted engine and front wheel drive.

**The LANCIA k** is available in 5 different versions.






































**The LANCIA k 2.0** is powered by a 1998 cc, 5 cylinder in line engine with 4 valves per cylinder with BOSCH Motronic integrated electronic injection/ignition which develops a power output of 107 kW (145 CV bhp)

**The LANCIA k 2.0 t** is powered by a 1995 cc, 4 cylinder in line engine with 4 valves per cylinder with BOSCH Motronic integrated electronic injection/ignition, supercharged by a Garrett turbocharger and develops a power output of 151 kW (205 CV bhp)

**The LANCIA k 2.4** is powered by a 2446 cc, 5 cylinder in line engine with 4 valves per cylinder with BOSCH Motronic integrated electronic injection/ignition and develops a power output of 129 kW (175 CV bhp)

**The LANCIA k 3.0** is powered by a 2959 cc 6 cylinder in 60° V engine, with 4 valves per cylinder, with BOSCH Motronic integrated electronic injection/ignition and develops a power output of 148 kW (201 CV bhp)

**The LANCIA k 2.4 td** is powered by a 2387 cc 5 cylinder in line Diesel engine with electronically controlled indirect injection, supercharged by an IHI turbocharger and develops a power output of 91 kW (124 CV bhp)

	Removing Disconnect		Inlet
	Refitting Connect		Exhaust
	Dismantling Disassembly		Operation
	Fitting Composition		Tolerance Difference in weight
	Tighten to torque		Pre-loading
	Tighten to torque plus angle		Rotation
	Fully tighten		Compression ratio
	Stake nut		Selection Classes
	Adjustment Regulation	 Oversize Greater than .... Maximum	 Undersize Smaller than .... Idling
	Visual inspection Check		Number of revs
	Warning		Ratio
	Lubricate Grease		Pressure
	Replace Genuine spares		Temperature
	Bleed braking system		Temperature < 0°C Cold Winter
	Work surface Machined surface		Temperature > 0°C Hot Summer
	Interference Force fit		Windscreen wiper with electric washer pump
	Distance to be measured Measurement - Check Thickness - Clearance		Rearscreen wiper with electric washer pump
	Rolling torque		Engine

## SERVICE MANUAL COMPOSITION




At present, September 1994, the LANCIA K 2nd volume manual is composed of the following booklets:

Print No.	Sections	Page Nos.	Versions	Comments
<b>506.475/01</b> With binder (IX/94)	<b>50</b>	1 ÷ 50	All versions	Automatic climate control Automatic heater
	<b>55</b>	1 ÷ 178	All versions	Electrical equipment
		1 ÷ 143	All versions	Wiring diagrams
	<b>55D</b>	1 ÷ 83	All versions	Electrical equipment diagnosis
	<b>70</b>	1 ÷ 82	All versions	Removing-refitting Replacing body panels

Print N°	Sections	Page Nos.	Versions	Comments
<b>506.475/08</b> (IV/96)	<b>55</b>	117-117/1 117/2-117/3 117/4-118	All versions	Lancia CODE emergency starting procedure using accelerator pedal (96 range)
<b>506.475/14</b> (VI/96)	<b>55</b>	18	All versions	Electrical equipment update
		1-17	96 range versions	Radiofrequency alarm
		1-43	All versions	Wiring diagrams update
	<b>55</b>	34/1-34/2 72/1	All versions	Update for fitting front door hinges and sticking interior rear view mirror support plate
<b>506.475/16</b> (VIII/96)	<b>50</b>	19-20	All versions	Update
	<b>55</b>	176/3-176/6	All versions	Passenger Air Bag-New Air Bag update
		23-24 29-32	All versions	Wiring diagrams update
		1-30	96 range versions	Wiring diagrams
<b>506.475/18</b> (X/96)	<b>55</b>	53-54	All versions	Infocenter update
	<b>70</b>	32/1	All versions	Replacing glove compartment flap lock barrel
<b>506.475/13</b> (XI/96)	<b>55</b>	Index 26/1-26/4 29	96 range versions	Radio phone wiring diagrams update
<b>506.475/19</b> (VI/97)	<b>55</b>	53-54	All versions	Update: Infocenter
		79-80 80/1		Update: Headlamp alignment
		26/5-26/10 29	96 range versions	Update: Wiring diagrams
	<b>70</b>	83-84	All versions	Update: Sound insulation panels
<b>506.475/20</b> (XI/97)	<b>55</b>	57-58	All versions	Update: I.G.E. control unit
		Index 26/11-26/12	96 range versions	Update: Wiring diagrams.

## SERVICE MANUAL COMPOSITION

At present, January 1999, the **LANCIA k 2nd volume** manual is composed as follows:

Print N°	Sections	Page Nos.	Versions	Comments
<b>506.475/01</b> With binder (IX/94)	50	1-50	All versions	Automatic climate control Automatic heater
	55	1-178	All versions	Electrical equipment
		1-143	All versions	Wiring diagrams
	55D	1-83	All versions	Electrical equipment fault diagnosis
	70	1-82	All versions	Removing-refitting Replacing body panels
<b>506.475/02</b> (X/94)	55	101-118	All versions	Electrical equipment: Lancia CODE
		1	All versions	Wiring diagrams index
<b>506.475/04</b> (XI/94)	70	35-36	All versions	I.S. 12/94
<b>506.475/05</b> (III/95)	70	35-36	All versions	Replacing rear window update
<b>506.475/07</b> (V/95)	55	31-54 117-118 175-176 176/1-176/1	All versions	Infocenter-Lancia CODE Air Bag: update
		13-14		Lancia CODE: wiring diagram update
<b>506.475/09</b> (VII/95)	50	28/1-28/2	All versions	I.S. 6/95
<b>506.475/11</b> (XI/95)	55	3-3/1 3/2-4	 20V   TD	I.S. 11-12/95
	70	34/1-34/2	All versions	




Print N°	Sections	Page Nos.	Versions	Comments
506.475/22 (II/98)	55	147-176	All versions	Update: Air Bag
506.475/23 (V/98)	55	Index 26/13-26/14	96 range versions	Update: Wiring diagrams
506.475/25 (II/99)	70	17-18 34/1-34/2	All versions	Update: Removing-refitting front seat and sticking interior rear view mirror support plate





## WORKSHOP MANUAL COMPOSITION

To date, June 1997, the LANCIA k volume 2 manual comprises the following:

Publication no.	Sections	Number of pages	Versions	Notes
<b>506.475/01</b> With binder (IX/94)	<b>50</b>	1-50	All versions	Automatic air conditioner Automatic heater
	<b>55</b>	1-178	All versions	Electrical system
		1-143	All versions	Wiring diagrams
	<b>55D</b>	1-83	All versions	Electrical equipment diagnosis
	<b>70</b>	1-82	All versions	Removing-refitting Replacing body panels
<b>506.475/02</b> (X/94)	<b>55</b>	101-118	All versions	Electrical system: Lancia CODE
		1	All versions	Contents wiring diagrams
<b>506.475/04</b> (XII/94)	<b>70</b>	35-36	All versions	S.I. 12/94
<b>506.475/05</b> (III/95)	<b>70</b>	35-36	All versions	Replacing rear window update
<b>506.475/07</b> (V/95)	<b>55</b>	31-54 117-118 175-176 176/1-176/1	All versions	Infocenter - Lancia CODE Air-Bag: update
		13-14		Lancia CODE: wiring diagram update
<b>506.475/09</b> (VII/95)	<b>50</b>	28/1-28/2	All versions	S.I. 6/95
<b>506.475/11</b> (XI/95)	<b>55</b>	3 - 3/1 3/2 - 4	 20V  20V  TD	S.I. 11-12/95
	<b>70</b>	34/1-34/2	All versions	


Cont.

Publication no.	Sections	Number of pages	Versions	Notes
<b>506.475/08</b> (IV/96)	<b>55</b>	117-117/1 117/2-117/3 117/4-118	All versions	Lancia CODE emergency starting procedure with accelerator pedal ('96 range)
<b>506.475/14</b> (VI/96)	<b>55</b>	18	All versions	Update of electrical system
		1-17	'96 range versions	Alarm and radiofrequency
		1-43	All versions	Update of wiring diagrams
	<b>55</b>	34/1-34/2 72/1	All versions	Update of fitting of front door hinges and glueing of interior rear-view mirror mounting plate
<b>506.475/16</b> (VIII/96)	<b>50</b>	19-20	All versions	Update
	<b>55</b>	176/3-176/6	All versions	Update of passenger Air-Bag - New Air-Bag
		23-24 29-32	All versions	Update of wiring diagrams
		1-30	'96 range versions	Wiring diagrams
<b>506.475/18</b> (X/96)	<b>55</b>	53-54	All versions	Update of Infocenter
	<b>70</b>	32/1	All versions	Replacing lock barrel on glove compartment door
<b>506.475/13</b> (XII/96)	<b>55</b>	Contents 26/1-26/4 29	'96 range versions	Update of wiring diagrams: Car 'phone
<b>506.475/19</b> (VI/97)	<b>55</b>	53-54	All versions	Update: Infocenter
		79-80 80/1		Update: Headlamp alignment
		26/5-26/10 29	'96 range versions	Update: Wiring diagrams
	<b>70</b>	83-84	All versions	Update: Sound-proofing panels

31045V

## SERVICE MANUAL COMPOSITION




At present, December 1995, the LANCIA k 2nd volume manual is composed of the following booklets:

Print No.	Sections	Page Nos.	Versions	Comments
<b>506.475/01</b> With binder (IX/94)	<b>50</b>	1 ÷ 50	All versions	Automatic climate control Automatic heater
	<b>55</b>	1 ÷ 178	All versions	Electrical equipment
		1 ÷ 143	All versions	Wiring diagrams
	<b>55D</b>	1 ÷ 83	All versions	Elec. Equip. fault diagnosis
	<b>70</b>	1 ÷ 82	All versions	Removing-refitting Replacing body panels
<b>506.475/02</b> (X/94)	<b>55</b>	101 ÷ 118	All versions	Electrical equip.: Lancia CODE
		1	All versions	Wiring diagrams index
<b>506.475/04</b> (XII/94)	<b>70</b>	35 ÷ 36	All versions	I.S. 12/94
<b>506.475/05</b> (III/95)	<b>70</b>	35 ÷ 36	All versions	Replacing rear window glass - update
<b>506.475/07</b> (V/95)	<b>55</b>	31 ÷ 54 117 ÷ 118 175 ÷ 176 176/1 ÷ 176/1	All versions	Infocenter - Lancia CODE Air-Bag: update
		13 ÷ 14		Lancia CODE: wiring diagram update
<b>506.475/09</b> (VII/95)	<b>50</b>	28/1-28/2	All versions	I.S. 6/95
<b>506.475/11</b> (XI/95)	<b>55</b>	3 - 3/1 3/2 - 4		I.S. 11-12/95
	<b>70</b>	34/1-34/2	All versions	



## SERVICE MANUAL COMPOSITION

At present, November 1997, the **LANCIA k 2nd volume** manual is composed as follows:

Print N°	Sections	Page Nos.	Versions	Comments
<b>506.475/01</b> With binder (IX/94)	<b>50</b>	1 ÷ 50	All versions	Automatic climate control Automatic heater
	<b>55</b>	1 ÷ 178	All versions	Electrical equipment
		1 ÷ 143	All versions	Wiring diagrams
	<b>55D</b>	1 ÷ 83	All versions	Electrical equip. fault diagnosis
	<b>70</b>	1 ÷ 82	All versions	Removing-refitting Replacing body panels
<b>506.475/02</b> (X/94)	<b>55</b>	101 ÷ 118	All versions	Electrical equip.: Lancia CODE
		1	All versions	Wiring diagrams index
<b>506.475/04</b> (XII/94)	<b>70</b>	35 ÷ 36	All versions	I.S. 12/94
<b>506.475/05</b> (III/95)	<b>70</b>	35 ÷ 36	All versions	Replacing rear windscreen: update
<b>506.475/07</b> (V/95)	<b>55</b>	31 ÷ 54 117 ÷ 118 175 ÷ 176 176/1 ÷ 176/1	All versions	Infocenter - Lancia CODE Air-Bag: update
		13 ÷ 14		Lancia CODE: wiring diagram update
<b>506.475/09</b> (VII/95)	<b>50</b>	28/1-28/2	All versions	I.S. 6/95
<b>506.475/11</b> (XI/95)	<b>55</b>	3 - 3/1 3/2 - 4	 20V  20V  TD	I.S. 11-12/95
	<b>70</b>	34/1-34/2	All versions	

Cont'

Print N°	Sections	Page Nos.	Versions	Comments
<b>506.475/08</b> (IV/96)	<b>55</b>	117-117/1 117/2-117/3 117/4-118	All versions	Lancia CODE emergency starting procedure with accelerator pedal (96 range)
<b>506.475/14</b> (VI/96)	<b>55</b>	18	All versions	Update: electrical equipment
		1 ÷ 17	96 range versions	Radiofrequency alarm
		1 ÷ 43	All versions	Wiring diagrams update
	<b>55</b>	34/1-34/2 72/1	All versions	Update: fitting front door hinges and sticking interior rear view mirror support plate
<b>506.475/16</b> (VIII/96)	<b>50</b>	19 ÷ 20	All versions	Update
	<b>55</b>	176/3 ÷ 176/6	All versions	Update: Passenger Air-Bag - New Air-Bag
		23 ÷ 24 29 ÷ 32	All versions	Wiring diagrams update
		1 ÷ 30	96 range versions	Wiring diagrams
<b>506.475/18</b> (X/96)	<b>55</b>	53 ÷ 54	All versions	Update: Infocenter
	<b>70</b>	32/1	All versions	Replacing glove compartment lock barrel
<b>506.475/13</b> (XII/96)	<b>55</b>	Index 26/1 ÷ 26/4 29	96 range versions	Wiring diagrams update: Radiotelephone
<b>506.475/19</b> (VI/97)	<b>55</b>	53 ÷ 54	All versions	Update: Infocenter
		79 ÷ 80 80/1		Update: Headlamp alignment
		26/5 ÷ 26/10 29	96 range versions	Update: Wiring diagrams
	<b>70</b>	83 ÷ 84	All versions	Update: Sound insulation panels
<b>506.475/20</b> (XI/97)	<b>55</b>	57 ÷ 58	All versions	Update: I.G.E. control unit
		Index 26/11 ÷ 26/12	96 range versions	Update: Wiring diagrams

**Update for the "LANCIA K 2nd volume" manual**

**Update: Air-Bag**

(Print no. 506.475/22) (II-98) order n° \*604.45.960\*

The pages in this booklet deal with the Air Bag and replace those in Section 55 of the manual.


Together with these pages comes the Summary for the 2nd and 3rd volumes and the update pages for Section 00 of the LANCIA K '97 update and 55-70 for the LANCIA K Coupé which likewise replace the pages in the manuals.





IL38F5

	page		page
<b>AUTOMATIC CLIMATE CONTROL</b>		<b>REPLACING POLLEN FILTER</b>	29
INTRODUCTION	1	REMOVING - REFITTING EVAPORATOR/ELECTRIC FAN ASSEMBLY	29
GENERAL DESCRIPTION OF THE CLIMATE CONTROL SYSTEM COMPONENTS	3	REMOVING - REFITTING HEATER RADIATOR	34
- Drier filter	3	REMOVING - REFITTING DRIER FILTER	34
- Expansion valve	4	REMOVING - REFITTING CONDENSER RADIATOR	35
- Three stage pressure switch	5	SANDEN 7V16 COMPRESSOR	39
- Evaporator	5	- Electro-magnetic clutch	39
- Anti-frost thermostat (only for 3000 V6 versions)	6	- Removing - refitting electro-magnetic clutch	40
- Condenser	6	- Adjusting clutch clearance	41
- Internal air temperature sensor	7	- Checking oil level	42
- Outside air temperature sensor	7	NIPPONDENSO 6CA17 COMPRESSOR	43
- Mixed air temperature sensor	8	- Electro-magnetic clutch	43
- Solar sensor	8	- Removing - refitting electro-magnetic clutch	44
- Compressor	8	- Adjusting clutch clearance	45
- Evaporator/heater assembly	9	<b>AUTOMATICALLY OPERATED HEATING SYSTEM</b>	
<b>CLIMATE CONTROL SYSTEM CONTROLS</b>	10	<b>AUTOMATIC HEATING SYSTEM CONTROLS</b>	46
- CLIMA switch	10	- CLIMA switch	46
- TEMP switches	10	- TEMP switches	46
- AUTO switch	10	- OFF switch	46
- OFF switch	11	- RECIRCULATION switch	46
- RECIRCULATION switch	11	- FAN speed switches	46
- ECON function	14	- VENT, BILEV, FLOOR air distribution switches	46
- ECON switch	14	- WINDSCREEN defrost switch	47
- FAN speed switches	15	- HI condition	47
- VENT, BILEV, FLOOR air distribution switches	15	AIR DISTRIBUTION DIAGRAM	48
- WINDSCREEN defrost switch	17	JUNCTION UNIT IN ENGINE COMPARTMENT FOR VEHICLE WITH AUTOMATIC HEATER	49
- Air flow rate	17	WIRING DIAGRAM FOR SYSTEM WITH AUTOMATIC HEATER	50
- Engagement of compressor	17		
- HI condition	18		
- LO condition	18		
OUTSIDE TEMPERATURE CALCULATION	18		
- Speedometer signal	18		
AIR DISTRIBUTION DIAGRAM	20		
WIRING DIAGRAM FOR CLIMATE CONTROL SYSTEM	21		
JUNCTION UNIT IN ENGINE COMPARTMENT FOR VEHICLE WITH CLIMATE CONTROL	22		
EQUIPMENT FOR CARRYING OUT OPERATIONS INVOLVING COOLANT FLUID	23		
AUTODIAGNOSIS	28/1		






### INTRODUCTION

The automatic heating/ventilation system may be divided into two parts for convenience.

The first part is a closed circuit (represented by lower figure). This generates cold air and mainly consists of the following parts:

- a compressor;
- a condenser, fitted in front of coolant radiator;
- an evaporator, fitted in evaporator/heater assembly;
- a dehydrating filter.


The second part of the system is a closed circuit that uses coolant from the engine to generate warm air.



P3U04AH01

Heating/ventilation system diagram

- |                       |                            |
|-----------------------|----------------------------|
| 1. Compressor         | 7. Heater evaporator       |
| 2. Condenser          | 8. Condenser fan           |
| 3. Dehydrating filter | 9. 3-stage pressure switch |
| 4. Expansion valve    | 10. Anti-frost thermostat  |
| 5. Evaporator fan     | A. Coolant intake          |
| 6. Evaporator         | B. Water outlet            |




P3U05AH01

Diagram showing heating/ventilation system


- |                                    |   |
|------------------------------------|---|
| 1. Compressor                      | 9. Mixed air temperature sensor             |
| 2. Condenser                       | 10. Charging valve                          |
| 3. Dehydrating filter              | 11. Discharging valve                       |
| 4. Expansion valve                 | 12. 3-stage pressure switch                 |
| 5. Evaporator                      | 13. Anti-frost thermostat (only for engines |
| 6. Solar radiation sensor          | 3000 V6)                                    |
| 7. Interior air temperature sensor |   |
| 8. Outside air temperature sensor  |   |

### GENERAL DESCRIPTION OF HEATING/VENTILATION SYSTEM COMPONENTS



P3U06AH01

1. Filter case
2. Filter
3. Drying pack
4. Outlet fitting
5. System inspection glass



P3U06AH02

#### DEHYDRATING FILTER

The dehydrating filter is installed between the condenser and expansion valve and performs three main tasks:

- acts as an accumulator for coolant
- acts as a filter
- acts as a dessicator.

The filter accumulates most of the coolant (in liquid state) from the system and acts as a separator between coolant in a liquid state and coolant in a gaseous state.


Moisture present in the system may be extremely damaging because it generates hydrochloric acid and hydrofluoric acid when it comes into contact with coolant. These compounds corrode and damage components.

Moisture may also bring about formation of ice in the system expansion valve.

The dessicating filter also contains substances (silica gel and activated aluminium) that capture moisture present in the coolant.

Dessicating filters must therefore be stored in a dry, well-sealed environment until installation. An inspection glass on the filter outlet allows system operation to be monitored. Four instances may arise:

- A. Glass clear:** indicates system has been charged correctly, or system completely lacks coolant (in this case a complete lack of cooling action will be noted in the evaporator). Glass may also be clear if coolant charge is excessive. It is advisable to check pressure.
- B. Glass with presence of bubbles:** formation of vapour bubbles or foam through the glass indicates that system contains an insufficient quantity of coolant, or air has leaked into system. Bubbles may be noticed occasionally during system start-up or during electromagnetic clutch release.
- C. Glass with strands of oil:** indicates a lack of coolant and that oil from compressor is flowing through system.
- D. Glass with uniform, streaked fluid:** indicates that dessicating substance in filter has broken down and is flowing through the system due to breaks in containing plates.



P3U07AH01

### BLOCK-TYPE EXPANSION VALVE

The expansion valve controls fluid flow to the evaporator in order to achieve maximum system cooling potential. Fluid flow and pressure are adjusted to adapt to the various compressor rotating speeds.

This type of valve has two different coolant passages:

- lower passage, from drying filter 4 to 7, contains overheating spring 5 and modulating element - in this case ball 6 housed in calibrated duct.
- upper passage, from evaporator 1 to compressor 3, containing thermostatic sensor 2, connected to upper part of diaphragm and ball 6.

This valve performs three different functions in the system:

- controlling coolant flow
- stabilising evaporation temperature;
- controlling overheating.

The flow control function is achieved through movement of ball 6, connected to thermostatic sensor 2 by means of rod 9. Ball action is countered by spring 5.

The position of ball 6 depends on the pressure difference acting on a diaphragm located inside sensor 2. This in turn depends on evaporator fluid outlet temperature.


High outlet temperatures from evaporator 1 (corresponding to situation where high levels of heat are being dissipated) increase pressure inside thermostatic sensor 2; this involves movement of rod 9 and connected ball 6. This increases passage cross section and consequently the flow of coolant through the system.

1. Evaporator output fluid duct
  2. Heat-sensitive element
  3. To compressor inlet fitting
  4. Fluid under pressure
  5. Counter spring
  6. Ball and calibrated hole
  7. Expanded fluid (to evaporator intake fitting)
  8. Expansion valve case
  9. Rod
- C. To compressor  
F. To dehydrating filter  
Ei. Evaporator intake  
Eu. Evaporator outlet

Low temperature at the output of evaporator 1 (reduced heat dissipation) means that cross section of calibrated hole 6 is restricted to reduce flow through system.

The calibrated hole also atomises fluid in the liquid state in order to promote evaporation. Evaporation pressure is stabilised on the basis of temperature difference between evaporator inlet and outlet as follows: lower part of diaphragm is sensitive to coolant temperature at evaporator intake because a duct joins it to valve outlet downstream of calibrated hole. Upper part is sensitive to evaporator outlet temperature. Pressure differences between evaporator inlet and outlet involve temperature changes that act against direction of rod 9 and connected ball 6 (helping to damp fluctuations).

Control of overheating is ensured by spring 5, which is calibrated to ensure regular operation with pre-established temperature gap. This temperature gap (overheating) ensures that fluid to evaporator is in a vapour state. If any fluid were present, it could damage the valves when taken up by the compressor.



P3U08AH01

SETTING LEVELS	
level 1	Opens $2.45 \pm 0.25$ bar closes $2.6 \pm 0.34$ bar
level 2	Closes $15.2 \pm 0.98$ bar Differential $3.92 \pm 0.98$ bar
level 3	Opens $28_{-3}^{+2}$ bar Differential $6 \pm 2$ bar


### THREE STAGE PRESSURE SWITCH

The three-stage pressure switch controls the condenser and radiator fans when the vehicle is still or moving at low speed and no air flow is generated by vehicle progress.

Coolant condensation is then activated by means of forced ventilation.

This switch also disconnects compressor electromagnetic coupling when fluid pressure (high pressure side) reaches dangerous levels despite action of condenser and radiator fan.

When pressure is less than 2.4 bar and outdoor temperature is less than 5°C, heat is also insufficient to evaporate coolant.



P3U08AH02

### EVAPORATOR


The evaporator is fitted inside the passenger compartment in evaporator/heater assembly. Expansion takes place inside the evaporator, with consequent vaporisation of fluid. This brings about a sudden temperature drop.

The evaporator is therefore a heat exchanger that cools air flowing over it.

Air within environment to be conditioned, i.e. the passenger compartment, is forced to flow over the radiant pack by the action of a fan. It is cooled and dried because vapour condenses on the coil surfaces and then drains to the outside through a pipe.

The system is designed to operate in a vehicle with its windows closed.

### 50.




P3U09AH01

ANTI-FROST THERMOSTAT (Only for 3000 V6 engines)

The anti-frost thermostat, whose heat-sensitive pipe is fastened to the evaporator low pressure outlet, performs the task of cutting off power to compressor pulley electromagnetic coupling when temperature in this pipe section drops below 0°C. Power is restored when temperature exceeds 2.5°C.

This function maintains required cooling level. If temperature drops to excessively low levels, condensate present on evaporator fins could easily bring about the formation of a layer of ice that would obstruct air flow to vehicle passenger compartment.

If the compressor stops under these conditions, coolant can no longer flow in sufficient quantities to cool the evaporator further. Evaporation temperature tends to rise until pressure switch turns compressor on again. Now the cycle may begin again normally if operating conditions are restored.



P3U09AH02

### CONDENSER


The condenser fitted on front of the engine radiator gives up a certain amount of heat to the outside. This leads to coolant R134A changing from a gaseous state to a liquid state (temperature of 60 °C).

This consists of a radiator made out of high thermal efficiency aluminium, which is cooled by moving air produced by a fan and vehicle motion.

Insufficient heat exchange within the condenser not only brings about a pressure increase within the system but also leads to incomplete condensation of R134A. The expansion valve therefore receives fluid still in the gaseous state, which considerably reduces system cooling capacity.

Under certain driving conditions (traffic queues or steep gradients) with high outdoor temperatures, the coolant may not liquify fully. A pressure switch is therefore fitted (in addition to the existing radiator thermostatic switch) with the purpose of turning on the fan independently of the coolant temperature control.






P3U10AH01

### INTERIOR AIR TEMPERATURE SENSOR

This is located between the steering column and the INFOCENTER. It is installed on an intake so that interior air temperature reading is more reliable.

The sensor is "NTC" type with resistance of 2.2 kOhm at 25°C; service temperature ranges from a minimum of -30°C to a maximum of +85°C.

Temperature (C°)	Resistance (Ohm)
-15	15982
-10	12154
0	7200
+10	4393
+20	2753
+30	1768
+40	1161



P3U10AH02


### AIR TEMPERATURE SENSOR OUTDOOR (D)

This is fitted beneath the left-hand door mirror, as shown in the figure.

This sensor is "NTC" type with rating of 10 kOhm at 25°C.

Temperature (C°)	Resistance (Ohm)
-20	100000
-10	55000
0	32650
+10	20000
+20	12500
+30	8000
+40	5000

- A. Turned over
- B. Vertical
- C. Horizontal
- D. External temperature probe
- E. Demisting



P3U11AH01

#### MIXED AIR TEMPERATURE SENSORS

Two sensors are used in order to optimise temperature recording. These can be distinguished by colour.

Sensor 1 measures air directed to lower outlets, while sensor 2 measures air directed to upper outlets.


If selected air distribution pattern includes both solutions, the INFOCENTER averages the readings from both sensors.

The sensors in question are "NTC" type with resistance of 10KOhm at 25°C. Service temperatures range from a minimum of -20°C to a maximum of +90°C.

Temperature (C°)	Resistance (Ohm)
-5	42326
0	32650
+10	19899
+20	12492
+30	8057

#### SOLAR RADIATION SENSOR

The solar radiation sensor is located on the fascia close to the windscreen. It is photodiode type.



P3U11AH02

#### COMPRESSOR

The compressors used in this heating/ventilation system are of two types, as follows:

- NIPPONDENSO 6 CA 17
- SANDEN SD 7 V 16.

## EVAPORATOR/HEATER ASSEMBLY


This system automatically regulates the following parameters: air temperature to outlets, fan speed, air distribution, recirculation, compressor activation.

The system must allow the following parameters and functions to be adjusted manually: fan speed over 5 positions, air distributor over 4 positions (5 automatic), recirculation, compressor activation.

Manual manoeuvres over-ride automatic actions and are saved until the user deletes the control by returning functional control to the automatic system.

If one of the parameters is altered manually, the others remain under automatic control. Temperature of air flowing to outlets is always controlled automatically to ensure temperature indicated on display is achieved in passenger compartment (unless system is off).


As already described previously, heating/ventilation system is integral with an INFOCENTER system, which will be discussed in greater detail in Section 55 - Electrical equipment.



P3U13AH01

1. Mixing actuator
2. Recirculation actuator
3. Distribution actuator

#### HEATING/VENTILATION SYSTEM CONTROLS



P3U14AH01


Automatic heating/ventilation system controls are located on the INFOCENTER, which is positioned in the middle of the facia.

#### CLIMA DATE key

Used to turn INFOCENTER to heating/ventilation mode.

#### TEMP keys

The TEMP keys are used to select passenger compartment temperature within a 15 °C range (from 18 °C to 32 °C). Temperature setting appears on the display, regardless of time for which held down.




P3U14AH02

If user selects a temperature higher than 32 °C (90 °F), HI status is set (see HI key), accompanied by deactivation of wording FULL AUTO and activation of wording AUTO. This status involves the following conditions:

- mixer flap locked in maximum heat position;
- FLOOR distribution (unless otherwise selected by user, or a different time interval elapses between engine start-up to achievement of service temperature, termed start-up transitory state)
- compressor controlled by system logic, unless otherwise selected by user;
- air flow equal to 300 m/h, unless otherwise selected by user, or flow of 80 m/h set by start-up transitory state;
- recirculation activated.

This situation may be altered only by **altering required temperature**.




P3U14AH03

#### AUTO key

When the AUTO key is pressed, the system automatically controls temperature, distribution, fan speed and activation of recirculation.


Wording FULL AUTO appears on display when system is in this condition.



P3U15AH01

### OFF key

When the OFF key is pressed, the system is deactivated (if on) or activated (if off). Any messages on system operation will disappear from the display while only recirculation will stay activated.




P3U15AH02

### RECIRCULATION key (🚗)

When the recirculation key is pressed, recirculation function is activated and display shows relevant symbol. If no manual commands are given, recirculation is controlled automatically (by means of an actuator). This occurs on the basis of outdoor temperature (if greater than 26 °C) and also of treated (or mixed) temperature).


A particular automatic cycle for control of recirculation is activated under these conditions. This involves the recirculation function coming on for 7 minutes (outside air flow cut off completely) as the recirculation symbol appears on the display. Once this period has elapsed, the system opens the recirculation flap for 32 seconds in order to allow air to be exchanged inside the passenger compartment. During this operation, the symbol disappears from the display. After 32 seconds, the recirculation flap closes again for a further 7 minutes and the symbol reappears on the display. Cycle is repeated if temperature is below 26 °C and recirculation key not pressed manually.

**NOTE** *With engine running (immediately following start-up), if outdoor temperature level is greater than or equal to 26 °C (condition when recirculation is activated automatically) this function is not enabled until interior temperature set by user has stabilised).*




P3U15AH04

Passenger compartment air exchange logic (only with treated temperature greater than 3°C)




P3U16AH01

If the system operates automatically, the wording FULL AUTO appears on the display. The INFOCENTER logic carries out timed recirculation flap openings (recirculation symbol disappears from display).




P3U16AH02

If the recirculation button is pressed when recirculation is on, the wording FULL AUTO disappears from the display and the recirculation symbol appears. The recirculation function is permanently active.




P3U16AH03

When the recirculation key is pressed again, the symbol disappears from the display and the recirculation function is permanently deactivated.



P3U17AH01


When the recirculation key is pressed for a third time, the original automatic recycle function is restored. The FULL AUTO function reappears on the display and the 7 min/32 sec. cycle is restored.




P3U17AH02

Other situations may also occur where temperature is lower than 26 °C:

1. During stage when INFOCENTER operates in FULL AUTO mode and RECIRCULATION function is active, when key (🚗) is pressed, the air outlets will open and can no longer be controlled through the ECU. The wording AUTO appears on the display and the recirculation symbol disappears.
2. When the ECU is in FULL AUTO mode, but not in RECIRCULATION phase (i.e. with outside air outlets open), the wording FULL AUTO will disappear when the (🚗) key is pressed and the wording AUTO will appear together with recirculation symbol.



P3U17AH03



P3U17AH04

#### Recirculation mode when ECON key activated

When the system operates in ECON mode, the RECIRCULATION function may only be activated manually.

When the ECON key is pressed, the heating/ventilation system introduces timed opening of outside air intake flaps. Symbol disappears from display when flaps are open.

When key is pressed a second time, this function is eliminated and the ECU takes over control of the heating/ventilation system.

#### ECON key

When the ECON key is pressed, the compressor is cut out and the wording AUTO ECON appears on the display.

Once the key is pressed, the function is saved for an indefinite time, even once the vehicle has stopped, as with the other manual controls.

When the key is pressed again, the function is cancelled and the automatic system takes over control of both the compressor and other ECON-related parameters.

When the ECON key is pressed, the system checks whether outdoor temperature is higher or lower than required.


Two situations may occur:

- A. If outdoor temperature is lower than required, system works normally and can provide requirement without activating compressor.
- B. If outdoor temperature is higher than interior temperature, the system cannot reduce passenger compartment temperature.


This situation is indicated on the INFOCENTER display when the flashing indication ECON appears for a time of about 10 seconds.

The flashing status is saved and redisplayed whenever vehicle is started up again or internal temperature is altered to a level higher or lower than outdoor temperature or AUTO mode is activated.


When the TEMP key is pressed, the user may increase or decrease the temperature. If a higher than requested outdoor temperature is accepted as valid, the ECON display will again show a flashing ECON indication which subsequently becomes fixed.



P3U18AH01




P3U18AH02



P3U18AH03





P3U19AH01

### FAN speed keys


When the AIR keys are pressed, the air flow changes. This is displayed by bar-graphs (containing 5 bars) and the word AUTO will appear on the display. If no manual command is given, speed will be controlled by the computer and FULL AUTO will appear on the screen.

AIR key may be pressed manually to increase (right-hand key) or reduce (left-hand key) the flow. If the flow is reduced with the compressor activated, the fan will stay on (minimum, one bar) while it will go off in ECON mode.


### Air distribution keys VENT (↗), BILEV (↖), FLOOR (↕)

When the VENT, BILEV, FLOOR keys are pressed, air distribution alters. The relevant symbols light up, plus the word AUTO on the display

A. When the VENT is pressed, the relevant symbol lights up on the display and air is conveyed to the middle of the facia.




P3U19AH02




P3U19AH03

### 50.

B. When the BILEV key is pressed, the symbol (🌀) is displayed and air is conveyed to the central-lower part of the facia.




P3U20AH01




P3U20AH02

C. When the FLOOR key is pressed, the symbol (🌀) appears on the display and air is conveyed to the bottom part of the facia.




P3U20AH03




P3U20AH04


During the stage of winter temperature increase, until temperature of treated air at outlets reaches a temperature of more than 21 °C, the system assumes distribution mode with fan on first speed.



P3U21AH01



P3U21AH02



P3U21AH03

### Windscreen demister key ( )

This function is activated automatically only during the temperature increase stage, until temperature at air outlets reaches a level higher than 21 °C.

In all other cases, activation may take place only manually and is accompanied by appearance of the relevant symbol and the wording AUTO.

### Air flow

When the AIR keys are activated, the change in air flow should be displayed by the bar-graph lighting up.

If no manual command is given, speed will be controlled continuously by INFOCENTER logic and the wording FULL AUTO will appear on the display.

With the compressor on, minimum possible manual speed setting will correspond to one lighted bar. This prevents the compressor becoming frozen.


### Compressor activation

The INFOCENTER sends a signal to the Bosch MOTRONIC electronic control unit in order to activate the compressor. Compressor activation, except for anti-frost sensor operation, is dependent upon outdoor temperature (A) in accordance with a set equation.



*With outdoor temperature between 5 and 7 °C the automatic logic should activate the compressor provided that OFF and ECON keys are not activated.*

If recirculation is activated manually the compressor will stay on until outdoor temperature drops to -5 °C.



P3U22AH01

#### HI status

If the user sets a temperature in excess of 32 °C (90 °F), system enters HI mode i.e. with full heating. This appears on the display accompanied by wording AUTO.

This situation involves the following consequences:


- mixer flap locked in "full heat" position;
- distribution flap set to FLOOR, unless user selects otherwise or distribution is set to DEF;
- compressor managed by logic, unless otherwise selected by user;
- air flow equal to 300 m<sup>3</sup>/h, unless otherwise selected or set to 80 m<sup>3</sup>/h;
- recirculation off.

This mode is turned off only when the temperature is reduced.


#### LO status

If the user sets a temperature less than 18 °C (64 °F), LO status is activated - i.e. maximum cooling. This word appears on the display accompanied by AUTO. This situation involves the following consequences:

- mixer flap locked in maximum cooling position;
  - distribution set to VENT, unless user selects otherwise;
  - air flow equal to 400 m<sup>3</sup>/h, unless user selects otherwise;
  - compressor controlled by logic, unless user selects otherwise;
  - recirculation activated without reopening.
- This status is deactivated only when required temperature is increased.



P3U22AH02



P3U22AH03

#### COMPUTING OUTDOOR TEMPERATURE

##### Speedometer signal

This signal from the multiple instrument is a signal processed by the INFOCENTER for computing temperature as a function of vehicle speed.



The pulse generator is based on a Hall-effect sensor, with 4 pulses/revolution (equal to 4 pulses/metre) operating at ambient temperature, 14V and 3000 rpm.

The external temperature value with which the system operates is selected each second from between the memorized value and the measured value, in accordance with the speed of advance and time, in accordance with a logic in the control unit.


In other words, when the ignition is on, the control unit takes account of the external temperature which the relevant sensor is measuring, and compares it with the last temperature measured before the ignition was switched off.

If the external temperature is below that memorized previously, the control unit replaces this value with the value in memory; if it is higher, it is not updated.

With the car running, the external temperature value is updated also using the signal coming from the instrument panel speedometer; this signal is considered in accordance with a threshold value of 30 km/h.

**If the car does not exceed 30 km/h**, the external air temperature is updated only if it decreases in relation to the value previously memorized at the time when the ignition was switched on.

**If the car exceeds 30 km/h for at least 1 minute**, the value relating to the external air temperature is replaced with that memorized previously, whether it has increased or decreased.



P3U23AH02


CONNECTOR	INPUT SIGNAL
A	Earths and supplies
B	Faults and wear
C	Faults
D	Climate control
E	Various signals
F	Fault diagnosis

## 50.

### AIR DISTRIBUTION DIAGRAM

The air is drawn in by the fan (2) through the air intakes in accordance with the position assumed by the recirculation flap (1); (B) indicates an air flow taken from outside and (A) an air flow taken from inside the car.

The air passes through the evaporator (3) and reaches the mixing area where the mixing flap (4), on the basis of the position assumed, diverts the air either directly to the distribution or to the radiator heater (5). Finally the mixed air is sent, depending on the position assumed by the distribution flap (6), either to the demister (C) or ventilation (D) or floor (E).




P3U12AH01

1. Recirculation flap
2. Electric fan
3. Evaporator
4. Mixing flap
5. Radiator heater
6. Distribution flap

- A. Car interior air flow (recirculation)
- B. External air flow
- C. Windscreen air flow
- D. Central, front, side outlets air flow
- E. Bottom and rear outlets air flow

## HEATING/VENTILATION SYSTEM WIRING DIAGRAM




\* Connection variants for TD version

\*\* Connection variant for 2959 version


\*\*\* Only for TD version

### JUNCTION UNIT ON ENGINE BAY FOR VEHICLES WITH A/C



P3U77CL01

- A. Air conditioner control relay
- B. Seat for multiple connector for leads connected to junction box
- C. Connection seat for two-way customer
- C1. Terminal connected to air conditioner compressor
- C2. Terminal connected to engine cooling fan (low speed)
- D. Single-pole terminal for connecting engine cooling fan (high speed)
- E. Terminal for connecting main battery power source
- F. 10A fuse for air conditioner compressor
- G. 50A fuse for cooling fan (low speed)
- H. 50A fuse for cooling fan (high speed))
- I. Fan relay for engine cooling (low speed))
- L. Cooling fan relay (high speed))




P3U24AH02




## COOLANT TRANSFER EQUIPMENT

The Cleaner 134 device (shown in the various figures) is used to carry out the following operations:

- monitor vehicle air conditioning system operation;
- recover coolant in system;
- clean recovered fluid;
- recharge air conditioning system:




P3U26AH01



P3U26AH02

1. Pressure gauge assembly
2. Fitting for connection hose
3. Fitting for connection hose
4. Dispensing cylinder
5. Slot for viewing level of oil separated from coolant
6. Drain cock for oil separated from recovered coolant
7. Oil drain fitting
8. Master switch knob
9. Seat for supply lead plug (female)




P3U25AH03

## CONNECTING DEVICE TO VEHICLE HEATING/VENTILATION SYSTEM

Carry out the following operations in order:


- check that device cocks are closed and electric control knobs are in position 0 (off);
- connect quick-release fitting (A) of blue hose to needle valve (1) welded to pipe section that forms part of pipe connecting evaporator to accumulator;
- connect fitting (A) of red hose to needle valve (2) welded to four-way fitting on first pipe section connecting condenser to evaporator.



P3U25AH04

## NOTE

*Move arrowed ring-nut fully upward before installing fitting to needle valve*




P3U26AH05

# Auxiliary units

LANCIA k

## Heating/ventilation system with automatic controls

50.



P3U27AH01

Detail of Cleaner 134 device top panel

1. Moisture indicator
2. Function selector
3. Function switch
4. Compressor forcing button and "LOCK" warning light
5. "PUMP" warning light
6. "LEVEL" warning light
7. Device "ON" warning light
8. Low pressure end pressure gauge
9. "LOW" pressure cock
10. Fitting for low pressure end hose
11. "VAC" cock
12. Liquid gauge
13. "REF" cock
14. High pressure end hose fitting
15. Fitting for connecting vehicle system oil filling device
16. High pressure cock
17. High pressure end pressure gauge.
18. Low pressure end hose
19. High pressure end hose

TABLE SHOWING POSITION OF COCKS AND ELECTRICAL PARTS DURING EACH OPERATION

OPERATION	COCK LOW (9)	COCK VAC (11)	COCK REF (13)	COCK HIGH (16)	KNOB FUNCTION SELECTOR (2)	KNOB FUNCTION SELECTOR (2)
[A]•	open	closed	open	open	position 1	position 1
[B]•	open	open	closed	open	position 2	position 0
[C]•	closed	closed	open	open	position 1	position 2
[D]•	closed	closed	open	open	position 1	position 2
[E]•	open	open	closed	open	position 1	position 1
[F]•	closed	closed	closed	closed	position 1	position 3


- [A]• Recovering and recycling coolant
- [B]• Draining and drying vehicle system
- [C]• Charging vehicle heating/ventilation system
- [D]• Transferring coolant from dispensing cylinder to a canister
- [E]• Transferring coolant from cannister to equipment dispensing cylinder
- [F]• Replacing vehicle filters

Before carrying out the operations listed at the bottom of the previous page, note the comments set out below.

### RECOVERING AND RECIRCULATING COOLANT FROM VEHICLE HEATING/VENTILATION SYSTEM

Before recovering coolant from vehicle system, ensure that device dispensing cylinder contains only a small amount of coolant. Then run vehicle engine and a/c system simultaneously for 10 - 15 minutes.

This will prevent the device dispensing cylinder filling completely with consequent automatic interruption of recovery operation with transfer of excess coolant to a canister. Maximum coolant recovery will also be achieved from the vehicle system.



P3U28AH01


When coolant pressure at low pressure side device intake reaches a level of - 0.2 bar, a pressure switch automatically stops operation and the «LOCK» warning light (14) comes on. An acoustic signal also advises that the recovery operation is complete.

When the signal sounds, leave the device connected with the vehicle system running for about 10 minutes so that any low pressure coolant pockets left in the system can take up heat, increase in pressure and be recovered.

To reduce waiting time for above operation, recovery of any coolant left in the system can be forced by pressing button (14), which activates device compressor and monitors vacuum level. Vacuum reading is shown on blue low pressure side gauge.

When the above operation is complete, oil separated out from recovered coolant in distillation column may be displayed by observing level indicator (A) and drained through fitting (B) after opening cock (C).

If necessary, the same amount of clean antifreeze can be added to the vehicle system to make up for the amount removed by the device together with the coolant.




P3U28AH02

### DRAINING AND DRYING VEHICLE HEATING/VENTILATION SYSTEM

Before draining and drying system, check that device vacuum pump contains the necessary amount of oil (free of impurities) by carrying out the following operations;

- operate pump by turning selector lever to 2. Check oil level in indicator window (1) and partly back off weight (2) to let out any uncondensed gas that could contaminate the oil and cause severe damage to the pump;
- after 5 minutes of operation, check that level of oil is just over half way up indicator window (1) and no impurities are present on surface;



**View of parts used to connect electronic vacuum gauge**

1. Fitting
2. Electrical power point

Oil level in hot vacuum pump should be within range shown on indicator window (1, lower figure on previous page). If level is too high, the pump will become clogged with oil and overheat so that its efficiency is reduced. If the level is too low, lubrication may be insufficient leading to a risk of seizing.

When the pump is running, «PUMP» warning light comes on. When left hand pressure/vacuum gauge (low pressure end) indicates a given vacuum level, close cock VAC (11) and turn selector knob to position 0.

During the next 5 minutes, check vehicle system seal by monitoring vacuum level shown on left hand pressure/vacuum gauge or an electronic vacuum gauge (connected to fitting 1) to ensure level does not drop. If no leaks are detected, continue with interrupted operation until pressure gauge shows a vacuum level of 10 mbar.

## CHARGING VEHICLE AIR CONDITIONING SYSTEM

Before charging vehicle air conditioning system, check that level assumed by coolant in device dispensing cylinder column corresponds to a quantity significantly greater than amount to be added to system because device will stop automatically when minimum level is reached.

Add 70 grams to quantity of coolant required for system to cover amount left in connection lines when disconnected from system needle valves.

If system cannot be fully charged because pressure in system becomes equal to pressure in device dispensing cylinder, close HIGH cock, start up vehicle engine, activate a/c system (maximum cooling position with fan at full speed), open LOW cock slowly and close together with REF cock when system is fully charged.

## TRANSFERRING COOLANT FROM DEVICE DISPENSING CYLINDER TO A CONTAINER

Before beginning transfer, ensure that recipient is approved for pressures up to 35 bars and that a vacuum has been set up inside (at least -0.1 bar)


During transfer, use only red connection hose (high pressure side). This should be connected to service valve of recipient. Note also that recipient should be filled only to a level equivalent to less than 80% of its volume.

## TRANSFERRING COOLANT FROM DEVICE DISPENSING CYLINDER TO A CONTAINER

If this operation is necessary while vehicle a/c system is being charged, first drain system again by recovering coolant added.

## CHECKING PRESSURES IN VEHICLE SYSTEM

Pressure levels can be read directly off two device pressure gauges (blue low pressure and red high pressure) after connecting both hoses to system.



P3U30AH02

### MOISTURE INDICATOR AND FILTER REPLACEMENT

The colour of moisture indicator (1) indicates level of moisture present in liquid coolant after passing through the first three device filters.

Percentage humidity levels at given temperatures correspond to the indicator colours given in the following table

INNER DISC COLOUR	WORDING	MOISTURE CONTENT (in parts per million)		
		24° C	38° C	52° C
LIGHT BLUE	DRY	Less than 5	Less than 10	Less than 20
PURPLE-BLUE	CAUTION	5 - 10	10 - 30	20 - 50
RED	WET	Greater than 15	Greater than 30	Greater than 50

When central disc is blue, coolant is in good condition. When colour becomes more bluish, filters are still in good condition and coolant contains an acceptable level of moisture.

When colour begins to lose its bluish shade to become purple, filters require replacement.

Filters must be replaced at the end of the current operation even if central disc becomes red again because an acceptable level of coolant purity is ensured by safety filter (third filter station).

To estimate coolant temperature inside moisture indicator, rest one thumb on clear part and determine temperature according to sensation felt by consulting following table:

Sensation of cold	Use colour column corresponding to 24°C
Sensation of warmth	Use colour column corresponding to 52°C
No sensation	Use colour column corresponding to 38°C

Maximum acceptable level of moisture in coolant is 15 parts per million.

The device automatically sets up a vacuum in the part of the system connected to filters to be replaced. When a vacuum of - 0.2 bar is set up in the compressor inlet line, a pressure switch stops the compressor and simultaneously lights up «LOCK» warning light while turning on acoustic signal;

When filters are removed from seats for replacement, ensure they are under a slight vacuum. Otherwise device system could be faulty.

After replacing filters with the aim of removing air and humidity from device, connect device to a canister of R 134 A or a vehicle a/c system and perform a recovery and cleaning cycle.

### 50.


When filters are replaced, moisture indicator disc becomes red. Before it changes back to blue, it may be necessary to recover and recycle up to 2.5 Kg of coolant. Even though moisture indicator disc colour has not completely settled, coolant is nevertheless quite clean.

Heating/ventilation system test device specifications

PART	CIRCUIT INVOLVED	FUNCTION	SETTING VALUES
Three-stage pressure switch	level 1: Compressor pulley electromagnetic coupling relay coil excitation circuit	Circuit open	2.20 bar to 2.65 bar ( $2.45 \pm 0.25$ bar)
		Circuit closed	2.26 bar to 2.94 bar ( $2.6 \pm 0.34$ bar)
	level 2: Radiator and condenser cooling fan power circuit	Circuit closed	14.22 to 16.18 bar ( $15.2 \pm 0.98$ bar)
		Circuit open	10.3 to 12.26 bar differ. $3.92 \pm 0.98$ bar
	level 3: Compressor pulley electromagnetic coupling relay coil excitation circuit	Circuit open	25 to 30 bar ( $28 + 2-3$ bar)
		Circuit closed	20 to 24 bar differenziale $6 \pm 2$ bar
Anti-front thermostat	Compressor pulley electromagnetic coupling relay coil excitation circuit	Circuit open	4°C
		Circuit closed	6°C

IL39F5


## AUTODIAGNOSIS



PIL01F501


The climate control system is equipped with an autodiagnostic function; to access this function, press the "CLIMA" switch shown in the diagram and turn the ignition key to the ON position; the word AUTODIAGNOSTIC should appear on the INFOCENTER display.

After several seconds one or more codes made up of pairs of letters with numbers or numbers only will appear.



PIL01F502

If no fault is detected the code "00" will be displayed.



PIL01F503

If the fault detected is not recognized by the autodiagnostic function, the code "FF"\* will be displayed

(\*) In this case, it is necessary to use the Fiat Lancia Tester.

The codes displayed are composed of two numbers or one letter and one number. The first number or letter identifies the faulty component whilst the second number identifies the type of failure.


Faulty component codes	
Code displayed	Faulty component
1...	Mixed air temperature sensor 1
2...	Mixed air temperature sensor 2
3...	Outside air temperature sensor
4...	Passenger compartment air temperature sensor
5...	Air mixture flap actuator
6...	Air distribution flap actuator
7...	Car interior fan
8...	Signalling mixture flap actuator position
9...	Signalling distribution flap actuator position
A...	Passenger compartment sensor fan
B...	Compressor operation
C...	Solar sensor
D...	Recirculation air flap actuator

Failure type codes	
Code displayed	Type of failure
... 1	Circuit broken
... 2	Short circuit to earth
... 3	Short circuit to battery
... 4	Broken circuit and short circuit cannot be distinguished


### Examples

- 11 Broken circuit for mixed air temperature sensor 1.
- 23 Short circuit to battery for mixed air temperature sensor 2.





P3U029H01




P3U029H02

**CHANGING ANTI-POLLEN FILTER**


Carry out this operation once a year. It is advisable to change filter element at the beginning of summer.

When using vehicle mainly in town, check filter element visually every three months. Heating/ventilation system efficiency may be reduced significantly if filter is not changed.

1. Remove relay unit cover.
2. Unscrew screws retaining antipollen filter and remove.




P3U029H03




P3U029H04

**REMOVING - REFITTING EVAPORATOR/FAN ASSEMBLY**


1. Remove both wiper arms, then unscrew bolts retaining relay unit cover and remove.
3. Unscrew retaining screws and remove protective grille.
4. Remove bracket on wiper frame, then remove motor with linkage.



P3U030H01




P3U030H02




P3U030H03




1. Unscrew screws (A) and remove relay unit. Unscrew screws (B) and remove EGR valve.
2. Unscrew retaining screws (A) and remove cover. Remove brake servo vacuum pipe (B) from bulkhead.
3. Disconnect bracket retaining fuel feed pipes (A). Remove all plastic retaining studs (B) located on left and right hand side of the vehicle using tool 1878077000.
4. Remove connector block (A) located on left hand side.
5. Release wiring by undoing clip (A) indicated.




P3U030H04




P3U030H05



P3U031H01




P3U031H04




P3U031H02



1. Remove flame bulkhead from engine bay.
2. After draining system, remove expansion valve by undoing fastenings indicated in figure.
3. Disconnect fittings (A) of evaporator/heater unit line. Unscrew screws (B) and remove anti-pollen filter.
4. Disconnect both fan connectors as shown in figure, then release electrical wiring.
5. Unscrew bolts indicated in figure and release fan from evaporator.




P3U031H03




P3U031H05


50.





P3U032H01




P3U032H04



P3U032H02




P3U032H03




P3U032H05


1. Unscrew retaining nut indicated.
2. Unscrew bolt indicated and disconnect fan assembly from body.
3. Unscrew bolt indicated.
4. Unscrew bolt indicated.
5. Unscrew the three screws indicated and remove profiled bracket from evaporator.



P3U033H01




P3U033H04



P3U033H02




P3U033H03




P3U033H05


1. Unscrew bolt indicated.
2. Remove fan unit from engine bay.
3. Remove evaporator unit from engine bay.
4. Unscrew the bolts indicated and remove re-circulation flap actuator.
5. Unscrew screws (A) indicated and remove mixer flap assembly.



P3U034H01



P3U034H04



P3U034H02




### REMOVING - REFITTING HEATER RADIATOR


1. If heating radiator is to be replaced, it is advisable to drain coolant system. Loosen clips indicated figure and disconnect delivery and return line.
2. Remove heater radiator.

### REMOVING - REFITTING DEHYDRATING FILTER


3. Drain system using CLEANER 134.
4. Disconnect both pipes (seal with plugs) and pressure switch.
5. Loosen screw indicated, then withdraw filter.




P3U034H03



P3U034H05



P3U035H01




P3U035H02


**REMOVING - REFITTING CONDENSER RADIATOR**

Dehydrating filter need not be removed in order to remove condenser. **Drain system using CLEANER 134.**


1. Remove both front lights by undoing screws indicated.
2. Remove both front fog lamps by undoing screws indicated.
3. Remove screws located inside fog lamp compartment.
4. Remove screws located near front wheels as shown in figure.




P3U035H03



P3U035H04




P3U036H01




P3U036H02



1. Unscrew screws on lower part of bumpers.
2. Unscrew dehydrating filter mount bracket retaining nuts.
3. Unscrew retaining screws on fan assembly fins, disconnect electrical connections from both fans and remove assembly from engine bay.
4. Remove bonnet opening linkage and fastenings securing upper beam as shown in figure. Then remove beam.




P3U036H03




P3U036H04






P3U037H01




P3U037H04




P3U037H02



1. Remove pipe located at right hand side of condenser.
2. Remove pipe located at left hand side of condenser and withdraw from pipe carrier bracket.
3. Remove both nuts indicated which secure bracket to engine oil radiator mounting. Take care not to damage shroud during removal.
4. Remove both right hand side screws and left hand screw from oil radiator shroud and remove.
5. Unscrew the bolts indicated on left hand side of shroud.




P3U037H03




P3U037H05


50.





P3U038H01




P3U038H04



P3U038H02




P3U038H03



P3U038H05

1. Unscrew retaining screw indicated.
2. Unscrew retaining screw indicated.
3. Unscrew retaining screws indicated.
4. Unscrew retaining screw indicated.
5. Move condenser-radiator assembly toward engine and shroud outward. Then remove retaining screws on condenser fins and remove from engine bay.


## SANDEN 7V16 COMPRESSOR



P3U039H01

Oil quantity and type	240 cm <sup>3</sup> of SP 10
Electromagnetic coupling operating voltage	12 V
Minimum electromagnetic coupling activation voltage	7.5 V
Power uptake by electromagnetic coupling	49 W
Current uptake by electromagnetic coupling	4.08 A
Quantity of R134A to charge system	0.73 kg

## ELECTROMAGNETIC CLUTCH




P3U039H02

## Electromagnetic clutch components


- A. Clutch assembly retaining nut
- B. Hub
- C. Pulley retaining ring
- D. Cylinder pulley
- E. Clutch clearance adjustment shims
- F. Solenoid pulley retaining ring

- G. Solenoids
- H. Solenoid power cable
- I. Metal ring
- L. Rubber sealing ring
- M. Gasket
- N. Compressor case
- O. Earth connection cable


50.



P3U040H01



P3U040H04




P3U040H02




### REMOVING - REFITTING ELECTRO-MAGNETIC CLUTCH

1. Use tool 32409\* (A) to retain hub so that clutch assembly retaining nut can be unscrewed.
2. Use tool 32416\* (A) to remove hub.
3. Remove pulley retaining ring and clutch clearance adjustment shims.
4. After removing pulley, loosen screw indicated to release solenoid power cables. Then remove retaining ring as shown in the figure.
5. Remove solenoid, noting that dowel (A) must fit into hole on compressor case during reassembly.


\* Tool made by MURRAY of Milan.



P3U040H03




P3U040H05



P3U041H01




1. Remove installation key (A) from compressor shaft, then withdraw metal ring with felt washer (B).



P3U041H02



2. Use appropriate pliers to remove retaining ring.



P3U041H03




3. Withdraw metal washer from compressor shaft together with rubber sealing ring (A). Use tool 32425\* to remove gasket (B).

#### ADJUSTING CLUTCH CLEARANCE

Adjust clearance between hub and clutch using shims provided.

\* Tool made by MURRAY of Milan.



P3U042H01



#### CHECKING OIL LEVEL

Carry out the following operations in order to check oil level:

- operate heating/ventilation system and then compressor for about ten minutes with engine idling to drain system slowly;
- position level gauge 32448 on flat surfaces of front anchorage dogs and read angle after centring air bubble in level;
- remove oil filler plug then turn compressor clutch plate to move internal compressor components to position described below.

A. With compressor angled to right, operating rod of piston (control rod) must be at beginning of its stroke toward rear of compressor.

B. With compressor angled to left, operating rod of piston (control rod) must be at beginning of its stroke toward front of compressor (pulley end).


- fit oil level dipstick 32447 into appropriate hole until bent part touches compressor case. Note that it must be positioned according to compressor angle;

- remove dipstick from compressor and count number of notches wet with oil.


Oil level in relation to compressor angle is given in table at bottom of page.

If level is lower (than indicated), add oil to average level given in table.

Tighten plug to a torque of 1.1 - 1.2 daNm (1.1 - 1.1 Kgm).




P3U042H02



P3U042H03

Gradient angle	Number of notches
0°	2 - 4
10°	4 - 5
20°	5 - 6
30°	6 - 7
40°	7 - 9
50°	9 - 10
60°	10 - 12
90°	12 - 13


## NIPPODENSO 6CA17 COMPRESSOR



P3U043H01

Oil quantity and type	155 ± 15 cm <sup>3</sup> of ND OIL 8
Electromagnetic coupling operating voltage	12 V
Minimum electromagnetic coupling activation voltage	7.5 V
Power uptake by electromagnetic coupling	40 W
Current uptake by electromagnetic coupling	2.2 A
Quantity of R134A to charge system	0.8 kg

## ELECTROMAGNETIC CLUTCH




P3U43AH02

## Electromagnetic clutch components

- A. Clutch assembly retaining bolt
- B. Hub
- C. Pulley retaining ring
- D. Pulley for cylinder
- E. Solenoid pulley retaining ring

- F. Solenoids
- G. Clutch clearance adjustment shims
- H. Earth connection lead
- I. Solenoid power cable
- L. Compressor case

50.




P3U044H01



### REMOVING - REFITTING ELECTRO-MAGNETIC CLUTCH COMPONENTS


1. Make three equidistant millings on tool 1860494000 at distances shown in figure.



P3U044H02



2. Use tool modified in this way to remove retaining nut.




P3U044H03




3. Remove pulley retaining ring and pulley.






P3U045H01

1. Unscrew solenoid lead retaining screw indicated.



P3U045H02

2. Remove solenoid retaining ring.



P3U045H03

3. Remove solenoid, ensuring dowel on solenoid coincides with hole on compressor case when reassembling.

*Reverse operations described above to refit.*

#### ADJUSTING CLUTCH CLEARANCE

Adjust clearance between hub and clutch by means of shims.

## 50.

### AUTOMATIC HEATING SYSTEM CONTROLS

Automatic heater controls are located on INFOCENTER (as indicated on facing page), which is positioned in the middle of the fascia.

#### CLIMA key

Used to access automatic heater function on INFOCENTER.

#### TEMP keys

TEMP keys can be used to alter temperature required in passenger compartment through a range of 15°C.

#### OFF key

When OFF key is pressed, system goes off (if on) or on (if off). When this key is pressed, system operating messages should disappear from display i.e. required temperature, recirculation function (distribution, wind-screen demisting) and wording CLIMA OFF appears on display.

#### RECIRCULATION key ()

When the RECIRCULATION key is pressed, recirculation function is activated and relevant symbol appears on display. Unless manual commands are given, recirculation is controlled automatically according to required temperature and outdoor temperature.

#### FAN speed keys

When the AIR keys are pressed, air flow is altered. This is displayed by means of bar graphs (5 bars) while word AUTO appears on display.


#### Distribution keys VENT () , BILEV () , FLOOR ()

When the VENT, BILEV, FLOOR keys are pressed, air distribution is altered. Relevant symbols light up and word AUTO appears on display. When keys for the three positions are pressed, the following distribution flap angular positions are obtained:

**VENT** = 0 degrees

**BILEV** = 35 degrees

**FLOOR** = 65 degrees



P3U33AH01

CONNECTOR	INPUT SIGNAL
A	Earths and power sources
B	Faults and wear
C	Faults
D	Do not connect *
E	Various signals
F	Fault diagnosis

### Windscreen demister key ( )

This key is pressed when all air is to be directed toward windscreen (distribution flap positioned at 95 degrees).

### HI status

If user sets temperature greater than 32 °C (90 °F), HI status is obtained, i.e. maximum heating. This appears on display accompanied by wording AUTO. This status is cancelled only when required temperature is decreased.

\* For vehicles with automatic heaters, connector D is not connected


## 50.

### AIR DISTRIBUTION LAYOUT

Air is taken up by fan (2) through air intakes according to position assumed by recirculation flap (1); where (A) indicates an air flow taken from outside and (B) an air flow taken from inside vehicle.

Air reaches mixing area where mixing flap (3) directs air directly to distribution system or to heater radiator (4) according to position assumed.

According to position taken up by distribution flap (5), mixed air is directed to demister (C), fan (D) or floor (E).




P3U30AH01

Diagram showing route taken by air through heating/ventilation assembly


- |                       |  |
|-----------------------|--|
| 1. Recirculation flap | A. Outdoor air flow                              |
| 2. Electric fan       | B. Interior air flow (recirculation)             |
| 3. Mixer flap         | C. Windscreen air flow                           |
| 4. Heater radiator    | D. Air flow from central, front and side outlets |
| 5. Distribution flap  | E. Air flow to rear outlets                      |

### JUNCTION UNIT ON ENGINE BAY FOR VEHICLE WITH AUTOMATIC HEATER



P3U35AH01


- A. Seat for multiple connector for leads connected to junction box
- B. Connection seat for two-way connector
- C. Terminal connected to engine cooling fan (low speed)
- D. Single-pole terminal for connecting engine cooling fan (high speed)
- E. Connection terminal for main battery power source
- F. 50A fuse for engine cooling fan (low speed)
- G. 50A fuse for cooling fan (high speed)
- H. Fan relay for engine cooling (low speed))
- I. Cooling fan relay (high speed)



P3U35AH02

50.

### WIRING DIAGRAM FOR SYSTEM WITH AUTOMATIC HEATER



P3U25AH01

	page		page
<b>RECHARGING</b>		- Removing-refitting	77
- Battery	1	<b>LIGHTING</b>	
- Alternator	1	- Front light cluster	78
- Overhauling M.Marelli alternator	3	- Electric vertical headlamp alignment (manually operated)	79
- Overhauling Bosch alternator	7	- Fog lights	81
<b>STARTING</b>		- Side direction indicator	81
- M.Marelli starter motor	9	- Rear light clusters	82
- Bosch starter motor	10	- Additional brake light	83
<b>INSTRUMENT PANEL</b>		- Number plate light	83
- Instrument panel (petrol and auto- matic transmission versions)	11	- Front courtesy light	84
- Instrument panel (diesel versions)	12	- Passenger mirror courtesy light	85
- Description of cables and connectors	13	- Glove compartment light	85
- Description of components	15	- Door light	86
- Removing-refitting	23	- Rear courtesy light	86
- Wiring diagram (for all versions)	24	- Luggage compartment light	86
- Main wiring diagram	25	- Vehicle interior and luggage compart- ment lights control unit	86/1
<b>JUNCTION UNIT</b>		<b>VARIOUS DEVICES</b>	
- Removing-refitting	26	- Ignition switch	87
- List of fuses and main circuits protected (for cars produced up to 31/12/95)	28	- Steering column switch unit	88
- Description of cables and connectors	29	- Electric window switches	89
- List of fuses and main protected circuits (for cars produced up to 01/01/96)	28	- Windscreen wiper motor	90
<b>INFOCENTER</b>		- Sun roof motor	91
- Introduction	31	- Heater plugs pre-heating	92
- Starting stage	33	- Fuel filter	92
- Procedure for selecting language and engine type	34	- Radiator fan	93
- Infocenter system diagram	35	- Electric seats (with memory and heated)	94
- Check function	36	- Removing-refitting electric seats control unit	96
- Main wiring diagram (check function)	45	- Folding, heated external rear view mirrors	97
- Climate function	47	- Location of components and cables on vehicle	99
- Main wiring diagram (climate function)	51	- Interior rear view mirror	99
- Service function	53	- Direction indicators control unit (for versions without alarm system)	100
- Removing-refitting	55	<b>Lancia CODE</b>	
<b>I.G.E. CONTROL UNIT</b>		- Introduction	101
- Introduction	57	- Composition of system	103
- I.G.E. system diagram	59	- Programming keys	106
- I.G.E. system functions	60	- Fault diagnosis	112/2
- Diagnostic methods	72	- Procedure for emergency starting with Fiat-Lancia Tester	114
- Signals from I.G.E. control unit to In- focenter	74	- Warnings for replacing electronic key system components	114
- Main general wiring diagram	75	- Wiring diagram	117
- Insufficient brake fluid level w/light	76/1	- Emergency starting procedure using ac- celerator pedal ('96 range)	117/1



	page		page
<b>RADIO</b>		- Safety instructions for handling	
- Location on vehicle of radio system components	118	Air Bag modules	165
- Description of the components	119	- Disposing of Air Bag modules	167
- ADT 838 radio with extractable front section	124	- Safety instructions for handling pre-tensioners	167
- Clarion ADM 838 radio with extractable front section	126	- Removing-refitting driver's Air Bag	169
		- Removing-refitting clock spring	170
		- Removing-refitting passenger Air Bag	173
		- New Air Bag system	175
<b>ANTI-THEFT DEVICE</b>			
- Anti-theft system (TRW-SIPEA)	130	<b>LOCATION OF COMPONENTS ON VEHICLE</b>	
- Anti-theft control unit	130	- Location of control units, relays and fuses on vehicle	177
- Signals entering and leaving the anti-theft control unit	131	- Location of diagnostic sockets on vehicle	178
- Location of components	132		
- Anti-theft siren	133		
- Remote key	133		
- Receiver	133		
- Volumetric sensors	134		
- Key	134		
- Switches on doors, bonnet and boot lids	135		
- Two colour (green-red) LED	135		
- Operation of the anti-theft system	136		
- Auto-switching on of electronic anti-theft system (German market only)	138		
- Autodiagnosis	138		
- Fault diagnosis with instruments	139		
- Programming	142		
- Wiring diagram	146		
- Operation of anti-theft devices: domestic regulations	147		
<b>AIR-BAG</b>			
- Electrically operate Air-Bag system with pre-tensioners	148		
- Composition of the system	148		
- Control unit (5021)	149		
- Driver's Air Bag module	151		
- Passenger Air Bag module	153		
- Electrically operated pyro-technic pre-tensioner	153		
- Air Bag system failure warning light	156		
- Wiring diagram	157		
- Plates	158		
- Autodiagnosis	159		
- Fault diagnosis	159		
- Safety instructions to be observed for operations on vehicles equipped with Air Bag systems	161		

**NOTE** The components identification key, for the wiring diagrams in this Section, is given at the end of Section 55 - Electrical Equipment - Wiring Diagrams.

### COPYRIGHT FIAT AUTO


The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A.  
D.M.C. - M.P.S.  
Servizi Post Vendita - Tecnologie Assistenziali  
Largo Senatore G. Agnelli, 5 - 10040 Volvera - To (Italia)  
Publication no. 506.475/22 - Marzo 1998 - 400  
Printed by Satiz S.p.A. - Turin (Italy)  
order no. 60445960






F3U001L01

If a discharged battery is suspected, **after leaving the battery on an open circuit for at least two hours**, measure the voltage without load, connecting a digital voltmeter to its terminals. If the reading is below 12.30 V it is 50% charged; if it is 12.48 V it is 75% charged, and if it is 12.66 V it is 100% charged.



*If the electrolyte level in one or more cells of the battery is below the minimum level marked on the plastic container, open the cell cover and add distilled and deionized water (as for ordinary batteries).*

**NOTE** Do not subject the battery to fast charging at voltages of over 15.5 V, or to high recharging currents or amperages.



P3U002L01

## ALTERNATOR

Checking the voltage and maximum current intensity delivered by the alternator on the car, using a digital multimeter and HALL effect clip-on ammeter.

### Description and use of the clip-on ammeter


This is clipped to a multimeter and permits the following to be measured: battery charging and discharging current, SCR (silicon-controlled diode) controlled current and currents absorbed by starter motors, between 10 and 600 A without the circuit having to be interrupted. Before starting the measurements:

- set the 'LO-HI' switch on the clip to "LO" for measurements up to 200 A or to "HI" for measurements between 200 and 600 A.

The reading is obtained in both positions for any value, but it is necessary to change the position to ensure greater precision of the reading on the display.

- After connecting the clip to the multimeter, set the multimeter to the 200 mV or 2 V range, alternating or direct depending on the current to be measured. If the selected range is 200 mV, the reading will be given directly in amperes; if the range is 2 V, the reading must be multiplied by one thousand.
- The reading must then be reset by operating the "ZERO ADJUST" button on the clip-on ammeter. If there is reason to suspect the existence of dispersed magnetic fields, the ammeter should be reset while being held at a distance of 5-10 cm from the conductor. When measuring DC, a possible hysteresis phenomenon could render it impossible to reset the clip. In this case, open and close the clip a few times and then reset it.

55.




P3U002L01 P3U002L02

### Checking the current intensity

- Clip the clip-on ammeter onto the alternator-cable junction block (see figure);
- start up the engine and increase its speed to 3000 - 4000 rpm;
- gradually switch on all the available electrical devices;
- read the value of the maximum current output on the multimeter display.

If the current intensity reading on the multimeter is over 5 A lower than the specified value, overhaul the alternator.




P3U002L03 P3U002L04

### Check the voltage

- Place the multimeter leads in contact with the battery terminals;
- start the engine and increase its speed to 3000 - 4000 rpm;
- gradually switch on a few electrical devices until an absorption of about half of the maximum load is obtained.

Under these conditions, the voltage reading must be between the maximum and minimum values shown in the graphs below, in accordance with the ambient temperature of the electronic regulator (alternator).



PIL01M504


**OVERHAULING MARELLI ALTERNATOR**

1998 20V 2448 20V

**Removing pulley**

Remove the nut fixing the pulley using a controlled torque pneumatic screwdriver. Alternatively, proceed as described below:


- firmly fix the alternator in a horizontal position, on a cradle support with the internal walls protected with a soft material, or in a vice securing it through one of the two fixing clamps with two lead jaws in position;



PIL01M505



- lock the nut fixing the pulley (A) using the spanner (B) and insert the 8 mm spanner (C) in the alternator shaft housing;
- using a plastic hammer, strike the long side of the spanner (C) firmly, repeating this operation, if necessary, until the nut has been loosened;
- after having removed the nut and the washer, remove the alternator pulley.



PIL01M506




8 daNm

**Refitting pulley**


Clean the threaded element of the alternator shaft using a wire brush to remove any residues of Loctite, then smear Loctite 270 sealant on the first 3-4 threads.

Manually tighten the pulley until it is in the end of travel position, then tighten to the recommended torque.

# 55.




PILO1M507




### Removing pulley

Proceed to dismantle the alternator pulley by carrying out the following operations:

- securely fix the alternator in a horizontal position on a cradle support with the internal walls protected by a soft material;
- alternatively, fix the alternator in a vice locking it in a horizontal position using one of the two fixing clamps with the two lead jaws in position;




PILO1M508



PILO1M509

- insert the pins for special tool 1860900000 in the corresponding alternator pulley apertures;



PILO1M510




- fit a 24 mm bush to a controlled torque pneumatic screwdriver;
- insert the bush in the corresponding housing in tool 1860900000 and, operating the pneumatic screwdriver in a left direction (anti-clockwise), loosen the pulley.


**NOTE** During this stage the pulley should be handled gently by a suitably protected hand.




It is **IMPERATIVE** to use a pneumatic screwdriver for the operation of removing the pulley.



PIL01M511



PIL01M512




PIL01M513

#### Refitting pulley

Fit the alternator pulley by carrying out the following operations:

1. clean the threaded element of the alternator shaft using a wire brush to remove any residues of Loctite, then smear Loctite 270 sealant on the first 3-4 threads;
2. fully tighten the pulley, manually then, insert the pins for tool 1860900000 in the pulley apertures;
3. working via the aperture in the tool, insert an 8 mm spanner in the housing in the alternator shaft and, working with a torque wrench set at 11 daNm in the square housing in the actual tool, tighten the pulley to the recommended torque figure.



PIL01M514


1998 20V 2446 20V 2387 TD

#### Removing-refitting protective cap

Rest the alternator in a vertical position with the straight side facing upwards, using a suitable support.

Using a suitable screwdriver, gently apply leverage to the cap fixing clips (E) and remove the cap.

55.




PIL01M515




### Removing-refitting regulator

1. Undo the following nuts:
  - (1) for the clamping screw and the relevant bush;
  - (2) for fixing the regulator and axle to the support;
  - (3) for fixing the axle to the support;
  - (4) for the clamping screw.

When refitting, tighten nut (1) and nuts (2) and (3) to the recommended torque (0.85 daNm) and (0.55 daNm).




PIL01M516




2. - Rest the welder (80W) on the stage connection to the rectifier bridge and release a drop of filling material;


- keep the welder resting on the connection and, at the same time, using a suitable screwdriver, gently apply leverage to the plastic support for the three energizing circuits;
- remove the excess material;
- repeat the operation for each of the terminals, reducing the interval to the minimum possible to prevent the diodes from overheating;
- remove the three circuits (where fitted), then undo the regulator and bridge fixing bolt on the support (6 fig.1), the bolt fixing the regulator to the support (5 fig.1) and the bolt fixing the regulator to the bridge (7 fig.1);
- when refitting, tighten the bolts (5) (6) (7) to the recommended torque (0.25 daNm).



PIL01M517



3. Remove the regulator taking care that the blades are not damaged during the operation.




P3U005L01

**Dismantling-fitting supports**

Proceed as described for the regulator on the previous page to remove phase terminals from bridge connectors.


1. Unscrew the bolts fastening (1).



P3U005L02



2. - Rest the control end of the alternator in horizontal position on the support cradle and fasten securely;
- strike the control end of the alternator shaft using a plastic mallet until the rectifier end mount comes out together with the rotor.




P3U005L03



3. - When fitting, rest tool 1860849000 on the rectifier end mount and strike using a plastic mallet until the rectifier end mount and control end mount fit together;
- tighten bolts(1) to the specified torque (0.55 daNm).

55.




P3U006L01



### Dismantling-fitting rotor

1. - Position the rectifier end mount with rotor on a suitable support (vice);
- rest one end of the soft cylinder-shaped tool (plastic) on the end of the rotor shaft (rectifier end) near the commutator and strike the opposite end of the cylinder using a plastic mallet;
- remove the rotor from the rectifier mount;
- when fitting, ensure that the rotor turns freely and without friction inside the mount.




P3U006L02




### Dismantling-fitting mounts together with regulator

2. The alternator mounts may also be removed and refitted without removing the regulator. In this case, proceed as described previously (ignore the instructions relating to the regulator). Take care to protect the brushes using an appropriate box (1), which should be removed following installation (see fig. 2).



P3U006L03




P3U006L04

Tools no. 1860849000

Rotor removal pin and mount fitting drift






P3U007L01



### OVERHAUL OF BOSCH ALTERNATOR

#### Dismantling


- Undo the nut (1), then remove the fan and pulley from the alternator shaft;



P3U007L02



- undo the screws (4) securing the voltage regulator (5) to the alternator's rear frame, then remove the voltage regulator.



P3U007L03




#### Electronic voltage regulator

A. brushes




*If the regulator is replaced, always check the state of wear of the rotor slip rings. If the brushes have caused recesses in the commutators, always replace the complete rotor.*

55.




P3U008L01

- undo the screw (6) and after disconnecting the connector (7) from the blade terminal, remove the capacitor (8);



P3U008L02


- undo the alternator attachment bolts (9);
- undo the bolts (10) securing the plate (11) mounted under the bearing (13) to the alternator's front frame (12);



P3U008L03

- using a press or brass drift, release the bearing (13) from the alternator's front frame (12) which can then be separated from the stator;
- to refit, proceed in reverse order to dismantling.

## M. MARELLI STARTER MOTOR



P3U009L01

## Components of the M. Marelli starter motor with epicyclic reduction gear

- |                                       |                             |
|---------------------------------------|-----------------------------|
| 1. Front frame                        | 6. Shaft                    |
| 2. Casing with stator windings        | 7. Epicyclic reduction gear |
| 3. Brush holders                      | 8. Armature                 |
| 4. Engagement solenoid                | 9. Rear frame               |
| 5. Pinion complete with roller clutch |                             |

## Checks

Conduct the following checks on the starter motor components:

**armature:** continuity, short circuit and earth insulation tests

**stator:** continuity and earth insulation tests


**brush holder mounting:** earth insulation test

**solenoid:** continuity and earth insulation tests



*The roller clutch must be replaced whenever the starter motor is noisy during starting.*

#### BOSCH STARTER MOTOR



P3U010L01

#### Components of the Bosch starter motor with epicyclic reduction gear

- |   |                                     |
|---|-------------------------------------|
| 1. Engagement pinion with roller clutch | 5. Casing with windings and brushes |
| 2. Satellite shaft                      | 6. Frame                            |
| 3. Stator (inner splines)               | 7. Engagement solenoid              |
| 4. Armature                             | 8. Frame                            |

#### Checks

Conduct the following checks on the starter motor components:


**armature:** continuity, short circuit and earth insulation tests

**stator:** continuity and earth insulation tests

**brush holder mounting:** earth insulation test

**solenoid:** continuity and earth insulation tests

## INSTRUMENT PANEL (Petrol and automatic transmission versions)




P3U21CL01

1. Water temperature gauge and warning light
2. Electronic speedometer
3. Odometer LCD display
4. Fuel gauge and warning light
5. Electronic rev counter
6. Voltmeter
7. Spare warning light
8. Plug preheating warning light (diesel version only)
9. False ABS key
10. Air Bag fault warning light
11. ASR warning light
12. ABS fault warning light
13. Low brake fluid level warning light
14. Handbrake warning light
15. Oil pressure warning light
16. Generator warning light
17. Seat belts warning light
18. Right direction indicator warning light
19. Display for cars with automatic transmission (Aisin - ZF)
20. Left direction indicator warning light
21. Check summary warning light
22. Main beam headlamps warning light
23. Dipped beam headlamps warning light
24. Side lights warning light
25. Rear fog lamps warning light
26. Front fog lamps warning light
27. Heated rear window warning light
28. Right heated seat warning light
29. Trip recorder reset button
30. Left heated seat warning light
31. Trailer indicators warning light


55.

### INSTRUMENT PANEL (Diesel versions)



P3U22CL01

### Rear view of instrument panel



P3U22CL02

- A White 20-pin connector (for warning lights)
- B Black 20-pin connector (automatic transmission)
- C Blue 20-pin connector (engine compartment)
- D Black 20-pin connector (various services)

## DESCRIPTION OF WIRES AND CONNECTORS

CONNECTOR A		
Pin no.	Wire colour	Circuit involved
1	LR	Main beam headlamps warning light
2	RV	Check summary warning light
3	AN	Left direction indicator warning light
4	CB	Rear fog lamps warning light (IGE control unit)
5	GN	Side lights warning light (IGE control unit)
6	HV	Dipped beam headlamps warning light
7	BN	Front fog lamps warning light (IGE control unit)
8	AV	Right heated seat warning light
9	AG	Left heated seat warning light
10	G	+12 V for lighting
11	A	+12 V from key (+15) instrument general supply
12	N	Instrument general earth
13	MB	+12 V from battery (+30) instrument supply
14	Z	Attenuator earth for Infocenter
15	NZ	Attenuator earth
16		Not connected
17		Not connected
18		Not connected
19	CN	Heated rear window warning light (IGE control unit)
20	LG	Trailer indicator warning light


CONNECTOR B		
Pin no.	Wire colour	Circuit involved
1	ZN	To auto. transmission control unit (pin 49)
2	RV	To auto. transmission control unit (pin 16)
3	HL	To auto. transmission control unit (pin 31)
4	BN	To auto. transmission control unit (pin 33Z)
5	G	To auto. transmission control unit (pin 14Y)
6	V	To auto. transmission control unit (pin 50X)
7	HB	Auto. transmission fluid maximum temperature
8	HN	Automatic transmission fault
9	CB	Serial line for AISIN transmission
10		Not connected
11	A	Signal for "P" symbol
12	B	Signal for "R" symbol
13	C	Signal for "N" symbol
14	H	Signal for "D" symbol
15	L	Signal for "3" symbol
16	S	Signal for "2" symbol
17	M	Signal for "1" symbol
18	N	Lighting earth
19	R	+12 V (+15 key)
20	GR	+12 V (lighting)

55.


CONNECTOR C		
Pin no.	Wire colour	Circuit involved
1	A	Generator warning light (12V)
2	HN	Minimum oil pressure warning light
3	B	Generator warning light (+D)
4	BG	Coolant pressure switch
5	HV	Heated rear window enablement
6	S	Seat belts warning light
7	BR	K line for Fiat Lancia Tester
8	AB	L line for Fiat Lancia Tester
9		G line for Fiat Lancia Tester
10	BL	Activation of low speed fan relay
11	AR	Activation of high speed fan relay
12		Repetition of speedometer signal
13	MG	Repetition of speedometer signal
14	V	Repetition of speedometer signal
15	MN	Repetition of speedometer signal
16	MV	Repetition of speedometer signal
17	HG	Repetition of speedometer signal
18		Repetition of speedometer signal
19		Repetition of speedometer signal
20	GR	+ 12V lights from rheostat

CONNECTOR D		
Pin no.	Wire colour	Circuit involved
1	MB	Plug preheating warning light (diesel version)
2	AB	Air Bag fault warning light
3		ASR fault warning light
4	LB	Right direction indicators warning light
5	LN	ABS fault warning light
6	AN	Low brake fluid warning light
7	BR	Handbrake warning light (from I.G.E. control unit)
8	MG	Earth (fuel gauge)
9	AG	Signal (fuel gauge)
10		Not connected
11		Not connected
12	AR	Repetition of rev counter signal (to Infocenter)
13	A	Rev counter signal
14	GN	Speedometer signal (pulse generator)
15		Not connected
16	M	Pulse generator earth
17		Not connected
18	L	Pulse generator supply
19	V	Radiator water temperature sensor (return)
20	BV	Radiator water temperature sensor (signal)





P3U26CL01



P3U26CL02

## DESCRIPTION OF COMPONENTS

## Coolant temperature gauge

The coolant temperature gauge is driven by an electronic control unit; the signal arrives from a PTC sensor located on the cylinder head which measures the temperature in the cooling system. The signal reaches the instrument when the ignition is on (+15).

The sensor is supplied by a maximum constant current of 0.5 mA.

The warning light comes on in the following cases:

- $120^{\circ}\text{C} \pm 1^{\circ}\text{C}$  for the 1998 20v, 1995 16v turbo and 2446 20v versions;
- $116^{\circ}\text{C} \pm 1^{\circ}\text{C}$  for the 2959 24v and 2387 TD versions.

The warning light goes out when the temperature is decreasing:

- $115^{\circ}\text{C}$  for the 1998 20v, 1995 16v and 2446 20v versions;
- $111^{\circ}\text{C}$  for the 2959 24v and 2387 TD versions.

In the case of a short circuit or open circuit, the indicator positions itself at the beginning of the scale ( $50^{\circ}\text{C}$ ) and the warning light does not come on.

The warning light comes on at each start-up for a period of 4 seconds to check that the warning light is working. After 4 seconds, it remains inhibited for about 2 minutes after each start-up.

Depending on the signal coming from the coolant temperature sensor, the instrument switches on/off:

- the low speed radiator fan control relay;
- the high speed radiator fan control relay.

## Coolant temperature control logic for 1998 20v - 2446 20v - 2959 24v - 2387 TD versions

Function	Temperature increase	Temperature reduction
Low-speed electric fan	ON for Temp. = $92 \pm 2^{\circ}\text{C}$	OFF for Temp. = $87 \pm 2^{\circ}\text{C}$
High-speed electric fan	ON for Temp. = $96 \pm 2^{\circ}\text{C}$	OFF for Temp. = $91 \pm 2^{\circ}\text{C}$

The high-speed relay only comes on if the low-speed relay has been on for at least 7 seconds. If there is a fault on the high-speed circuit, the instrument keeps the low-speed relay active.

The temperature control circuit must recognize the fault state of the sensor and/or wiring.

In the event of a fault (because of break or short circuit in sensor), the system carried out the following functions:

- activation of the low-speed fan;
- coolant temperature gauge at beginning of scale ( $50^{\circ}\text{C}$ ).

## 55.

The information relating to the fault is made available through the Fiat Lancia Tester.

On versions with air conditioner, a pressure switch is mounted in the air conditioning cooling radiator; this is for activating the engine cooling fan irrespective of the engine's temperature condition.



When the pressure switch is activated:

- the low-speed fan is switched on immediately;
- the high-speed fan is switched on after 7 seconds.

When the pressure switch is activated:

- the high-speed fan is switched off immediately;
- the low-speed fan is switched off after 7 seconds.

If the pressure switch is switched off before the high speed is activated, the fan must remain activated for 7 seconds at low speed before being switched off.




### Fuel gauge

The fuel gauge is an instrument driven by an electronic control unit. In the fuel tank, there is a float which sends a signal to the instrument when the ignition is on (+15).


When the fuel reserve (9 l) is being consumed, the warning light on the instrument comes on. At each start-up, the warning light comes on for 4 seconds to check the efficiency of the system.

### Values controlling the fuel gauge


Fuel level	Values (in Ohm)
4/4	0 - 6
3/4	59 - 69
1/2	116 - 126
1/4	186 - 201
start of reserve (9 ± 1 l)	239 ± 3
0	295 - 315



P3U28CL01



P3U28CL02



P3U28CL03

### Speedometer

The speedometer is driven by an electronic control unit; the instrument and its circuit receive a speed signal from a pulse generator fitted on the gearbox.

2 scales are used:


- scale from 0-260 km/h for 1998 20v, 2446 20v and 2959 24v versions;
- scale from 0-220 km/h for 2387 TD versions.

At a speed of between 0-4 km/h, the needle on the instrument does not move; once this value is exceeded, the needle will indicate the vehicle's speed.

The pulse generator located on the gearbox is supplied directly from the instrument panel; it exploits the Hall effect and provides the instrument input a square wave which has already been amplified. For the speedometer to work, the signal must have a minimum value of below 1V and a maximum value of over 7V.

The input signal into the instrument emerges unchanged from the instrument panel and is used for other functions (e.g. air conditioner). These outputs are all separate from each other and are protected against short circuits towards the supply and towards earth.

55.




P3U29CL01

### Odometer

The odometer is electronic with LCD display, and is mounted at the top of the dashboard. The display has two numerators on 2 rows which indicate the total mileage and trip length. The data are displayed on 6 digits with 7 segments for the total mileage counter, and 4 digits for the trip recorder. To reset the trip recorder, press the appropriate button the the dashboard.

The LCD display is activated when the ignition is on (+15), the total mileage and trip length values displayed are the same as those when the engine was last switched off. When the battery terminal (+30) is disconnected, the total mileage memory is not reset, but there may be a loss of up to 4 kilometres. The trip recorder is reset whenever the direct voltage (+30) from the battery is cut.




P3U29CL02

### Rev counter

This instrument receives its signal from the fuel injection/ignition control unit. The same signal is sent to both the Infocenter for the air conditioner and the I.G.E. control unit to enable the activation of the time-lagged heated rear window.


Engine	Full scale indication	Signal collection point	Red sector	Full scale pulses
1998 20v	8000	Motronic M2.10.3 control unit	7000 - 8000	5 pulses/2 engine revs
2446 20v	8000	Motronic M2.10.3 control unit	7000 - 8000	5 pulses/2 engine revs
2959 24v	8000	Motronic M3.7 control unit	7000 - 8000	3 pulses/engine rev
2387 TD	6000	MSA11 control unit	5000 - 6000	5 pulses/2 engine revs

GENERAL WIRING DIAGRAM



P3U25CL01

55.




P3U026L01




### REMOVING-REFITTING


- Remove the trim under the dashboard, steering wheel side;



P3U026L02




- undo the attachment screw, lower the fuse and relay unit and disconnect the supply connectors, then remove the fuse and relay unit.



P3U026L03



### Fuse and relay unit, fuse side



P3U027L01




## JUNCTION UNIT

## Location of connectors on control unit



The connectors cannot be connected incorrectly because each one is individually shaped. The same letters are used to identify the connectors as are adopted in the wiring diagrams.



P3U027L02








## Location of fuses and relays on control unit


- E1. Ignition switch discharge relay.
- E2. Turn signal/hazard warning light flasher unit.
- E3. Headlamp washer timer.

55.

### LIST OF FUSES AND MAIN PROTECTED CIRCUITS (for vehicles produced up to 31/12/95)

N° Fus.	Amp.	Symbol	Protected circuit	N° Fus.	Amp.	Symbol	Protected circuit
1	15	Services 1	Switch for signal to brake light fuse IGE control unit; braking lights; brake light control signal pressed for ABS; automatic transmission; i.e. system for turbodiesel.	13	25	Services 13	Sun-roof; reversing lights; reversing light signal for electrochromic mirror.
				14	25		Front wash/wipe.
				15	25		Motors for right and left front windows.
				16	5	Services 16	electrochrome interior mirror; Infocenter; air bag system; indicator for timer; rear electric window inhibition control light; IGE control unit signal.; signal to infra-red ray receiver; signal to electric front window control unit-signal to rear electric window ECU electrici; Servotronic control unit; passenger side door lighting.
2	5	Services 2	IGE control unit signal switch for dipped beams; main beam relay; instrument panel; fog lamp/rear fog lamp warning light; Infocenter.				
3	15	Fuel Pump	Fuel pump.				
4	10	Services 4	4 puddle lights; 2 floor lights; r. and l. rear courtesy lights; boot light-compartment light; front courtesy light; timer for front courtesy light.				
5	10	Services 5	Heated electric mirrors; fold-down, heated, electric mirror courtesy light; electronic a/t.	17	5	Services 17	Infocenter; instrument panel; car radio (security code); signal for automatic transmission; acoustic signal for automatic transmission.
6	30		Heating/ventilation system.	18	5	Services 18	Siren for alarm; alarm receiver.
7	15	Services 7	Car radio; electric aerial; front cigarette lighter.	19	25		Door lock motors; fuel flap release motor.
8	10		Hazard warning light system.				
9	5	Services 9	Relay for compressor; heated seat heat pad relay.	20	5	Services 20	Electronic key system (Lancia CODE).
10	5	Services 10	Boot release electromechanical relay.				
11	25	Services 11	Free.				
12	20		Headlamp wash/wipe.				





P3U30CL01

**Seat belt warning light**

The "SEAT BELT" warning light is managed by the instrument's electronics as follows: when the ignition is switched on (+15), if the driver has not fastened his seat belt, the warning light comes on for a maximum period of 120 seconds. After this time, the warning light goes out.


LEVER POSITION	X	Y	Z
P	1	0	0
R	1	1	0
N	0	1	0
D	0	1	1
3	1	1	1
2	1	0	1
1	0	0	1

0 = contact open  
1 = contact closed

**Automatic transmission option***"ZF" gearbox*

The control unit of the "ZF" automatic transmission receives, from a mechanical selector, the gearlever's position by means of three coded signals. These signals are sent to the instrument, inside which there are separating diodes which prevent the return of currents to the control unit, thus avoiding interference or malfunctions.

The gearlever coding is effected by mechanical switches anchored to earth, and is described in the table opposite.



P3U30CL02

- A. Gear selector
- B. ZF control unit
  - 1. pin 50
  - 2. pin 14
  - 3. pin 33
- C. Instrument panel


## 55.

Information concerning the driving mode and any faults is supplied to the instrument or the Infocenter from the "ZF" control unit. If the output signal is logic "1", this is equivalent to an earth signal. The table below lists the relevant pins of the "ZF" control unit and the various situations that may arise at their outputs.

pin 16	pin 49	pin 31	Display on instrument	Display on Infocenter
1	0	0	NORM	
1	1	0	POWER	
0	1	0	ICE	
x	x	1		Automatic transmission fluid over-heating fault
1	0	1	NORM	Automatic transmission fluid over-heating fault
1	1	1	POWER	Automatic transmission fluid over-heating fault
0	1	1	ICE	Automatic transmission fluid over-heating fault
0	0	0	Display off	Auto. transmission control unit fault

### "AISIN" gearbox

On cars fitted with the "AISIN" automatic transmission, the control unit supplies to the instrument information relating to the driving mode and danger information; the communication is via a serial line. The graph below shows a serial transmission of data between the instrument and the "AISIN" control unit. After the ignition has been switched on (+15), about 512 ms must elapse before there is the "start bit", which permits transmission of the 8 information bits. To end the transmission there is a "stop bit", after which 50 ms elapse before a new data transmission.



- A. Information bits
- B. Start bit
- C. Stop bit
- D. Parity bit

The 8 bits which constitute the transmission contain information relating to the gearlever position, information relating to the set driving mode and the fault conditions as shown in the tables on the next page.

Bit 7	Bit 6	Bit 5	Selected driving mode
0	0	1	NORM MODE
0	1	0	POWER MODE
1	0	0	ICE MODE

Gearlever position	Bit 4	Bit 3	Bit 2
P	1	1	1
R	1	1	0
N	1	0	1
D	1	0	0
3	0	1	1
2	0	1	0
1	0	0	1

Bit 0	Bit 1	Type of fault	Display on instrument	Display on Infocenter
1	0	Control unit fault	Display off	AUTO. TRANSMISSION CONTROL UNIT FAULT
0	1	Automatic transmission fluid overheating	Normal display	AUTO. TRANSMISSION FLUID OVERHEATING FAULT

The control unit's outputs, used to indicate faults to the Infocenter (automatic transmission fluid overheating and system fault), are protected from short circuits to the battery positive or earth.

For purposes of diagnosis, when the ignition is switched on (+15), the outputs assume the ON state for 2 seconds followed by an OFF state for 1 second; immediately after they assume the correct value received from the automatic transmission control unit to which the instrument is connected.

## FAULT DIAGNOSIS

The instrument panel has a diagnostic socket located in the console under the dashboard for dialogue with the Fiat Lancia Tester. The connection is serial and is effected by means of dedicated K and L lines. Fault diagnosis takes place by sending requests from the Fiat Lancia Tester to the instrument, which only answers if interrogated.

### Coolant temperature signal

Check on open circuit and short circuit to earth and to battery.

On request from the Fiat Lancia Tester, the coolant temperature read by the microprocessor may be obtained via the K and L lines; it is also possible to activate the coolant temperature gauge with a specific command, issued by the Fiat Lancia Tester.

## 55.

### *Rev counter signal*

Check on open circuit and short circuit to earth and to the battery.

On request from the Fiat Lancia Tester, the signal sent from the fuel injection electronic control unit to the instrument panel may be displayed, and it is also possible to activate the rev counter with a specific command from the Fiat Lancia Tester.

### *Speedometer signal*

Check on open circuit and short circuit to earth and to the battery.

The pulses sent from the generator to the instrument are requested via the Fiat Lancia Tester.

The Fiat Lancia Tester activates the speedometer, but the number of miles on the odometer does not increase.

The voltage values (+15 and +30) may be linked to the speedometer signal.

### *Fuel gauge*

Check on open circuit and short circuit to earth and to the battery.

Reading by the Fiat Lancia Tester of the voltage signal, which indicates the amount of fuel measured in the tank and is transmitted by the K and L lines.

Activation of the fuel gauge by a command from the Fiat Lancia Tester.

### *Signal from automatic transmission*

"ZF" gearbox

Reading with Fiat Lancia Tester of the operating state of the gear engaged indicator switch.

Check on the 3 inputs relating to the gearbox status; check on the presence of short circuit and open circuit on these 3 inputs.

### *Engine cooling fan*

The Fiat Lancia Tester may activate and check the efficiency of the engine cooling relay and select its speed.

### *Automatic transmission display*


All the segments of the display may be activated by the Fiat Lancia Tester.

### *Warning lights on instrument panel*

The warning lights on the instrument panel may be checked from the Fiat Lancia Tester to check that they are working; it is possible to check the minimum or maximum intensity of each warning light.

Interface for Electronic suspension system (optional extra)

**NOTE** This car is ready for controlled-damping suspension to be fitted; this optional extra will be on the market shortly, but is not available at the moment.




P3U023L01



### REMOVING-REFITTING


- Undo the screws securing the instrument panel to the dashboard;





P3U023L02



- undo the attachment screw and remove the steering upper trim;



P3U023L03




P3U023L04

- gently withdraw the instrument panel from its seating and disconnect the supply cables;
- remove the instrument panel from the dashboard.

55.

### WIRING DIAGRAM (all versions)



P3U24CL01

## DESCRIPTION OF WIRING AND CONNECTORS

CONNECTOR A		
Terminal no.	Wiring colour	Circuit involved
1	R	Interior lights
2	-	Available
3	GN	Sun-roof
4	-	Reserve
5	GV	Windscreen wash/wipe
6	RN	Front window power supply
7	S	Door lock and fuel flap lock system

CONNECTOR B		
Terminal no.	Wiring colour	Circuit involved
1	R	Heating/ventilation system
2	A	+15 ignition switch

CONNECTOR C		
Terminal no.	Wiring colour	Circuit involved
1	H	Electric fuel pump
2	S	Reversing lights
3	AB	Right rear turn signal
4	AN	Left rear turn signal
5	RN	Electric aerial
6	RV	+15 rear wiper positive *

CONNECTOR D		
NOT USED		

CONNECTOR E		
Terminal no.	Wiring colour	Circuit involved
1	-	Available
2	-	Available
3	AR	Right turn signal control
4	AN	Left turn signal warning light
5	-	Reserve
6	AG	Left turn signal control
7	-	Available
8	N	Emergency power source for alarm
9	M	+15 from ignition switch (radio position)
10	R	Infocenter control lights
11	AV	Emergency light control
12	-	Available
13	LG	Trailer turn signal warning light
14	LB	Right turn signal warning light

\* Valid only for SW versions.

### CONNECTOR F

Terminal no.	Wiring colours	Circuit involved
1	-	Available.
2	RN	Compressor/heat pad/-electric seat relays.
3	B	Boot release relay.
4	RG	Fold-down door mirrors; electronic automatic transmission.
5	-	Available.
6	NL	Reversing light signal for electrochromic mirror.
7	AB	Right side turn signal.
8	RB	Facia (Infocenter; Servotronic control unit).
9	GV	Reversing lights with electronic automatic transmission.
10	-	Available.
11	S	Electronic code system (Lancia CODE).
12	-	Available.
13	-	Available.
14	-	Free.
15	N	Headlamp wiper timer; emergency turn signal bulb.
16	R	Car radio.
17	HV	Dipped beam signal for headlamp wiper timer
18	GR	Infra-red ray receivers.
19	M	Alarm siren and leds.
20	RV	Signal for windscreen washer for headlamp wash/wipe timer.

### CONNECTOR G

Terminal no.	Wiring colours	Circuit involved
1	R	+ 30 Battery unprotected to IGE control unit.
2	R	+ 30 Battery.

### CONNECTOR H



Terminal no.	Wiring colour	Circuit involved
1	-	Available.
2	-	Available.
3	MB	Infocenter power; instrument panel.
4	-	Available.
5	BR	Reversing light control from automatic transmission.
6	VN	Brake light control.
7	V	Brake light power supply.
8	RN	Cigar lighter.





### CONNECTOR I

Terminal no.	Wiring colours	Circuit involved
1	HN	Relay to bypass appliances during start-up.
2	-	Available.
3	-	Available.
4	HR	Reversing light control.
5	-	Reserve.
6	-	Free.
7	BR	Reversing light control.
8	VN	Headlamp pump.
9		Fuel pump.
10	A	Right front turn signal.
11	L	Left side turn signal.
12	AN	Left front turn signal.



## LIST OF FUSES AND MAIN PROTECTED CIRCUITS (for vehicles produced from 1st January 96)


N° Fus.	Amp.	Symbol	Protected circuit
1	15	Services 1	Switch for signal to brake light fuse IGE control unit; braking lights; brake light control signal pressed for ABS; automatic transmission; i.e. system for turbodiesel.
2	5	Services 2	IGE control unit signal switch for dipped beams; main beam relay; instrument panel; fog lamp/rear fog lamp warning light; Infocenter; control panel lighting dimmer; electric mirror switch lighting; front cigar lighter lighting; ashtray lighting; headlamp alignment correct control lighting; Car radio; electric windows; indicator for timer; rear electric window inhibition control light; signal to infra-red ray receiver; passenger side door lighting.
3	15	Fuel Pump	Fuel pump.
4	10	Services 4	4 puddle lights; 2 floor lights; right and left rear courtesy lights; boot light; compartment light; front courtesy light; timer for front courtesy light.
5	10	Services 5	Heated electric mirrors; fold-down, heated, electric mirror courtesy light; electronic automatic transmission.
6	30		Heating/ventilation system.
7	15	Services 7	Car radio-electric aerial; front cigarette lighter.
8	10		Hazard warning light system.
9	5		Relay for compressor; electric seat heat pad control relay.
		Services 9	

N° Fus.	Amp.	Symb-ol	Protected circuit
10	5	Services 10	Boot release electromechanical relay.
11	25	Services 11	Free.
12	20		Headlamp wash/wipe.
13	25	Services 13	Sun-roof; reversing lights; reversing light signal for electrochromic mirror.
14	25		Windscreen wash/wipe.
15	25		Engines for right and left front windows.
16	15	Services 16	Infocenter; air bag system; IGE control unit signal.; signal to electric front window control unit; signal to rear electric window ECU; Servotronic control unit.
17	5	Services 17	Infocenter; instrument panel; car radio (security code); signal for automatic transmission; acoustic signal for automatic transmission.
18	5		Siren for alarm; alarm receiver.
19	25	 Services 18	Engines for central locking; engine for fuel flap lock.
20	5	Services 20	Electronic code system (Lancia CODE).

### INTRODUCTION

The "INFOCENTER" on-board information centre is fitted to all specifications and consists of:

- a liquid crystal display;
- 18 keys to call up/activate functions;
- two function control microprocessors.



**Components of INFOCENTER**

P3U55CL02

- |   |   |
|---|---|
| 1. Left front side/parking light                | 17. Rear boot closure sensor                                |
| 2. Right front side/parking light               | 18. Left rear side light                                    |
| 3. Coolant level sensor                         | 19. Left brake light  |
| 4. Right-hand brake lining wear sensor          | 20. Left rear fog lamp                                      |
| 5. Turbo pressure sensor (only Diesel versions) | 21. Left number plate light                                 |
| 6. Automatic transmission ECU                   | 22. Left rear door closure sensor                           |
| 7. Electronic injection control unit            | 23. Left front door closure sensor                          |
| 8. Automatic air conditioner                    | 24. Diagnostic socket                                       |
| 9. Infocenter                                   | 25. IGE control unit.                                       |
| 10. Right front door closure sensor             | 26. Interconnection control unit on facia                   |
| 11. Right rear door closure sensor              | 27. Water in fuel filter sensor (only Diesel versions)      |
| 12. Variable-rate suspension ECU                | 28. Maximum automatic transmission fluid temperature sensor |
| 13. Right brake light                           | 29. Left hand brake lining wear sensor                      |
| 14. Right rear side light                       | 30. Engine oil level sensor                                 |
| 15. Right rear fog lamp                         | 31. Peripheral ECU (for air conditioner)                    |
| 16. Right number plate light                    | 32. Left front side/parking light                           |

### 55.

The "INFOCENTER" on-board information system performs the following functions:

CHECK: runs check on entire vehicle;

CLIMA: controls interior vehicle temperature;


SERVICE: displays messages relating to vehicle programmed maintenance.

All this information is displayed on a transmissive monochromatic liquid crystal display optimised for negative contrast.

The flow diagram summarises initial Infocenter module operation. Note that the system sets itself to CLIMA mode after the initial stage.

The user may select CHECK or SERVICE functions by pressing the relevant keys.


The ANOMALY CHECK display takes precedence over all other functions and displays a message corresponding to the anomaly on the screen.




P3U57CL01

## START-UP STAGE

The flow diagram shows all the Infocenter initialisation stages. If a CLIMA mode key is pressed during the start-up stage, the function relating to the key is activated but the display does not show confirmation until the initialisation procedure is complete.




P3U58CL01



P3U59CL01


### LANGUAGE AND ENGINE VERSION SELECTION PROCESS



P3U59CL02

Proceed as follows to display CHECK and SERVICE messages in the required language:


- press SERVICE key and turn ignition key to MARCIA (+15);



P3U59CL05

- the wording "ITALIANO" and "MOTORE BENZINA" appears on the display. Two options are available at this point:

1. if the language and engine type are as required, simply press "CLIMA DATE" key to save the selection:




P3U59CL04

2. press the "SERVICE" key to view the available language and engine type options. The available languages are: French, English, German and Spanish. The engine versions are: petrol and diesel.

- After selecting the language and the engine version, press "CLIMA DATE" key to save the displayed data.

## INFOCENTER SYSTEM DIAGRAM



P3U60CL02

1. Electronic injection control unit
2. Engine oil level sensor
3. Instrument panel
4. Rear boot closure sensor
5. Right and left rear door closure sensor
6. Right and left front door closure sensor
7. Vehicle brake light fault signal and fuse
8. Rear fog lamp fault signal
9. Number plate light and front/rear side light fault signal

10. Maximum automatic transmission fluid temperature sensor (only for versions with automatic transmission)
11. Brake lining wear sensor
12. Water in fuel filter sensor (only Diesel versions)
13. Radiator fluid level sensor
14. Turbo pressure sensor (only Diesel versions)
15. Variable-rate suspension ECU
16. Tester socket for Fiat Lancia Tester/SDC
17. Infocenter information system
19. IGE control unit

## 55.


### CHECK FUNCTION

Functions monitored by the "CHECK" with key in MARCIA position or with engine running are:

- right and left front door open indication;
- right and left rear door open indication;
- boot open indication;
- vehicle brake light and fuse fault indication;
- front and rear side light fault indication
- rear fog lamp fault indication;
- number plate light fault indication;
- low radiator fluid indication;
- brake pad wear indication
- variable-rate suspension fault indication;
- electronic injection system fault indication;
- catalytic converter max. temperature indication (only for Japanese market)
- maximum automatic transmission fluid temperature indication;
- automatic transmission ECU fault indication;
- engine oillevel indication (function inhibited with engine running)
- water in fuel filter indication (only for diesel engines);
- turbo over-pressure indication (only Diesel versions).

Press "CHECK" key to call up any anomalies displayed and saved previously on the Infocenter display.


The flow diagram shows the various fault search stages on the vehicle. The manual fault search process is shown overleaf.




P3U61CL01



## Check display: manual request



P3U62CL01



P3U63C103


when the microprocessor receives an earth signal from one of the sensors (located in the locks), the following wording appears on the display "INCOMPLETE CLOSURE: RIGHT FRONT DOOR", "INCOMPLETE CLOSURE LEFT FRONT DOOR", "INCOMPLETE CLOSURE RIGHT REAR DOOR", "INCOMPLETE CLOSURE LEFT REAR DOOR" and "INCOMPLETE CLOSURE BOOT LID".

Contacts are considered:

- open with resistance greater than 2 Ohm;
- closed with a resistance less than 100 Ohm.

Contact clearing current is about 10 mA.

Vehicle brake lights and fuse - front and rear side lights - number plate lights (see key to wiring diagrams)




P3U64CL01

The functions listed on this page (vehicle brake lights and fuse, front and rear side lights, rear fog lamps and number plate lights) are controlled from the IGE control unit. This sends an anomaly signal (via a dedicated line) to the Infocenter.

The anomaly is displayed on the display 3 seconds after initial diagnosis has been carried out by the IGE control unit.

### 55.

Brake pad wear - engine oil level - radiator coolant level (see key to wiring diagrams)



#### Brake pad wear

The "BRAKE PAD WEAR" fault is indicated on the Infocenter display only when the anomaly has been repeated on ten consecutive occasions) i.e. 10 braking manoeuvres lasting at least 2 seconds each).

#### Engine oil level

The engine oil level sensor, located in the oil sump, carries out a check only with ENGINE OFF and the vehicle level.

With key in MARCIA position (+ 15), press "CHECK" key. The hot wire sensor submerged in the engine oil consists of a heated wire for which the voltage drop is recorded on two different occasions. The difference is then taken between the two readings.


The resulting values are controlled by the Infocenter module, which is able to indicate the following anomalies on the display:

- low engine oil level;
- fault in engine oil check system. Two options are possible: short circuit or circuit (wiring/sensor) open.

With the key turned to MARCIA position, the sensor is supplied with a current of 200 mA. After a settling period ( $t_0 \div t_1 = 150$  msec) the Infocenter electronic system takes an initial voltage measurement (time  $t_1 - t_2 = 10$  msec).

After a second waiting period (time  $t_2 - t_3 = 865$  msec) the system takes another voltage reading, which is compared with the first and the following conditions may occur:

1. if the potential difference between the two voltage readings is less than 245 mV, engine oil level is as specified;
2. if the potential difference exceeds 245 mV, the engine oil level is on minimum;
3. if the second voltage reading is greater than 3.5 V, the sensor is broken (circuit open)
4. if the voltage is less than 1 V the sensor is short-circuited.



P3U66CL01

$t_3 - t_1 =$  probe activation time: 875 msec

$t_2 - t_1 =$  reading time: 10 msec

$t_1 - t_0 =$  supply settling period: 150 msec

### Radiator coolant level

The low coolant level sensor consists of a switch enclosed in a sealed case and a float located in the expansion tank.

When the fluid level drops below minimum level, the float is lowered to close switch contacts and thus the electrical circuit.

This lights up the "LOW COOLANT LEVEL" message on the Infocenter display.

From the time the anomaly is recorded, only once it has persisted for 30 seconds, enablement is given for activation of the wording on the display.

If the fault signal disappears for a time in excess of 30 seconds for any reason, the message disappears from the Infocenter display.


The Infocenter intake is protected by radiofrequency signals and electrostatic discharge by special filters.

Other features include:

- contact clearing current = 10 mA;
- maximum resistance with contacts closed = 100 Ohm;
- maximum resistance with contact open = 1 K Ohm.

### 55.

**Fault in variable-rate suspension ECU - fault in electronic injection ECU - fault in automatic transmission ECU**  
(see key to wiring diagrams)



P3U67CL01

#### *Fault in variable-rate suspension ECU*

The Infocenter electronic module receives a fault signal from the variable rate suspension ECU. Once the first 3 seconds of diagnosis have elapsed, a fault signal is displayed for the component in question.


#### *Fault in electronic injection ECU*

The Infocenter module receives a fault signal from the electronic injection control unit. This anomaly is immediately displayed on the infocenter display.

#### *Fault in automatic transmission ECU*

The Infocenter electronic module receives a signal not from the automatic transmission ECU but from the instrument panel. The instrument panel output is protected by short-circuits to the battery positive terminal. A ECU fault message is displayed 3 seconds following initial diagnosis.

Water in fuel filter indication - turbo over-pressure indication - catalytic converter max. temperature indication - maximum automatic transmission fluid temperature indication - icy road acoustic/visual signal (see key to wiring diagrams)



\* Only for version 2387 TD

P3U68CL01

#### Water in fuel filter indication (only diesel versions)

This device is designed to indicate the presence of a certain amount of condensate water in the fuel filter before it goes on to jeopardise engine operation.

The system works on the basis that water is a better conductor than fuel and has a different specific weight. If sufficient condensate gathers in the lower part of the filter to touch the sensor, the electrical conductivity between sensor and vehicle earth changes significantly.

### 55.

The sensor is normally insulated electrically, while the filter is connected to the vehicle earth through its mount. When the connection between sensor and fuel is only through fuel, electrical conductivity is almost zero. When the connection is through water, the electrical conductivity between sensor and filter is very high. This brings about operation of the electronic module, which is connected to the sensor and incorporated in the fuel filter bleed knob.

Thirty seconds elapse once the sensor has recorded the anomaly before the Infocenter displays the message "WATER IN DIESEL FILTER".

#### *Turbo pressure sensor*

The turbo pressure sensor is fitted to the first cylinder intake manifold. This records excess pressure and at least 30 seconds elapse before the anomaly message is displayed by the Infocenter.

The turbo pressure sensor intake on the Infocenter must be protected against radiofrequency signals and electrostatic discharge by means of special filters.

#### *Maximum catalytic converter temperature (only Japanese market)*

The signal from the sensor is processed by an ECU and immediately displayed by the Infocenter.

#### *Maximum automatic transmission fluid temperature sensor*

The Infocenter displays a fault message 3 seconds after the fault is detected by the sensor.

The signal does not come directly from the sensor but from the control panel. This output is protected by short-circuits to the positive terminal and it is able to withstand a current drop of 10mA with a voltage drop of 1.7 V.

#### *Automatic transmission ECU fault indication*

The Infocenter indicates a fault 3 seconds after the fault is recorded by the ECU.

The signal does not reach the ECU directly but passes from the instrument panel; this output is protected by short circuits toward the positive terminal and it is able to withstand a current drop of 10 mA with a voltage drop of 1.7 V.

#### *Ice on road acoustic/visual signal*

Every time the vehicle is started up or is driven on the road, when outdoor temperature drops to +3 °C, the horn comes on for about 5 seconds and the message "WARNING, POSSIBILITY OF ICE ON ROAD" is displayed.

The Infocenter module uses the same message system when temperature drops to +1 °C.

The module no longer intervenes after three signals because the displayed warnings are now considered sufficient.


The horn may or may not come on to indicate the presence of ice on the road surface.

When the horn has come on at least once:

- if the outdoor temperature reaches or exceeds +6 °C and then drops again to +3 °C the horn comes on as described above;
- if the outdoor temperature does not reach +6 °C and then drops to +3 °C the horn does not come on.



BASIC WIRING DIAGRAM (function "CHECK") (see key to wiring diagrams)




\* Connection for version 2959 V6 24v

\*\* Connection for version 1995 16v turbo

\*\*\* Connection for version 2387 TD



Rear view of Infocenter ECU



P3U7ZCLO1

### CONNECTOR A

1. +12 V from battery (+30)
2. +12 V from battery (+15)

### CONNECTOR B

1. Fault in electronic injection ECU
2. Maximum catalytic converter temperature (only Japanese market)
3. Low coolant level
4. Not connected
5. Variable-rate suspension system fault
6. Not connected
7. Excess turbo pressure (only diesel versions)
8. Water in fuel filter (only Diesel versions)
9. Brake lining wear
10. Brake lining wear
- b1. Low engine oil level 1
12. Low engine oil level 2
13. Maximum automatic transmission fluid temperature
14. Fault in automatic transmission system
15. To red check warning light on instrument
16. Hazard warning light control
17. Hazard warning light flasher signal
18. Not connected

### CONNECTOR C

1. Front side light failure
2. Rear side light failure
3. Rear fog lamp fault
4. Number plate light failure
5. Vehicle brake light fault
6. Vehicle brake light fuse fault
7. Not connected
8. Right front door open
9. Left front door open
10. Right rear door open
11. Left rear door open
12. Boot lid open

### CONNECTOR E

1. Speedometer signal
2. Heated rear windscreen
3. positive from light switch
4. Earth for signal circuits
5. Dimmer (low signal)
6. Dimmer (high signal)
7. Rev counter signal (from instrument)
8. Not connected

### CONNECTOR F

1. Serial line K
2. Serial line L
3. Serial line G



## CLIMATE FUNCTION

Press the "CLIMA" key when screen is to be used exclusively for air conditioner functions.

Key wording and identification points are lit in green by means of a warning light.

The automatic air conditioner control system automatically regulates the following parameters/function:

- air temperature to outlets;
- fan speed (continuous speed);
- air distribution;
- air recirculation;
- compressor activation.

It also governs the following parameters/functions manually:

- fan speed (continuous);
- air distribution in four positions;
- recirculation;
- compressor activation.

All manual operations carried out under the "CLIMA" function take priority over the automatic functions and are saved until the user wishes to alter the function by turning to automatic mode.


When one of the parameters is set manually, the others are controlled automatically. In particular, air temperature to outlets allows temperature requested on display to be maintained in the passenger compartment (except when off).

The system saves the functions even when the vehicle stalls and the engine is turned off.

The system is zeroed only when the battery is disconnected from the system. When the battery is refitted, the first time the engine is turned on, the Infocenter memory is set to "AUTO" and a temperature of 24 °C appears on the display. The remaining functions are set automatically.

Temperature is expressed in degrees centigrade for Italy and Central Europe and in Fahrenheit for the United Kingdom.


The figure below shows a flow diagram for the automatic air conditioner.



P3U73CL01

## 55.

### Front view of Infocenter



P3U74CL01

### Key

- |   |  |
|---|--|
| 1. Climate function                             | 11. Key for activating hazard warning lights                                       |
| 2. Automatic air conditioner key                | 12. Interior air recirculation function activation key                             |
| 3. Liquid crystal display                       | 13. Key for directing air toward lower part of passenger compartment               |
| 4. Air conditioner ECU on/off key               | 14. Key for directing air to the central part of the passenger compartment         |
| 5. Clock keys                                   | 15. Key for directing air to the lower - central part of the passenger compartment |
| 6. Service function                             | 16. Keys for changing temperature from 18 to 32 °C                                 |
| 7. Fan speed adjustment keys                    | 17. Check function   |
| 8. ECON function activation key                 |  |
| 9. Timed rear window heater activation key      |  |
| 10. Key for directing air toward the windscreen |  |

### Operation

The Infocenter is located in the middle of the instrument panel and controls the air conditioning system by means of the following controls:

- auto;
- econ;
- off;
- passenger compartment temperature;
- recirculation;
- timing gear;
- windscreen demister or defroster;
- air flow.

The following sensors for passenger compartment temperature control are connected to the Infocenter ECU:

- outdoor temperature;
- treated air;
- passenger compartment temperature;
- solar radiation.

*CLIMA key*

Press "CLIMA" key to set air conditioning function on Infocenter.

*TEMP keys*

Adjust "TEMP" keys to alter temperature in passenger compartment through a range of 15°C.

*AUTO key*

Press "AUTO" key for system to take automatic control of air temperature and distribution, fan speed, compressor activation and recirculation activation. The display shows the wording FULL AUTO.

*OFF key*

Press the "OFF" key to turn off the system (if on) and turn on the system (if off). When this key is pressed, the display is cleared of messages relating to air conditioner operation, i.e. temperature required, recirculation functions (timing gear, windscreen demisting) and the wording CLIMA OFF should appear on the display.

*ECON key*

Press the "ECON" key to turn off the compressor and the wording AUTO ECON appears on the display.

*RECIRCULATION key*

Press "RECIRCULATION" key to set recirculation mode and the display will show the associated symbol. If no manual action is taken, recirculation is controlled automatically on the basis of temperature required and outdoor temperature.

*FAN speed keys*

Operate "AIR" keys to change the air flow and display pattern by means of bar graphs (consisting of 5 bars). The wording AUTO appears on the display.

*Distribution keys*

Press VENT-BILEV-FLOOR keys to alter air distribution pattern. Associated symbols light up and wording AUTO appears on the display. The following angular distribution flap positions correspond to the three settings:

**VENT** = 0 degrees  
**BILEV** = 35 degrees  
**FLOOR** = 65 degrees

*Windscreen demister key*

Operate this key to direct air toward the windscreen (distribution flap position at a 95 degrees). If the system is set to ECON mode by pressing "ECON" key, this operation is cancelled and the compressor is again controlled automatically.

*HIGH temperature*

If the user sets a temperature higher than 32 °C (90 °F) a condition of HIGH is achieved, i.e. maximum heating. This appears on the display accompanied by the wording AUTO. This status ceases only when the required temperature is reduced.

*LOW temperature*

If the user sets a temperature of less than 18 °C (64 °F). Temperature is LOW, i.e. condition is of maximum cooling. This appears on the display accompanied by the wording AUTO. This status ceases only when the temperature setting is increased.

## 55.

### *Setting the date*


- Turn the key to marcia position (+ 15). The CLIMA screen will appear if no anomaly is displayed;
- set the Infocenter to the CLIMA function;
- press "CLIMA/DATE" key so that the date appears on the liquid crystal display;
- press button "h" using a pencil tip. The month - day - year will appear on the display (example: FEBRUARY - 10 - 95), with the right hand year figure flashing;
- use button "m" to adjust the flashing number to the required value (example: 5 for the year 95);
- press button "h" per to confirm selected value and move to the flashing left hand year figure;
- use button "m" to adjust the flashing figure to the required value (example: 9 for the year 95);
- press button "h" to confirm the selected value and move to the flashing month;
- use button "m" to select the month (example: FEBRUARY);
- press button "h" to confirm month selected and move to flashing day figures;
- use button "m" to adjust day figures (example: 10);
- press button "h" to confirm the selected day and finish programming. When programming is completed, the two figures indicating the year disappear from the display.



*Whenever the battery is disconnected or the Infocenter is deactivated, repeat the date programming procedure because this does not remain in the memory.*



GENERAL BASIC WIRING DIAGRAM (function "CLIMA") (see key to wiring diagrams)




- \* Connection for version 2387 TD
- \*\* Connection for version 2959 V6 24v
- \*\*\* Connection exists only for version 2387 TD

PAU77C01



55.

Rear view of Infocenter



PSU77G101

### CONNECTOR A

1. + 12 V battery (+ 30)
2. + 12 V from ignition switch (+ 15)
3. Earth for power circuits
4. Interior fan earth
5. Mixed air potentiometer earth
6. Air distribution potentiometer earth
7. Outdoor temperature sensor earth
8. Mixed air potentiometer supply
9. Air distribution potentiometer supply
10. Mixed air potentiometer signal
11. Air distribution potentiometer signal
12. Outdoor temperature sensor signal
13. Mixed air motor +/-
14. Mixed air motor +/-
15. Air distribution motor +/-
16. Air distribution motor +/-
17. Air recirculation motor +/-
18. Air recirculation motor +/-
19. Interior fan PWM signal
20. Input for vehicle interior speedometer signal

### CONNECTOR D

1. Interior fan supply
2. Interior fan earth
3. Interior temperature sensor earth
4. Mixed air temperature sensor earth 1
5. Mixed air temperature sensor earth 2
6. Solar sensor earth
7. Interior temperature sensor
8. Mixed air temperature sensor 1
9. Mixed air temperature sensor 2
10. Solar sensor
11. Compressor (signal from electronic injection control unit) microswitch 1
12. Compressor (signal from electronic injection control unit) microswitch 2

### CONNECTOR E


1. Speedometer signal
2. Heated rear windscreen
3. Positive from light switch
4. Earth for signal circuits
5. Dimmer (low signal)
6. Dimmer (high signal)
7. Rev counter signal (from instrument)
8. Not connected

### CONNECTOR F

1. Serial line K
2. Serial line L
3. Serial line G



## SERVICE FUNCTION



P3U79CL01

The "SERVICE" is obtained by pressing the button shown in the diagram; this function takes advantage of the infocenter logic module and the signal from the speedometer sensor, detected by the instrument panel. To obtain messages on the display the ignition key must be in the ON position (+15) or the engine must be running.


When the "SERVICE" button is pressed the words: "CHECK TYRE WEAR" appear on the display; by pressing the button once again, within 8 seconds, further information appears on the display; if the button is kept pressed the messages are displayed cyclically (3 seconds for each message). If problems occur for the functions under the "CHECK" service whilst the "SERVICE" function is being read, the fault messages take priority over the "SERVICE" ones.

55.


The Infocenter module counts backwards every 50 scale is 100 km.

When 0 km is reached, the replacement in question To return to the initial counting state simply press the SERVICE function and the appropriate replacement The principle is the same as far as the counting of the month to month until the appropriate replacement

### Display Service



## SERVICE FUNCTION



P3U79CL01

The "SERVICE" function is called up by pressing the button shown in the diagram; this function uses the infocenter module and the signal from the speedometer sensor, taken from the instrument panel. The key must be in the ON position (+15) or the engine running in order to obtain the messages on the display.

When the "SERVICE" button is pressed, the following words appear on the display: "CHECK TYRE WEAR"; by pressing the button once again, in less than 8 seconds, further information appears on the display; by keeping this button pressed, the messages will be displayed in cycles (3 seconds for each message). If, whilst reading the "SERVICE" function, faults occur for the functions controlled by the "CHECK", the fault messages will appear instead of the "SERVICE" ones.

## Messages displayed (on vehicles produced until 1995)

- check tyre wear;
- front tyres min 2.2 - max 2.3 bar;
- rear tyres min 2.2 - max 2.3 bar;
- planned maintenance between 15000 km;
- engine oil SELENIA SAE 10W40 - engine oil SELENIA TURBO DIESEL;
- changing engine oil between 15000 km - changing engine oil between 7500 km (diesel versions only);
- replace engine oil filter between 15000 km;
- replace fuel filter between 30000 km - replace fuel filter between 15000 km (diesel versions only);
- replace air filter between 30000 km - replace air filter between 15000 km (diesel versions only);
- replace spark plugs between 30000 km (excluding 2959 V6 24v versions);
- check emissions between 15000 km;
- replace pollen filter between 6 months;
- replace windscreen wiper blades between 12 months;
- brake fluid TUTELA TOP4;
- engine coolant type PARAFLU' FIAT;
- change brake fluid between 24 months;
- for further information, see handbook.

## Messages displayed (on vehicles produced since 1996)

- check tyre wear;
- front tyres min 2.2 - max 2.3 bar;
- rear tyres min 2.2 - max 2.3 bar;
- planned maintenance between 20000 km;
- engine oil SELENIA 20K - engine oil SELENIA TURBO DIESEL;
- changing engine oil between 20000 km - changing engine oil between 10000 km (diesel versions only);
- replace engine oil filter between 20000 km - replace engine oil filter between 10000 km (diesel versions only);
- replace fuel filter between 80000 km - replace fuel filter between 20000 km (diesel versions only);
- replace air filter between 40000 km - replace air filter between 20000 km (diesel versions only);
- replace spark plugs between 40000 km (excluding 2959 V6 24v versions);
- check emissions between 40000 km;
- replace pollen filter between 20000 Km;
- replace windscreen wiper blades between 12 months;
- brake fluid TUTELA TOP4;
- engine coolant type PARAFLU' 11;
- change brake fluid between 60000 km;
- for further information, see handbook.

### 55.


The Infocenter module counts, in reverse, every 500 km; when the reverse counting reaches 1000 km, the counting scale is 100 km.

When it arrives at 0 km, the message for the replacement in question appears.

To return to the original counting state, simply press buttons "h" or "m" with the tip of a pencil remaining in the SERVICE function and the replacement being carried out.


As far as the counting of the months is concerned, the principle is the same. The Infocenter module goes from month to month until the appropriate replacement appears on the display.

### Display Service




P3U80CL01






P3U055L01



P3U055L02




P3U055L03




## REMOVING-REFITTING

1. Remove the top central air diffuser grille from the dashboard.
2. Remove the central air diffuser grille from the dashboard.
3. Remove the radio compartment and ash-tray, then undo the screws underneath.
4. Undo the attachment screws and remove the central frame.
5. Unscrew at the points indicated, disconnect the connectors then remove the "Infocenter".



P3U055L04




P3U055L05


## 55.

### Location of hazard warning lights key

The hazard warning lights key located in the Infocenter module is of the unstable type. However, the hazard lights circuit is not linked to the Infocenter's logic.




P3U81CL02



P3U81CL03

### Wiring diagram of hazard warning lights



P3U81CL01


### INTRODUCTION

The I.G.E. junction box (Impianto Gestione Elettronica - Electronic Management System) operates and checks the following functions:

- side lights;
- parking lights;
- number plate lights;
- brake lights (stop);
- rear fog lamps;
- fog lights;
- dipped headlamps relay feed;
- dipped headlamps relay feed (\*);
- warning lights in instrument panel (side lights, fog lights, rear fog lamps, heated rear windscreen and hand-brake);
- heated rear windscreen timer.

(\*) In accordance with European regulations, North European market vehicles equipped with electric headlamp alignment are exempted from fitting the DIM DIP headlamp circuit.

### Location on vehicle of connectors managed by the I.G.E. control unit



P3U34CL01

1. Left front side/parking light
2. Right front side/parking light
3. Heated rear windscreen relay
4. Additional brake light
5. Left rear side/parking light - left brake light
6. Left rear fog lamp
7. Left no. plate light

8. Right no. plate light
9. Right rear fog lamp
10. Right rear side/parking light - right brake light
11. Warning lights in instrument panel
12. Diagnostic socket
13. I.G.E. control unit
14. Fog lights relay
15. Left fog light
16. Right fog light

### 55.

The I.G.E. electronic control unit, equipped with a microprocessor, possesses static electronic components which have the task of receiving the operating signal for the switches, activating the consumers (5/21 W bulb) and simultaneously transmitting the diagnosis, via the dedicated connection, to the infocenter control unit. Each inlet is protected by suitable filters against any electrostatic discharges or radiofrequency signals. The activation of the external lights (brake lights, side/parking lights, no. plate light, rear fog lamp) is carried out by means of semiconductor switches which simultaneously control the operation and the check of the function.

A failure of the above mentioned bulbs is signalled via a dedicated line to the infocenter.

The I.G.E. control unit inlets for the operation of the various switches (side light, rear fog lamps, fog lights) allow a connection, inside the control unit, to earth; this connection makes it possible to activate the above mentioned devices.

The I.G.E. junction box comes into operation when the following conditions occur:

- key in ON position (connector C pin 9);
- parking lights go ahead (connector A pin 9).

The lack of one of these conditions deactivates the control unit and engages the stand-by function.




*In vehicles for North European markets, the cable loom and the wiring diagrams for the exterior lights system remain the same. The system differs as far as the operating logic is concerned because there is a specific I.G.E. junction box for the North European market.*

#### I.G.E. system diagram key (see overleaf)

- |   |  |
|---|--|
| 1. Infocenter control unit  | 9. Fog lights relay feed                     |
| 2. I.G.E. junction box  | 10. Brake lights switch                      |
| 3. Instrument panel (warning lights, side/- parking lights, for lights, rear fog lamps, heated rear windscreen and handbrake) | 11. Rear fog lamps switch                    |
| 4. Side/parking lights, number plate lights   | 12. Fog lights switch                        |
| 5. Dipped beam headlamps  | 13. Dipped headlamps switch                  |
| 6. Rear fog lamps   | 14. Heated rear windscreen with timer switch |
| 7. Braking lights   | 15. Side/number plate lights switch          |
| 8. Heated rear windscreen with timer  | 16. Diagnostic socket                        |

DIAGRAM OF I.G.E. SYSTEM




P3U36CL01


# 55.

## FUNCTIONS OF THE I.G.E. SYSTEM

### Side lights and number plate lights



P3U37CL01



P3U37CL02

The side lights are enabled if the following conditions are present:

- presence of ignition ON (+15) signal at connector C pin 9;
- closure to earth (connector C pin 7) of the circuit controlled by the side lights switch (connector A pin 5).

From connector B pin 9, there emerges a signal which switches on the side lights warning light on the instrument panel.

The side lights and number plate lights are connected to the I.G.E. control unit as follows:

Side lights	Connector	Pin	No.plate	Connector	Pin
front right	D	4	left	E	1
front left	D	4	right	E	6
rear right	E	2			
rear left	E	12			
additional rear right	E	3			
additional rear left	E	11			

Diagram illustrating the internal structure of the P3U38CL02 connector, showing various components and pin locations:

- 5: Top cover
- 4: Pin 1
- A: Pin 2
- B: Pin 3
- 9: Pin 4
- 11: Pin 5
- 6: Pin 6
- D: Pin 7
- 12: Pin 8
- C: Pin 9
- 7: Pin 10
- 3: Pin 11
- 2: Pin 12
- E: Pin 13


P3U38CL02

The parking lights are connected to the I.G.E. control unit as follows:


Parking lights	Connector	Pin	Parking lights	Connector	Pin
front right	D	4	rear left	E	12
front left	D	6	additional rear right	E	3
rear right	E	2	additional rear left	E	11

55.

### Stop lights



P3U39CL01



P3U39CL02

The stop lights circuit is connected to the control unit as follows:

- right stop light = connector E pin 5;
- left stop light = connector E pin 7;

The stop lights are enabled if the following conditions arise:


- presence of ignition ON (+15) signal in connector C pin 9;
- the circuit, controlled by the switch on the brake pedal (connector B pin 1) is closed towards the positive.

Since the stop lights system is an active protection, it is monitored by the I.G.E. control unit. The fuse (F1) supplies the stop lights and receives a key-dependent positive (+15); the connector C pin 2 of the I.G.E. control unit checks the efficiency of the fuse F1 and the stop lights.


The car has an additional stop light; this is not controlled by the I.G.E. control unit, but receives the signal directly from the brake pedal switch.



## Rear fog lamps



P3U40CL01



P3U40CL02

The rear fog lamps circuit is connected to the control unit as follows:

- rear right fog lamp = connector E pin 4;
- rear left fog lamp = connector E pin 5.

The rear fog lamps are enabled if the following conditions arise:


- presence of the ignition ON (+15) signal in connector C pin 9;
- the circuit, controlled by the side lights switch (connector A pin 5), is closed to earth (connector C pin 7);
- presence of rear fog lamps ON signal on connector A pin 10;
- presence of dipped beam headlights ON signal (positive signal on connector B pin 6) or front fog lamps ON (negative signal on connector A pin 2).

Under these conditions, the rear fog lamps must come on, with their warning light on the instrument panel which is connected to the I.G.E. control unit via connector B pin 3.


If there is a change in the lights (dipped headlights, main beam headlights, front fog lamps) the rear fog lamps must not be switched off. The outputs on the control unit are only deactivated in the following two cases:

- by pressing the rear fog lamps control button;
- absence of +15 signal on connector C pin 9 (ignition ON), or absence of dipped beam/main beam headlights/front fog lamps ON signal.

#### Front fog lamp relay



P3U41CL01




P3U41CL02

The front fog lamp relay is connected to the control unit via connector D pin 1; the front fog lamp relay is activated if the following conditions arise:

- presence of the ignition ON signal (+15) in connector C pin 9;
- input on connector A pin 5, side lights control, is closed to earth (connector C pin 7);
- presence of a front fog lamps control signal on connector A pin 2.


Under these conditions, the front fog lamps must come on, with their warning light on the instrument panel which is connected to the I.G.E. control unit via connector B pin 7.

Time-lagged heated rear window relay



P3U42CL01

55.



P3U43CL01

The timed heated rear window relay is connected to the control unit by means of connector C pin 10.

It is activated if the following conditions arise:

- presence of ignition ON (+15) signal in connector C pin 9;
- input to connector A pin 11, timed heated rear window control closed to earth (connector C pin 7).

It is only activated when the switch is released, in order to prevent it being continuously switched on, in the event of a short circuit of the input of the I.G.E. control unit.

The output on the I.G.E. control unit which controls the heated rear window is deactivated in two ways:

- MANUALLY, by pressing the heated rear window switch again or in the absence of the positive (+15) on connector C pin 9;
- AUTOMATICALLY, after 60 minutes of actual operation of the heated rear window.

The automatic operation of the heated rear window is basically linked to the following:

- the engine rpm signal, present at the input of connector B pin 8;
- the battery voltage;
- the heated rear window switch on/off logic.


The switch on/off logic is as follows:

- the first 10 minutes of operation are independent from the engine rpm;
- after this period of time, the switching on of the heated rear window depends on the engine rpm, namely:
  - if the rpm is below 1000 rpm (OFF signal) the rear window is switched off after 10 seconds;
  - if the rpm is over 1000 rpm (ON signal) for a duration of at least 10 seconds, the rear window is switched on and stays on (if already activated) until 60 minutes of actual operation are reached.


Throughout the period of automatic operation, the heated rear window relay must switch off when the battery voltage falls below  $8.5 \pm 0.5$  V for a period of 150 ms.

When the heated rear window is switched on, its warning light on the instrument panel should come on (a positive signal is present on connector B pin 2). The heated rear window warning light stays on permanently for a maximum period of 60 minutes during automatic operation, and only goes out if the rear window is switched off manually.

### Dipped beam relay



P3U44CL01



P3U44CL02


The dipped beam relay is activated if the following conditions arise:

- presence of the ignition ON signal (+15) in connector C pin 9;
- input controlled by the dipped beam/main beam headlamps switch (connector B pin 6) closed to earth.


The dipped beam headlamps warning light is controlled by the dipped beam relay, which is connected to the output of connector D pin 5 of the I.G.E. control unit.

55.

### Handbrake warning light



P3U45CL01



P3U45CL02

The handbrake warning light is connected to the control unit via connector B pin 11.


The warning light comes on under the following conditions:

- presence of ignition ON (+15) signal in connector C pin 9;
- input, on connector A pin 12, closed to earth (connector C pin 7).

Under these conditions, the handbrake warning light on the instrument panel must flash simultaneously at a frequency of 1.5 Hz with a 50% duty cycle.

The handbrake warning light can be controlled by other electronic units, so this output requires appropriate separation so that the warning light can be driven in parallel.


## Information from I.G.E. control unit to Infocenter



The I.G.E. control unit is connected to the Infocenter by means of dedicated serial lines. The information sent to the Infocenter is:

- front side lights fault (output on connector A pin 17);
- rear side lights fault (output on connector A pin 7);
- rear fog lamps fault (output on connector A pin 16);
- right and left stop lights fault (output on connector A pin 15);
- number plate lights fault (output on connector A pin 18);
- stop lights fuse fault (output on connector A pin 8).

P3U46CL01



P3U46CL02

The connections between the I.G.E. control unit and the Infocenter are activated when:

- the ignition ON (+15) signal is present in connector C pin 9;
- the individual functions (only if activated) are faulty.


The stop lights function is always monitored by the control unit.

When the I.G.E. control unit is put into operation, all the outputs to the Infocenter are activated and any fault information is sent. After 2 seconds, the outputs to the Infocenter are deactivated for about one second to confirm the information sent.


When normal operation is resumed, the connections between the I.G.E. control unit and Infocenter are again activated, then any faults that may have occurred can be displayed.

### 55.

#### Towhook wiring



P3U47CL01



P3U47CL02


The towhook wiring comprises:

- stop lights control (output on connector C pin 5);
- rear fog lamps control (output on connector C pin 3);
- control for side lights (output on connector C pin 4) and parking lights on all the side lights (connector A pin 9); while for the right side (connector B pin 4) and left side (connector B pin 5).


The above-mentioned outputs are activated to earth (connector C pin 7) when the relevant functions are switched on by the user.



## Connections between I.G.E. control unit and diagnostic socket



P3U48CL01



P3U48CL02

The I.G.E. control unit has a diagnostic socket located in the console under the dashboard which dialogues with the Fiat Lancia Tester or C.D.S.; the connection is serial with dedicated K-L-G lines.

The connections are as follows:

- L line dedicated to communication between Fiat Lancia Tester and I.G.E. control unit (output on connector C pin 12);
- K line dedicated to communication between I.G.E. control unit and Fiat Lancia Tester (output on connector C pin 11);
- G line connected to earth (output on connector C pin 8).

The diagnostic instrument can check the following switches (with the ignition ON):

- parking lights right side;
- parking lights left side;
- rear fog lamps;
- side lights;
- front fog lamps;
- stop lights
- handbrake warning light;
- timed heated rear windscreen;
- headlamps ON signal.

## 55.

### FAULT DIAGNOSIS PROCEDURES

The diagnostic instrument checks whether:

- the switch is active or inactive in its circuit;
- the circuit is short-circuited or open;
- incorrect bulbs have been fitted (21W rather than 5W and vice versa).

The latter check is made on the following functions:

- rear fog lamps;
- rear side lights;
- additional rear side lights;
- front side lights;
- number plate lights;
- braking lights.

If bulbs of incorrect rating are fitted, this is indicated on the diagnostic instrument as follows:

- **SHORT CIRCUIT**, if a 21W bulb is fitted instead of a 5W bulb;
- **OPEN CIRCUIT**, if a 5W bulb is fitted instead of a 21W bulb.

Two checks may be conducted using the Fiat Lancia Tester or C.D.S.:

- if the bulbs are lit, the diagnostic instrument carries out a short circuit and open circuit check;
- if the bulbs are NOT lit, the diagnostic instrument only conducts an open circuit check.

The Fiat Lancia Tester/C.D.S. can check:

- heated rear window warning light;
- rear fog lamps warning light;
- side lights warning light;
- right and left parking lights warning light;
- timed heated rear window relay;
- front fog lamps relay.

The above-mentioned circuits are switched on via the Fiat Lancia Tester/C.D.S.

The latter also controls individually the outputs used for the check, in order to conduct a specific test.

The outputs checked for possible fault finding are:


- front side lights;
- rear and additional side lights;
- right and left stop lights;
- rear fog lamps;
- number plate lights;
- stop lights fuse;

The Fiat Lancia Tester/C.D.S. checks the efficiency of the lines of the "towhook wiring", in particular the side lights and rear fog lamps.

The check is carried out as follows:

- rear fog lamps wiring in parallel with the rear fog lamps warning light;
- side lights wiring in parallel with the side lights warning light.

Check integrated in the I.G.E. control unit




P3U50CL01

The many functions of the I.G.E. control unit also include the check function; the fault information is sent to the Infocenter by activating the dedicated lines which have a serial protection resistance of 390 Ohm.

The I.G.E. control unit checks the efficiency of the following:

- bulbs;
- relevant connections (wiring);
- stop lights control button, subordinate to the relevant fuse.



P3U50CL02

The lights check function is deactivated if the battery voltage is less than 9V. Any fault indications are stored in the I.G.E. unit's memory and only displayed when the battery voltage returns to the specified values.

If the open circuit faults are present in the absence of an active command of the function in question, the indication is stored in the control unit's memory but not displayed by the Infocenter. The fault is only displayed when the relevant circuit is activated.

The I.G.E. control unit checks whether the following circuits fail to come on:

- front side lights;
- rear side lights;
- number plate lights;
- rear fog lamps;
- stop lights because of intervention of the fuse protecting the pedal switch.

Other types of errors that can be diagnosed by the control unit are:

- faulty bulb;
- wiring short-circuited;
- bulb with incorrect rating (5W rather than 21W).

#### SIGNALS FROM I.G.E. CONTROL UNIT TO INFOCENTER

##### *Side lights and number plate lights check*

The side lights fault indication is made with the ignition ON (connector C pin 9) and the control switch actuated (circuit to earth connector A pin 5).

The "front side lights fault" message is activated when:

- one or both front right and/or left bulbs or their supply cables are broken (connector D pin 4 and 6);
- one or both bulb supply cables are short-circuited to earth;
- one or both bulbs are of incorrect rating (21W instead of 5W).

The "rear side lights fault" message is activated when:

- one or both the rear side lights or their supply cables are broken (connector E pin 2 and 12);
- one or both additional rear side lights or relevant supply cables are broken (connector E pin 3 and 11);
- one or both of the bulb supply cables are short-circuited to earth;
- one or both bulbs are of incorrect rating (21W rather than 5W).

The "number plate lights fault" message is activated when:

- the rear number plate light bulb(s) or their supply cables are broken (connector E pin 1 and 6);
- one or both bulb supply cables are short-circuited to earth;
- the bulb(s) are of incorrect rating (21W rather than 5W).

##### *Rear fog lamps check*

The rear fog lamps fault indication is made when the ignition is ON (connector C pin 9) and with the rear fog lamps circuit active (connector E pin 4 and 10).

The "rear fog lamps fault" message is activated when:

- the rear fog lamp bulbs or their supply cables are broken (connector E pin 4 and 10);
- the bulb supply cables are short-circuited to earth;
- one or both bulbs are of incorrect rating (5W rather than 21W).

##### *Stop lights check*

The stop lights fault indication is made when the ignition is ON (connector C pin 9) and is subordinate to the type of fault detected.

The "stop lights fault" message is displayed if one or both bulbs are blown, there is no power supply or the wiring is faulty. The fault indication is made whether or not there is a signal coming from the stop lights button.

If the bulb supply is short-circuited to earth, the "stop lights fault" indication only takes place if the button located on the brake pedal is operated.

If the stop lights button fuse is found to be blown, when the "stop lights fuse fault" is displayed, the "stop lights fault" message is also activated.

When the stop lights fuse is working properly, the "stop lights fault" message is activated when:

- one or more stop lights bulbs or their supply cables are broken;
- one or more stop lights bulbw supply cables are short-cricuited to earth;
- one or both bulbs are of incorrect rating (5W rather than 21W).

##### *Stop lights fuse check*


The "stop lights fuse fault" message is displayed when the ignition is ON (connector C pin 9) and the fuse (F1) in the fuse and relay unit is blown. This fault is displayed as "stop lights fuse fault". The message "stop lights fault" is also displayed since, because the fuse is blown, the system is faulty and does not cause the warning lamps to come on.

##### *Supply check*

A break in the positive cables (connector C pin 1 and 6) is only recognized at the instant when a circuit is activated.

The Infocenter will display the following faults:




- "front side lights", "rear side lights", "rear fog lamps", "stop lights" and "number plate lights".





55.

Connections on I.G.E. control unit



**Connector A (white)**

- 1 Not connected
- 2 Input for front fog lamps
- 3 Not connected
- 4 Output to earth for lights switch side lights input
- 5 Not connected
- 6 Output for rear side lights check
- 7 Output for stop lights fuse check
- 8 Input for parking lights control
- 9 Input for rear fog lamps
- 10 Input for heated rear window
- 11 Input for handbrake button
- 12 Output parking lights to external lights control
- 13 Not connected
- 14 Output for stop lights check
- 15 Output for rear fog lamps
- 16 Output for front side lights check
- 17 Output for number plate lights

**Connector C (red)**

- 1 Input for brake switch
- 2 Output for rear window warning light
- 3 Output for rear fog lamps warning light
- 4 Input for right parking lights
- 5 Input for left parking lights
- 6 Output for dipped beam control
- 7 Output for front fog lamps warning light
- 8 Input for engine rpm
- 9 Output for side lights warning light
- 10 Not connected
- 11 Output for handbrake ON warning light
- 12 Output for parking on stalk unit

**Connector E (grey)**

- 1 Output for left number plate light
- 2 Output for rear right side light
- 3 Output for additional rear right side light
- 4 Not connected
- 5 Output for right stop light
- 6 Output for right number plate light
- 7 Output for left stop lights
- 8 Not connected
- 9 Not connected
- 10 Output for rear fog lamps
- 11 Output for rear left additional side light
- 12 Output for rear left side light

**Connector D (white)**


- 1 Output for front fog lamps relay control
- 2 Not connected
- 3 Not connected
- 4 Output for front right side light
- 5 Output for dipped beam headlamp relay control
- 6 Output for front left side light





## INSUFFICIENT BRAKE FLUID LEVEL WARNING LIGHT


From vehicle chassis number n° 2011476, a connection diode has been fitted between the warning light and the parking light warning light in order to check operation of the insufficient brake fluid level warning light. It is possible to check the operation of the insufficient brake fluid level warning light by operating the parking brake.



P3U076L01


- |  |  |
|--|--|
| 3 Left front earth   | 96 Earth on carrier  |
| 7 Battery  | 97 Earth on floor pan  |
| 8 Main junction unit   | 99 Cigar lighter   |
| 9 Earth on body  | 100 Connection between facia lead and left longitudinal lead   |
| 12 Low brake fluid level indication sensor                   | 105 Ignition switch  |
| 14 Pulse generator for speedometer signal                    | 117 Parking brake indicator switch                             |
| 32B Connection between facia cable and left engine bay cable | 119D Connection between facia cable and right front door cable |
| 68 Electronic injection lead connection                      | 131 Earth on steering column mount                             |
| 72 Fuel injection control unit                               | 167 Fuel level gauge   |
| 73 Secondary junction unit                                   | 200 Electronic variable rate suspension control unit.          |
| 73B 60A fuse protecting IGE control unit-junction unit       | 271 Braking light switch                                       |
| 73C 30A fuse protecting ignition switch/anti-theft device    | 430 Diode connecting parking brake /low brake fluid system     |
| 75 Junction unit (facia)                                     |  |
| 76 IGE control unit.   |  |
| 78 Instrument panel  |  |
| 88 Diagnostic socket for Fiat/Lancia/Tester                  |  |

55.



### Key

- |  |   |
|--|---|
| 3 Left front earth   | 96 Earth on carrier   |
| 12 Low brake fluid level indication sensor                   | 117 Parking brake indicator switch                                |
| 32B Connection between facia cable and left engine bay cable | 430 Diode connecting parking brake / low brake fluid level system |
| 76 IGE control unit.   |   |
| 78 Instrument panel  |   |
| N Parking brake warning light                                | N.D. Taped ultrasound welding in wiring bundle                    |
| O Insufficient brake fluid level warning light               |   |




P3U026L01



### REMOVING-REFITTING

- Remove the dashboard lower trim, steering wheel side;




P3U077L01



### Location of I.G.E. control unit

**NOTE** The arrows shows the position of the control unit attachment screw.




P3U077L02



- undo the attachment screw, lower the control unit and disconnect the supply connectors, then withdraw the control unit.

55.



P3U078L01




### FRONT LIGHTS CLUSTER



#### Removing-refitting


- Lift the bonnet;
- remove the bottom trim on the lights clusters by undoing the attachment screws (arrowed);



P3U078L02



- undo the attachment screws;




P3U078L03




- remove the lights cluster from its seating, disconnecting the connectors (arrowed).

## ELECTRIC VERTICAL HEADLAMP ALIGNMENT (manually operated)



P3U01CL01

The device in question is designed to correctly vertically align the dipped headlamp beam via a manual control in the passenger compartment irrespective of the load on the axles by positioning the knob at a number corresponding to a given load, details of which are in the table:




P3U01CL02

A. Actuators on headlamps


B. Control potentiometer

Knob position	Load condition
-1	driver and passenger with full fuel tank
0	driver only with full fuel tank
1	all the seats occupied and heavy load
2	all the seats occupied plus load in the luggage compartment reaching maximum permissible load on the rear axle with full fuel tank
3	driver plus load in the luggage compartment reaching maximum permissible load on the rear axle with full fuel tank



The electrical vertical headlamp alignment device is not fitted on the LANCIA k SW because it is equipped with self-levelling rear suspension which keeps the vehicle geometry constant as the load varies.

### Device connection wiring diagram




P3U02CL01

### Operation

The adjustment is electrical and can be carried out when the dipped headlamps are switched on. The movement is produced by two motor actuators (367 and 368) fitted directly on the light clusters. The operation (103C) is via a potentiometer controlled by a knob located in the dashboard which can be placed in five different positions, corresponding to the same number of positions for the light clusters. This knob has an ideogram which is lit up when the side lights are switched on.

The system is supplied, when the dipped headlamps are switched on, with a positive voltage of 12V coming from the fuse (F7) line in the junction unit (31) (see also dipped headlamps wiring diagram). The actuator comprises a geared motor on which a potentiometric type position transducer is fitted plus an electronic control unit.



P3U080L06

**HEADLAMP ALIGNMENT**

1. Screw for adjusting light beam in a horizontal direction
2. Screw for adjusting light beam in a vertical direction

The vehicle should be equipped with a spare wheel, tools, fluids and fuel reserve; the tyres should be inflated to the normal pressure with the driver on board.

Place the vehicle on a flat surface with the light clusters 10 m away from a screen or an opaque surface on which the following lines have been traced:


**V - V:** vertical corresponding to the symmetrical plane of the vehicle.

**C - C:** corresponding to the vertical planes passing through the reference centres of the light clusters.

**HC-HC:** horizontal corresponding to the height from the ground of the light cluster reference centres.

**AC-AC:** horizontal below the 13 cm line Hc-Hc (figure for new vehicles corresponding to a decrease of 1.3%).

Carry out the alignment of the light clusters for the dipped beam. Acting on the headlamp alignment device, proceed as follows.



P3U080L07

**Vertical alignment**


Ensure that the horizontal section of the demarcation line between the dark zone and the one lit by the light beam coincides with the line **AC-AC** traced on the screen.

**Horizontal alignment**

Ensure that point where the two horizontal and tilted lines cross with the point where lines **C-C** and **AC-AC** on the screen coincides. If the screen must be positioned closer, this value should be reduced proportionally.








P3U079L01


**FRONT FOG LAMPS****Stacco-riattacco**

- Undo the screws shown in the figure;



P3U079L02

- disconnect the supply connector then remove the front fog lamp.




P3U079L03

P3U079L04


**SIDE REPEATER****Removing-refitting**

- Prise off the side repeater using a screwdriver (left picture);
- disconnect the supply connector then remove the side repeater (right picture).


55.



P3U080L01



P3U080L02



P3U080L03




### REAR LIGHTS CLUSTERS

#### Removing-refitting lights cluster (on boot lid)


1. Open the boot and remove the attachment embellishment;
2. disconnect the connector, undo the screws shown in the figure and withdraw the lights cluster.

#### Removing-refitting lights cluster (on mudguard)


3. Open the boot and remove the attachment buttons;
4. disconnect the supply connector, remove the attachment screws and withdraw the lights cluster;
5. to refit, reverse the procedure for removal.




P3U080L04




P3U080L05



P3U081L01



P3U081L02



P3U081L03



### ADDITIONAL STOP LIGHT


#### Removing-refitting

1. Remove the attachment embellishment;
2. undo the screws (arrowed), disconnect the wiring connector then remove the additional stop light;
3. to refit, reverse the procedure for removal.


### NUMBER PLATE LIGHT

#### Removing-refitting


4. Undo the screws (arrowed);
5. disconnect the supply connectors and remove the number plate light.



P3U081L04



P3U081L05



P3U082L01




#### FRONT COURTESY LIGHT



#### Removing-refitting


- Prise off the lens;



P3U082L02




- undo the attachment screws;



P3U082L03




- disconnect the supply connectors, then remove the courtesy light.



P3U083L01




### PASSENGER MIRROR COURTESY LIGHT



P3U083L02

### Removing-refitting

- Prise off the courtesy light (top picture);
- disconnect the supply connector, then remove the courtesy light (bottom picture).



P3U083L03




### GLOV COMPARTMENT LIGHT



### Removing-refitting

- Prise the light off its seating using a screwdriver;




P3U083L04




- disconnect the supply connector, then remove the light.


55.



P3U084L01



P3U084L02



P3U084L03

### PUDDLE LIGHT

#### Removing-refitting

1. Undo the attachment screws;
2. disconnect the supply connector, then remove the light.

### REAR COURTESY LIGHT


#### Removing-refitting

3. Prise off the lens and remove the attachment screw which is underneath;
4. disconnect the supply connector then remove the courtesy light.


### BOOT LIGHT

#### Removing-refitting


5. Prise off the light;
6. disconnect the supply connector, then remove the light.



P3U084L04



P3U084L05



P3U084L06

**VEHICLE INTERIOR AND LUGGAGE COMPARTMENT LIGHT CONTROL UNIT**

For vehicles produced from the month of JULY 95, a new vehicle interior and luggage compartment light control unit has been introduced to allow the luggage compartment light to be put on a 20 minute delay while a different system is adopted for car interior courtesy lights.

**Operation**

The control unit is located in the passenger compartment beneath the facia and turns the interior courtesy light on and off gradually by means of a timer. The control unit can handle up to 10 W.

The interior courtesy light function is controlled by:

- 2 switches which indicate that the doors have been opened (this function is also linked to the alarm and Infocenter "CHECK" function);
- 15V input from ignition key;
- door lock confirmation input (earthed).


The control unit receives an enabling signal from the two front doors, the courtesy light comes on and reaches maximum intensity within 3 seconds. A timer (T1) simultaneously comes on for 150 seconds. After this, the front courtesy light is gradually de-activated over a period of 3 seconds..

If timer (T1) is de-activated before the 150 seconds are over, a second timer (T2) is activated for 6 seconds. After this, the courtesy light is gradually turned off.

When the key is turned to + 15 position, both timers are de-activated and the courtesy light gradually goes off within 3 seconds. The courtesy light also gradually goes off over a period of 3 seconds from the moment a door lock signal is received.

The luggage compartment light activation function is controlled by the control unit. A signal from the tail-gate position (open/closure) switch detects opening and activates a time for 20 minutes.

When the set time has elapsed, the courtesy light goes off even when the tail-gate is still open. When the tail-gate is closed, the light goes off automatically to interrupt the timer cycle.




P3U084L07

Connector A	
1	Tail-gate switch
2	Door lock control
3	Tail-gate bulb

Connector B	
1	Earth
2	Front courtesy light output
3	+ 30 battery
4	Right front door
5	Left front door
6	+ 15 Battery

55.




\* Only on versions SW

### Key

- |   |   |
|---|---|
| 75 Junction unit (facia)  | 205 Left floor light                              |
| 93 Puddle light on left front door                                      | 226 Right floor light                             |
| 95 Left front motor and left front door open and alarm on warning light | 266 Alarm device receiver                         |
| 97 Earth on floor pan   | 281 Front courtesy light for car interior         |
| 124 Right front puddle light  | 300 Central locking electronic control unit       |
| 126 Left front puddle light   | 425 Right hand luggage compartment courtesy light |
| 128 Front/luggage compartment courtesy light                            |   |
| 137 Luggage compartment tail-gate lock assembly                         |   |
| 162 Luggage compartment lighting  |   |





P3U085L01




## IGNITION SWITCH




## Removing-refitting

- Unscrew the retaining bolts and remove the steering column trim;



P3U085L02




P3U085L03

- disconnect ignition switch, as shown in the figure.




Before removing the ignition switch, disconnect the battery terminals and turn key to "MARCIA".

## Diagram showing ignition switch internal connections




NOTE. An extra 20A fuse in the Lancia k protects the ignition switch. The fuse is located in the middle of the engine bay.

55.



P3U086L01



P3U086L02


### STALK UNIT

#### Removing-refitting


1. Unscrew the bolts indicated and remove the steering column trim;
2. unscrew the bolts fastening the air bag assembly to the steering wheel;
3. remove the air bag from the steering wheel as described on page 175;
4. remove the steering wheel using an appropriate extractor, then disconnect the clock spring connector;
5. separate the steering column trim mount plate after unscrewing the relevant bolts. Then disconnect the connectors and remove the stalk unit.




*Before beginning this procedure, ensure the SAFETY REGULATIONS beginning on page 167 are scrupulously adhered to.*



P3U086L03




P3U086L04




P3U086L05

Front view




P3U086L06

Rear view



P3U086L07




P3U086L08

1. Windscreen wiper pump control
  2. Windscreen wiper control
  3. Windscreen wiper speed intermittent function
  4. Turn signal lever
  5. Main beam lever
- A-B-C-D Electrical connectors

### 55.

#### Light switch wiring diagram




P3U088L09

Connector A		Wiring colours
1	Dipped beam relays (I.G.E.)	HN
2	Exterior lighting control	AB
3	Main beam relay	AV
4	Exterior lighting control (I.G.E.)	GL
5	IGE control unit.	LN
6	IGE control unit.	L

Connector B		Wiring colour
1	Left branch turn signal	AG
2	Right branch turn signal	AR
3	Ignition switch (provision)	-
4	Ignition switch	A


#### Windscreen wiper switch wiring diagram



P3U086L10

Connector C		Wiring colour
1	Available	-
2	Available	-
3	Windscreen wiper unit	H


Connector D		Wiring colours
1	Windscreen wiper unit	AV
2	Horn relay	BN
3	Windscreen wiper unit	GN
4	Washer pump	-
5	Windscreen wiper unit	R
6	Headlamp washer intermittent function	-
7	Front/rear washer earth	-
8	Rear wash/wipe	B
9	Available	-
10	Windscreen wiper unit	AR



P3U086L11

#### Fixed resistance windscreen wiper beat variator


Pos.4	R = 0 - 350Ω
Pos.3	R1 = 1.8 KΩ ± 7%
Pos.2	R2 = 3.3 KΩ ± 7%
Pos.1	R3 = 5.1 KΩ ± 7%



P3U087L01


**ELECTRIC WINDOW SWITCHES****Removing-refitting electric windows switches, driver's side**

- Undo the screws shown in the figure;



P3U087L02

- disconnect the supply connector, then remove the electric windows switch unit.




P3U087L03


**Removing-refitting electric windows switch, passenger side**

- Prise off the assembly, then disconnect the supply connector and remove the electric window switch.


### 55.



P3U088L01



P3U088L02



P3U088L03




### WINDSCREEN WIPER MOTOR




#### Removing-refitting


1. Lift off the button and undo the attachment nuts which are underneath;
2. release the supporting arms using a screwdriver;
3. undo the screws securing the plastic cover and remove it;
4. undo the screws securing the windscreen wiper motor to the bodywork;
5. disconnect the supply connectors and withdraw the motor from its seating.



P3U088L04



P3U088L05



P3U089L01




## SUNROOF MOTOR



### Removing-refitting


- Remove the sunshades and courtesy light, disconnecting the supply connector;




P3U089L02



- lower the courtesy light, releasing it from its attachment points;




P3U089L03



P3U089L04

- undo the screws attaching the motor to the roof, disconnect the supply connectors and then remove the motor.

55.




P3U090L01



### PLUG PREHEATING DEVICE

#### Removing-refitting


- Undo the attachment screw shown;



P3U090L02



- disconnect the supply connectors then remove the plug preheating device.



P3U090L03




### FUEL FILTER

#### Removing-refitting

- Disconnect the supply connectors shown in the figure;

**NOTE** *The fuel filter is of the heated type, and comprises a water detector.*







P3U091L01



- disconnect the diesel fuel delivery and return pipes from the fuel filter;




P3U091L02



P3U091L03


- remove the screw securing the fuel filter, then remove the filter.



P3U091L04



### RADIATOR FAN



P3U091L05

### Removing-refitting


- Disconnect the supply connectors, then remove the fan by undoing it at the points indicated.

### 55.

#### ELECTRIC SEAT (with memory and heated)

##### Memorization

The device can store in memory and recall 3 different positions of the driver's seat; the buttons which adjust the seat are located on the console beside the bottom seat cushion.




The front seat can make 4 different movements:

1. front vertical;
2. horizontal;
3. rear vertical;
4. lumbar, vertical and horizontal.


With the ignition ON (+15), adjust the seat position, press the **MEMORY** button and at the same time press for 1 second one of the 3 recall buttons (1, 2 or 3) corresponding to each position that can be memorized. A further 2 positions can be memorized in the same way; the memorization of a new seat position automatically cancels that previously memorized with the same button.

With the ignition ON (+15), press the desired recall button (1, 2 or 3) until the memorized position is reached.

If the button is released at any moment, the seat is immediately locked.



- A. Memorized position recall buttons
- B. Button for memorizing the positions required by the user




P3U04CL01

**Electric heating**

The front seats can be heated by thermostat-controlled heating pads placed between the seat stuffing and upholstery.

To switch the device on or off, use the button on the seat's side console.

When the electric heating is on, the symbol on the instrument panel is lit up.


**Wiring diagram**

P3U04CL02

When the ignition is switched ON, the front seat heating pads are supplied; the relay contacts are normally closed.

When the heating pads reach a temperature of about 28 °C, the thermostats open and are automatically cut off the supply; the heating pads can nevertheless be switched off by using the two switches mounted on the seats. When the switches are switched off, the relays 183 and 184 are energized, the normally closed contacts are opened and the supply to the heating pads is cut off.

55.



P3U107L01




### ELECTRIC SEATS CONTROL UNIT



#### Removing-refitting


- Undo the screws (arrowed in the figure) securing the control unit to the seat;



P3U107L02



- disconnect the supply connectors;




P3U107L03



- withdraw the control unit from its seating.

## EXTERNAL FOLDING AND HEATED REARVIEW MIRRORS



P3U06CL01


Pin	Description
A	To right mirror horizontal movement motor
B	To left mirror horizontal movement motor
C	To right mirror vertical movement motor
D	To left mirror vertical movement motor
E	To 12 V (+ 15 key-dependent)
F	Earth
G	To shared motors
H	To 12 V symbol illumination
I	To right mirror folding motor
L	To left mirror folding motor
M	To left mirror folding motor
N	To right mirror folding motor

## Internal view of rearview mirror

The external rearview mirrors can be folded by means of a command issued by the user, thus permitting better manoeuvrability while parking, accessing garages and in all cases where the vehicle's lateral dimensions need to be reduced as much as possible.

In addition to being folding, they also comprise heating elements for demisting the mirror.

## Wiring diagram: external rearview mirror closure function




P3U06CL02


### 55.

Assuming that the starting position is the open position, when the button (3) controlling the mirror closure is pressed, the coil 15 is energized. The voltage reaches point 6 of the relay and supplies pins L and I (white-red wire). The motors are actuated and close the external mirrors.

#### Wiring diagram: external rearview mirrors open function



P3U07CL01



P3U07CL02

Starting from the closed position, when the mirror open button (3) is pressed, the coil 16 is energized and the voltage reaches point 9 from the relay, supplying pins M and N (white-green wire). The motors are actuated and so close the mirrors.


The control unit's electronics prevent the motors from remaining actuated once they reach the required position (open or closed), thus preventing damage to the motors.

A single pulse is sufficient to fully open or close the external rearview mirrors. The pushbutton unit includes the control for adjusting the position of the external mirrors.

Select the mirror to be adjusted with the button (1), and use the control (2) to adjust the selected mirror vertically and horizontally.


#### External rearview mirror operating button

### Location of door mirror components and cable-ways on the vehicle



P3U099L03

After the first batch of vehicles, a 7.5A fuse (429) was added. This is located at the right hand side of the luggage compartment.




P3U099L02

**NOTE** The component identification numbers are as used in the wiring diagrams in section 55 - Electrical equipment - Wiring diagrams; refer to the key at the end of this section

### INTERIOR REAR VIEW MIRROR


The interior rear view mirror features an automatic anti-glare function. A photodiode sensor measures the intensity of the light beam striking the mirror and sends a message to the electronic control unit. This in turn partly obscures the liquid crystal diodes in the anti-glare device.



P3U08CL01

Switch (1) can be used to cut-out the function or set to different mirror light intensities according to the sensitivity of the driver's vision. When reverse is engaged, the anti-glare device cuts out to allow maximum visibility while manoeuvring the vehicle. The mirror is continually adjustable in all directions.


55.



### TURN SIGNAL CONTROL UNIT (For versions WITHOUT alarm signal)

P3U08CL02

Versions without an alarm signal are fitted with an electronic control unit beneath the central console facia. This controls the turn signals when the vehicle doors are closed (using a key or remote control). The turn signals flash only during door closure.



P3U100L05

#### Control unit connector

1	Available
2	Lancia CODE led input
3	Right hand turn signals
4	Hazard warning light flasher control
5	Available
6	Lancia CODE output
7	Battery positive (12V)
8	Available
9	Available
10	Turn signal control
11	Left hand turn signal
12	Available
13	Lancia CODE led battery positive



## INTRODUCTION

The **Lancia Code** is an electronic key that protects the vehicle against theft attempts. It consists of:

- four electronic keys containing a secret code;
- an electronic key ECU and external aerial;
- Injection ECU (for petrol engines and diesel electronic pumps) with a serial line for control of communication to electronic key ECU;
- card with secret code for emergency procedure.


The electronic key system enables the electronic injection ECU for operation via an exchange of codes.

When key is set to MARCIA (+15) the electronic injection ECU sends a code request to the electronic key ECU. This responds by sending a secret code, only after recognising a known electronic key within the ignition switch (by aerial).

The injection ECU begins the electronic engine management process once the code has been recognised. The electronic injection ECU may only memorise the secret code via a special procedure.

Electronic key ECU functions are as follows:

- recognise insertion and turning of key in ignition;
- emit an electromagnetic field to power and activate the key TRANSPONDER (code emitter);
- receive secret code issued by key;
- memorise up to 8 keys using the same number of secret codes;
- manage code checking/processing;
- control a single-wire bidirectional serial link with the injection ECU;
- control a test warning light (LED) located in the middle of the dashboard.



P3U094L01


1. Injection ECU

2. Ignition switch with aerial

3. Electronic key ECU

### 55.

#### Electronic key system



P3U095L01

1. Key with transponder T (engine start-up code emitter)

2. Ignition switch with built-in aerial A

3. Electronic key ECU (CCE)

4. Electronic injection control unit (IE)

5. Injectors

O.R.1 Radio waves for activating transponder

O.R.2 Radio waves for sending secret key code

## SYSTEM COMPONENTS

### Electronic injection control unit

The electronic injection control unit is the main component of the electronic key system because it contains the Master Code.

When the key is turned to MARCIA (+15), the injection control unit asks the electronic key ECU for a code. The received code is then compared with the Master Code in the memory. If the code comparison is successful, the electronic injection control unit allows engine operation and management to proceed.

If the electronic key ECU is faulty, the electronic injection ECU manages the emergency start-up procedure using a Fiat Lancia Tester.



*Under no circumstances should electronic injection ECUs be swapped between vehicles to check their efficiency.*



*During fault diagnosis, before replacing a electronic injection control unit, ensure that the component under examination is really inefficient because when a new electronic injection ECU is activated the Master Code is saved and the unit can no longer be used on any other vehicle.*

### Electronic key ECU

The electronic key ECU is located beneath the front driver's seat and its main function is to recognise keys inserted in the ignition switch.

Upon a request by the electronic injection ECU, the electronic key ECU sends it:

- the master code, thus enabling engine operation and management;
- the fault diagnosis code (key not recognised) to block engine operation.

The electronic key ECU is also responsible for:

- controlling key saving and re-saving;
- arranging to save the Master Code in the electronic injection control unit (upon a request from the electronic injection control unit);
- management of green electronic key system warning light (LED).

Two procedures existing between the electronic key ECU and the injection ECU allow dialogue between the units:


1. after the electronic key ECU saves the keys, dialogue with the as yet BLANK injection ECU begins. Exchange of information (code saving) between injection ECU and electronic key ECU is governed solely by the injection ECU. The electronic key ECU is only enabled to respond to enquiries from the injection ECU;
2. code checking is a standard procedure that is repeated whenever the driver inserts the electronic key in the ignition and turns it to MARCIA (+15). The checking process continues even when the user moves the key to AVVIAMENTO(+50).

With the key in MARCIA position (+15), the electronic key ECU must recognise the electronic key with its code. Two options are possible:

- code recognition by the electronic key ECU, the injection ECU enables engine operation (the green led goes off);
- if code recognition is negative, the electronic key ECU sends a code to the injection ECU, which does not allow engine operation (green led is on with steady light).

### 55.

#### Perspective view of electronic key ECU and connectors



P3U097L01

#### Connector A

1. Aerial
2. Not connected
3. Antenna earth

#### Connector B

1. Not connected
2. Signal for warning light (led)
3. +12 V from battery (+30)
4. Earth

5. Line K from injection ECU tester socket
6. Serial line to injection ECU
7. Not connected
8. +12 V with key in MARCIA position (+15)

#### Electronic keys

The key grip contains a Transponder. This electronic device (NOT supplied by the battery) contains a code and transmits information through the atmosphere. When the key is inserted in the ignition and the Transponder is energised by radio waves received via the aerial, the Transponder responds by emitting a code.

Four keys are provided with the vehicle:

- n° 1 electronic key RED;
- n° 2 electronic keys;
- n° 1 electronic key for garage;
- n° 1 card with secret code for emergency vehicle start-up using Fiat Lancia Tester.

Each key contains a Transponder with a secret code. The RED contains the Master Code and must be used SOLELY for the key memorisation process.


The RED key code is the Master Code saved in the electronic injection control unit and electronic key ECU. This represents an insoluble link between the electronic injection control unit and the RED key. If the RED key is lost or damaged, no further new keys may be saved. If the electronic key ECU becomes faulty and the RED key is not available, the electronic key and electronic injection ECUs must be replaced.



*The vehicle owner is advised to observe the following instructions SCRUPOLOUSLY:*

- The Red key must be kept in a safe place (not in car);
- The RED key must be used only for saving new keys;
- the card with the secret code must not be left in the car in case the car is stolen, but must nevertheless be available for the emergency start-up procedure using a Fiat Lancia Tester.

The RED key is proof of vehicle ownership. This must always be present (together with card) when the car is bought or sold.



P3U098L01

1. RED key
2. Normal key
3. Transponder

### Aerial

The aerial:


- provides energy to the Transponder in order to send the code;
- receives code from Transponder and sends it to electronic key ECU.

Because the aerial must be close to the Transponder (for reasons of electromagnetic immunity, small aerial size and small Transponder range of action), it is fitted co-axially with the ignition switch.

### Code Card

This card bears a 5-figure code for the emergency start-up using a Fiat Lancia Tester (electronic code). It also bears a mechanical code used to copy the milling on the key.

The other side of the card shows precautions to be observed. Two spaces are also provided for labels bearing car alarm remote control codes.




P3U098L03

4. Card with secret code (Lancia CODE CARD)
5. Aerial

### Electronic key system warning light

The green indicator light (LED) is located in the middle of the facia between the ventilation outlets. When an alarm is fitted, the two-coloured warning light (green/red) is used for both systems.



P3U099L01

The warning light is controlled by the electronic key ECU as follows:

- OFF - key recognised in MARCIA position (+15), correct system operation;
- FLASHING - key not in or key turned to STOP, engine lock in operation;
- FLASHING WITH KEY ON MARCIA (+15) - the warning light (LED) indicates that the electronic key ECU is blank and flashing 2.5 seconds after turning key to MARCIA (+15);

- ON WITH KEY TURNED TO MARCIA (+15) - when warning light stays on permanently with key turned to MARCIA (+15):
  - a. key not recognised by electronic key ECU (engine control prohibited);
  - b. serial line not connected;
  - c. key rememorisation procedure not carried out correctly.

### 55.



*If ELECTRONIC KEY LEDs come on temporarily or permanently while the vehicle is in motion or during start-up, the system is not necessarily faulty. Under certain circumstances it may indicate an attempt at theft has taken place.*

*If this situation occurs, test the system properly by stopping the vehicle, turning off the engine and turning ignition key to STOP. Turn key back to MARCIA, when the electronic key LED should come on and then go off again after 1 second.*

*If the LED stays on following this procedure, repeat the operation and wait in STOP position for longer than 30 seconds. If the electronic key LED stays permanently on when the key is in MARCIA position, test the electronic key system.*

## KEY MEMORISATION

### First key memorisation

The first key memorisation takes place in the factory.

To check memorisation has taken place, insert key in ignition and turn to MARCIA (+15):

- if the warning light goes off, key has been memorised;
- if warning light begins to flash at a higher frequency after about 2.5 seconds, the system is still blank.

A Fiat Lancia Tester can be used to check whether a key is blank during testing of the electronic injection control unit.

### Key memorisation with blank system

A blank system means that neither the electronic injection control unit nor the electronic key ECU fitted to the vehicle contain ANY memorised codes (e.g. following a repair that involved replacement of both control units).



*Before beginning this procedure, ensure that the electronic key ECU is really blank. Use of a faulty electronic key ECU or one with contents in memory will lead to irreversible memorisation of an incorrect code in the electronic injection control unit, which may then no longer be used on other vehicles (led flashing with key turned to MARCIA).*

The key memorisation procedure is divided into two stages in sequence:

- the electronic key secret code is memorised in the electronic key ECU;
- the electronic key ECU is responsible for memorising the master code in the injection ECU (even if blank).

This second stage is implemented automatically when the first has been completed successfully, providing a further +15.

This procedure permits up to 8 different keys to be memorised, with a minimum number of 3.


The memorisation procedure may be carried out only once ECU has checked that everything is properly connected and working (universal code active and hence vehicle not protected).

The presence of a universal code is indicated by the flashing of a warning light (green led). This flashes at a rate of 1.6 Hz with a 50% operating cycle;

flashing starts 2.5 seconds after key has been turned to MARCIA (+15). Memorisation procedure can proceed after carrying out this check.



*To avoid mistakes during key memorisation process, it is advisable to read the procedure described overleaf carefully before carrying out process on vehicle.*




P3U100L01




*If a new key is added, all keys provided with vehicle must be remembered because any keys not used during this procedure will be deleted from the memory.*

Insert RED key in ignition when in STOP position.




P3U100L04

Turn RED key to MARCIA (+15). The warning light will come on for 0.7 sec.



P3U100L03

Turn RED key to STOP when the warning light goes off.




P3U100L02

Within 10 seconds:


- remove RED key from ignition;
- insert a new key (1) in the ignition and turn to MARCIA (+15). The warning light will come on for 0.7 sec.

### 55.



P3U101L01


When the warning light goes off, turn key (1) to STOP.




P3U101L02

Within 10 seconds:

- remove key (1) from ignition;
- insert a new key (2) in the ignition and turn to MARCIA (+15), warning light will come on for 0.7 sec.



Turn key (2) to STOP once warning light goes off.




P3U100L04

Within 10 seconds:

- remove key (2) from ignition;
- insert RED key in ignition and turn to MARCIA (+15). Warning light will come on for 0.7 sec.





P3U102L01

When the warning light goes off, turn RED key to STOP.

The memorisation process is completed (master code memorised in electronic injection control unit) as follows:


- turn RED key to MARCIA (+15);
- hold RED key on MARCIA for about 3 seconds;
- the LED warning light will come on for 0.7 sec and go off permanently if process has been successful;

- the LED warning light comes on for 0.7 seconds and begins to flash again after about 2 seconds if memorisation has not been successful. In this case, remove the RED key and repeat key memorisation procedure from the beginning.

On a blank system, the key memorisation procedure will not be successful in the following cases:

- a key is inserted on 2 consecutive occasions;
- the same key is inserted twice or more between 2 insertions of a RED key;
- key held on MARCIA (+15) for longer than 2 seconds;
- key held on STOP for longer than 10 seconds.

**NOTE** The memorisation procedure is described for 3 keys (including RED key), but must be applied to all keys provided with the vehicle (4 keys), plus any additional keys.



P3U102L02

The diagram shows led activation as a function of key memorisation.

- If the procedure has not been carried out properly, the memorisation procedure must be repeated very carefully.
- If a mistake is made at any time and for any reason, hold key on MARCIA (+15) for longer than 2 seconds or on STOP for longer than 10 seconds. Then begin key memorisation sequence again.

Once memorisation has been completed, ensure that all keys provided are able to start the engine. If one of the keys will not start the engine, repeat the key memorisation process.


#### Key memorisation with electronic key ECU blank and NOT blank

See section on "key memorisation with blank system" described from page 6 onward in order to memorise keys with electronic key ECU blank and electronic injection ECU not blank.

#### Key memorisation with electronic key ECU and electronic injection control unit NOT blank

This procedure is required whenever further blank keys are memorised or when keys are reset following dowel replacement.

### 55.




P3U100L01



*Addition of a new key involves re-memorisation of all keys provided because keys not used during this process are deleted from the memory.*


*To avoid errors in the key memorisation process, it is advisable to read the following instructions carefully before working on vehicle.*

Insert RED key in ignition in STOP position.




P3U103L02

Turn RED key to MARCIA (+15) when warning light will come on for 0.7 sec.



P3U103L03


When the warning light goes off, turn RED key to STOP.



P3U103L04


Within 10 seconds:

- remove RED key from ignition;
- insert a new key (1) in the ignition and turn to MARCIA (+15), when the warning light will come on for 0.7 sec.



P3U104L01


When warning light goes off, turn key (1) to STOP.



P3U101L02


Within 10 seconds:

- remove key (1) from ignition.
- insert a new key (2) in the ignition and turn to MARCIA (+15), when the warning light will come on for 0.7 sec.



P3U101L01

When the warning light goes off, turn key (2) to STOP.




P3U100L04

Within 10 seconds:

- remove key (2) from ignition;
- insert RED key in ignition and turn to MARCIA (+15), when warning light will come on for 0.7 sec.

### 55.



When the warning light goes off, turn RED key to STOP.

After saving, ensure that all keys provided can start the engine. If one of the keys will not start the engine, repeat the key memorisation procedure.

This procedure cancels recognition of keys memorised previously and saves RED key with recently memorised keys.

#### Key memorisation with electronic key ECU and electronic injection control unit NOT blank

The key rememorisation process will not be successful under the following circumstances:

- if a key is inserted on 2 consecutive occasions;
- if the same key is inserted twice or more between 2 insertions of a RED key;
- key held on MARCIA (+15) for longer than 2 seconds;
- key held on STOP for longer than 10 seconds.

If the procedure has not been carried out properly, repeat memorisation procedure carefully.

If a mistake has been made for any reason and at any time, turn key to MARCIA (+15) for at least 2 seconds or to STOP for at least 10 seconds, then begin key memorisation process again.

If the LED comes on with a steady light during the rememorisation procedure, the process has been halted because a mistake has been made. Repeat procedure from the beginning in this case.



*If LED comes on with steady light (with RED key on MARCIA) upon 2nd consecutive insertion, system is not malfunctioning but rememorisation process has started (1st insertion) and then been halted (2nd insertion).*

*To restore LED to correct operation, turn RED key to STOP.*

**NOTE** *The memorisation procedure has been described for 3 keys (including RED key), but must be applied to all keys provided with vehicle (4 keys), plus any additional keys.*

**Memorising keys with electronic key ECU not blank and electronic injection control unit blank**

If the electronic injection ECU requires replacement, the Master Code must be saved in the unit.

To save the master code in the electronic injection control unit, simply turn key to MARCIA (+15) after checking electronic key ECU is efficient.



*It is absolutely prohibited to swap injection ECUs between vehicles to check their efficiency.*



*When testing, before replacing the electronic injection control unit, check component under examination is really inefficient because the Master Code is saved when a new injection ECU is activated and the unit is rendered completely unusable on other vehicles.*

**MANUAL FAULT DIAGNOSIS**

When the LED remains lit with a steady beam with key on MARCIA (+15), the following problems may arise:

- key not recognised by *electronic key ECU*;
- serial line not connected;
- key re-saving process not carried out correctly (procedure interrupted).

**System blank and key on MARCIA**

A blank system denotes simultaneous presence on a vehicle of an *electronic injection control unit* and an *electronic key ECU* with no codes saved (e.g. following an operation that required replacement of both control units).

- a) When the LED comes on for 0.7 seconds and begins to flash again after 2 seconds, everything is properly connected and operational. Vehicle is not protected, universal code is active.
- b) When the LED flashes with code 1 (one flash, pause, one flash etc.), the serial line is not connected or ECUs are not communicating with one another.
- c) When the LED flashes with code 2 (2 flashes, pause, 2 flashes, etc.) one of the following applies:
  - aerial broken;
  - Trasponder broken;
  - Trasponder missing;
  - the *electronic injection control unit* has received an incorrect code.

---

### 55.

#### Electronic key ECU blank and key on MARCIA

Vehicle with *electronic key ECU* blank and *electronic injection control unit* NOT blank.

When LED is lit with a steady beam with key on MARCIA, one of the following applies:

- aerial broken;
- Trasponder broken;
- Trasponder missing.

#### FAULT DIAGNOSIS

The electronic key system does not have its own tester socket. To check system efficiency, use Fiat Lancia Tester and test via electronic injection system.

A Fiat Lancia Tester is used to find out injection ECU lock status or when vehicle start-up code is not recognised.

A serial line between injection ECU and Fiat Lancia Tester is obtained only after the key is turned to MARCIA (+15).

The injection ECU sends the Fiat Lancia Tester a byte containing error or status information.

#### Errors:

1. Serial line not active, code not received or time out.  
This error indicates that the ECUs (electronic and injection key) have not been able to communicate. Probable causes are a broken line/short circuit or a problem on the ECUs. If the system is blank, this error indicates no response from aerial (aerial broken, Trasponder broken or missing).
2. Incorrect code received.  
The injection ECU has received a code from the electronic key ECU that does not correspond to its master code. Probable cause may lie in swapping of injection ECU or use of another RED key during re-saving.
3. Incorrect code in electronic key ECU.  
This means that an unknown key has been inserted in the electronic key ECU and car is not permitted to start.

Status information:

- injection ECU blank;
- prohibit engine management procedure active;
- incorrect code in electronic key ECU.

The ECU contains a counter which is activated when an error is saved and decreases whenever the error is not present. The ECU deletes the error from its memory when the counter reaches zero. When memorised, the error may be identified as PRESENT or NOT PRESENT.


#### Internal relay controlling line K

When relay controlling line K is in rest position, the ECU is able to dialogue with the electronic key ECU and the electronic injection control unit. The relay switches to the K line only when the following events occur simultaneously:

- no activity in serial line between electronic key ECU and electronic injection;
- low signal on pin B5 for time in excess of 500 msec.

The relay returns to rest position when pin B5 is inactive (and high signal thus present) for a time in excess of 30 seconds. If pin B5 remains at low levels for a period in excess of 5 seconds, system probably contains a short-circuit to earth and relay returns to rest position.

The electronic key ECU tests the inner relay. The LED comes on if the inner relay is not tripped after connecting the Fiat Lancia Tester.



P3U122L01

1. Electronic injection control unit
2. Electronic key ECU
3. Tester socket

## 55.

### EMERGENCY START-UP PROCEDURE USING FIAT LANCIA TESTER

The emergency start-up procedure can be used to start the engine when electronic key system is not working properly (electronic key ECU faulty, keys unusable etc.).

The emergency procedure may be activated only if electronic injection control unit status is "prohibit engine management".

The procedure is activated by entering the 5-figure code on the Code Card on the Fiat Lancia Tester keypad.

This procedure may be used to start the engine only once but may be repeated an unlimited number of times.

### PRECAUTIONS TO BE OBSERVED WHEN REPLACING ELECTRONIC KEY SYSTEM COMPONENTS

The electronic key system consists of various interconnected components. Care must be taken when one of these parts is repaired or replaced.

#### Electronic injection control unit



*It is absolutely prohibited to exchange ECUs between vehicles to check their efficiency.*



*During fault diagnosis, before replacing an electronic injection control unit ensure that the component in question is really inefficient because when the Master Code is saved in a new electronic injection ECU, the unit is rendered completely useless on other vehicles.*

#### Electronic key ECU



*When the electronic key ECU is replaced, all electronic keys must be memorised by following the instructions given on page 106.*

#### RED key



*If the RED key is not available, new engine start-up keys cannot be saved.*



*If the RED key is lost or the associated Transponder is broken/lost, the following must be replaced:*

- kit of dowels and new keys;
- electronic key ECU;
- electronic injection control unit.

*These components are replaced at the first service where use of the RED key is required (e.g. ignition broken).*

#### Kit of dowels and new keys




*Whenever the ignition requires replacement, simply remove Transponder from the old RED key and fit it into the new key. Then carry out the new key memorisation process (procedure on page 106).*

If the ignition has been damaged far from the place where the RED key is kept, carry out the following emergency procedure:

- replace damaged ignition;
- insert the new RED key without Transponder in the ignition;
- bring Transponder of old key into contact with new RED key without Transponder inserted in ignition (see figure page 115);






1. New RED key with TRANSPONDER
2. Old black key with TRANSPONDER



- Turn key and while holding grips in contact to start engine.

As soon as possible, the Transponder in the OLD RED key must be transferred to the housing in the grip of the NEW RED key.




*Proceed with great care to avoid the Transponder (which is a small part) becoming broken or lost (disassemble on a table)*


- Insert a small screwdriver in the key slot and prise open;
- open the RED key carefully. This consists of two halves and the Transponder is indicated by an arrow;
- use a small screwdriver or awl to remove Transponder from its seat in the OLD RED key;



55.




P3U109L01



P3U109L03

- fit the Transponder of the OLD RED key into the housing of the NEW RED key. Respect positioning shown in the figure above and take care not to damage the electrical component;



P3U109L02

- press both halves of the NEW RED key lightly together to join;
- after carrying out the above operation, save the new key set.

### Transponder



*It is absolutely forbidden to handle, replace or exchange key Transponders (except when replacing dowel kit| new keys and only in the case of the RED key).*

### Addition of a new key to the four keys provided with the vehicle



*Addition of a new key involves re-saving all existing keys provided with vehicle because keys not used during this process will be deleted from the memory.*



88 Tester socket for Fiat Lancia Tester  
97 Earth on floor pan  
105 Ignition switch  
106 Electronic key aerial  
107 Car alarm ECU  
108 Electronic key ECU  
297 Car alarm/electronic key device warning  
light


117

55.

### EMERGENCY START-UP PROCEDURE USING ACCELERATOR PEDAL WITH INDICATION ON INFOCENTER DISPLAY




*Follow the procedure described below very carefully to avoid mistakes when carrying out emergency start-up using the accelerator pedal.*



P3U117L01




1. Read the code on the CODE CARD before beginning the code entry procedure.



P3U100L04


2. Insert the ignition key and turn to MAR.




P3U117L02



3. Press the two "TEMP" keys shown in the figure simultaneously for at least 4 seconds. The display will read: "PRESS ACCELERATOR AND AWAIT CODE".





P3U118L01



P3U118L02


1. When the accelerator pedal is pressed, the display shows the following message "PRESS ACCELERATOR AND AWAIT CODE". To continue the procedure, keep the accelerator pedal pressed for at least 8 seconds.




P3U118L03

2. After pressing the pedal for 8 seconds, the following message will appear on the display "LEAVE ACCELERATOR CODE".
3. When the accelerator pedal is released, the display will show the first figure, starting from number 1.

55.





P3U119L01





P3U119L02

1. The first figure on the display begins a progressive count from 1 to 9 to the accompaniment of an acoustic signal. The display shows the message "IF CODE OK, PRESS ACCELERATOR CODE". When the first figure on the display is the same as the first number of the code on the CODE CARD, press the accelerator pedal as shown in the figure.




2. Keep the accelerator pedal pressed down, and the display will read "PRESS ACCELERATOR AND AWAIT CODE"
3. When the accelerator pedal is kept pressed for 4 seconds, the display shows the message "LEAVE ACCELERATOR CODE".



P3U119L03


3U188L




P3U118L01



1. After releasing the accelerator pedal, the code entry procedure begins again from the message "IF FIGURE OK PRESS ACCELERATOR CODE"; the other figures making up the code on the code card must be entered in the same way as the first.




2. If the code is correctly entered, the infocenter display will show the message "CODE OK 35117 START UP ENGINE".



P3U120L01




3. When the engine is started, the infocenter display will show the CLIMATE or CHECK screen.



4. If an incorrect code is entered or the code entry procedure is incorrect, the display will show the message "CODE INCORRECT XXXXX REPEAT PROCEDURE".

#### LOCATION OF CAR RADIO COMPONENTS ON VEHICLE




P3U10CL01

1. Right front speaker (woofer)
2. Right front speaker (tweeter)
3. Car radio ADT 838 (medium - high level) / ADM 838 (high level Hi Fi)
4. Amplifier for aerial on heated rear window
5. Right hand rear speaker (woofer and tweeter)
6. Aerial screen-printed on rear window
7. Left hand rear speaker (woofer and tweeter)

8. CD player (fitted with high level - Hi Fi)
9. Amplifier (fitted with high level -Hi Fi)
10. Left front loudspeaker (woofer)
11. Left front loudspeaker (tweeter)
12. Junction unit with fuses F7 (15A) and F17 (5A) protecting car radio
13. 60 A fuse
14. Battery



## DESCRIPTION OF COMPONENTS




P3U09CL01

## Removing the removable front

The removable front of the radio may be removed to prevent theft whenever the vehicle is left unattended. Each time it is removed, it must be placed in its case to avoid damage.

A. Connector on car radio




P3U09CL02



Ensure connector contact areas on the radio and removable front are kept clean. Avoid contact with hands or tools. The presence of dirt could cause the radio to work inefficiently. It is therefore advisable to clean the surfaces with a soft, dry cloth.

B. Connector on removable front  
C. Removable front



P3U09CL03

## Location of anti-theft warning light (led) on the radio

To increase the protective function against theft, a red warning light (led) located on the radio may be made to flash. Proceed as follows to turn on:

- turn off the power by means of the ON switch
- remove the removable front of the radio.

### 55.

#### Standard wiring

The vehicle is equipped with wiring to connect all speakers, the rear window aerial amplifier and the radio power source.

The following leads leave the radio connector:

- leads BN and RN connected to the left front speaker;
- leads SN and NZ connected to right front speaker;
- leads and C connected to left hand rear speaker;
- leads AN and A connected to right hand rear speaker;

Speaker housings are located:

- front tweeters, at the end of the instrument facia;
- woofers, on the front doors;
- rear tweeters and woofers, at the end of the rear parcel rack;

The speakers are connected by means of connector B (black) located on the rear of the radio. Connector A (white) is used to connect the following power supplies:

- battery through fuse (F7 - 15A) located in the junction unit;
- radio earth;
- radio control light power source;
- aerial amplifier;
- +12 V (accessory position).

A +12V protected by fuse F7 (15A) is available for connection of an electric stylus-type aerial (lead RN on the aerial amplifier connector).

#### Provision for car radio

The "provision for car radio" option allows for:

- tweeter on instrument facia with passband of 2500-20000 Hz, nominal impedance of 4 Ohm, power of 30 W in RDS and weight of 30 g;
- woofer on front doors with passband of 100÷8000 Hz, nominal impedance of 4 Ohm, power of 12 W in RDS weight of 330 g and diameter of 130 mm;
- woofer and tweeter on rear parcel sheft with passband of 70-20000 Hz, nominal impedance of 4 Ohm, power of 30 W in RDS, weight of 500 g and bore of 160 mm (woofer);
- aerial amplifier and aerial built into the rear window.


The right hand side of the luggage compartment houses a shielded lead and connector for connection of the aerial amplifier built into the rear window.

The space available in the conventional rear window has been used to create an AM/FM aerial by laying two wires of conducting material in parallel with the existing heater elements. The vehicle chassis acts as an earth plane.

It was not possible to use the existing heated windscreen wires because it is not possible to uncouple the signal received by the heated rear window supply. This effect is due to the fact that the heated window supply is usually subject to considerable interference generated by the electrical system and electronic equipment.

The amplifier for this type of aerial is located beneath the right pillar trim and bolted to the steel body frame. The fastening ensures that the amplifier is earthed.

It consists of two separate amplification circuits, one for the AM band and the other for the FM band. An anti-interference filter fitted in line with the heater wire power source suppresses the interference generated by the vehicle.



P3U12CL01

1. Heated rear window positive terminal
2. FM aerial terminal
3. AM aerial terminal
4. Amplifier earth: nut secured to body shell

5. Supply to heated rear window (circuit with anti-interference filter)
6. Amplifier supply through the car radio
7. Connection with the aerial coaxial cable coming from the car radio

### Medium level (High)

With the "medium level radio" option, the car is fitted with:

- amplifier for aerial built into heated rear window;
- loudspeakers;
- radio with removable front, model ADT 838.

The radio is of compact size as specified by DIN standards. On the front, it is possible to control all the functions for radio (with RDS), tape and CD by means of a multi-function keyboard, and to display the set commands via a green alphanumeric liquid crystal display. The radio must have a high output power (4 x 20W), in order to ensure low distortion and a high sound level without interference.

- Operating voltage = 10-16 V;
- nominal voltage = 13.5 V;
- memory supply voltage = 4.2 V;
- absorbed current = less than 10A at the maximum output power;  
less than 3 mA with the radio off and the ignition OFF (STOP);  
less than 8 mA with the radio off, ignition OFF (STOP) and CD connected.

### 55.


#### Radio

- Type of tuner = PLL quartz;
- band limits = FM 87.5 - 108.0 MHz; MW 531.0 - 1602.0 kHz; LW 153.0 - 279.0 kHz;
- intermediate frequencies = 10.7 MHz (FM), 450 kHz (MW), 450 (LW).

#### Power section

- number of output channels: 4
- musical output power: 26 W peak (per channel)
- load impedance: 4 Ohm
- supply voltage: 13.5 V
- nominal output power: 13 W RDS

#### General wiring diagram of ADT 838 car radio



P3U13CL01

**High level (Hi Fi)**

With the "high-level radio" option, the car is fitted with:

- amplifier for aerial built into heated rear window;
- loudspeakers;
- radio with removable front, model ADM 838;
- amplifier with DSP for radio;
- CD reader with 6-disc loader, model CDC 838.

The radio is of compact size as specified by DIN standards. On the front, it is possible to control all the functions for radio (with RDS), tape and CD by means of a multi-function keyboard, and to display the set functions via a green alphanumeric liquid crystal display. The system (radio and amplifier) must have a high output power (4 x 25W), in order to ensure low distortion and a high sound level without interference.


- Operating voltage = 10.2 - 15.6 V;
- nominal voltage = 13.5 V with negative to earth;
- memory supply voltage = 4.2 V;
- absorbed current = less than 10 A at maximum output power;  
less than 2 mA with the radio off.

**Radio**

- Type of tuner = PLL quartz;
- band limits = FM 87.5 - 108.0 MHz; MW 531.0 - 1602.0 kHz; LW 153.0 - 279.0 kHz;
- intermediate frequencies: 10.7 MHz

Power amplifier (external with incorporated DSP) model ADM 838

- Number of output channels: 4    - load impedance: 4 Ohm;
- output power: 25 W max;        - supply voltage: 13.5 V;



P3U16CL01

**Anti-theft protection***Secret code*

The 4-digit secret code is indicated on the anti-theft card which is supplied with the car. The card, with the secret code, should then be stored in a safe place.

If the battery is disconnected, the radio will only work if the secret code is entered. After 3 consecutive errors in entering the code, the anti-theft device cannot be switched off for one hour, even if the code is correct.

It is necessary to enter the code in the radio at the time of delivery of the car and whenever the battery supply is temporarily cut off.


If, for example, the code number stated on the anti-theft card is 2541, the procedure is as follows:

- switch on the radio;
- the message "CODE IN" is displayed;
- press the "2 SCN" button;
- the number "2" will be displayed;
- press the "5 BLS" button;
- the number "25" will be displayed;
- press the "4 BNR" button;
- the number "254" will be displayed;
- press the "1 RPT" button;
- the number "2541" will be displayed.


A radio frequency indication will be displayed. If an incorrect code has been entered, the radio remains blocked and the "CODE IN" message is displayed again. Re-enter the correct code, repeating the procedure described above.

55.


ADT 838 RADIO WITH REMOVABLE FRONT




P3U14CL01




P3U14CL02



P3U14CL03



P3U14CL04



P3U14CL05

N°	AUTO MODE	RADIO MODE	TAPE MODE	CD MODE
1	Power on-off			
2	Radio-tape-cd selector			
3		FM1-FM2-FM3-MWLW band selector	Manual cassette reverse	Compact disc selection
4	Removable unit (DCP) disconnect button			
5		Scan. preselec. stations auto store(FM1 only)		
6		RDS (radio data system) selector		
7		TA (traffic announcement) selector		
8		Preselected station indicator LED	Function activated indicator LED	Function activated indicator LED
9			Cassette expulsion	
10	Sound flavor rock-jazz- classic			
11	Liquid crystal display			
12		Distant/local function selector		
13	Removable unit (DCP)			
14		Manual tuning (up)	Tape forward feed (ff)	Fast forward (ff)
15		Preselec./memoriz. station n°6		
16		Preselec./memoriz. station n°3		Random passage selection
17		Preselec./memoriz. station n°5	Blank skip function selection	
18		Automatic tuning (up-down)	Forward/rewind passage search (ff-rew)	Forward/rewind passage search (ff-rew)
19		Preselec./memoriz. station n°2	Passage scan	Passage scan
20		Preselec./memoriz. station n°4	Dolby B-nr function selection	
21		Manual tuning (down)	Tape rewind (rew)	Fast backward (fb)
22		Preselec./memoriz. station n°1	Passage repeater	Passage repeater
23	Low/high pitch-fader-balance selectors			
24	Anti = theft LED			
25	Rec, low/high pitch-fader-balance level			
26	Rec, volume level			

Conn.	A	B	E
1	Not connected	Rear right loudspeaker (+)	Input/output signal
2	Not connected	Rear right loudspeaker (-)	+ 12 V (+ 15 under key)
3	Not connected	Front right loudspeaker (+)	Not connected
4	+ 12 V	Front right loudspeaker (-)	Signal request
5	Aerial enablement	Front left loudspeaker (+)	Not connected
6	+ 12 V radio illumination	Front left loudspeaker (-)	Signal earth
7	+ 12V	Rear left loudspeaker (+)	Left input
8	Earth	Rear left loudspeaker (-)	Right input
9			Not connected
10			Back up (+ 12 V)
11			+ 12 V (+ 30 permanent)
12			Earth
13			Not connected







D 10 A fuse

E Seating for multi-pole cable (13 pins) for connection between CD and radio

F Seating for aerial extension cable jack plug

55.

CLARION ADM 838 RADIO WITH REMOVABLE FRONT





N°	AUDIO MODE	RADIO MODE	TAPE MODE	CD MODE
1	Power on-off			
2	Radio-tape-CD selector			
3		FM1-FM2-FM3-MW-LW band selector	Manual cassette reverse	Compact Disc selection
4	Removable unit (DCP) disconnect button			
5		Scan. preselec. stations auto store (FM only)		
6		RDS (radio data system) selector		
7		TA (traffic announcement) selector		
8		Preselected station indicator LED	Function activated indicator LED	Function activated indicator LED
9			Cassette expulsion	
10	Avail: hall-church-stadium-disco-off			
11	Selection of listening position in car			
12	Liquid crystal display			
13		Distant/local function selector		
14	Removable unit (DCP)			
15		Manual tuning (up)	Tape forward feed (ff)	Fast forward (ff)
16		Preselec./memoriz. station n°6		
17		Preselec./memoriz. station n°3		Random passage selection
18		Preselec./memoriz. station n°5	Blank skip function selection	
19		Automatic tuning (up-down)	Forward/rewind passage search (ff-rew)	Forward/rewind passage search (ff-rew)
20		Preselec./memoriz. station n°2	Passage scan	Passage scan
21		Preselec./memoriz. station n°4	Dolby B-nr function selection	
22		Manual tuning (down)	Tape rewind (rew)	Fast backward (fb)
23		Preselec./memoriz. station n°1	Passage repetition	Passage repetition
24	Low/high pitch-fader-balance selectors			
25	Anti-theft LED			
26	Rec. low/high pitch-fader-balance level			
27	Rec. volume level			


Conn.	A	B	E
1	Telephone mute (N.C.)	Left channel (+)	Input/output signal
2	Not connected	Left channel (-)	+ 12 V (+ 30 permanent)
3	Not connected	Right channel (+)	Not connected
4	+ 12 V	Right channel (-)	Signal request
5	Aerial enablement	Mute	Telecommand + B
6	+ 12 V radio illumination	Earth	Signal earth
7	+ 12V	Not connected	Left output
8	Earth	Not connected	Right output
9		Not connected	Mute
10		Not connected	Back up (+ 12 V)
11			+ 12 V (+ 15 under key)
12			Earth
13			Not connected

D 3A fuse

F Seating for multi-pole cable (13 pins) for connection between CD and radio seating for aerial extension cable jack plug



55.

General wiring diagram of ADM 838 car radio




P3U17CL01

## External amplifier



P3U20CL02



P3U20CL03


P3U20CL04

CON.	A	C	D
1	Front left loudspeaker (+)	Input/output signal	Input/output signal
2	Front left loudspeaker (-)	+12 V (+30 permanent)	+12 V (+30 permanent)
3	Front right loudspeaker (+)	Not connected	Not connected
4	Front right loudspeaker (-)	Signal request	Signal request
5	Rear left loudspeaker (+)	Control + B	Not connected
6	Rear left loudspeaker (-)	Signal earth	Signal earth
7	Rear right loudspeaker (+)	Left output	Left input
8	Rear right loudspeaker (-)	Rear right	Right input
9	Earth	Mute	Not connected
10	Earth	Back up (+12 V)	Back up (+12 V)
11	+12 V Battery	+12 V (+15 under key)	+12 V (+15 under key)
12	+12 V Battery	Earth	Earth
13		Not connected	Not connected

B 10 A fuse

D Multi-pole cable for connection between amplifier and CD

C Seating for multi-pole cable (13 pins) for connection between amplifier and radio



P3U20CL05

## CD reader model CDC 838

- Sampling frequency: 44.1 kHz (8 times over-sampling)
- Frequency response: 8-20000 Hz ( $\pm 1$  dB)
- Signal/noise ratio: 94 dB (1 kHz) IHF-A
- Tone control:
 

LOW	-100 Hz $\pm 10$ dB
HIGH	-10 kHz $\pm 10$ dB

1. Seating for multi-pole cable (13 pins) for connection between amplifier and CD.

## 55.

### ANTI-THEFT DEVICE (TRW-SIPEA)

#### Introduction

On request, the car may be fitted with the anti-theft device linked to the central door locking system with remote control.

The TRW anti-theft system is a device which offers volumetric and perimetral protection; it can monitor the status of the doors and the presence of a moving person or object inside the interior compartment.

The system is "universal" in that it offers the possibility of managing the sound level of the anti-theft device and the type of flashing of the direction indicators, depending on the regulations in various countries. In addition, a sophisticated self-test system checks:

- errors or intermittent or permanent faults;
- specific faults in the control unit;
- number of activations of the anti-theft device and the alarms effected.


The anti-theft device basically consists of an infrared receiver on the courtesy light, an infrared transmitter (or remote control) integrated in the key, three volumetric sensors incorporated in a plate secured to the roof trim before the courtesy light, six switches (doors, boot and bonnet), an electronic control unit (red) located under the dashboard in the central console area just above the Air Bag control unit, and an alarm siren located on the right in the boot, fitted with an emergency microswitch with ON-OFF key command.

### ANTI-THEFT DEVICE CONTROL UNIT

This is the main unit of the anti-theft device. It checks and processes the status of the following sensors:

1. boot switch;
2. bonnet switch;
3. status of the doors, supplied by the door open indicator switches or check control;
5. volumetric sensors alarm;
6. insertion of ignition key.

The control unit has two male connectors A and B with 17 and 13 pins; to these are connected two female connectors (forming part of the 14- and 11-pin wiring).



Anti-theft control unit - view of top


Anti-theft control unit - view of connectors side

## INPUT AND OUTPUT SIGNALS TO/FROM THE ANTI-THEFT CONTROL UNIT

PIN	I/O	FUNCTION
B1	OUT	EARTH IN CONTROL UNIT
B2	I/O	FOR DRIVING TWO-COLOUR FLASHING LED ON DASHBOARD
B3	OUT	N.O. RELAY CONTACT: CONTROL OF LEFT BLINKER BRANCH
B4	N.C.	N.C.
B5	N.C.	N.C.
B6	IN	ELECTRONIC KEY SYSTEM
B7	IN	POSITIVE DIRECT SUPPLY (+ 30)
B8	I/O	LINE K FIAT/LANCIA TESTER
B9	IN	CONTROL UNIT EARTH
B10	IN	POSITIVE DIRECT SUPPLY (+ 30) TO DIRECTION INDICATORS
B11	OUT	N.O. RELAY CONTACT: CONTROL OF RIGHT BLINKER BRANCH
B12	IN	KEY-DEPENDENT POSITIVE (+ 15)
B13	I/O	FOR DRIVING TWO-COLOUR FLASHING LED ON DASHBOARD
A1	IN	EARTH IN CONTROL UNIT LINE (-) FIAT/LANCIA TESTER
A2	IN	LINE FOR DEACTIVATION FROM REMOTE KEY
A3	N.C.	N.C.
A4	IN	BRIDGED TO EARTH ON B1
A5	IN	REAR RIGHT DOOR OPEN DETECTION SWITCH
A6	IN	FRONT RIGHT DOOR OPEN DETECTION SWITCH
A7	IN	FRONT LEFT DOOR OPEN DETECTION SWITCH
A8	IN	SIREN ACTIVATION LINE
A9	IN	SERIAL LINE FROM COURTESY LIGHT
A10	I/O	SIGNAL LINE FROM VOLUMETRIC SENSORS
A11	IN	POSITIVE SUPPLY TO VOLUMETRIC SENSORS UNIT
A12	N.C.	N.C.
A13	N.C.	N.C.
A14	N.C.	N.C.
A15	IN	REAR LEFT DOOR OPEN DETECTION SWITCH
A16	IN	BOOT OPEN DETECTION SWITCH
A17	IN	BONNET OPEN DETECTION SWITCH

# 55.

## LOCATION OF COMPONENTS




P3U03AL01

### Key

- |  |   |
|--|---|
| 1. Anti-theft control unit (red) under dash-board in central console, passenger side | 8. Boot open indicator switch                         |
| 2. Infrared receiver on courtesy light   | 9. Front left door open indicator switch              |
| 3. Mounting with volumetric sensors  | 10. Rear left door open indicator switch              |
| 4. Warning light (two-colour LED) indicating anti-theft device ON                    | 11. Self-supplied anti-theft siren (on right of boot) |
| 5. Infrared remote control   | 12. Bonnet open indicator switch                      |
| 6. Front right door open indicator switch  |   |
| 7. Rear right door open indicator switch   |   |

**NOTE** With the doors, boot and bonnet shut, the switches 6-7-8-9-10-12 are electrically open (i.e. not connected to earth).



P3U04AL01

**ANTI-THEFT SIREN**

K. Ignition switch

A. Connector

**Technical characteristics**

Supply	10.5 - 15 VDC
Absorption at rest	4 mA
Absorption in operation	2A
Frequency	1700 - 2300 Hz
Acoustic pressure	118 dB at 1 metre
Dimensions	112 x 98 x 82 (mm)

The anti-theft siren is located in the space between the metal wall and the fabric boot trim on the right side. This is of the self-supplied type, so it can operate even if the car's battery is disconnected or its leads are cut. The self-supply is achieved by suitable batteries installed directly in the siren's container.

The siren has a connector (A) with five cables which make the following connections:

A - positive +12 V direct from battery (+30) (cable R)

B - general earth (cable N)

C - siren activation/deactivation signal from alarm unit (cable A)

D - positive +12V from ignition switch (+15/54) (cable M)


E - manual siren disablement signal (cable B)

**REMOTE KEY**

The siren also has a key switch (K) for disabling it if it is activated because of a fault in the system.

**Deactivation:** when the key is turned, the control unit emits an acoustic signal: the anti-theft device is deactivated or in the OFF position (EUROPEAN MARKET EXCLUDING GER-

**Activation:** when the key is turned, the control unit stays silent; the anti-theft device is activated or in the ON position



P3U04AL02

**RECEIVER**

1. LED
  2. Programming button
  3. Infrared semisphere or receiver
  4. Volumetric sensors
- B. Connector B (courtesy light)  
C. Connector C (volumetric sensors)

## 55.

The **receiver**, incorporated in the front courtesy light, is an electronic device which receives the infrared signal via a semisphere projecting from the receiver itself. The particular semispherical shape enables it to receive the signal at 360 degrees, provided that the transmitter is not more than about 5 metres away.

It controls the opening/closure of the doors and activates the alarm control unit. Each receiver may be tuned with one or more transmitters (up to a maximum of 4), by storing their relevant codes in memory. There is also a red LED (1) on the receiver, which comes on when the signal is received, while a button (2) is for storing in memory the secret control code.

When it is fitted to the car, the receiver contains a so-called "UNIVERSAL" code, used for carrying out tests at the end of the production line with an appropriate transmitter with universal code.

When the car is delivered to the Customer, the receiver has to be customized by replacing the "UNIVERSAL" code with the code supplied to each Customer.

### *Courtesy light connector B*

- |  |                                    |
|--|------------------------------------|
| 1. Door locking                          | 5. Courtesy light earth            |
| 2. Door unlocking                        | 6. Positive 12V from battery (+30) |
| 3. Serial line to the alarm control unit | 7. N.C.                            |
| 4. N.C.                                  | 8. Key-dependent positive (+15/54) |

## VOLUMETRIC SENSORS

The three volumetric sensors permit additional surveillance, checking that there has been no intrusion in the vehicle. They are incorporated into a plastic mounting located behind the front courtesy light: two function as transmitters and the third as receiver; the ultrasonic wave beam emitted by the transmitters (the left is that facing the dashboard) must be received by the third (the right one) after the waves have been reflected from the car's internal walls.

If there are no moving objects inside the car, the infrared signal reaches the receiver with the same frequency as that transmitted; if not, a signal is sent to the alarm control unit in order to activate the siren.

### *Volumetric sensor connector C*

1. Earth
2. Positive from alarm control unit pin A11
3. Line for signal from volumetric sensor

## KEY

The keys provided with the car have the following functions:


### A) Mechanical function

Locking/unlocking of all the locks, steering lock and engine starting.

### B) Electronic key system function

Protected by the rubber casing on the ignition key handle, there is a device called a **TRANSPONDER** (electronic key) which contains a code. This code is transmitted (when the key is inserted in the ignition switch) to the electronic key system control unit to unlock the fuel injection-ignition system.

### C) Transmitter (or infrared remote controls) function)



P3U05AL01

1. Control button
2. Infrared LED
3. Repeater LED
4. Password code plate
5. Transponder

The **transmitter**, protected by a rubber casing, consists of a printed circuit and an infrared emitter. It is supplied by two 3 V lithium batteries. Whenever the control button (1) is pressed, the transmitter sends a beam of rays in the direction in which the LED (2) is pointed.



It is an infrared device with continuous transmission of the code; the maximum duration is 5 seconds, even if the button is pressed for longer. At the same time, the repeater LED (3) comes on whenever a signal is emitted, thus permitting a visual check that the transmitter is sending the code.

It contains a memory which is customized with a non-modifiable code consisting of six groups of numbers selected from unnumerable possible combinations. This memorization is done in the factory. The code is printed on a card which is supplied with each transmitter; printed above the code on the card, there is also the "Password" which consists of 4 digits.




*If this transmitter is replaced or an additional one is used, memorization must be carried out using the procedures which apply to both the anti-theft device and the electronic key system.*

**NOTE** *The remote control works with infrared rays, and so does not pollute the environment with radio waves. At the same time it ensures better protection from attempts at understanding its secret code. Its radius of action is about 5 m with the battery well charged. It should be directed towards the receiver located on the courtesy light to avoid the interposition of obstacles which could also be parts of the same car (e.g. shadows of the door pillars). Even the presence of dirt, snow or ice on the side windows can impede reception. If the button is held pressed down, the remote control continues to emit the signal for a maximum period of 5 seconds. If the receiver is not activated, change the angle of the transmitter in relation to the receiver.*

### SWITCHES ON DOORS, BONNET AND BOOT

To check the doors and boot, the same switches as for the door and boot open indication circuit are used; the bonnet has its own switch. All these switches indicate non-closure by means of an "earth" signal towards the control unit (doors, boot and bonnet shut = switches open).

### TWO-COLOUR (GREEN-RED) INDICATOR LED



P3U06AL01

1. Anti-theft control unit
2. Electronic key system
3. Two-colour LED on instrument panel

The indicator LED (3) located on the instrument panel is a semiconductor display device. It consists of a light-emitting diode which emits a visible beam of light whose colour depends on the semiconductor material used.

For it to emit light, it must be supplied (polarized) with an appropriate voltage of between 1.3 and 2.5 V. In this specific case, it is a two-colour LED, i.e. consisting of two diodes connected in antiparallel on the same container.

## 55.

### Flashing green LED: electronic key system operative

With the ignition and anti-theft device OFF, the green LED flashes because the anti-theft control unit's microprocessor blocks the transistor T2 and keeps the transistor T1 polarized; this enables the green LED to close to earth on the electronic key system. The green LED indicates that the fuel injection control unit is locked.


### Flashing red LED: anti-theft device operative

The LED changes from green to red when the anti-theft device is switched on with the remote control. Under these conditions, the microprocessor blocks the transistor T1 and polarizes the transistor T2, allowing the red LED to close to earth on T2.

When the anti-theft device is switched off with the remote control, the red LED goes out and the green LED starts flashing again.

### OPERATION OF ANTI-THEFT DEVICE

The anti-theft device can only be switched on with the ignition OFF (STOP position).



P3U07AL01

#### Activation

Direct the transmitter (remote control) towards the receiver dome and press the button. The infrared receiver sends a command to the door locking control unit to lock the doors, and at the same time a second signal to the anti-theft control unit. The activation of the anti-theft device is indicated both visually and acoustically (on markets where this is required). When the alarm system is on, the two-colour LED at the centre of the instrument panel comes on with a red flashing light.

#### Deactivation

Again direct the transmitter towards the receiver dome and press the button. The infrared receiver sends the respective commands to the control units to unlock the doors and deactivate the anti-theft device. Deactivation is also indicated visually and acoustically (on markets where this is required). When the anti-theft system is switched off, the two-colour LED becomes green (electronic key system operative = fuel injection locked).

**NOTE** *The system is protected from illegal recording of the secret code.*

#### Exclusion of system

If the transmitter batteries become discharged or the anti-theft device becomes faulty, the activated siren can be excluded by turning the remote key, on the siren, to the OFF position. When the remote key is turned to OFF, the siren is switched off, but the anti-theft system remains active; to deactivate it, use the remote control.

If the vehicle is not used for long periods (over one month), set the key to the OFF position and disconnect the battery's negative lead. With the key at the OFF position, surveillance of battery lead cutting (battery disconnection) is no longer active.

**Surveillance stage (anti-theft device ON)**

During the surveillance stage (vehicle locked and anti-theft device ON), the dissuasion LED flashes at a frequency of about 0.8 Hz; in this state, the anti-theft system monitors:

- a) doors, bonnet and boot;
- b) disconnection/cutting of the battery cables;
- c) unauthorized insertion of the ignition key;
- d) movements inside the interior compartment (volumetric surveillance);
- e) cutting of the remote key cables;
- f) if the battery loses more than 1 Volt/hour (e.g. short circuit).

**Alarm state**

The system enters into an alarm state when:

- 1. One of the doors, bonnet or boot is opened.
- 2. The battery is disconnected or the supply cables to the anti-theft device are cut; if the battery loses more than 1 Volt/hour (short circuit).
- 3. The ignition key is turned to the ignition ON position.
- 4. Something invades the car interior space (e.g. if the window is lowered, is it sufficient for a person to put a hand in).

The alarm state is manifested by the activation of the siren and the direction indicators, with times varying depending on the market. The fuel injection-ignition system is blocked by the electronic key system.

If the alarm condition ceases (e.g. if the doors are shut again or the movement of the hand inside the car stops), the siren and the hazard warning lights are deactivated; at the end of the cycle, the system returns to the wait condition (stand-by).

You can exit from the alarm situation:

- a) with a switch-off command from the transmitter (remote control);
- b) 25 seconds after the last entry into the alarm state;
- c) by means of the emergency key (remote) present on the siren.

**NOTE** *In conditions (c-b), the anti-theft device stays on.*

**Exclusion of volumetric surveillance**

Volumetric surveillance only can be excluded by means of one of the following actions:

- a) Switch off the engine (the anti-theft device is not ON yet); in strict sequence starting from the ignition key at the ignition ON position, turn the ignition key to OFF-ON-OFF. The exclusion of volumetric surveillance is confirmed by the two-colour dissuasion LED (red) coming on for about 2 seconds and by the activation for 2 seconds of the buzzer located in the volumetric sensor ceiling plate.
- b) Starting with the ignition key at the ignition ON position, press the button on the receiver (for less than 0.5 s) and then within a maximum of 8 seconds turn the ignition key to the ignition OFF position. The exclusion of volumetric surveillance is again confirmed by the LED on the courtesy light coming on.

**Switching volumetric surveillance back on**

Volumetric surveillance is switched on fully automatically, and takes place when the ignition key is next turned to the ignition ON position.

**NOTE** *The ignition key can be set to the ignition ON position (with the anti-theft device ON) for a maximum of 30 s without re-enabling volumetric surveillance (this may be useful for example to permit the closure of windows that may have been left open accidentally).*

## 55.

### AUTO SWITCH-ON OF ELECTRONIC ANTI-THEFT DEVICE (German market only)

Cars with the electronic anti-theft device programmed for the German market include the **"passive"** auto switch-on function. This function ensures the automatic partial switch-on of the anti-theft device a short time (4 minutes) after the car has been left by the user.

Surveillance in the **"passive"** operating mode is as normal, activated by the remote control, except for the following points:

- the doors are not locked;
- volumetric surveillance is not carried out.

Automatic switch-on is activated 4 minutes after the following conditions have arisen:

- ignition key moved from the ignition ON to the ignition OFF position;
- opening and subsequent closure of the driver's door.

The opening of the driver's door or bonnet before the delay period (4 minutes) has elapsed stops the counting. Closure restart the counting.

### SELF-TEST

#### Switching on the anti-theft device

When switched on, the system carries out a self-test to check the correct status of the of the anti-theft device; if there is a fault, the two-colour LED (red) located at the centre of the instrument panel indicates it in accordance with the table below.

#### Self-test display

FLASHING MODE	MEANING
15 Hz, duration 3 s	Door/bonnet/boot left open or switch faulty
Fixed light, duration 3 s	Volumetric sensor faulty

If a door, the bonnet or the boot are found to be open or a fault in the volumetric sensors is detected, the relevant sensor is excluded from surveillance and an acoustic warning (beep) is emitted one second after switch-on.

#### Switching off the anti-theft device

When switched off the system indicates, by the timed flashing of the dissuasion two-colour LED (red), which sensor has triggered an alarm that may have occurred during surveillance; the methods are stated in the table below.

**NOTE** When the ignition key is turned to the ignition ON position, the indications are cancelled.

No. of FLASHES	MEANING
1st FLASH	FRONT RIGHT DOOR
2nd FLASH	FRONT LEFT DOOR
3rd FLASH	RIGHT REAR DOOR
4th FLASH	REAR LEFT DOOR
5th FLASH	ADDITIONAL SENSORS - U.S. SENSORS FROM COURTESY LIGHT
6th FLASH	BONNET
7th FLASH	BOOT
8th FLASH	+ 15 INTERRUPTION IN KEY-DEPENDENT SUPPLY
9th FLASH	+ 30 INTERRUPTION IN BATTERY SUPPLY
10th FLASH	AT LEAST 3 SIMULTANEOUS CAUSES FOR ALARM

If there are several alarm codes, they are presented in sequence.

**FAULT DIAGNOSIS WITH INSTRUMENTS**

The system comprises a diagnostic socket for connection of the C.D.S. Diagnostic Station or the FIAT-LANCIA Tester. The alarm control unit permits entry into fault diagnosis with the ignition OFF, after at least 5 seconds, or with the ignition ON but with the alarm system deactivated.

**Fault diagnosis with Fiat-Lancia Tester (M40A MODULE)**

The FIAT-LANCIA Tester makes it possible to transfer data to the outside, i.e. to read the contents of the anti-theft control unit's memory.

To use the FIAT-LANCIA Tester on the anti-theft device, it is necessary to connect the ADT101A adaptor. To connect it, always proceed as follows:

1. Supply the FIAT-LANCIA Tester through the cigar lighter socket, or connecting it directly to the battery (there is a special cable for the latter alternative).
2. Connect the Tester to the diagnostic socket (check whether the control unit is enabled from the remote key; if not, dialogue with the FIAT-LANCIA Tester is not established).

With the FIAT-LANCIA Tester supplied, fault diagnosis may be started in three different modes: 1) AUTOMATIC; 2) WRITE ISO CODE; 3) SKIP ISO CODE.

**Searching for errors in memory**

Executing one of the three procedure, the control unit starts transmitting data to the FIAT-LANCIA Tester which represent any errors that may be present. If there are any errors, press the OK key to proceed with searching for the cause of the fault. The check is guided by the FIAT-LANCIA Tester (GUIDED DIAGNOSIS).

After repairing the fault automatically, the FIAT-LANCIA Tester deletes the errors in memory, and then executes a procedure for activation and deactivation of the anti-theft device in order to check that the fault has been eliminated.

The error can be suspended by pressing the OXK key. The error will be stored in the FIAT-LANCIA Tester's memory, and it may be redisplayed by pressing the FC key and selecting SUSPENDED ERRORS.

**State of errors in perimetral protection switches**

The FIAT-LANCIA Tester indicates whether the respective switches change state (closed to earth-broken) when doors, boot and bonnet are opened and shut. It indicates whether the ignition key is at the ignition ON or ignition OFF position.

**Country code programming**

The FIAT-LANCIA Tester can program the code of the country where the vehicle will be marketed; it is sufficient to press the OXK key during ACTIVE DIAGNOSIS. The country codes are:

Italy 1 - Germany 2 - France 3 - Switzerland 4 - United Kingdom 5 - Holland 6 - USA 7 - EEC 8 - spare 9 and 10.

**Alarm counter**

If a theft has been attempted, it is possible to know which protection has intervened and how many times it has intervened. The alarm counter thus indicates how many times the key has been inserted; how many times each individual door, boot or bonnet have been stressed; how many times the volumetric sensors have been activated or whether a supply cable has been disconnected or cut.

**Guided diagnosis**

If a fault is detected, there will be an acoustic signal from the FIAT-LANCIA Tester and the message relating to the faulty channel will be displayed (e.g. error in warning lamp).


When the OK button is pressed, a procedure for checking the faulty channel will be activated, and the probable causes of the fault will then be indicated. The operator will have to check that the components are working, making sure to repair or replaced any faulty ones.

In order to check whether the fault has been repaired, the program will delete the errors automatically and will make the operator carry out a series of operations, such as activation and deactivation of the alarm system. If the repair has been successful, the Tester will display the next error (if there is one), otherwise it will return to data reading (status of the perimetral protection switches).

## 55.

When the errors are deleted, the alarm counters are also deleted.

**NOTE** Always follow the FIAT-LANCIA Tester's instructions fully.



P3U11AL01

### Manual diagnosis

MANUAL DIAGNOSIS can be carried out. To enter into this mode, the ignition key must have been at the ignition OFF position for at least 5 seconds, and the siren's remote key must be in the ON position. The alarm control unit carries out two types of check: automatic and manual.

#### 1) Automatic check

Press the bonnet protection button (A) 7 times in rapid succession within no more than 8-12 seconds. Under these conditions, the self-test of the volumetric sensors connected to the control unit is activated automatically.

#### a) Positive test (volumetric sensors)

If the test is positive, the direction indicators and the two-colour surveillance LED (red) on the instrument panel will flash 3 times, while the buzzer incorporated in the volumetric sensor mounting will sound for about 2 seconds.

#### b) Negative test (volumetric sensors)

If the test is negative, a single flash of the direction indicators and the two-colour surveillance LED (red) will indicate that the volumetric sensors are not active (possible break or lack of connection).

#### 2) Manual check

After waiting 2 seconds after the volumetric sensor tests, the efficiency of the connection lines and the status of the door, boot and bonnet switches may be checked.

#### a) Positive test (door, boot and bonnet switches)

Open and close in succession each door, the boot and the bonnet; one flash of the direction indicators will correspond to each opening and closure.

#### b) Negative test (door, boot and bonnet switches)

No flashing of the direction indicators will indicate that the door, boot and bonnet switch is faulty or is not connected electrically.

#### c) Positive test (ignition switch and siren)

The supply to the ignition switch terminal (+15) may be checked by turning the key to the ignition ON position; one flash of the direction indicators will indicate that the circuit under examination is working. A brief acoustic signal from the siren will indicate that it is working. This test must be carried out with the bonnet shut.

#### d) Negative test (ignition switch and siren)

No flashing will indicate that the circuit (+15) has no voltage and the lack of an acoustic signal will indicate that the siren is not working.

#### e) Positive test (transmitter, serial line, courtesy light and control unit)

This test must be carried out with the doors, boot and bonnet shut.

Direct one of the known remote controls towards the receiver dome, press the remote control button twice and at each press of the button one flash of the direction indicators will show that there are no communication problems between the courtesy light and anti-theft control unit.

- f) Negative test (transmitter, serial line, courtesy light and control unit)  
No flashing whenever the button is pressed indicates that there are communication problems between the courtesy light and anti-theft control unit.

**Exit from manual diagnosis**

To exit from MANUAL DIAGNOSIS, refrain from effecting any action on the system's sensor for 30 seconds, or press the bonnet button 7 times in succession. The exit will be indicated by the direction indicators coming on for about 3 seconds.

**NOTE** *It should be remembered that during service interventions on the car, or in the event of faults in the anti-theft system which activate the siren, the latter may be silenced by turning the key switch on the control unit from the ON position to the OFF position.*

**On completion of the intervention, always return the key to the ON position and reclose the protective cover on the control unit.**



*It should be borne in mind that each individual component of the anti-theft device installed in the car forms an integral part of the system and must not be fitted to or tested on other cars, even if of the same model.*

## 55.

### PROGRAMMING

The anti-theft device originally fitted requires programming since: coming out of production, the receiver contains a "UNIVERSAL" code which, controlled by a "UNIVERSAL" transmitter, allows the car to be tested and handled in the factory.

Before delivery, it is therefore necessary to programme the receiver with the code of the transmitter supplied with the car.


The anti-theft device's indication methods may vary depending on the current laws of the country where the car is registered, so it may be necessary to program the system by entering the country code.

There are two programming methods:

A - before entering the Password: **SIMPLIFIED PROGRAMMING**

B - after entering the Password: **PROTECTED PROGRAMMING**.

Every transmitter has a paper card with two codes: the 4-digit code and the **Password** for protecting against unauthorized programming (protected programming). The card must be removed by the Customer at the time of purchase and stored in a safe place.



P3U13AL01

1. Repeater LED
2. Button on transmitter
3. Infrared LED on transmitter
4. Plate with code with 6 groups of numbers and 4-digit password
5. Programming button on courtesy light
6. LED on courtesy light
7. Infrared receiver

#### A) Simplified programming

Simplified programming is used for a new memory which has not yet been closed and must accept the recognition of all the codes of the transmitters (remote controls) without limitation as to number.

Consequently there may be many recognized codes, but only the last four will remain in memory.

**The memorization of a transmitter must always be done with:**

- anti-theft control unit switched off with the remote control (dissuasion LED off)
- ignition key set to ignition OFF position
- emergency key on siren in the ON position.

#### Programming (memorization) of 1st transmitter

1. Press the programming button (5) present on the receiver; the receiver's LED (6) starts to FLASH, indicating "waiting to receive code".



*If the LED (6) remains off when the button is pressed, this means that:*

- the anti-theft device is ON. In this case it can only be switched off by means of the **UNIVERSAL REMOTE CONTROL**;
- the receiver is faulty or there is no supply.

2. Keep the receiver button (5) pressed, direct one of the remote controls supplied with the car towards the receiver's dome (7) (keeping it at a distance of at least 20 cm); press the remote control button (only once); the LED (6) on the courtesy light comes on permanently, indicating that the code has been memorized.



3. When the receiver button (5) is released, the LED (6) on the courtesy light goes out. Two possibilities are now available:
- Programme the anti-theft device for the operation required by the laws in the country where the car will be located (country code).
  - Do not change the operation programmed previously.

Code	Country	Code	Country
1	Italy	6	Holland
2	Germany *	7	U.S.A.
3	Switzerland	8	EEC (Europe)
4	Switzerland	9	Spare
5	United Kingdom	10	Spare

(\*) For this country, there is a specific control unit with an appropriate operating logic.

To programme the anti-theft device in accordance with point "a", within 3 seconds of the LED going out, press in succession the programming button (5) as many times as indicated in the table.



*At each press, the LED (6) will emit a flash.*

At the end of the simplified programming procedure, if the courtesy light LED (6):

- FLASHES 6 times, the code has been memorized correctly;
- FLASHES 18 times it means that the serial line between the receiver and anti-theft device is broken, or the anti-theft device's memory contains a previously-memorized code (lack of acceptance of new code). If an undesired code has been entered, repeat the entire procedure starting from point 1 of simplified programming.

**NOTE** *If the programming button on the courtesy light is not pressed, the EEC operating mode will be automatically recognized, if this operation is being carried out for the first time. If this operation has instead been carried out previously, the system sets itself in accordance with the mode already memorized.*

**NOTE** *To programme the country code, also use the procedure with the M40A module and the Fiat-Lancia Tester.*

#### PROGRAMMING FURTHER TRANSMITTERS (REMOTE CONTROLS)

To memorize further remote controls, repeat the simplified programming procedure from point 1. An unlimited number of remote controls can be memorized, but the courtesy light will only retain the last four in memory.




*The simplified programming procedure definitively deletes the universal codes present in the courtesy light and electronic control unit of the anti-theft device.*

#### B) Protected programming

To prevent outsiders entering their code, the memory must be protected (closed). This operation takes place:

- automatically after the anti-theft device has been switched on/off successfully;
- by an intentional action on the part of the user, by entering the password (four-digit code present on the transmitter card) before the 256 switch on/off actions, for example on the new car after all the codes of the remote controls supplied to the Customer have been entered.

## 55.



P3U15AL01

### Manual closure of memory (entry of password)

The method of entering the password is as follows:

1. Press the receiver button for about 2 seconds: the LED will flash for as long as the button is held pressed down.
2. Release the button: after about 2 seconds, the LED will emit a brief flash which indicates the possibility of entering the first digit of the password.
3. Immediately press the receiver's button as many times as the first digit of the password (e.g. 5 times); note that at each press, the LED comes on briefly to give visual confirmation.
4. About 2 seconds after the last press (in the example, the fifth press), the LED will emit another flash to request the entry of the next digit (2).
5. Immediately press the receiver button as many times as the second digit of the password (e.g. twice); note that at each press, the LED comes on briefly to give visual confirmation.
6. About 2 seconds after the last press (in the example, the second press), the LED will emit another flash to request the entry of the next digit (zero).
7. *When the password includes a "zero", do not press the receiver button, but wait for a new request to enter a digit, indicated by the next flash.*
8. After about 2 seconds the LED will emit another flash to request the entry of the last digit (3).
9. Immediately press the receiver button as many times as the fourth digit of the password (e.g. 3 times); note that at each press, the LED comes on briefly to give visual confirmation.

After entering the four digits of the password, the LED on the receiver may behave as follows:

- a) **it does not come on.** This indicates that the password has been entered correctly and that it belongs to one of the memorized remote control codes;
- b) **it comes on permanently.** This indicates that the password has not been entered correctly, or that it does not correspond to any of the memorized remote control codes. In this case, after the LED has gone out, the correct password should be entered starting from point 1.

When the password has been entered, the memory is closed.

**Programming of a transmitter (remote control) with memory closed**

1. Press the programming button on the receiver. The receiver's LED will start to flash, indicating "waiting to receive code".
2. The operator should hold the receiver button pressed down, and direct one of the new remote controls towards the receiver's dome (keeping it at a distance of at least 20 cm), then press the remote control button (once only).
3. After transmitting the new code, the LED on the courtesy light will stop flashing, indicating that the operation has failed.  
In this case, to enter the code of the new remote control, you will need to use code programming with manual access.

**Programming of a transmitter with manual access**

Once the memory is "closed", further remote control codes are entered by manually opening the memory. This opening must be carried out in accordance with the instructions given from point 1 to point 12, working in rapid sequence as described on the previous page, then proceed as described below.

After entering the four digits of the password, the LED on the receiver may behave as follows:

- a) **it starts to flash** if the password has been entered correctly (opening of memory);
  - b) **it comes on permanently** for several seconds, indicating that the password has not been entered correctly, or that it does not correspond to any code of the memorized remote controls. In this case, after the LED has gone out, the correct password will have to be entered, starting from point 1.
10. While the LED is flashing, press the button on the courtesy light; the LED will continue to flash.
  11. The operator, holding the receiver button pressed down, should direct the new remote control towards the receiver's dome (keeping it at a distance of at least 20 cm); then press the remote control's button (only once).  
The LED on the courtesy light comes on permanently, indicating that the code has been memorized.
  12. Release the button: the LED on the courtesy light GOES OUT.

At the end of the procedure, if the LED:


- FLASHES 6 times, the code has been memorized correctly;
- FLASHES 18 times, this means that the serial line between receiver and control unit is broken.



*After the new remote control's code has been entered, the memory automatically returns to the closed state. To enter a new remote control, repeat the procedure from point 1.*

# 55.

## WIRING DIAGRAM



P3U146L01

## Key


1. Battery
2. Positive node
3. Fuse unit
4. 60 A fuse
5. Volumetric sensors
6. Infrared remote control
7. Infrared receiver
8. Central door locking control unit
9. Switch on rear left door
10. Switch on rear right door
11. Switch on front right door
12. Switch on front left door
13. Anti-theft control unit
14. Switch on bonnet
15. Switch on boot
16. Direction indicators
17. Two-colour surveillance LED
18. Fuel injection control unit
19. Electronic key system
20. Diagnostic socket for fuel injection control unit
21. Diagnostic socket for Fiat-Lancia Tester
22. Fiat-Lancia Tester
23. Alarm siren
24. Ignition switch

## ANTI-THEFT DEVICE OPERATION: DOMESTIC REGULATIONS

Country mode	On/off		Alarm							Installation restrictions
	Vis. sig. from direct. ind.	Auditory	Auditory				Visual			
			Power	FREQIE	Tone	Max. duration	Type of lights	Type of signal	Max. duration	
Germany	PROHIBITED (W/light on vehicle ext. permitted)	PROHIBITED	115-118 dBA at 2 m	1800-3550 Hz	SINGLE intermittent 2,5 (+0,5-1,5)Hz	30 Sec	-Direct. indicators -Comp. lights	Flash-ing	5 mins	
France			< 100 dBA at 2 m	1800-3550 Hz	-SINGLE intermittent -MODULATED	30 Secs	-Direct. indicators -H/lamps	Flash-ing		
Switz.	ALLOWED				SINGLE continuous	30 Secs	Dipped head-lamps		5 mins	
Great Britain	ALLOWED	ALLOWED	> 90 dBA at 1 m	< 1500 Hz	-SINGLE intermittent -MODULATED	30 Secs	Front lights			
Belgium	ALLOWED		> 001 dBA at 1 m			30 Sec	-Direction indicators -H/lamps		30 secs	
Holland	COMPULSORY (int. or ext.)	PROHIBITED	> 118 dBA at 1 m	1800-3550 Hz	MODULATED	30 Secs	-Direction indicators -H/lamps		30 secs	Siren and control unit should be located in two separate modules. Control unit should be fitted in passenger comp.
Sweden	COMPULSORY (int. or ext.)				-SINGLE intermittent -MODULATED	30 Secs	-Direction indicators -H/lamps		5 mins	
Italy	ALLOWED						-Direct. ind. -Side lights	Flash-ing	5 mins	
European Regulations	ALLOWED	ALLOWED < 60 dBA	> 108 dBA at 1 m	1800-3550 Hz	-SINGLE -MODULATED	30 Secs	-Dir. ind. -Side lights	Flash-ing	5 mins	

#### AIR BAG SYSTEM WITH ELECTRICALLY OPERATED PRE-TENSIONERS


The Air-Bag system is a safety system which protects the driver and (if present) the passenger. When an impact of a certain degree of severity takes place, the electronic control unit detects it, via its sensors, and sends the order to the inflation system to intervene. Under these circumstances the bags inflate almost instantly and position themselves as a barrier between the bodies of the occupants of the front seats and the dashboard structure which could cause injury.



P3U01BL01


#### COMPOSITION OF THE SYSTEM

The Air Bag system is made up of: an electronic control unit, Air Bag modules - driver and passenger, Air Bag red warning light, diagnostic socket, pre-tensioner, control unit.



P3U02BL02

## CONTROL UNIT (5021)



1. Electronic control unit
2. Arrow indicating control unit fitting position
3. 10 pin connector
4. FIAT/LANCIA tester
5. Failure warning light
6. Driver's AIR-BAG module
7. Passenger AIR-BAG module
8. Passenger seat belt pre-tensioner
9. Driver's seat belt pre-tensioner

P3U03BL01

PIN No.	FUNCTION	PIN No.	FUNCTION
1	Pre-tensioner line (+)	6	Driver's Air Bag line (-)
2	Air Bag line (+)	7	Driver's pre-tensioner line (-)
3	Warning light (failure and diagnosis)	8	Earth line on tunnel
4	Serial line K for Fiat/Lancia tester	9	Positive controlled by ignition with fuse
5	Passenger Air Bag line (-)	10	Passenger pre-tensioner line (-)

The electronic control unit (1) is located in the central tray and is rigidly fixed to the floor. It is equipped with a 10 pin connector (3) with all pins connected to the electrical equipment. When the ignition is switched ON it receives a 12V supply, but it still operates for about 100 msec after the supply is cut off as a result of an impact. This is made possible due to the presence of a buffer condenser inside the circuits which accumulates electrical energy for the normal operation of the control unit and to produce the explosive capsule ignition signal. The operation of the Air Bag is thereby guaranteed even if the impact causes a drop in the system voltage (e.g.: battery damaged or broken, supply cables interrupted, etc.).

### 55.

The control unit should be positioned with the arrow (2) pointing in the direction of travel of the vehicle. This position should be **scrupulously adhered to** because it determines the direction in which the acceleration sensor reads the negative acceleration values to determine the impact condition and implement the operation of the Air Bag and pre-tensioners.

There is an accelerometric sensor inside the control unit which emits a signal which, when processed by a microprocessor, makes it possible to determine the severity of an impact and consequently decide whether to implement the operation of the pre-tensioners or the Air Bags.

A second sensor, with safety functions, gives the go ahead to activate the Air Bags.



*There are two different activation thresholds: one higher one for the Air Bags (which intervene together, driver's and passenger) and a lower one for the pre-tensioners for the right and left seats.*

#### Failure memory

Whilst the vehicle is driving the electronic control unit carries out a constant fault diagnosis of the system, thereby checking the continuity of the circuits and components.

If a fault is detected it is memorized and, at the same time, the "Air Bag failure" warning light in the instrument panel comes on.

The failure memory can be consulted in a service situation by connecting the FIAT/LANCIA TESTER or other diagnostic equipment to the diagnostic socket (see details below).

#### Impact memory


As stated previously, the control unit microprocessor carries out complex algorithm calculations and checks on the signal coming from the accelerometric sensor and recognizes the degree of severity of an impact. Depending on this degree of severity and, with the go ahead of the safety sensor, it sends an activation signal to the pre-tensioners and to the Air Bags.

This activation order is stored in a special impact memory which contains information relating to the exceeding of the intervention thresholds and the go ahead of the safety sensor.



**DRIVER'S AIR BAG MODULE**

The steering wheel has side controls (7) for the horns whilst there is a housing in the centre section for the module containing the folded bag (driver's Air Bag).



P3U09BL01

- |  |  |
|--|--|
| 1. Bag   | 9. Electronic control unit                         |
| 2. Cowling   | 10. Clock spring                                   |
| 3. Filter  | 11. Spacers  |
| 4. Chemical compound for the formation of the gas                | 12. Resistive bridge                               |
| 5. Detonator   | 13. Short circuit terminal with connector detached |
| 6. Metal support   | 14. Plate fixed to the detonator cable             |
| 7. Horn buttons  |  |
| 8. Steering column switch unit prepared for fitting clock spring |  |

The steering column switch unit (8) is prepared for housing the clock spring (10).


The module is fixed by two bolts to the steering wheel (at the rear) and is composed of an external metal support (6) connected to a polyurethane cowling (2) which has pre-pressed break lines on the exterior.

The container houses the suitably folded bag (1) and the inflation device. This device contains the detonator (5) which is electrically activated by the electronic control unit (9) when the resistive bridge (12) overheats. In addition there is a container full of tablets of a chemical compound (4) - sodium nitride - ready to produce the gas (nitrogen) during the explosion required to inflate the bag (1). A filter (3) regulates the pressure and the speed of the gases which are produced and, at the same time, absorbs the most solid residues of the chemical compound which is broken down during the explosion.

### 55.

As the neoprene bag unfolds it tears through the outer casing of the steering wheel along the special break lines and inflates producing a large ball with a volume 55 dm coming out of the centre of the steering wheel. The sides of the bag are perforated for the gradual, but extremely rapid deflation after intervention. An orange coloured plate (14) fixed to the detonator (5) supply cable reminds the operator, in four languages, that before fixing the clock spring they must position the front wheels of the vehicle aligned in a straight line.

#### Clock spring



P3U10BL01

A Steering column switch unit side

B Steering wheel side

1-2 Plates with warnings to be followed when installing the clock spring

3 Band joining clock spring cable upper and lower plates to prevent rotation; it should be removed when the device is fitted; it should be fitted when the device is removed for operations which do not involve its replacement.

The clock spring is a device which is fitted between the steering column switch unit and the steering wheel; it allows the connecting cable for the Air Bag module fitted on the steering wheel to follow the rotation of the latter without danger of breaking. The device comprises two plates: the lower one penetrates the steering column switch unit, whilst the upper one is fixed to the steering wheel by three bolts. Inside the two plates, the connecting cable for the module is wound round in a spiral thereby allowing it to follow the movements of the steering wheel.


The clock spring is fitted with a safety device which stops it rotating (plate 1) both when it is originally fitted and when it is ordered from the warehouse; this safety device should be removed during fitting. In the case of service operations, proceed as follows:

1. disconnect both battery terminals and wait at least 10 minutes;
2. align the front wheels with them in a straight position;
3. undo the two bolts at the back of the steering wheel frame which fix the Air Bag module, remove the electric socket and remove the module from its housing;
4. remove the steering wheel undoing the centre nut;
5. remove the connector for the clock spring, system side; if it is not being replaced, join the two plates using a band (as illustrated) before removing the clock spring from its housing;
6. to replace the clock spring, undo the three bolts fixing it to the steering wheel, recovering the three shims;
7. when the operation has been completed, refit the assembly remembering to remove the band.

**NOTE** When removing, the need to lock the upper and lower plates together using a band is to prevent them from rotating which would cause winding or unwinding resulting in the cable breaking once the clock spring were fitted between the steering wheel and the steering column switch unit.

If, for any reason, the upper clock spring plate should rotate in relation to the lower one so that the position during the removal is no longer known, **THE CLOCK SPRING MUST BE REPLACED.**

If the clock spring is being replaced, it is supplied separately from the steering column switch unit.

**PASSENGER AIR BAG MODULE**

P3U11BL01

The passenger Air Bag module is also enclosed in a container fixed to a mechanical frame. Its composition and operating principles (apart from its shape) are the same as those described for the driver's Air Bag module.

The intervention of the Bag is programmed by its own intervention threshold by the electronic control unit. On this module too, when the connector is disconnected, the two terminals short circuit automatically; a device with a spring incorporated in the actual connector joins the two terminals. This means that it cannot be activated through a direct supply.

**NOTE** *Air Bag modules should be replaced 10 years after they have been fitted which can be determined from the date on the label.*

**ELECTRICALLY OPERATED PYROTECHNIC PRE-TENSIONER**

Seat belt PRE-TENSIONERS are devices integrated in the reel which, in the case of a frontal impact, restore the inevitable extension of the belt due to the action of the weight of the body, keeping the latter against the seat backrest.

It is vital, in fact, for the belt to remain as close as possible to the body in order to gradually absorb the kinetic energy produced during an impact.


The reasons that a seat belt may, during an impact, no longer guarantee that the body is kept against the backrest, are mainly due to:

- delay in the intervention of the inertia locking device;
- stretching of the belt fibres;
- excess unwinding of the seat belt from the reel;
- thick clothing which creates a space between the belt and the chest.

From all of these causes it is easy to deduce that the belt can only be effective after the body has moved forwards a certain amount.

Pre-tensioners are fitted on both front seat belts; the latter should always be fastened when Air Bags are fitted as they are an integral part of their operation.

55.



P3U12BL01

1. Tape
2. Cylinder
3. Gas generator
4. Piston

5. Steel cable
6. Electrical connection
7. Seat belt rewinding coil

### Composition and operation


A pre-tensioner is a device integrated in the reel assembly which is activated by an electrical command from the electronic control unit when an impact of a certain degree of severity takes place.

The moment the necessary deceleration occurs, the control unit supplies the gas generator (3).

The pressure of the gas which is produced by the generator (3) applied to the surface of the piston (4), creates a force which pushes it upwards, into the cylinder (2).

The upwards linear movement of the piston (4), to which a steel cable (5) is fitted and which is fixed at one end to the coil flange, is transformed into a rotary movement of the actual coil, rewinding the tape by several centimetres. The inevitable extension of the belts is recovered in this way and the body of the occupant is kept against the seat backrest. Seat belt pre-tensioners are set to intervene at a lower level than Air Bags. Pre-tensioners cannot be overhauled or repaired therefore they must **ALWAYS BE REPLACED** after intervention; however, in spite of this, the pre-tensioners fitted on this model continue **TO OPERATE** after intervention **AS IF THE SEAT BELT WERE A REGULAR BELT**, i.e. the reel still allows the tape to unwind or wind.

## Fitting/dismantling seat belt with pre-tensioner



P3U13BL01

- |  |                                  |
|--|----------------------------------|
| 1. Electrically operated pre-tensioner | 6. Gas generator supply terminal |
| 2. Centre pillar                       | 7. Gas generator                 |
| 3. Fixing point on centre pillar       | 8. Reel mounting bracket element |
| 4. Fixing bolt                         | 9. Short circuit bridge          |
| 5. Supply connectors                   |                                  |

The reel with the integral pre-tensioner is fitted on the centre pillar, one on the driver's side and the other on the passenger side. When fitting, proceed as follows:

1. Fix the reel with the bolt (4) in the fitting position at the point (3) on the centre pillar. The bolt (4) should be fully tightened to a torque of 4 daNm.
2. Check that the element (8) on the reel mounting bracket is correctly positioned in the corresponding housing (3) in the pillar.
3. Connect the supply connector (5) coming from the electronic control unit in the housing (6) in the gas generator (7). Check that the connector is correctly attached.

To dismantle, proceed as follows:


1. Disconnect both battery terminals and wait at least 10 minutes.
2. Disconnect the supply connector (5) from the housing (6) in the gas generator (7).
3. Undo the bolt (4) and extract the reel from the centre pillar.



*For further information on dismantling-refitting the pre-tensioner, see Section 70 - Bodywork, page 24.*

**NOTE** *If the connector (5) is disconnected from the pre-tensioner (1) the two terminals will automatically short circuit; a device incorporating a spring connects the two terminals to each other for safety reasons (see detail A).*

### WARNING LIGHT SIGNALLING AIR BAG SYSTEM FAILURES




P3U14BL01

The 1W-12V Air Bag warning light (A) in the instrument panel (connector A, Pin 19) is supplied through the ignition when it is switched ON and is operated to earth through the electronic control unit (terminal 3). This warning light comes on for about 4 seconds when the engine is started up or when the ignition is switched ON.

The user should always check that the warning light has come on (test stage).

If the warning light does NOT come on or does NOT go out after the 4 seconds, this indicates a failure in the Air Bag system. If the electronic control unit detects a failure during the autodiagnostic checks (test) which it carries out to ascertain that the entire system is working properly, it immediately orders the Air Bag warning light to come on.

### WIRING DIAGRAM



P3U15BL01

- |                                 |   |
|---------------------------------|---|
| 1. Battery                      | 8. Earth connector on tunnel                  |
| 2. Connector block (+)          | 9. Clock spring                               |
| 3. Ignition switch              | 10. Driver's Air Bag module                   |
| 4. Air Bag warning light        | 11. Passenger Air Bag module                  |
| 5. 7.5A fuse in control unit    | 12. Passenger pre-tensioner (white connector) |
| 6. Diagnostic socket            | 13. Driver's pre-tensioner (red connector)    |
| 7. Electronic control unit 5021 |   |
| SU. Ultrasound welding          |   |

**NOTE** With the connector detached from the control unit, pins 1-2-5-6-7-10 are automatically connected to one another.

## Air-Bag


55.

- The electronic control unit (7) is supplied at terminal 9 from the battery voltage through the ignition switch (3), with the key in the services position (15/54). There is a 7.5A protective fuse (5) on the junction unit.
- The earth (8) is fixed by a bolt to the centre tunnel.
- If one or more failures are detected in the system, this is signalled by the electronic control unit (7) through the Air Bag warning light (4) in the dashboard coming on.
- The fault diagnosis of the system is carried out by connecting the Fiat-Lancia Tester (or SDC diagnostic station) to the socket (6). Alternatively, it is possible to use the blink code system using the actual Air Bag failure warning light (4), placing pin 1 (AB) for line L of the diagnostic socket (6) to earth for 1 - 5 seconds.
- All the terminals in this system are clamped and sealed.
- The wiring is special and there are 4 ultrasound welds (SU) inside. To make it more visible for whoever is carrying out service operations, this cable is protected by yellow tape which says Air Bag on it.

## PLATES

A series of adhesive labels located at various points on the vehicle remind the operator and the user of the main rules that must be followed.

**A. Sticker inside the oddments tray** in four languages: it advises consulting the owner's handbook and gives the expiry date before which it is necessary to have a Lancia Dealer check the efficiency of the device. **The device will work for a period of 10 years.** The sticker is perforated before it is fitted by the production month and for the 10 years after the production year (for example from 1994 to 2004). This is valid for both Air Bag modules and pre-tensioners.



P3U16BL01

Location on vehicle of plates containing instructions for using the device



- B. Plate in four languages** fixed on the detonator cable, warning the operator that before fixing the clock spring the front wheels of the vehicle should be in a straight position.
- C. Sticker on the front cross member:** warning the use and the operator that the vehicle is fitted with an Air Bag and recommending that the instruction booklet should be read.
- D. Sticket on the electronic control unit:** indicating to the operator that the control unit must be fitted in a longitudinal position in relation to the vehicle (in order to allow the accelerometers to detect the deceleration in the correct direction). It also contains a warning that only specialist and authorized personnel should work on the Air Bag system following the warnings in the Service Manual.
- E. Fitting and dismantling** should only be carried out by specialist workshop personnel. Before fitting or removing the steering wheel, it is necessary to ensure that the front wheels are straight. Remove the orange coloured connector from the Air Bag assembly and from under the steering lock-ignition switch cover.

### AUTODIAGNOSIS

The entire time the vehicle is driving, the electronic control unit carries out an autodiagnosis, checking the Air Bag system and memorizing any failures. The moment a fault is detected, as well as memorizing it, it orders the "Air Bag" warning light in the instrument panel to come on.

During starting, this warning light comes on for about 4 seconds (initial test stage) and then goes out.

If the warning light does NOT come on or does NOT go out after the 4 seconds have elapsed, this indicates a failure in the Air Bag system.

Activation of the system following a particularly severe impact is also memorized by the control unit.

### FAULT DIAGNOSIS

#### Fault diagnosis with the FIAT/LANCIA TESTER

It is possible to analyze the faults memorized in the control unit using the FIAT/LANCIA TESTER or other diagnostic equipment.

The faults memorized in the control unit can be cancelled, after the fault has been repaired, still using the FIAT/LANCIA TESTER or other diagnostic equipment.

**NOTE** *In the case of an impact which has caused the activation of the entire system (Air-Bag and pre-tensioners), the control unit memory cannot be cancelled and must therefore always be replaced. In addition, the warning light in the instrument panel remains on permanently.  
If, on the other hand, only the pre-tensioners are activated, the memory can be cancelled, twice. The control unit only has to be replaced in the case of a third activation.*



*During the fault diagnosis, if it is necessary to take continuity measurements on the module lines, the modules must be disconnected from the wiring and replaced with the appropriate simulation resistances.*

### 55.

**Alternative fault diagnosis with (Air Bag) warning light blink code only to be used if the FIAT/LANCIA TESTER is not available.**

It is possible to carry out a fault diagnosis on the control unit by interpreting the blink codes emitted by the Air Bag failure warning light located in the instrument panel (see wiring diagram).

#### Request for blink code

To activate the diagnostic system using the blink codes, the diagnostic socket (6) pin 1 (AB) cable for the serial line must be connected to earth for between 1 and 5 seconds. Pin 1 for the diagnostic socket is connected to terminal 3 of the control unit and the Air Bag system failure warning light is connected at the same terminal. The table shows the faults which can be detected and any remedies to adopt according to the number of flashes emitted by the warning light.

N° of Flashes	POSSIBLE FAILURE	REMEDIES
1	System all in order	
2	Control unit faulty	Replace control unit
3	Wiring for module priming circuits in contact with +12 V	Check the wiring
4	Wiring for module priming circuits in contact with earth (-)	Check the wiring
5	Driver's module priming device outside of tolerance	Check the wiring or replace driver's module
6	Passenger module priming device outside of tolerance	Check the wiring or replace passenger module
7	Supply voltage below 9.5V	Recharge or replace battery
8	Warning light circuit faulty	Replace warning light bulb - Check the wiring
9	Data memorized for impacts	Replace control unit
10	Wiring for seat belt pre-tensioner priming circuits in contact with +12 V	Check the wiring
11	Wiring for seat belt pre-tensioner priming circuits in contact with earth (-)	Check the wiring
12	Driver's seat belt pre-tensioner primer broken	Replace the pre-tensioner
13	Passenger seat belt pre-tensioner primer broken	Replace the pre-tensioner

If the warning light only comes on once when the request is made for the blink code, the Air Bag electrical system is "all in order".

If the memory contains various faults (e.g. 3), the control unit orders the warning light to come on with the code for the first fault memorized (e.g. 2); the next fault will be signalled when a new request is made, i.e. by placing the serial line L for the diagnostic socket to earth and so on for subsequent faults. If the codes memorized were 2, 4, 9 after signalling the last fault, if a new code is required the first fault, i.e. 2, will be signalled again.

### Cancelling fault codes

When the repairs have been completed the fault codes stored in the control unit memory can be cancelled. This is carried out by connecting pin 1 (AB) cable for serial line L of the diagnostic socket to earth once again for between 5 and 10 seconds. Only the last fault signalled can be cancelled. Therefore the operation has to be repeated as many times as the number of faults to be cancelled.

It is necessary to pay attention to the length of time the diagnostic socket is to earth (short circuited): if this period exceeds 10 seconds then the electronic control unit will ignore the order to cancel the faults. The memory cannot be zeroed until all the faults stored in the memory have been repaired.

**NOTE** *Fault number 2 is cancelled automatically if it is not detected within 10 seconds of the ignition key being inserted.*

*Fault number 9 (memorizing impact data) can only be cancelled using the Fiat-Lancia Tester.*

## SAFETY INSTRUCTIONS TO BE FOLLOWED WHEN WORKING ON VEHICLES EQUIPPED WITH AIR BAG SYSTEMS

### Operations on vehicle


Below are several rules which **MUST, UNDER ALL CIRCUMSTANCES, BE FOLLOWED** when carrying out any sort of operation involving vehicles equipped with Air Bags.

It should also be remembered that Air Bag modules are explosive devices. Their usage, transportation and storage are governed by the laws dealing with explosives in the countries where the vehicles are marketed. Before starting to carry out:

- bodywork repairs;
  - welding operations;
  - work which requires the removal of the Air Bag modules or the control unit.
- A. Always disconnect the battery, i.e.: **DISCONNECT BOTH LEADS (+) and (-) from the terminals AND INSULATE THEM THOROUGHLY.**
  - B. Disconnect the 10 pin connector for the control unit waiting at least 10 minutes after the battery has been disconnected.
  - C. When removing the inflation device for a bag, scrupulously observe the following procedure:

### 55.

1. Wait at least 10 minutes after having disconnected the battery before starting to remove the module.
2. Undo the fixing bolts.
3. Disconnect the socket for the bag inflation devices (modules).
4. Place the devices, with the cover facing upwards, in a lockable, metal cupboard. This cupboard should be designed exclusively for this purpose; it should not, under any circumstances, be used for storing other types of material, especially if they are inflammable. The cupboard should meet the requirements for housing pyrotechnic charges (metal, impact-resistant with vents to allow natural ventilation) and should have signs on the outside in accordance with the laws in force (DANGER EXPLOSIVES - NO NAKED FLAMES - TO BE OPENED BY AUTHORIZED PERSONNEL ONLY).



P3U22BL01

**NOTE** All the connectors used and wired for the Air Bag modules have a short circuit clip inside. Until the Air Bag modules are connected, via a suitable connector, to an appropriate energy source, there is no possibility of accidental activation.



A system component which is NOT activated in the case of an accident should still be considered as "active", therefore components which have not exploded because they are defective or have reached the end of their warranty or have to be replaced for other reasons, should be returned to the special centre following the procedure described below.



*The refitting and dismantling of the safety system components should ONLY be carried out by skilled, authorized personnel.*

*The failure to adhere to the instructions given below could involve the system being activated involuntarily resulting in unnecessary injury to persons or repairs to the system.*

**DISMANTLING AIR BAG MODULES INTO THEIR COMPONENTS IS STRICTLY FORBIDDEN.**

**NOTE** *All the system components have been specifically designed to work on a particular marque and type of vehicle, therefore modules and pre-tensioners cannot be adapted, reused or installed on other vehicles, but only on those for which they have been specially designed and produced.*

*Any attempt to reuse, adapt or install a system on a different type of vehicle can cause injury to the occupants of the vehicle in the case of an accident.*

### Replacing an Air Bag (because of defects or expiry of the warranty)

If an Air Bag module is being replaced because it is defective or because the warranty has expired, it is necessary to:

1. Remove the sticker from the new module, stick it in a special file (register) with the vehicle details (chassis no., registration date, model, etc.) and add the serial number of the old module. This file with the registration data should be kept for any future checks.
2. Before being stuck on top of the existing sticker, the new sticker should be perforated at the month and for the ten years following the year in which the module is fitted (e.g. from 1996 to 2006).
3. Connect the module to the appropriate connector coming out of the steering wheel.
4. Fit the Air Bag module in the special housing in the steering wheel checking that the connecting cable is correctly connected and tighten the bolts to the recommended torque.

### Replacing the control unit

The electronic control unit should ALWAYS be replaced in the case of an impact which completely activates the safety system (Air Bag modules + pre-tensioners).



*Do not, any circumstances, attempt to reuse the electronic control unit.*

If the control unit is being replaced, the sticker on the control unit must be removed and stuck in the special file following the procedure described above.

**NOTE** *After having carried out repairs to the system, check its operation using the FIAT/LANCIA TESTER.*

### Operations after an accident

If any of the safety system components are damaged following an accident, they **SHOULD BE** replaced. Do not attempt to repair the control unit, the clock spring or the Air Bag modules.

### Accidents where the Air Bag system is or is not activated

Several of the safety system components should be inspected if the system has been activated and if it has been partly activated or if it has not been activated at all.

These components are the:

- steering column;
- steering column supports;
- area where the electronic control unit and modules are secured;
- clock spring;
- dashboard (in the area of the passenger air bag module).

If the component is distorted, broken or bent it should be replaced.

### Accidents where the Air Bag system is activated

Several of the safety system components should be replaced if the vehicle suffers a frontal impact where the safety system is completely or partly activated.

If the system is partly activated (pre-tensioners only), these components are the:

- pre-tensioners;
- electronic control unit (it should only be replaced after the pre-tensioners have been activated for the third time).

If the safety system is completely activated, these components are the:

- Air Bag modules;
- pre-tensioners;
- electronic control unit.

As far as the wiring and the connectors are concerned, they should be inspected in order to identify any signs of burning, melting of the external insulation or damage due to excessive heat.

Any signs of damage to the clock spring or in the area where the electronic control unit and Air Bag modules are secured will involve the replacement of the damaged components.

### Painting operations

There are no particular safety regulations to be observed for painting operations and drying in the oven, given that the safety system (Air Bags and pre-tensioners) have been designed so that they are not damaged when the exterior of the vehicle gets hot in normal paint drying systems.



*The use of naked flames near modules is forbidden.*

*All electronic control units (including the one for the Air Bag system) should, however, always be removed in case the temperature in certain environments may reach or exceed 85°C).*

### Dangers to health

The precautions to be observed when handling activated Air Bag modules are listed below:

1. Wear protective gloves and safety goggles.
2. After having touched Air Bag units, wash your hands and exposed parts of the body with soap and water.

### Effects of over exposure

There is no potential danger in exposure to the propellants as the system is completely sealed.

The mixture of propellants is in a solid state, therefore inhalation is impossible even if the gas generator cartridge were to break.

If there is an escape of gas, this presents no danger to health (for humans).

Contact with skin should be avoided and do not ingest the propellant.



*In the case of:*


- *Contact with skin: wash immediately with soap and water.*
- *Contact with eyes: wash the eyes immediately with plenty of water for at least 15 minutes.*
- *Inhalation: move the patient immediately into the fresh air.*
- *Swallowing: make the person vomit if they are conscious.*

*It is always necessary to seek medical assistance.*

### SAFETY INSTRUCTIONS FOR HANDLING AIR BAG MODULES

Under normal circumstances, the driver's and passenger Air Bags are activated through the electronic command during impact. The gas which is produced in these conditions is mainly nitrogen which is not toxic. It is important that whoever carries out operations to devices fitted on the vehicle observes the safety instructions listed below.

Only suitably trained personnel should be allowed to work on devices.



P3U27BL01

- When removing and replacing open (exploded) Air Bags, only move one module at a time and wear protective gloves and goggles for the removal operations.

At the end of the operations, wash your hands thoroughly with neutral soap and, in the case of possible contact with residual powder from the device with eyes, rinse immediately with plenty of running water.

Once the Air Bag has exploded the metal components are very hot. Avoid touching them for several minutes (about 20) after the Air Bag has been activated.

**A** When removing and replacing UNEXPLODED Air Bags, always rest the Air Bag module with the opening flap and the pre-breakage splining facing upwards. Never place anything on top of this flap.

**B** Do not, under any circumstances, supply an Air Bag module with an electric current.



*The system components can only have continuity measurements taken after the modules have been replaced with simulation resistances.*

**C** Do not carry out repairs to Air Bag modules. All defective modules should be sent to the supplier.

**D** Never subject an Air Bag module to heat, for example through welding, percussion, drilling, mechanical machining, etc.

- Never install Air Bag units which have been dropped or which show signs of any sort of damage on vehicle.
- It is forbidden to store Air Bag modules together with inflammable or combustible materials.
- The gas generators should not come into contact with acid, grease or heavy metals: contact with these substances could cause the formation of poisonous or harmful gases or explosive compounds.
- Spare parts must be stored in the original packaging and their temporary storage must be in accordance with the same procedure as for an Air Bag module which has been removed from the vehicle and not activated, i.e. in a specially designed, lockable, metal cupboard (impact-resistant with special vents to allow natural ventilation). The cupboard should have special notices on the outside (DANGER EXPLOSIVES - NO NAKED FLAMES - TO BE OPENED BY AUTHORIZED PERSONNEL ONLY).
- It is forbidden, on all versions with Air Bags, to carry out repairs to the front seats, unless the system has been rendered inoperational previously by switching OFF the ignition, extracting the key, disconnecting and insulating the battery and then waiting for 10 minutes.
- If, on account of exceptional weather conditions (flooding, high tides, etc.), water and mud reaches such a height as to affect the device components, then it must be replaced.



### DISPOSING OF AIR BAG MODULES

Air Bag modules fitted in vehicles should NOT be scrapped with the actual vehicle, but removed previously. Air Bag units cannot be disposed of without being activated first.

If, during an accident, the Air Bag module is not activated, then the device must be considered as still charged. All unexploded material should be sent to GEMCA in Chivasso, stating the following on the accompanying docket:

“AIR BAG/PRE-TENSIONER CONTAINING PYROTECHNIC CHARGE TO BE DEACTIVATED”.

The devices must be sent to GEMCA in the same packaging as the spare parts are received in and, if this packaging is no longer available, it can be ordered from the Parts Warehouse in Volvera.

Obviously if AIR BAGS - PRE-TENSIONERS are being replaced, the original packaging should be kept intact for sending the device which has not been activated to GEMCA.

### Foreign markets

As far as foreign markets are concerned, check the laws in force and notify the network.



*Not complying with the procedures listed below can cause involuntary activation of Air Bag units and injury to persons. Air Bag units which have not been activated should NOT be disposed via the usual means. Air Bag units which have not been activated contain substances which are dangerous to health and can cause injury if the sealed container is damaged during disposal. The disposal of Air Bag units which is not carried out in accordance with these procedures, could be in violation of laws in force on the subject.*

### Ordering instructions

If necessary, the devices should be requested, from time to time, from the After Sales Parts Division-Volvera using the V.O.R. procedure only because the Network must not keep stocks of these components. In any case, as mentioned previously, a register is kept, for internal movements, recording the module identification numbers and details of the vehicle (chassis number, registration date, model, etc.).

**NOTE** For foreign markets the local laws must be checked and the network notified.

### SAFETY INSTRUCTIONS FOR HANDLING PRE-TENSIONERS

Pre-tensioners are pyrotechnic and therefore they must be correctly handled, moved and stored in order to avoid damage or injury.

In normal conditions, pre-tensioners are only activated through the action and electronic command during an impact. Small quantities of gas are produced which are mainly nitrogen which is not toxic.



*The following rules MUST be followed for the safety of operators and the condition of the seat belt with pre-tensioner units. Before any operation, switch the ignition OFF, extract the key, disconnect the battery and wait for 10 minutes before disconnecting the pre-tensioner connectors.*


A pre-tensioner which has not been activated in the case of an accident should still be considered “active”, therefore pre-tensioners which have not exploded because they are faulty, or whose warranty has expired or which have to be replaced for other reasons, should be returned (complete device) to the special centre, following the procedure described previously for Air Bag modules.



*If, as a result of exceptional weather conditions (flooding, high tides, etc.), water and mud reach such levels as to affect the device components, the unit must be replaced.*

*Pre-tensioners do not require any maintenance and should not, under any circumstances, be lubricated. Any modifications to the original state will adversely affect operation.*

55.



P3U28BL01

- A** Do not handle pre-tensioners by gripping the pipe.
- B** Do not handle pre-tensioners by gripping the belt.
- C** Do not tamper with pre-tensioners or carry out any repairs; all defective pre-tensioners should be returned to the supplier.
- D** Do not subject pre-tensioners to percussion, drilling, mechanical machining or heating through welding.

- E** Do not drop the unit or expose it to impacts; pre-tensioners which have been dropped from a height of more than 1 metre should not be used, but returned to the supplier.


When operations on the vehicle require the temporary removal of the unit, place it in a metal cupboard which meets the standards laid down by law for housing pyrotechnic charges (see description for Air Bag modules).

- F** Keep away from naked flames, fluids, solvents or lubricants and do not expose to temperatures in excess of 90° C.

At temperatures above 165° C, the gas generator may self-ignite.

If a device which has been activated has to be handled, wear protective goggles and gloves. If the device has been activated, ALWAYS wait for at least 20 minutes after activation before carrying out any sort of operation on it.

Wash your hands with soap and water after handling the device.




P3U28BL02

### Ordering instructions


Follow the same procedures already described for ordering Air Bag modules.

### Disposing of pre-tensioners


Follow the same procedures described for Air Bags.



P3U169L04



P3U169L05



P3U169L06

**REMOVING DRIVER'S AIR BAG****Safety measures**

Operations to the Air Bag system components should be carried out by suitably trained personnel, **SCRUPULOUSLY** following the safety measures listed below. Polythene gloves and protective goggles must be worn during removal and replacement operations.


Before proceeding with the removal of an Air-bag, disconnect the battery leads and wait at least 10 minutes.

Do not use naked flames near an Air Bag or the system components.

The individual system components should not be repaired in any way, but always replaced in one piece.


For more detailed information on the safety instructions, see page 161 onwards.

1. Undo the fixing bolt and remove the upper steering column cover.
2. Remove the lower steering column cover undoing the bolts shown.
3. Undo the bolts fixing the Air Bag module, suitably turning the steering wheel.
4. Lift up the Air Bag module rotating it slightly towards the right.



P3U169L07

55.



P3U169L08



1. Disconnect the connector for the supply cable from the Air Bag module.



After they have been removed, Air Bag modules which have not been activated should be immediately placed in a suitably marked, locked metal cupboard. Figure n° 2 illustrates the way the module should be positioned with the metal part resting on the surface.

**NOTE** To refit simply reverse the order of the operations carried out for the removal.



**DO NOT CONNECT THE BATTERY UNTIL IT IS CORRECTLY FITTED**


**NOTE** After the operation, check the operation of the system using the FIAT/LANCIA TESTER or other diagnostic equipment

### REMOVING-REFITTING CLOCK SPRING




Align the wheels in a straight position


3. Remove the shield for the nut fixing the steering wheel and the yellow plate containing the safety instructions.
4. Disconnect the connectors for the horns.




P3U169L09




P3U169L10




P3U169L11



P3U169L12




P3U169L13




P3U169L14

1. Undo the bolts shown fixing the clock spring to the steering wheel.
2. Undo the nut fixing the steering wheel.
3. Mark the position of the steering wheel hub in relation to the actual steering column.
4. Slightly detach the steering wheel from the steering column using tool 1847218000.
5. Remove the supply cables for the horns through the special slots in the steering wheel hub.




P3U169L15




P3U169L16

## Air bag


55.



P3U169L17



1. Remove the Air Bag supply cable, complete with plate, taking care not to damage it and then remove the steering wheel.
2. Disconnect the yellow electrical connector connecting the Air Bag control unit and the clock spring.
3. Working on the tab shown, release the yellow connector for the supply cable and extract the clock spring.
4. Prevent clock spring plates from rotating by fitting a band to maintain the initial reference position.



P3U169L18




*When refitting the clock spring the band preventing its rotation must be removed.*


To refit reverse the order of the operations carried out for the removal.




*After activation, the metal Air Bag components are very hot, avoid touching them for at least 20 minutes.*



P3U169L19



P3U169L20



P3U176L01



## REMOVING-REFITTING PASSENGER AIR BAG

### Safety measures

Only suitably trained personnel should carry out operations to the Air Bag system components, **SCRUPULOUSLY** following the safety measures listed below. Protective goggles and polythene gloves should be worn for the removal and replacement operations.

Before proceeding with the removal of the Air Bag, disconnect the battery leads and wait at least 10 minutes.

Do not use naked flames near the Air Bag and system components.


The individual system components should not be repaired in any way, but should be replaced in one piece.

For more detailed information on the safety instructions, see page 161 onwards.




### Removing-refitting


1. Open the glove compartment flap, then remove the courtesy light and the fixing cover.
2. Undo the bolts shown.
3. Carefully extract the Air Bag from its housing in the dashboard.
4. Remove the Air Bag from the dashboard, taking care not to damage the cable.



P3U176L02




P3U176L03



P3U176L04


55.



P3U176L05



1. Using a screwdriver, release the connector.



P3U176L06



2. Disconnect the connector, taking care not to damage the cable.


3. Remove the device and position it as illustrated below.



*After Air Bags which have not been activated are removed, they should be placed immediately in a suitably marked cupboard which should then be locked.*

*The diagram shows how to position the device with the metal section resting on the surface.*

**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*



P3U22BL01



**NON COLLEGARE LA BATTERIA SE NON DOPO AVER COMPLETATO CORRETTAMENTE IL MONTAGGIO**

**NOTA** *Dopo l'intervento verificare la funzionalità del sistema tramite FIAT/LANCIA TESTER o altri strumenti diagnostici*



**NEW AIR BAG SYSTEM**


The entire LANCIA k range has new Air Bag system fitted which differs from the previous version in the following ways:

The electronic control unit connector (1) has 30 pins, 13 of which are used for the electronic connection. The connection between the wiring and the Air Bag control unit is ensured by a mechanical closure which is in the correct position when the wiring is reconnected with the control unit.


The Air Bag warning light, in the instrument panel, is supplied when the ignition is switched ON and is placed to earth via terminal 13 of the electronic control unit.

The CLOCK SPRING comprises two plates: the upper plate is fixed to the steering wheel by three bolts, whilst the lower plate is secured to the steering column switch unit by a special turret.

The system fault diagnosis cannot be carried out using the blink code (see page 160).



P3U176L07




P3U176L08

- 78. Instrument panel with AIR BAG failure warning light
- 135. AIR BAG system earth
- 272. Passenger AIR BAG module
- 273. Driver's AIR BAG module
- 273A. Connector for CLOCK SPRING
- 274. Connector connecting AIR BAG system to dashboard cable loom, located under the dashboard, to the left of the heater unit
- 275. AIR BAG electronic control unit
- 276. Driver's pre-tensioner
- 277. Passenger side pre-tensioner
- 278. Diagnostic socket for FIAT-LANCIA TESTER

Pin	Description	Colour
1	Driver's Air Bag (-)	Z
2	Driver's Air Bag (+)	A
3	Passenger Air Bag (-)	Z
4	Passenger Air Bag (+)	B
6	Passenger pre-tensioner (+)	C
7	Passenger pre-tensioner (-)	M
8	Earth for FIAT-LANCIA TESTER	N
9	Serial line (k) for FIAT-LANCIA TESTER	BR
10	Driver's pre-tensioner (+)	L
11	Driver's pre-tensioner (-)	M
13	Failure warning light	AB
14	System earth	NZ
15	Starting	R

## LOCATION OF CONTROL UNITS, RELAYS AND FUSES ON VEHICLE




P3U97CL01

- |  |   |
|--|---|
| 1. Electronic fuel injection control unit        | 12. I.G.E. control unit   |
| 2. Infocenter                                    | 13. Air Bag control unit  |
| 3. Central door locking control unit             | 14. Plug preheating control unit  |
| 4. Sunroof control unit                          | 15. Peripheral control unit   |
| 5. Rear relay and fuse unit:                     | 16. ABS control unit  |
| - rear bonnet relay;                             | 17. Front electric windows control unit                                   |
| - fuel flap relay;                               | 18. Courtesy light delay control unit                                     |
| - heated rear window relay;                      | 19. Anti-theft control unit   |
| - left seat heating pad relay;                   | 20. Relay and fuse unit in engine compartment:                            |
| - right seat heating pad relay;                  | - timing variator relay;  |
| - boot fuse (25A);                               | - fuel injector control relay;  |
| - fuel flap fuse (25A);                          | - flow meter relay;   |
| - heated rear window relay (30A);                | - fuel pump relay;  |
| - rear electric windows control unit fuse (25A); | - modular manifold relay;   |
| - left seat heating pad fuse (7.5A);             | - electronic fuel injection control unit fuse (7.5A);                     |
| - right seat heating pad fuse (7.5A);            | - fuse protecting supply to electronic fuel injection control unit (30A); |
| - front right seat electric motors fuse (30A);   | - Lambda probe fuse (10A);  |
| - front left seat electric motors fuse (30A).    | - ABS fuse (10A);   |
| 6. Rear electric windows control unit            | - fuse protecting I.G.E. and connection unit (60A);                       |
| 7. Servotronic control unit                      | - fuse protecting supply cable (80A);                                     |
| 8. Suspension control unit                       | - fuse protecting anti-theft device (30A).                                |
| 9. Electronic key system control unit            | 21. Automatic transmission control unit                                   |
| 10. Left seat memory control unit                |   |
| 11. Fuse and relay unit on dashboard             |   |

### 55.

#### LOCATION OF DIAGNOSTIC SOCKETS IN VEHICLE



P3U98CL01

1. Diagnostic socket in engine compartment for ABS
2. Diagnostic socket, passenger side, for automatic transmission
3. Diagnostic socket on console under dashboard for Air Bag
4. Diagnostic socket on console under dash. for:
  - I.G.E. control unit;
  - Infocenter;
  - instrument panel;
  - anti-theft control unit;
  - electronic key system control unit;
  - electronic fuel injection control unit.
5. Rear right diagnostic socket for:
  - controlled suspension control unit;
  - Servotronic control unit

**RADIOFREQUENCY ALARM**

- Alarm system (TRW-SIPEA)	1
- Alarm control unit	1
- Output and input signals to and from alarm control unit	2
- Location of components	3
- Alarm siren	4
- Remote key	4
- Receiver	4
- Volumetric sensors	5
- Key	5
- Switches on doors, bonnet and boot	6
- Two-coloured indicator led (green-red)	6
- Operation of alarm system	7
- Automatic diagnosis	9
- Testing using instruments and controls	10
- Programming	13
- Manual closure of memory (password entry)	15
- Wiring diagram	17



## **COPYRIGHT FIAT AUTO**

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A.  
D.M.C. - M.P.S.  
Servizi Post Vendita - Assistenza Tecnica  
10040 Volvera - TO - (Italia) - Largo Senatore G. Agnelli, 5  
Publication no. 506.475/14 - Giugno 1996 - 400  
Printed in Italy - Tip. Sosso - Grugliasco - Torino  
order no. 60444399

## **ALARM SYSTEM (TRW-SIPEA)**

### **Introduction**

The vehicle may optionally be equipped with an alarm system combined with the remote control central locking.

The TRW system offers volumetric and perimetral protection. It is able to monitor the status of the doors and detect a moving object inside the passenger compartment.

The system is universal because the alarm sound level and turn signal flashing mode can be altered to meet requirements in different countries. A sophisticated self-diagnostic system is also able to test for:

- intermittent or permanent errors or faults;
- specific control unit faults;
- number of times alarm activated and alarms carried out.


The system consists essentially of a radio receiver on the courtesy light, a radio transmitter (or remote control) in the key, three volumetric sensors built into a plate fitted to the roof panel before the courtesy light, six switches (door, boot and bonnet lid), an electronic control unit (red) located beneath the central console area of the facia immediately above the air bag control unit, an alarm siren located in the right hand side of the boot fitted with an emergency switch with ON-OFF key control.

### **ALARM CONTROL UNIT**

This is the main system unit. It monitors and processes the status of the following sensors:

1. boot switch;
2. bonnet lid switch;
3. door status supplied by door open indicator switches or check control;
5. volumetric sensor alarm;
6. ignition key insertion.

The control unit is fitted with two plug connectors A and B (17 and 13-way respectively). These are connected to two sockets (forming part of the 14 and 11-way wiring).



**Alarm control unit - view of top side**


**Alarm control unit - view of connector side**

**55.****OUTPUT AND INPUT SIGNALS TO AND FROM ALARM CONTROL UNIT**

<b>PIN</b>	<b>I/O</b>	<b>FUNCTION</b>
B1	OUT	EARTH IN CONTROL UNIT
B2	I/O	COMMAND FOR TWO-COLOURED FLASHING LED ON FACIA
B3	OUT	LEFT TURN SIGNAL NA RELAY CONTACT
B4	N.C.	N.C.
B5	N.C.	N.C.
B6	IN	ELECTRONIC KEY SYSTEM
B7	IN	DIRECT POWER SUPPLY POSITIVE (+30)
B8	I/O	K LINE FIAT/LANCIA TESTER
B9	IN	CONTROL UNIT EARTH
B10	IN	DIRECT POWER SUPPLY POSITIVE (+30) FOR TURN SIGNALS
B11	OUT	NA RELAY CONTACT CONTROLLING RIGHT TURN SIGNALS
B12	IN	KEY-OPERATED POSITIVE (+15)
B13	I/O	COMMAND FOR TWO-COLOURED FLASHING LED ON FACIA
A1	OUT	FIAT/LANCIA TESTER LINE (-) EARTH IN CONTROL UNIT
A2	IN	DE-ACTIVATION LINE FROM REMOTE KEY
A3	N.C.	N.C.
A4	IN	BRIDGE TO EARTH ON B1
A5	IN	RIGHT REAR DOOR OPEN RECORDING SWITCH
A6	IN	RIGHT FRONT DOOR OPEN RECORDING SWITCH
A7	IN	LEFT FRONT DOOR OPEN RECORDING SWITCH
A8	I/O	SIREN ACTIVATION LINE
A9	I/O	SERIAL LINE FROM COURTESY LIGHT
A10	I/O	SIGNAL LINE FROM VOLUMETRIC SENSORS
A11	OUT	VOLUMETRIC SENSOR UNIT ACTIVATION POSITIVE
A12	N.C.	N.C.
A13	N.C.	N.C.
A14	N.C.	N.C.
A15	IN	LEFT REAR DOOR OPEN RECORDING SWITCH
A16	IN	BOOT OPENING RECORDING SWITCH
A17	IN	BONNET LID OPEN RECORDING SWITCH



**LOCATION OF COMPONENTS**




P3U03HL01

**Key**

- |   |  |
|---|--|
| 1. Alarm control unit (red) below fascia in central console, passenger side | 8. Boot open indicator switch                          |
| 2. Radio receiver on courtesy light   | 9. Left front door open indicator switch               |
| 3. Support with volumetric sensors  | 10. Left rear door open indicator switch               |
| 4. Warning light (two-colour led) indicating alarm activated                | 11. Self-activated alarm siren (on right side of boot) |
| 5. Radio-controlled remote control  | 12. Bonnet lid open indicator switch                   |
| 6. Right front door open indicator switch                                   | 13. Bonnet lid vertical adjustment device              |
| 7. Right rear door open indicator switch                                    |  |

**NOTE** When doors, boot and bonnet are closed, switches 6-7-8-9-10-12 are electrically open (i.e. not connected to earth).

**55.**



P3U04AL01

### ALARM SIREN

- K. Ignition switch  
A. Connector

### Technical characteristics

Power supply	10.5 - 15 Vdc
Uptake at rest	2 mA
Uptake during operation	2A
Frequency	1700 - 2300 Hz
Acoustic pressure	118 dB at 1 metre
Dimensions	112 x 98 x 82 (mm)

The siren is housed in a compartment between the steel wall and the cloth cover at the right hand side of the boot.

It is self-activated and therefore able to work even if the vehicle battery is disconnected or if the connection leads are cut.

The power supply is provided by batteries fitted directly in the siren case.

The case is fitted with a connector (A) with five leads, which are connected to the following:


- A - positive +12 V directly from battery (+30) (lead R)
- B - general earth (lead N)
- C - siren activation/de-activation signal from alarm unit (lead A)
- D - positive +12V from ignition switch (+15/54) (lead M)
- E - manual siren disablement signal (lead B)

### REMOTE KEY

The siren is also equipped with a selector key (K) which can be used to shut it off if it is activated as a result of a fault in the system.

**De-activation:** the alarm system is de-activated when the key is turned to OFF

**Activation:** the alarm system is activated when the key is turned to ON



P3U04HL02

### RECEIVER

- 1. Light emitting diode (led)
- 2. Programming button
- 3. Radio receiver seat
- 4. Volumetric sensors
- B. Connector B (courtesy light)
- C. Connector C (volumetric sensors)

The **receiver**, built into the front courtesy light is an electronic device which receives a control signal. It is responsible for door opening/closure and for activating the alarm control unit. Each receiver may be programmed for one or more transmitters (up to a maximum of 8) and is able to store the relative codes. A green led (1) on the receiver comes on when the signal is received. Button (2) allows a secret code to be stored.

When they are fitted in the vehicle, the receivers contain a UNIVERSAL code which is used to carry out tests on cars when they come off the production line using a transmitter with the universal code.

When the vehicle is delivered to the customer, the receiver must be personalised by replacing the UNIVERSAL code with the code for the transmitters supplied with the car.

*Courtesy light connector B*

- |  |                                   |
|--|-----------------------------------|
| 1. Flash (for vehicles without alarms and provision for blinker) | 5. Door release                   |
| 2. Serial line to alarm control unit                             | 6. Door lock                      |
| 3. 12V battery positive (+30)                                    | 7. Key-operated positive (+15/54) |
| 4. Courtesy light earth  | 8-12. N.C.                        |

**VOLUMETRIC SENSORS**

The volumetric sensors are used for additional surveillance: they ensure no intruders have entered the car. They are fitted in a plastic caes located behind the front courtesy light. Two work as a transmitter and one as a receiver. The ultrasound wave beam emitted by the transmitters (left hand transmitter and unit facing the facia) must be received by the third (on the right) after being reflected off the interior walls of the vehicle.

When the vehicle does not contain moving objects, the ultrasound signal reaches the receiver at the same frequency with which it was transmitted. Otherwise, a signal designed to activate the siren is sent to the alarm control unit.


*Volumetric sensor connector C*

1. Earth
2. Positive from alarm control unit pin A11
3. Signal line from volumetric sensors

**KEY**

The keys provided with the vehicle perform the following functions:

- A) Mechanical function  
Lock-release of all locks, steering lock and engine start-up.
- B) Electronic key system function  
A device known as a TRANSPONDER (electronic key) is protected by the rubber grip of the ignition key. This contains a code which is transmitted (when the key is in the ignition) to the electronic code system control unit to release the injection-ignition system.
- C) Function of sending unit (or radio-controlled remote control)



1. Control button
2. Flashing led
3. Password card
4. Transponder

The **sending unit**, protected by a rubber case, consists of a printed circuit and a radio emitter. It is powered by a battery (2 3V lithium batteries). Whenever the control button (1) is pressed, the transmitter sends out a radio signal.

P3U05HL01

### 55.

This radio-operated device emits a continuous code: maximum duration is 8 seconds even if the button is held down for longer. At the same time, flashing led (2) comes on each time a signal is emitted to provide visual evidence that the transmitter is sending out a code.

The secret code consists of a fixed part and variable part, which changes upon each transmission to prevent the code being broken by unauthorised people. The fixed part is associated with a password, which consists of 4 numbers printed on a label provided with the key itself.




*If this transmitter is replaced, or an additional transmitter is used, it must be stored by means of the same system used for the alarm and the electronic code system.*

**NOTE** *The remote control is radio-operated and provides more effective protection against attempts to break the secret code. Its radius of action is about 10 m when the batteries are properly charged.*

### SWITCHES ON DOORS, BONNET AND BOOT

Door and boot open indicator circuit switches are used to monitor the doors, boot and bonnet. The bonnet lid is fitted with a special switch. All switches indicate failure to close by sending an earth signal to the control unit (doors, boot and bonnet open = switches open)

### TWO-COLOUR INDICATOR LED (GREEN-RED)



P3U06AL01

1. Alarm control unit
2. Electronic key system
3. Two-colour led on instrument facia

The indicator led (3) on the instrument facia is a semi-conductor display device. It consists of a light-emitting diode which emits a visible light beam: the colour of the light depends on the type of semi-conductor material used.

In order for the led to emit light, it must be supplied (polarised) with an appropriate voltage between 3 and 2.5 Volt. If the led is two-coloured, it is made up of two diodes connected in parallel in the same container.

**Green led flashing: electronic code system operational**

When the key is in the ignition and the alarm is off, the green led flashes because the alarm control unit microprocessor blocks transistor T2 and keeps transistor T1 polarised; this allows the green led to earth through the electronic code system. The green led indicates that the injection control unit is locked.


**Red led flashing: alarm system operational**

The green light turns red when the alarm is turned on by means of the remote control. Under these conditions, the microprocesor locks transistor T1 and polarises transistor T2 to allow the red light to earth itself through T2.

When the alarm is turned off using the remote control, the red led goes off and the green led begins to flash again.

**OPERATION OF ALARM SYSTEM**

The alarm system may only be turned on when the key is turned to STOP.



P3U07HL01

**Activation**

Press the transmitter button. The radio receiver sends a control to the electronic control unit in order to lock the doors and simultaneously sends out a second signal to the alarm system electronic unit. Activation of the alarm system is indicated visually and acoustically (for markets where this is permitted). When the alarm system is active, the two-coloured led in the middle of the instrument facia comes on and flashes red.

**De-activation**

Press the transmitter button. The radio receiver send controls to the control unit to release the doors and de-activate the alarm. De-activation is also indicated visually and acoustically (for markets where this is permitted). When the alarm system is off, the two-coloured led changes to green (electronic code system operational = injection locked).

**NOTE** *The system is protected against illicit recording of the secret code.*

**System by-pass**

When the transmitter batteries are flat or the alarm system is faulty, the siren may be de-activated by turning a remote key located on the siren to OFF. When the remote key is turned to OFF, the siren goes off, **but the alarm system remains active and must be de-activated by means of the remote control unit.**

During long periods of unuse (more than one month), turn the key to OFF and disconnect the battery negative lead. When the key is turned to OFF, lead cutting can no longer be monitored (i.e. battery disconnection).

### 55.

#### Surveillance mode (alarm system on)

During surveillance (vehicle closed and alarm system activated), the dissuasion led flashes at a rate of 0.8 Hz. In this status, the alarm system monitors:

- a) doors, bonnet lid and boot lid
- b) battery disconnection/leads cut
- c) unauthorised activation of the ignition switch
- d) movements inside the passenger compartment (volumetric surveillance)
- e) remote key leads cut
- f) if the battery loses more than 1 volt/hour (e.g. a short circuit).

#### Alarm mode

The system enters alarm mode when:

- 1. One of the doors, the bonnet lid or the boot lid is opened.
- 2. The battery is disconnected or the alarm supply leads are cut; if the battery loses more than 1 Volt/hour (e.g. short-circuit).
- 3. The ignition key is turned to MARCIA.
- 4. Something invades the passenger compartment space (e.g. even if a window is lowered and someone puts in a hand).

An alarm status is indicated by activation of the siren and turn signals. Timing rates vary from market to market. The injection-ignition system is locked by the electronic code system.

If the alarm status ceases (e.g. if the door is closed again or the hand stops moving about inside the vehicle), the siren and the emergency lights go off). The system returns to surveillance mode when the system cycle is over.

Alarm mode is exited:

- a) by de-activating the transmitter (remote control);
- b) 25 seconds after the last alarm mode activation;
- c) by means of the emergency key (remote) on the siren.

**NOTE** *The alarm stays on in conditions (b-c).*

#### Turning off volumetric surveillance

Volumetric surveillance may be turned off by carrying out one of the following procedures:

- a) Turn off the engine (the alarm is not yet activated). Beginning with the key on MARCIA, turn it in quick succession to STOP-MARCIA-STOP. Confirmation that volumetric surveillance has been turned off is provided by the two-coloured dissuasion led coming on (red light) for about 2 seconds and the buzzer on the volumetric sensor courtesy light coming on for 2 seconds.
- b) Beginning with the ignition key turned to MAR, press the small button on the receiver (for less than 0.5 seconds) and then move the ignition key to STOP within 8 seconds. In this case too, confirmation that volumetric surveillance has been turned off is provided by a led on the courtesy light coming on.

#### Re-activating volumetric surveillance

Volumetric surveillance is re-activated automatically. This occurs when the ignition key is turned to MAR again.

**NOTE** *The key may be turned to MARCIA (with alarm system off) for up to 30 sec. without re-enabling volumetric surveillance (this may be useful, for example, when closing windows which have been left open).*

## **AUTOMATIC DIAGNOSIS**

### **Turning on the alarm system**

When activated, the alarm system runs a self-diagnostic test to check that the alarm is working properly. If a fault is present, the two-coloured led (red light) in the middle of the instrument facia provides an indication as shown in the following table.

### **Automatic test display**

<b>FLASHING MODE</b>	<b>MEANING</b>
15 Hz, duration 3 sec.	Door/bonnet/boot left open or switch faulty
Constant light, duration 3 sec.	Volumetric sensors faulty

If a door, the bonnet or boot is found open or a fault is detected in the volumetric sensor, the relevant sensor is excluded from surveillance and a beep is issued one second following activation

### **Turning off the alarm system**

At the moment of de-activation, the system causes the two-coloured LED (red light) to flash to indicate which sensor triggered an alarm during surveillance. Flashing modes are shown in the following table.

**NOTE** *The signals are cancelled when the key is turned to MARCIA.*

<b>N° PULSES</b>	<b>MEANING</b>
1st PULSE	RIGHT FRONT DOOR
2nd PULSE	LEFT FRONT DOOR
3rd PULSE	RIGHT REAR DOOR
4th PULSE	LEFT REAR DOOR
5th PULSE	SUPPLEMENTARY SENSORS - COURTESY LIGHT SENSORS
6th PULSE	BONNET LID
7th PULSE	BOOT
8th PULSE	+15 INTERRUPT KEY-ACTIVATED POWER SUPPLY
9th PULSE	+30 INTERRUPT BATTERY POWER SUPPLY
10th PULSE	AT LEAST 3 SIMULTANEOUS ALARM CAUSES

Where more than one alarm code is present, the codes are shown in sequence.

### 55.

#### TESTING WITH INSTRUMENTS

The system is equipped with a tester socket for a SDC Test Station or a FIAT-LANCIA Tester. The alarm control unit allows the system to enter test mode with the ignition key turned to STOP, after at least 5 seconds or with the key turned to MARCIA but with the alarm system de-activated.

#### Fault diagnosis using a Fiat-Lancia Tester (MODULE M40A)

The FIAT-LANCIA Tester can be used to download data, i.e. transfer the contents of the alarm control unit memory.

To use the FIAT-LANCIA Tester on the alarm system, it is necessary to connect adaptor ADT101A. Proceed as follows to connect:

1. Activate the FIAT-LANCIA Tester through the cigar lighter or connect it directly to the battery (a special cable is provided for this option).
2. Connect the Tester to the tester socket (check that the control unit is enabled by the remote key. Otherwise communication cannot be established with the FIAT-LANCIA Tester).

When the FIAT-LANCIA Tester is activated, diagnosis can be in one of three different modes: 1) AUTOMATICALLY; 2) ENTER ISO COD; 3) SKIP ISO COD.

#### Searching for errors in the memory

When one of the three procedures is carried out, the control unit begins to transmit data on the errors present to the FIAT-LANCIA Tester. If errors are present, press the OK key to move on to search for the cause of the fault. The test is guided by the FIAT-LANCIA Tester (GUIDED TESTING).

After repairing the fault automatically, the FIAT-LANCIA Tester delete the errors in its memory before activating and de-activating the alarm in order to see whether the fault has been eliminated.

The error may be suspended by pressing the OXK key. The error may be stored by the FIAT-LANCIA Tester and then viewed by pressing the FC key and selecting SUSPENDED ERRORS.

#### Error status of perimeter protection switches

The FIAT-LANCIA Tester reveals whether switch status has changed (earthed-interrupted) when doors, boot and bonnet are opened and closed. It indicates whether the ignition key is turned to MARCIA or STOP..

#### Programming the country code

The FIAT-LANCIA Tester can be used to enter the code of the country where the vehicle is to be sold; simply press the OXK key during ACTIVE TESTING - the country codes are:

Italy 1 - Germany 2 - France 3 - Switzerland 4 - United Kingdom 5 - Holland 6 - USA 7 - EC 8 - 9 and 10 are free.

#### Alarm counter

If a theft attempt has taken place, it is possible to find out which protection intervened and how many times this happened. The alarm counter indicates how many times the key was inserted; how many times each individual door, boot or bonnet has been touched; how many times the volumetric sensors have been activated or whether any supply leads have been disconnected or cut.

#### Guided testing

If a defect is detected, the FIAT-LANCIA Tester will emit an acoustic signal and the display will indicate the defective channel (e.g. error in warning light bulb).


When the OK key is pressed, a check will be run on the defective channel to indicate the probable causes of the defect. The operator will then check that the component is working properly and either repair or replace any defective parts.

In order to check that the defect has been repaired, the program will automatically delete the errors or ask the operator to carry out a series of operations such as alarm activation and de-activation. If the repair has been successful, the next error will be displayed (if present). Otherwise, it will re-enter data reading mode (perimeter protection switch mode).



When the errors are deleted, the alarm counters are also cancelled.

**NOTE** Always follow all FIAT-LANCIA Tester instructions to the full.



### Manual fault diagnosis

It is possible to carry out MANUAL FAULT DIAGNOSIS; to enter this mode, turn the ignition key to STOP for at least 5 seconds and ensure the siren remote key is turned to ON. The alarm control unit runs two types of checks, one automatic and one manual.

#### 1) Automatic check

Press bonnet lid protection button (A) 7 times in rapid succession within no more than 8-10 seconds. Under these conditions, the volumetric sensors connected to the control unit are automatically self-tested.

- a) **Positive test** (volumetric sensors)  
If the test outcome is positive, the turn signals will flash three times and the two-coloured surveillance led (red light) on the instrument facia will flash three times, while the buzzer in the volumetric sensor carrier mount will go off for 2 seconds.
- b) **Negative test** (volumetric sensors)  
If the test is negative the turn signals and two-coloured surveillance led (red light) will flash once only to indicate that the volumetric sensors are not active (possibility of break or poor connection).

#### 2) Manual testing

Wait about 2 seconds after testing the volumetric sensors in order to check the efficiency of the connection lines and the status of door, boot and bonnet switches.

- a) **Positive test** (door, boot and bonnet lid switches)  
Open and close each individual door, the boot and the bonnet in succession. The turn signals will flash upon each opening or closure.
- b) **Negative test** (door, boot and bonnet lid switches)  
When the turn signals fail to flash, this means that the door, boot and bonnet switch is faulty or not connected electrically.
- c) **Positive test** (ignition switch and siren)  
It is possible to check the efficiency of power supply (+15) to the ignition switch by turning the key to MARCIA; the turn signals flash once to indicate that the circuit under examination is efficient. Efficient operation is indicated by the siren going off for a short time. This test must be carried out with the bonnet lid closed.
- d) **Negative test** (ignition switch and siren)  
Failure to flash indicates that the circuit (+15) is not activated and failure of the siren to go off indicates that the siren is not working properly.
- e) **Positive test** (transmitter, serial line, courtesy light and control unit)  
This test must be carried out with doors, boot and bonnet lid closed.  
Press the remote control unit button twice: each time the button is pressed, the turn signals will flash to indicate that communication between the courtesy light and alarm control unit is efficient.

### 55.

- f) **Negative test** (transmitter, serial line, courtesy light and control unit)  
Failure to flash each time the button is pressed indicates that communication between the courtesy light and alarm control unit is inefficient

#### Exit from manual fault diagnosis

Leave MANUAL FAULT DIAGNOSIS mode by not activating any system sensors for 30 seconds or by pressing the bonnet lid button 7 times in sequence. The turn signals will come on for about 3 seconds to indicate that exit has taken place.

**NOTE** *During service operations on the vehicle or in the case of alarm system faults which cause the siren to go off, the siren may be turned off by turning the key switch on the control unit from ON to OFF.*

**Once the operation is over, always turn the key switch to ON and always seal the protective plug on the control unit.**



*Note that each individual alarm system component on the vehicle is an integral part of the system and cannot be fitted or tested on other vehicles, even if the model is the same.*

## PROGRAMMING

The alarm signal fitted originally requires programming because:

when the car leaves the production line, the receiver contains a UNIVERSAL code. This is controlled by a UNIVERSAL transmitter to allow the car to be inspected and moved within the factory.

Before delivery, it is therefore necessary to programme the receiver with the code of the transmitter supplied with the vehicle.


Alarm warning modes may alter according to the legislation in the country where the car is sold. It may therefore be necessary to programme the system by entering a country code "n".

Two programming modes are possible:

A - before entering a password: SIMPLIFIED PROGRAMMING

B - after entering a password: PROTECTED PROGRAMMING

Each transmitter has a card bearing a **Password** to safeguard against unauthorised programming (protected programming). The card may be removed by the customer at the time of purchase and applied to the space present on the back of the Code Card.



P3U13HL01

1. Flashing led
2. Button on transmitter
3. Plate with 4-figure password
4. Programming button on courtesy light
5. LED on courtesy light
6. Radio receiver

### A) Simplified programming

Simplified programming is used for a new memory which has not yet been closed and can recognise all transmitter codes (remote control commands) without any limit of quantity.

Any number of remote control codes are recognised, but only the final eight are stored.

**Always store a transmitter with:**

- alarm control unit de-activated with remote control (dissuasion led off)
- ignition key turned to STOP
- emergency key on siren in ON position.

### Programming (storing) 1st transmitter

1. Press programming button (4) on the receiver. The receiver led (5) will begin to FLASH to indicate "awaiting code reception".



*If led (5) stays off when the button is pressed, this means that:*

- the alarm system is ON. In this case, de-activation can be carried out only using a UNIVERSAL REMOTE CONTROL;
- the receiver is faulty or not supplied with power.

2. Hold down button (4) on the receiver; press the button on the remote control until led (5) on the courtesy light stays on continually to indicate that code "n" has been stored.

### 55.

3. When receiver button (4) is released, led (5) on the courtesy light goes off. Two options are now available:
- To program the alarm system for the system required by the laws of the country where the car will be driven (country code).
  - To leave the operating mode stored previously.

Code "n"	Country	Code "n"	Country
1	Italy	6	Holland
2	Germany	7	U.S.A.
3	France	8	EC (Europe)
4	Switzerland	9	Free
5	United Kingdom	10	Free

To program the alarm system for option "a", press button (4) as many times as are indicated in the table in succession within 15 seconds of the led going off.



*Led (5) will flash each time the button is pressed.*

At the end of the simplified programming cycle, if courtesy light led (5):

- FLASHES "n" (n=country code stored) times, the code has been stored correctly;
- COMES ON CONTINUOUSLY for 5 seconds, the serial line between receiver and alarm is broken or the code saved previously is still in the alarm system memory (failure to accept new code). If a wrong code has been entered, repeat all operations beginning from point 1 of the simplified programming procedure.

**NOTE** *If the programming button on the courtesy light is not pressed, the EC operating mode will automatically be recognised if this operation is being carried out for the first time. If the operation has already been carried out previously, the system will set itself for the mode stored previously.*

**NOTE** *To program the country code, use the procedure in module M40A of the Fiat Lancia Tester.*

### PROGRAMMING FURTHER TRANSMITTERS (REMOTE CONTROL UNITS)

To store further remote control units, repeat the simplified programming procedure from point 1. An unlimited number of remote controls units may be stored, but the courtesy light will only store the last eight.




*The simplified programming procedure deletes the universal codes on the courtesy light and alarm system electronic control unit.*

### B) Protected programming

To prevent intruders from entering their own code, it is necessary to protect (close) the memory. This operation is carried out:

- automatically once the alarm system has been activated/de-activated 256 times with success;
- deliberately, by the user entering a password (four-figure code on the transmitter plate) before the unit has been activated/de-activated 256 times, e.g. on new units after all remote control codes supplied to the customer have been entered.



### **CLOSING THE MEMORY MANUALLY (ENTERING PASSWORD)**

The Password input procedure is as follows::

1. Press the button on the receiver for 2 seconds. The LED flashes for the entire time the button is held down.
2. Release the button: after about 2 seconds, the LED emits a short flash to indicate that the first figure of the Password may be entered.
3. Immediately press the receiver button as many times as the first figure of the password (e.g. press five times); the LED will come on briefly to provide visual confirmation each time the button is pressed.
4. About 2 seconds after the button is operated for the last time (the fifth press in our example), the LED will flash once more to request entry of the next figure (e.g. 2).
5. Immediately press the receiver button as many times as the second figure of the password (e.g. twice) the LED will come on briefly to provide visual confirmation each time the button is pressed.
6. About 2 seconds after the button is operated for the last time (the second press in our example), the LED will flash once more to request entry of the next figure (zero).
7. When a "zero" appears in the password, do not press the button on the receiver, but wait for a new figure entry request indicated by another flash.
8. After about 2 seconds, the LED will flash once more to request entry of the next figure (a three).
9. Press the receiver button as many times as the fourth figure of the password (e.g. press three times) Note that the LED should come on briefly to provide visual confirmation each time the button is pressed.

After entering the 4 figures of the Password, the LED on the receiver may behave as follows:

- a) **stays off.** this indicates that the Password has been correctly entered and corresponds to one of the stored remote control codes;
- b) **stays on continuously.** this indicates that Password has been incorrectly entered or does not correspond to any of the stored remote control codes. In this case, re-enter the correct Password beginning from point 1 once the LED has gone off.

The memory is closed once the Password has been entered correctly.

### 55.

#### Programming a transmitter (remote control unit) with closed memory

1. Press the programming button on the receiver. The receiver led will begin to flash to indicate that it is awaiting a code.
2. The operator should press the remote control button while holding down the receiver button.
3. After sending the new code, the LED on the courtesy light will cease to flash to indicate that the operation has failed.  
In this case, programme the code with manual access.

#### Programming a transmitter with manual access

As soon as the memory is closed, further codes can be entered by the remote control only by re-opening the memory. Open the memory by carrying operations indicated under points 1 to 9 in rapid succession as described on the previous page. Then proceed as follows.

After entering the four figures of the password, the LED on the receiver may behave as follows:

- a) **being to flash** if the password has been entered correctly (memory open);
  - b) **come on continuously** for several seconds to indicate that the password has been incorrectly entered or that the password does not correspond to any of the stored remote control units. In this case, once the LD has gone off, re-enter the correct password beginning from point 1.
10. While the led is flashing, press the button on the courtesy light. The led will continue to flash.
  11. The operator should continue to hold the receiver button down and press the button on the remote control.  
The LED on the courtesy light comes on continuously to indicate that the code has been stored.
  12. Release the button: the LED on the courtesy light GOES OFF.


At the end of the procedure, if the courtesy light led (5):

- FLASHES "n" (n=stored country code) times, the code has been correctly stored;
- COMES ON CONTINUOUSLY for 5 seconds, the serial line between receiver and control unit is broken.



*After entering a new remote control code, the memory closes automatically. Repeat the procedure from point 1 to enter a new remote control unit.*

**WIRING DIAGRAM**



P3U17HL01

**Key**

- |                                    |  |
|------------------------------------|--|
| 1. Battery                         | 13. Alarm control unit                             |
| 2. Positive centre                 | 14. Switch on bonnet lid                           |
| 3. Fuse box                        | 15. Switch on boot                                 |
| 4. Fuse 60A                        | 16. Direction indicators                           |
| 5. Volumetric sensors              | 17. Two-colour surveillance led                    |
| 6. Radio-controlled remote control | 18. Injection ECU                                  |
| 7. Radio receiver                  | 19. Electronic key system                          |
| 8. Door lock control unit          | 20. Electronic injection control unit tester point |
| 9. Switch on left rear door        | 21. Fiat-Lancia Tester connection point            |
| 10. Switch on right rear door      | 22. Fiat-Lancia Tester                             |
| 11. Switch on right front door     | 23. Alarm siren                                    |
| 12. Switch on left front door      | 24. Ignition switch                                |





	page
- Electrical symbols	1
- Explonation of wiring diagram	4
- Wiring diagram	5
- Key to components	143

**COPYRIGHT Fiat Auto S.p.A.**

Reproduction of all or part of the text and illustrations is prohibited.

The information in this publication is intended as a guide and could be superseded by modifications introduced by the Manufacturer at any time for technical and commercial reasons or in accordance with local regulations.



Fiat Auto S.p.A.  
Direzione Marketing Commerciale  
Direzione Post-Vendita - Servizi Assistenziali  
10134 TURIN (Italy) - Corso E. Giambone, 33  
Print no. 506.475/01 - Ottobre 1994 - 500  
Printed in Italy - Tip. Europrint - Torino

DESCRIPTION	ENGINE TYPE				
	1998	2446	1995T	2959	2387 Td
Preparation for medium range radio	5	5	5	5	5
Preparation for top range radio	7	7	7	7	7
Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light				9	
Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light					11
Direction indicators and warning light - Hazard warning lights and warning light - Braking lights - Reversing lights	13	13	13	13	13
Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer/trip meter and zeroing button - Rev counter - Current socket - Voltmeter	15	15	15	15	15
Ideogram lights - Heated rear windscreen and warning light	17	17	17	17	17
Version with alarm: central locking and signalling doors open	19	19	19	19	19
Version without alarm: central locking and signalling doors open - Door closing device	21	21	21	21	21
Complete Inforcenter	23	23	23	23	23
Air-bag and failure warning light - Seat belt pre-tensioners - Servotronic device	25	25	25	25	25
Preparation for medium range radio - Preparation for radiotelephone	26/1	26/1	26/1	26/1	26/1
Preparation for top range radio	26/3	26/3	26/3	26/3	26/3

Cont'  
13

**NOTE** The numbers in the table correspond to the electrical equipment page number in the manual

2001









































NAME	VERSIONS AND ENGINES					
	1998	2446	1995 T	2959	2387 Td	
Provision for car radio, high range	5	5	5	5	5	5
Lancia CODE device	7	7	7	7	7	7
Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light	9	11	13	15		
Starting - Fuel pump ECU MSA11-310 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light						17
Courtesy light	19	19	19	19	19	19
Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Mileometer/trip counter and reset button - Rev counter	21	21	21	21	21	21
Electrically-adjusted, heated, fold-down door mirrors - Interior rear view mirror	23	23	23	23	23	23
Version with antitheft device Door lock and door open indicator	25	25	25	25	25	25
Version without antitheft device Door lock and door open indicator	27	27	27	27	27	27
Automatic transmission (AISN)	29					
Automatic transmission (ZF)				31		
Alarm	33	33	33	33	33	33
IGE ECU assembly connections	35	35	35	35	35	35
Instrument panel connection	37	37	37	37	37	37

NOTE Numbers in the table correspond to page numbers in electrical eqpt section







































## Electrical symbols

	Positions		Cold (starter)	starting		Ignition discharge
	Main beam headlamps		Water in fuel filter			Dipped headlamps
	Heated seat		Glow plug preheating			Turn signal with central locking warning light
	Seat belt		Turbocharger pressure			Electric horns
	Heated rear windscreen		Rear fog lamp			Left turn signal
	Handbrake on and low brake fluid level		Fog lamps			Right turn signal
	A.B.S.		Brake lining wear			Engine cooling system
	Hazard lights warning		Turbocharger pressure			Windscreen wiper
	Turn signals		Automatic transmission fluid temperature			Electrically operated sun roof
	Handbrake and low brake fluid level		Speed limit			Catalytic converter temperature
	Recharging		Fuel level			Resistance
	Engine oil pressure		Coolant temperature			Diode

P3U001N01

#### Electrical symbols

	Warning light		Trip computer control		Differential lock
	Bulb		Electronic injection		Automatic transmission fluid temperature
	Fuse with reference number		Engine oil level		Temperature
	Switch open		Brake fluid level (Japanese version)		Antitheft device
	Selector switch		Doors open		Electrically-operated windows
	Button open		Central locking		Earth
	Coil-controlled switch (Relay)		Electronic suspension sport setting		Number plate lights
	Engine		Transistor		Pulse (Timer) generator
	Rearscreen wash/wipe		Air-Bag		Analogue clock
	Headlamp washer		A.B.S. (Japanese version)		Digital clock
	Windscreen wash/wipe		Vehicle brake failure		Speedometer
	Rear wash/wipe		Windscreen wiper		Rev counter

P3U002N01





Digital speedometer



Digital rev counter



Digital fuel gauge



Analogue fuel gauge



Analogue coolant temperature gauge



Econometer



Digital coolant temperature gauge



Engine oil temperature




Engine oil pressure gauge



Voltmeter

## 55.

How to read the wiring diagram




### Reference key



- A Component number
- B Connection number
- C Identification of connector on component
- D Connection pin number
- E Taped ultrasound welding in wiring bundle

P3U004N01

Device (Lancia CODE) - (See key following diagrams)



Device (Lancia CODE)



Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA

PIUGSANO

PIUGSANO

Updates diagram on page 13

PIUGSANO

LANCIA



## 55.



### Key to components


- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 44 Power earth
- 68 Connection between fascia lead and electronic injection lead
- 72 Fuel injection control unit
- 72A Fuel pump ECU (2387 Td)
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse for ignition switch/alarm device
- 75 Junction unit (fascia)
- 88 Diagnostic socket for Fiat / Lancia tester
- 97 Earth on floor pan
- 105 Ignition switch
- 106 Lancia CODE device aerial
- 107 Alarm control unit
- 108 Lancia CODE control unit
- 297 Alarm / Lancia CODE device warning light
- N.D. Taped ultrasound welding in wiring bundle

\* Wires involved in the wiring diagram are marked with an asterisk



Provision for car radio, high range - (See key following diagrams)




Provision for car radio, high range



\* See symbol illumination diagram

Updates diagram on page 11

P3U09AN01




P3U018N01

18, 19, 20





55.



Provision for car radio, high range


### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit
- 73C 30A fuse for ignition switch/alarm device
- 75 Junction unit (facia)
- 90 Connection between facia cable and left front door cable
- 91 Speaker on left hand front door
- 96 Earth on carrier
- 100 Connection between facia lead and left longitudinal lead
- 105 Ignition switch
- 119B Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- 122 Speaker on right hand front door
- 131 Amplifier for car radio
- 164 Left hand rear speaker
- 166 Amplifier for aerial on back window
- 166A Rear cable connection on rear window
- 169 Right hand rear speaker
- 178 Left rear earth
- 181 Connection between left longitudinal cable and right longitudinal cable
- 227 Right front speaker


- 228 Left front loudspeaker
- 295 Radio cable connection
- 296 Radio cable connection
- 422 Connection between facia lead and left longitudinal lead

N.D. Taped ultrasound welding in wiring bundle


100 Connection between facia lead and left longitudinal lead




119B Connection between facia lead and left longitudinal lead




181 Connection between left longitudinal cable and right longitudinal cable



166A Rear cable connection on rear window



296 Radio cable connection




\* Wires involved in the wiring diagram are marked with an asterisk



Version: 1998

Starting - Motronic electronic ignition and injection 2.10.3 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - (See key following diagrams)




\* See air conditioner diagram

Updates diagram on page 23

PIU13AND





55.



1998 version: Starting - Motronic electronic ignition and injection 2.10.3 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light

### Key to components

- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 12 Starter motor
- 13 Spark plugs
- 20 Alternator
- 23 Minimum engine oil pressure indicator sensor
- 25 Temperature sensor
- 26 Three stage pressure switch
- 31 Peripheral ECU (engine bay)
- 32A E3 Compressor coupling control relay
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and left engine bay cable
- 33A Connection between facia cable and left engine bay cable
- 33B Connection between facia cable and left engine bay cable
- 33C Connection between facia cable and right engine bay cable
- 35 Connection between engine bay cable and electronic injection cable
- 36 Hot Lambda probe
- 37 Idle adjustment actuator
- 41 Fuel vapour cut-off solenoid
- 42 30A fuse for electronic injection system
- 43 Electronic earth
- 44 Power earth
- 45 Air flow meter (Debimeter)
- 50 Electronic injection system control relay
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Injectors
- 59 1 Knock sensor
- 60 2 Knock sensor
- 61 Electronic injection engine coolant temperature sensor
- 62 Rpm sensor
- 63 Potentiometer on throttle valve
- 66 Timing sensor
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 72 Fuel injection control unit
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 74 60A fuse protecting peripheral control unit (engine bay)
- 75 Junction unit (facia)
- E1 Switch discharge connector
- 78 Instrument panel
- K Battery charging warning light
- N Insufficient engine oil pressure warning light
- V Electronic rev counter
- Y Electronic tachometer
- 85 Infocenter ECU
- 88 Diagnostic socket for Fiat / Lancia tester
- 97 Earth on floor pan
- 105 Ignition switch
- 107 Alarm control unit
- 108 Lancia CODE control unit
- 168 Electric fuel pump
- 191 Electronic inertia switch
- 192 Inertia switch
- 317 Connection between automatic transmission cable and electronic injection cable
- 343 40A starter relay
- 377 Timing variator
- 380 Relay for timing variator
- 432 20A Ignition switch control relay fuse
- N.D. Taped ultrasound welding in wiring bundle




\* Wires involved in the wiring diagram are marked with an asterisk



Version: 2446

Starting - Motronic electronic ignition and injection 2.10.3 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - (See key following diagrams)



\* See air conditioner diagram


Updates diagram on page 25

PSUITANGI





55.



Version 2446: Starting - Motronic electronic ignition and injection 2.10.3 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light


## Key to components

- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 15 Starter motor
- 20 Spark plugs
- 21 Minimum engine oil pressure indicator sensor
- 23 Air temperature sensor
- 26 Three stage pressure switch
- 31 Peripheral ECU (engine bay)
- 32 E3 Compressor coupling control relay
- 32A Connection between facia cable and left engine bay cable
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and right engine bay cable
- 33 Connection between facia cable and right engine bay cable
- 35 Cold engine bay cable and electronic injection cable
- 36 Hot Lambda probe
- 37 Idle adjustment actuator
- 40 EGR device control solenoid
- 41 Fuel vapour cut-off solenoid
- 42 30A fuse for electronic injection system
- 43 Electronic earth
- 44 Power earth
- 45 Ignition coil
- 46 7.5A electronic system fuse
- 48 10A hot lambda probe and air flow meter relay fuse (Debimeter)
- 49 Relay for electric fuel pump and hot Lambda probe
- 50 Electronic injection system control relay
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 57 Ignition coil
- 58 Ignition coil
- 59 1 Knock sensor
- 60 2 Knock sensor
- 61 Electronic injection engine coolant temperature sensor
- 62 Rom sensor
- 63 Potentiometer on throttle valve


66 Timing sensor

55A


32A Connection between facia cable and left engine bay cable




35 Connection between engine bay cable and electronic injection cable



68 Connection between facia lead and electronic injection lead



69 Engine service lead connection



\* Wires involved in the wiring diagram are marked with an asterisk

P30047N01




\* See air conditioner diagram





55.




Version 1995 T: Starting - Motronic electronic ignition and injection M 2.7 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light


### Key to components

- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 15 Starter motor
- 16 Spark plug
- 20 Alternator
- 23 Minimum engine oil pressure indicator sensor
- 24 Barometric capsule
- 25 Air temperature sensor
- 26 Three stage pressure switch
- 31 Peripheral ECU (engine bay)
- 32A Compressor coupling control relay
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and left engine bay cable
- 33A Connection between facia cable and right engine bay cable
- 35 Connection between engine bay cable and electronic injection cable
- 36 Hot Lambda probe
- 37 Idle adjustment actuator
- 40 EGR device control solenoid
- 41 Fuel vapour cut-off solenoid
- 42 30A fuse for electronic injection system
- 43 Electronic earth
- 44 Power earth
- 45 Air flow meter (Debitmeter)
- 48 10A hot lambda probe and air flow meter relay fuse (Debitmeter)
- 49 Fuel pump control relay and hot Lambda probe
- 50 Electronic injection system control relay
- 58 Injectors
- 59 Detonation sensor
- 61 Electronic injection engine coolant temperature sensor
- 62 Rom sensor
- 63 Potentiometer on throttle valve
- 66 Timing sensor
- 67 Electronic injection wiring connection
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 70 HT distributor
- 72 Fuel injection control unit
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 74 60A fuse protecting peripheral control unit (engine bay)
- 75 Junction unit (facia)
- E1 Switch discharge connector
- 78 Instrument panel
- K Battery recharging warning light
- M Insufficient engine oil pressure warning light
- U Electronic rev counter
- Y Electronic tachometer
- 85 Infocenter ECU
- 88 Diagnostic socket for Fiat/Lancia tester
- 97 Earth on floor pan
- 105 Ignition switch
- 107 Alarm control unit
- 108 Lancia CODE control unit
- 161 100A alternator fuse
- 168 Electric fuel pump
- 191 Earth for inertia switch
- 192 Inertia switch
- 343 40A starter relay
- 432 20A ignition switch control relay fuse
- N.D. Taped ultrasound welding in wiring bundle


35 Connection between engine bay cable and electronic injection cable




67 Engine service lead connection



68 Connection between facia lead and electronic injection lead



69 Engine service lead connection




\* Wires involved in the wiring diagram are marked with an asterisk

14



Version: 2959

Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - (See key following diagrams)



\* See automatic transmission wiring diagram  
\*\* See air conditioner diagram


PS1025AN01

Updates diagram on page 29





55.




Version 2959; Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light


### Key to components

- 1 Left front earth
- 2 Battery
- 3 Main fuse unit
- 4 Earth on body
- 5 Starter motor
- 6 Spark plugs
- 7 Alternator
- 8 Minimum engine oil pressure indicator sensor
- 9 Air temperature sensor
- 10 Three stage pressure switch
- 11 Peripheral ECU (engine bay)
- 12 ECU
- 13 Idle adjustment actuator
- 14 Fuel vapour cut-off solenoid
- 15 Fuel vapour cut-off
- 16 Fuel vapour cut-off
- 17 Power earth
- 18 Air flow meter (Debitmeter)
- 19 7.5A electronic injection system fuse
- 20 10A hot lambda probe and air flow meter relay fuse (Debitmeter)
- 21 Fuel pump control relay and hot lambda probe
- 22 Electronic injection system control relay
- 23 Air flow meter control relay (Debitmeter)
- 24 Ignition coil
- 25 Ignition coil
- 26 Ignition coil
- 27 Ignition coil
- 28 Injectors
- 29 Denonation sensor
- 30 Denonation sensor
- 31 Electronic injection engine coolant temperature sensor
- 32A Connection between coupling control relay and engine bay cable
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and right engine bay cable
- 33A Connection between engine bay cable and right engine bay cable
- 33B Connection between engine bay cable and electronic injection cable
- 34 Hot lambda probe
- 35 Idle adjustment actuator
- 36 Fuel vapour cut-off solenoid
- 37 Fuel vapour cut-off
- 38 Fuel vapour cut-off
- 39 ECU
- 40 ECU
- 41 Fuel vapour cut-off
- 42 30A fuse for electronic injection system
- 43 Power earth
- 44 Air flow meter (Debitmeter)
- 45 7.5A electronic injection system fuse
- 46 10A hot lambda probe and air flow meter relay fuse (Debitmeter)
- 47 Fuel pump control relay and hot lambda probe
- 48 Electronic injection system control relay
- 49 Air flow meter control relay (Debitmeter)
- 50 Ignition coil
- 51 Ignition coil
- 52 Ignition coil
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Injectors
- 59 Denonation sensor
- 60 Denonation sensor
- 61 Electronic injection engine coolant temperature sensor


35 Connection between engine bay cable and electronic injection cable




68 Connection between facia lead and electronic injection lead



317 Connection between automatic transmission lead and electronic injection lead



334 Connection between electronic injection lead and injector braid




\* Wires involved in the wiring diagram are marked with an asterisk

16



Version: 2387 Td

Starting - Fuel pump ECUMSA11-310 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light - (See key following diagrams)



\* See air conditioner diagram


\*\* See vehicle brake light diagram

Updates diagram on page 31

PIUZZANOT



55.




Version 2387 Td - Starting - Fuel pump ECU MSA11-310 - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light

### Key to components


- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 15 Starter motor
- 20 Alternator
- 26 Three stage pressure switch
- 31 Peripheral ECU (engine bay)
- 32A Connection between facia cable and left engine bay cable
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and left engine bay cable
- 33 Connection between facia cable and right engine bay cable
- 35 Connection between engine bay cable and electronic injection cable
- 39 Relay for inertia switch
- 40 EGR device control solenoid
- 42 30A fuse for electronic injection system
- 43 Electronic earth
- 45 Air flow meter (Debitmeter)
- 50 Electronic injection system control relay
- 61 Electronic injection engine coolant temperature sensor
- 62 rpm sensor
- 64 40A glow plug fuse
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 72A Fuel pump control unit
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 74 60A fuse protecting peripheral control unit (engine bay)
- 75 Junction unit (facia)
- E1 Switch discharge connector

N.D. Taped ultrasound welding in wiring bundle


32B Connection between facia cable and left engine bay cable (only for 2387 Tds)




35 Connection between engine bay cable and electronic injection cable




382 Hot diesel filter control relay (P.T.C.)



68 Connection between facia lead and electronic injection lead



69 Engine service lead connection




\* Wires involved in the wiring diagram are marked with an asterisk

18

18




Courtesy light - (See key following diagrams)










Courtesy light


Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 75 Junction unit (facia)
- 79 Connection between facia cable and courtesy light cable
- 87 Glove compartment / boot release control lighting
- 90 Connection between facia cable and left front door cable
- 93 Puddle light on left front door
- 95 Left front door lock motor and left front door open warning light
- 96 Earth on carrier
- 97 Earth on floor pan
- 100 Connection between facia lead and left longitudinal lead
- 105 Ignition switch
- 120 Connection between facia cable and right front door cable
- 124 Puddle light on right front door
- 126 Right front door lock motor and right front door open warning light
- 128 Front courtesy light control timer
- 131 Earth on steering column mount
- 137 Luggage compartment tail-gate lock assembly
- 141 Connection between right longitudinal cable and right rear door cable
- 144 Puddle light on right rear door
- 146 Right rear door lock motor and right door open/car alarm activated w/light
- 150 Connection between left longitudinal cable and left rear door cable
- 153 Puddle light on left rear door
- 155 Left rear door lock motor and left rear door open/car alarm activated w/light
- 162 Luggage compartment lighting
- 163 Left rear courtesy light for car interior
- 170 Right rear courtesy light for vehicle interior
- 173 Right rear earth
- 175 Connection between left longitudinal cable and tail-gate cable
- 176 Luggage compartment tail-gate cable connection
- 178 Left rear earth
- 181 Connection between left longitudinal cable and right longitudinal cable
- 225 Left floor light
- 226 Right floor light
- 266 Infra-red ray receiver for alarm device
- 269 Connection between facia cable and receiver cable
- 281 Front courtesy light for car interior
- 283 Lighted panel on passenger side
- 300 Central locking electronic control unit
- 422 Connection between facia lead and left longitudinal lead


79 Connection between facia cable and courtesy light cable




141 Connection between right longitudinal cable and right rear door cable



150 Connection between left longitudinal cable and left rear door cable



175 Connection between left longitudinal cable and tail-gate cable




\* Wires involved in the wiring diagram are marked with an asterisk

PJ079NDT




Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Mileometer/trip counter and reset button - Rev counter - (See key following diagrams)



\* Connection variant for 2959 version  
\*\* Variant for version 2387 Td







55.



Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Mileometer/trip counter and reset button - Rev counter

### Key to components

- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 12 Low brake fluid level indication sensor
- 14 Pulse generator for speedometer signal
- 32B Connection between facia cable and left engine bay cable
- 68 Connection between facia lead and electronic injection lead
- 72 Fuel injection control unit
- 73 Secondary junction unit
- 73B 40A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 75 Junction unit (facia)
- 76 IGE control unit
- 78 Instrument panel
- J Seat belt undone warning light
- N Handbrake warning light / IGE control unit.
- O Insufficient brake fluid level warning light
- U Electronic rev counter
- V Fuel level gauge
- V1 Fuel reserve warning light
- X Mileometer/trip counter display
- Y Electronic tachometer
- Z1 Trip computer reset button




\* Wires involved in the wiring diagram are marked with an asterisk

30033001

22




Electrically-adjusted, heated, fold-down door mirrors - Electro-chromic interior rear view mirror - (See key following diagrams)




Updates diagram on page 51

PJ041ANG01

### Connection between facia cable and left engine bay cable




## P3U42AN07




### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 13 Reversing lights switch
- 73 Secondary junction unit
- 73A 80A rear service fuse
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 75 Junction unit (facia)
- E1 Switch discharge connector
- 79 Connection between facia cable and courtesy light cable
- 85 Infocenter ECU
- 89 Left door mirror
- A Left door mirror fold-down motor
- B Left door mirror vertical positioning motor
- C Left door mirror horizontal positioning motor
- D Left door mirror heater coil
- E Outdoor temperature sensor
- 90 Connection between facia cable and left front door cable
- 96 Earth on carrier
- 005 Ignition switch
- 115 Electrically-adjustable door mirror control unit
- 119B Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- 121 Right door mirror
  - A Right door mirror fold-down motor
  - B Right door mirror vertical positioning motor
  - C Right door mirror horizontal positioning motor
  - D Right door mirror heater coil
- 131 Earth on steering column mount
- 180 Heated back window relay
- 282 Interior chrome-plated mirror
- 429 7.5A heated door mirror fuse
- N.D. Taped ultrasound welding in wiring bundle

# Connection between facia lead and electronic injection lead




Engine service lead connection  
AP 190




\* Wires involved in the wiring diagram are marked with an asterisk







55.




Door lock and door open indicator

### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 23 Minimum engine oil pressure indicator sensor
- 32B Connection between facia cable and left engine bay cable
- 69 Engine service lead connection
- 73 Secondary junction unit
- 73A 80A rear service fuse
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (facia)
- 85 Infocenter ECU
- 87 Glove compartment light / luggage compartment release controls
- 90 Connection between facia cable and left front door cable
- 95 Left front door lock motor and left front door open warning light and anti-theft device activation
- 96 Earth on carrier
- 97 Earth on floor pan
- 100 Connection between facia lead and left longitudinal lead
- 105 Ignition switch
- 107 Car alarm ECU
- 119A Connection between facia cable and right longitudinal cable
- 119B Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- 126 Right front door lock motor and right front door open warning light and anti-theft device activation
- 131 Earth on steering column mount
- Luggage compartment tail-gate lock assembly

- A Luggage compartment light switch and anti-theft activation
- B Tail-gate lock/release motor
- 141 Connection between right longitudinal cable and right rear door cable
- 146 Right rear door lock motor and right door open/car alarm activated w/light and anti-theft device activation
- 150 Connection between left longitudinal cable and left rear door
- 155 Left rear door lock motor and left rear door open/car alarm activated w/light and anti-theft device activation
- 173 Right rear earth
- 175 Connection between left longitudinal cable and tail-gate cable
- 176 Luggage compartment tail-gate cable connection
- 178 Left rear earth
- 181 Connection between left longitudinal cable and right longitudinal cable
- 188 25A luggage compartment release electromagnetic fuse
- 190 Luggage compartment tail-gate lock/release relay
- 195 Fuel flap release motor
- 266 Infra-red ray receiver for anti-theft device
- 269 Connection between facia cable and receiver cable
- 300

Central locking electronic control unit  
N.D. Taped ultrasound welding in wiring bundle




\* The wires marked with an asterisk refer to the wiring diagram



Version without alarm


Door lock and door open indicator - Door closure control device - (See key following diagrams)



\* See turn signal diagram

PSA/SANDI






Version without alarm: Central locking and door open warning light - Door closure control device

### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 23 Minimum engine oil pressure indicator sensor
- 32B Connection between facia cable and left engine bay cable
- 69 Engine service lead connection
- 73 Secondary junction unit
- 73A 80A rear service fuse
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 75 Junction unit (facia)
- E2 Turn signal flasher unit/hazard warning lights
- 85 Infocenter ECU
- 87 Glove compartment light / luggage compartment release controls
- 90 Connection between facia cable and left front door cable
- 95 Left front door lock motor and left front door open warning light and alarm activation
- 96 Earth on carrier
- 97 Earth on floor pan
- 100 Connection between facia lead and left longitudinal lead
- 105 Ignition switch
- 108 Immobiliser control unit
- 119A Connection between facia cable and right longitudinal cable
- 119B Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- 126 Right front door lock motor and right front door open warning light and alarm activation
- 131 Earth on steering column mount
- 137 Luggage compartment tail-gate lock assembly
- A Luggage compartment light switch and alarm activation
- B Luggage compartment tail-gate lock/release motor
- 141 Connection between right longitudinal cable and right rear door cable
- 146 Right rear door lock motor and right door open/car alarm activated w/light and alarm activation
- 150 Connection between left longitudinal cable and left rear door
- 155 Left rear door lock motor and left rear door open/car alarm activated w/light and alarm activation
- 173 Right rear earth
- 175 Connection between left longitudinal cable and tail-gate cable
- 176 Luggage compartment tail-gate cable connection
- 178 Left rear earth
- 181 Connection between left longitudinal cable and right longitudinal cable
- 188 25A luggage compartment release electromagnetic fuse
- 190 Luggage compartment tail-gate lock/release relay
- 195 Fuel flap release motor
- 266 Infra-red ray receiver for alarm device
- 269 Connection between facia cable and receiver cable
- 297 Anti-theft device/Lancia CODE device warning light
- 300 Central locking electronic control unit
- 431 Turn signal and door closure control device
- N.D. Taped ultrasound welding in wiring bundle




\* The wires marked with an asterisk refer to the wiring diagram






Version: 1998

Automatic transmission (Aisin) - (See key following diagrams)



Updates diagram on page 63

55.




1998 version: Automatic transmission (Aisin)

### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 13 Reversing lights switch
- 15 Starter motor
- 32B Connection between facia cable and left engine bay cable
- 68 Engine service lead connection
- 69 Fuel injection control unit
- 72 Secondary junction unit
- 73 30A fuse protecting ignition switch/car alarm
- 74 60A fuse protecting peripheral control unit (engine bay))
- 75 Junction unit (facia)
- E1 Switch discharge connector
- 78 Instrument panel
- Z Electronic automatic transmission gear selection display
- 85 Infocenter ECU
- 90 Connection between facia cable and left front door cable
- 95 Left front door lock motor and alarm activation indicator
- 105 Ignition switch
- 131 Earth on steering column mount
- 171 Supplementary stop light indicator
- 174 Right tail-light cluster on mobile part
- 175 Connection between left longitudinal cable and tail-gate cable
- 177 Left tail-light cluster on mobile part
- 178 Left rear earth
- 306 Electronic automatic transmission acoustic alarm


P503A001

### 69 Engine service lead connection




### 175

Connection between left longitudinal cable and tail-gate cable




### 317

Connection between electronic automatic transmission and injection lead



### 318

Connection between electronic automatic transmission lead and facia lead




\* Wires involved in the wiring diagram are marked with an asterisk

P503A001

Version: 2959


Automatic transmission (ZF) - (See key following diagrams)



Updates diagram on page 65

31

55.



Version 2959: Automatic transmission (ZF)

PAUSA/ANGI


### Key to components

- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 13 Reversing lights switch
- 15 Starter motor
- 32B Connection between facia cable and left engine bay cable
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 72 Fuel injection control unit
- 73 Secondary junction unit
- 73C 30A fuse protecting ignition switch/car alarm
- 74 60A fuse protecting peripheral control unit (engine bay))
- 75 Junction unit (facia)
- 78 Instrument panel
- 95 Electronic tachometer
- 96 Electronic automatic transmission gear selection display
- 99 Intocenter ECU
- 105 Connection between facia cable and left front door cable
- 131 Left front door lock motor and left front door open warning light and alarm activation
- 174 Right tail-light cluster on mobile part
- 175 Connection between left longitudinal cable and tail-gate cable
- 177 Left tail-light cluster on mobile part
- 178 Left rear earth
- 301 Solenoid unit
- 302 Switch control assembly
- 306 Electronic automatic transmission acoustic alarm
- 307 Electronic automatic transmission acoustic alarm switch
- 315 Electronic automatic transmission speed selection control unit (ZF)
- 316 Electronic automatic transmission tester socket
- 317 Connection between automatic transmission lead and electronic injection lead
- 318 Connection between electronic automatic transmission lead and facia lead
- 320 Electronic automatic transmission speed selection lever display
- 343 40A starter relay
- 432 20A ignition switch control relay fuse

N.D. Taped ultrasound welding in wiring bundle


68

Facia wiring connection with electronic injection cable




175

Connection between left longitudinal cable and tail-gate cable




317

Connection between electronic automatic transmission and injection lead




318

Connection between electronic automatic transmission lead and facia lead



\* Wires involved in the wiring diagram are marked with an asterisk

Alarm device - (See key following diagrams)



\* Connection variant for versions 1998 - 1995 T - 2446

\*\* Variant for version 2387 Td


\*\*\* See central locking diagram

Updates diagram on page 67

PSURAND01



55.




23U62AN01

### Alarm device

### Key to components

- |    |  |      |  |
|----|--|------|--|
| 1  | Left front light cluster   | 119B | Connection between fascia cable and right longitudinal cable                                       |
| 3  | Left front earth   | 120  | Connection between fascia cable and right front door cable   |
| 6  | Left side turn signal  | 126  | Right front door lock motor and right front door open warning light and alarm activation           |
| 7  | Battery  | 131  | Earth on steering column mount   |
| 8  | Main junction unit   | 137  | Luggage compartment tail-gate lock assembly  |
| 9  | Earth on body  | 141  | Connection between right longitudinal cable and right rear door cable                              |
| 10 | Button on bonnet for activation of alarm   | 146  | Right rear door lock motor and right door open/car alarm activated w/light and alarm activation    |
| 27 | Right front earth  | 150  | Connection between left longitudinal cable and left rear door                                      |
| 30 | Right front light cluster  | 155  | Left rear door lock motor and left rear door open/car alarm activated w/light and alarm activation |
| 2A | Connection between fascia cable and left engine bay cable                              | 172  | Right tail-light cluster on fixed part   |
| 3A | Connection between fascia cable and right engine bay cable                             | 173  | Right rear earth   |
| 44 | Power earth  | 175  | Connection between left longitudinal cable and tail-gate cable                                     |
| 68 | Connection between fascia lead and electronic injection lead                           | 176  | Luggage compartment tail-gate cable connection   |
| 72 | Fuel injection control unit  | 177  | Left tail-light cluster on mobile part   |
| 73 | Secondary junction unit  | 178  | Left rear earth  |
| 75 | Function unit (facia)  | 179  | Left tail-light cluster on fixed part  |
| 3B | 60A fuse protecting I.G.E. control unit/junction unit                                  | 199  | Alarm siren  |
| 3C | 30A fuse protecting ignition switch/car alarm  | 266  | Intra-red ray receiver for alarm device  |
| E1 | Switch discharge warning light flasher   | 267  | Volumetric sensors for alarm device  |
| E2 | Turn signal/hazard warning light flasher   | 269  | Connection between fascia cable and receiver cable   |
| 88 | Tester socket for Fiat/Lancia tester   | 297  | Alarm / Lancia CODE device warning light   |
| 90 | Connection between fascia cable and left front door cable                              | 300  | Central locking electronic control unit  |
| 95 | Left front door lock motor and left front door open warning light and alarm activation | 341  | Right side turn signal   |
| 96 | Earth on carrier   | 345  | Right front earth  |
| 97 | Earth on floor pan   |      |  |
| 00 | Connection between fascia lead and left longitudinal lead                              |      |  |
| 05 | Ignition switch  |      |  |
| 07 | Alarm control unit   |      |  |
| 08 | Lancia CODE control unit   |      |  |

N.D. Taped ultrasound welding in wiring bundle




Wires involved in the wiring diagram are marked with an asterisk

1965






I.G.E. control unit assembly connections - (See key following diagrams)



Updates diagram on page 71



55.




**I.G.E. control unit assembly connections**


### Key to components

- |     |   |      |   |
|-----|---|------|---|
| 1   | Left front light cluster                                  | 96   | Earth on carrier  |
| 2   | Left fog lamp   | 97   | Earth on floor pan  |
| 3   | Left front earth  | 100  | Connection between fascia lead and left longitudinal lead               |
| 7   | Battery   | 102  | Exterior lighting unit  |
| 8   | Main junction unit  | 103  | Switch control unit   |
| 9   | Earth on body   | 104  | Stalk unit  |
| 12  | Low brake fluid level indication sensor                   | 105  | Ignition switch   |
| 27  | Right front earth   | 117  | Hand brake warning light switch   |
| 29  | Right fog lamp  | 119B | Connection between fascia cable and right longitudinal cable            |
| 30  | Right front light cluster                                 | 131  | Earth on steering column mount  |
| 31  | Peripheral ECU (engine bay)                               | 165  | Heated rear windshield  |
| E1  | Dipped beam relay   | 165A | Earth for heated rear windshield  |
| E5  | Fog lamp relay  | 171  | Amplifier for aerial on back window                                     |
| 32B | Connection between fascia cable and left engine bay cable | 172  | Right tail-light cluster on fixed part                                  |
| 71  | Tow hook control unit                                     | 173  | Right rear earth  |
| 73  | Secondary junction unit                                   | 174  | Right tail-light cluster on mobile part                                 |
| 73A | 80A fuse protecting I.G.E. control unit/function unit     | 175  | Connection between left longitudinal cable and tail-gate cable          |
| 73B | 30A fuse protecting ignition switch/car alarm             | 175S | Left number plate light   |
| 74  | 60A fuse protecting peripheral control unit (engine bay)  | 175D | Right number plate light  |
| 75  | Junction unit (fascia)                                    | 177  | Left tail-light cluster on mobile part                                  |
| 76  | IGE control unit.   | 178  | Left rear earth   |
| 78  | Instrument panel  | 179  | Left tail-light cluster on fixed part                                   |
| C   | Heated rear windshield warning light                      | 180  | Heated back window relay  |
| D   | Fog lights warning light                                  | 181  | Connection between left longitudinal cable and right longitudinal cable |
| E   | Rear fog lamps warning light                              | 189  | 30A fuse for heated rear window   |
| F   | Side lights warning light                                 | 196  | Wiring for trailer  |
| N   | Handbrake warning light / IGE control unit.               | 271  | Braking light switch  |
| O   | Insufficient brake fluid level warning light              | 430  | Handbrake on/low brake fluid level connection diode                     |
| U   | Electronic rev counter                                    | N.D. | Taped ultrasound welding in wiring bundle                               |
| 85  | Infocenter ECU  |      |   |
| 88  | Tester socket for Fiat/Lancia tester                      |      |   |

88 Tester socket for Fiat/Lancia tester




78A Instrument panel




88


**119B** Connection between facia cable and right longitudinal cable




**175** Connection between left longitudinal cable and tail-gate cable



**119A** Connection between facia cable and right longitudinal cable




196 Provision for trailer



\* Wires involved in the wiring diagram are marked with an asterisk



Instrument panel connections - (See key following diagrams)




\* Connection variant for 2959 version  
 \*\* Variant for version 2387 Td  
 \*\*\* Variant for version 1995 T / 2959

Updates diagram on page 75

PIRELLA









PSU/70AN01

### Instrument panel connections

#### Key to components

- 3 Left front earth
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 12 Low brake fluid level indication sensor
- 14 Pulse generator for speedometer signal
- 20 Alternator
- 22 Engine coolant temperature sender unit
- 23 Minimum engine oil pressure indicator sensor
- 26 Three stage pressure switch
- 31 Peripheral ECU (engine bay)
- E1 Dipped beam relay
- E4 Main beam relay
- E6 Cooling fan high speed relay
- E7 Cooling fan low speed relay
- 32A Connection between facia cable and left engine bay cable
- 32B Connection between facia cable and left engine bay cable
- 33A Connection between facia cable and right engine bay cable
- 34 Anti-lock brake hydraulic control unit (A.B.S.)
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 72 Fuel injection control unit
- 72A Fuel pump ECU (2387 Td)
- 73 Secondary junction unit
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (facia)
- E2 Turn signal/hazard warning light flasher
- 76 IGE control unit
- 78 Instrument panel
- 85 Infocenter ECU
- 88 Tester socket for Fiat/Lancia tester
- 96 Earth on carrier
- 97 Earth on floor pan
- 100 Connection between facia lead and left longitudinal lead
- 101 Lighting dimmer
- 105 Ignition switch
- 117 Hand brake warning light switch
- 119B Connection between facia cable and r. longitudinal cable
- 119C Connection between facia cable and l. longitudinal cable
- 119D Connection between facia lead and right front door lead
- 131 Earth on steering column mount
- 167 Fuel level gauge
- 183 Relay for driver's side heat pad
- 184 Relay for passenger's side heat pad
- 198 Servotronic device electronic control unit
- 200 Electronic variable rate suspension control unit
- 271 Braking light switch
- 274 Connection between facia cable and air bag lead
- 275 Air-bag ECU
- 302 Switch control assembly
- 315 Electronic automatic transmission speed selection control unit (ZF)
- 318 Connection between electronic automatic transmission lead and facia lead
- 320 Electronic automatic transmission speed selection lever display
- 344 Facia cable connection with anti-lock brake cable (A.B.S.)
- 401 Electronic automatic transmission speed selection control unit (AISIN)
- 430 Handbrake on/low brake fluid level connection diode
- N.D. Taped ultrasound welding in wiring bundle




\* Wires involved in the wiring diagram are marked with an asterisk

PSU/147N01






Windscreen wash/wipe - Headlamp washer - Electric horns - (See key following diagrams)






55.



Windscreen wash/wipe - Headlamp washer - Electric horns

Key to components


- 3 Front left earth
- 4 Electric horns
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 27 Front right earth
- 28 Headlamp washer pump
- 31 Peripheral control unit (engine compartment)
- E1 Dipped beam relay
- E2 Horn relay
- 32B Connection between dashboard cable/left engine bay cable
- 33A Connection between dashboard cable/right engine bay cable
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- E1 Ignition switch discharge relay
- E2 Direction indicators / hazard warning lights intermittent switch
- 76 I.G.E. control unit
- 80 Power earth on dashboard
- 83 Windscreen wiper control assembly
- 102 External lights controls
- B Side lights / number plate lights switch
- C Dipped beam / main beam headlamps switch
- D Parking lights switch
- E Symbols illumination switch
- 104 Stalk unit
- A Windscreen washer / headlamp washer switch
- B Windscreen wiper switch
- C Horn button
- D Direction indicators / parking lights switch
- E Main beam headlamps flasher button
- F Main beam headlamps switch
- 105 Ignition switch
- 131 Earth on steering column mounting
- 342 Electric windscreen washer pump
- 345 Front right earth
- N.D. Ultrasound-soldered joint taped into wiring loom



\* The relevant cables on the wiring diagram are marked with an asterisk




Car interior lighting - (See key following diagrams)





55.




Car interior lighting


Key to components

- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboard)
- 79 Connection between dashboard cable/courtesy light cable
- 87 Glove compartment lighting / boot unlock controls
- 90 Connection between dashboard cable/front left door cable
- 93 Puddle light on front left door
- 95 Front left door locking motor, front left door open indicator and anti-theft device on switch
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard cable/left longitudinal cable
- 105 Ignition switch
- 120 Connection between dashboard cable/front right door cable
- 124 Puddle light on front right door
- 126 Front right door locking motor, front right door open indicator and anti-theft device on switch
- 128 Front courtesy light timer
- 131 Earth on steering column mounting
- 137 Boot lock assembly
- 141 Connection between right longitudinal cable/rear right door cable
- 144 Puddle light on rear right door
- 146 Rear right door locking motor, rear right door open indicator and anti-theft device on switch
- 150 Connection between left longitudinal cable/rear left door cable
- 153 Puddle light on rear left door
- 155 Rear left door locking motor, rear left door open indicator and anti-theft device on switch
- 162 Boot light
- 163 Rear left courtesy light
- 170 Rear right courtesy light
- 173 Rear right earth
- 175 Connection between left longitudinal cable/boot cable
- 176 Boot cables connection
- 178 Rear left earth
- 181 Connection between left longitudinal cable/right longitudinal cable
- 225 Left floor light
- 226 Right floor light
- 281 Front courtesy light
- 283 Illuminated sunshade, passenger's side
- N.D. Ultrasound-soldered joint taped into wiring loom


79 Connection between dashboard cable/courtesy light cable




141 Connection between right longitudinal cable/rear right door cable



150 Connection between left longitudinal cable/rear left door cable



175 Connection between left longitudinal cable/boot cable




\* The relevant cables on the wiring diagram are marked with an asterisk

P3U078N01






Fuel level gauge and reserve warning light - Handbrake warning light - Low brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Total mileage counter/trip recorder and reset button - Rev counter - (See key following diagrams)



\* Variant connections for 2959 version

\*\* Variant connections for Turbo D version






Fuel level gauge and reserve warning light - Handbrake warning light - Low brake fluid level warning light - Seat belt unlatched warning light - Speedometer - Total mileage counter / trip recorder and reset button - Rev counter

Key to components


- 3 Front left earth
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 12 Low brake fluid level sensor
- 14 Pulse generator for speedometer signal
- 32B Connection between dashboard cable/left engine bay cable
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73C 30A fuse protecting I.G.E. control unit / junction unit
- 75 Junction unit (dashboard)
- 76 I.G.E. control unit
- 78 Instrument panel
- J Seat belt undone warning light
- N Handbrake warning light / I.G.E. control unit
- O Low brake fluid level warning light
- U Electronic rev counter
- V Fuel gauge
- V1 Fuel reserve warning light
- X Total mileage counter / trip recorder
- Y Electronic speedometer
- Z1 Trip computer reset button
- 88 Diagnostic socket for Fiat / Lancia tester
- 96 Earth on carrier
- 97 Earth on floor
- 99 Cigar lighter
- 100 Connection between dashboard cable/left longitudinal cable
- 105 Ignition switch
- 117 Handbrake on warning light switch
- 119D Connection between dashboard cable/right longitudinal cable
- 131 Earth on steering column mounting
- 167 Fuel gauge sender unit
- 200 Controlled damping suspension control unit
- 271 Stop lights switch

N.D. Ultrasound-soldered joint taped into wiring loom


32B Connection between dashboard cable/left engine bay cable




68 Connection between dashboard cable/fuel injection cable



100 Dashboard cable/left longitudinal cable connection




119D Connection between dashboard cable/right longitudinal cable



\* The relevant cables on the wiring diagram are marked with an asterisk




Electric front windows - (See key following diagrams)





55.




## Electric front windows

### Key to components


- 7 Battery
  - 8 Main connector block
  - 9 Earth on body shell
  - 73 Secondary connector block
  - 73B 60A fuse protecting I.G.E. control unit / junction unit
  - 73C 30A fuse protecting ignition switch/anti-theft device
  - 75 Junction unit (dashboard)
  - 90 Connection between dashboard cable/front left door cable
  - 92 Electric front windows / electric rear windows pushbutton unit on front left door
  - 94 Front left electric window motor
  - 96 Earth on carrier
  - 97 Earth on floor
  - 102 External lights controls
    - B Side lights / number plate lights switch
    - C Dipped beam / main beam headlamps switch
    - D Parking lights control switch
    - E Symbols illumination switch
  - 105 Ignition switch
  - 120 Connection between dashboard cable/front right door cable
  - 123 Front right electric window pushbutton unit on front right door
  - 125 Front right electric window motor
  - 298 Electric front windows control unit
- N D. Ultrasound-soldered joint taped into wiring loom

N.D. Ultrasound-soldered joint taped into wiring loom

Connection between dashboard cable/front left door cable



**120** Connection between dashboard cable/front right door cable




\* The relevant cables on the wiring diagram are marked with an asterisk





Electric rear windows - (See key following diagrams)




\* See symbols illumination wiring diagram






## Key to components

- N.D. Ultrasound-soldered joint taped into wiring loom











55.



Symbol illumination - Heated rear window and warning light

### Key to components

- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboard)
- 76 I.G.E. control unit
- 78 Instrument panel
- C Heated rear window warning light
- F1 Instrument panel lighting bulbs
- U Electronic rev counter
- 85 Infocenter control unit
- 96 Earth on carrier
- 97 Earth on floor
- 98 Ashtray light
- 99 Cigar lighter
- 101 Lighting brightness adjustment rheostat
- 102 External lights controls
- B Side lights / number plate lights switch
- C Dipped beam / main beam headlights switch
- D Parking lights switch
- E Symbols lights switch
- 103 Switch control assembly
- A Fog lamps control switch
- B Rear fog lamps switch
- C Headlamp adjustment device
- 105 Ignition switch
- 119A Connection between dashboard cable/right longitudinal cable
- 119B Connection between dashboard cable/right longitudinal cable
- 131 Earth on steering column mounting
- 165 Heated rear window
- 165A Earth for heated rear window
- 166 Amplifier for aerial built into rear window
- 180 Heated rear window relay
- 189 30A fuse protecting heated rear window
- 290 Front left air vent controls illumination
- 291 Central left air vent controls illumination
- 292 Central right air vent controls illumination
- 293 Front right air vent controls illumination
- 295 Radio cables connection
- N.D. Ultrasound-soldered joint taped into wiring loom




\* The relevant cables on the wiring diagram are marked with an asterisk






Electrically adjustable, heated and tilting external rearview mirror - (See key following diagrams)



- \* See starting system wiring diagram
- \*\* See heated rear window wiring diagram
- \*\*\*\* See symbol illumination wiring diagram



55.




Electrically-adjustable, heated and tilting external rearview mirrors - Electrochromic internal rearview mirror

### Key to components


- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 13 Reversing lights switch
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboard)
- 79 Ignition switch discharge relay
- 85 Infocenter control unit
- 89 Left rearview mirror
- 90 Left rearview mirror tilting motor
- 96 Earth on carrier
- 105 Ignition switch
- 115 Electrically-adjustable rearview mirror controls
- 119B Connection between dashboard cable/right longitudinal cable
- 120 Connection between dashboard cable/front right door cable
- 121 Right rearview mirror
- 121A Right rearview mirror tilting motor
- 121B Right rearview mirror vertical adjustment motor
- 121C Right rearview mirror horizontal adjustment motor
- 121D Right rearview mirror heating element
- 131 Earth on steering column mounting
- 180 Heated rear window relay
- 282 Internal electrochromic rearview mirror

N.D. Ultrasound-soldered joint taped into wiring loom


79 Connection between dashboard cable/courtesy light cable



90 Connection between dashboard cable/front left door cable




119B Connection between dashboard cable/right longitudinal cable




\* The relevant cables on the wiring diagram are marked with an asterisk








Central door locking and doors open indication - (See key following diagrams)







55.




Central door locking and door open indication

### Key to components

- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 23 Low engine oil pressure sensor
- 32B Connection between dashboard cable/left engine bay cable
- 69 Engine services cable connection
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboard)
- 85 Infocenter control unit
- 87 Glove compartment light / boot unlock controls
- 90 Connection between dashboard cable/front left door cable
- 95 Front left door locking motor, front left door open indicator and anti-theft device on switch
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard cable/left longitudinal cable
- 105 Ignition switch
- 107 Anti-theft device control unit
- 119A Connection between dashboard cable/right longitudinal cable
- 119B Connection between dashboard cable/right longitudinal cable
- 120 Connection between dashboard cable/front right door cable
- 126 Front right door locking motor, front right door open indicator and anti-theft device on switch
- 131 Earth on steering column mounting
- 137 Boot lock assembly

PSU/06/01




\* The relevant cables on the wiring diagram are marked with an asterisk

PSU/07/01




Electrically-adjustable and heated front seats - Driver's seat with memory - (See key following diagrams)



\* See symbol illumination wiring diagram

\*\* See starting system wiring diagram






Electrically-adjustable and heated front seats - Driver's seat with memory


Key to components

- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 75 Junction unit (dashboard)
- 78 Ignition switch discharge relay
- 78 Instrument panel
- B Driver's heated seat warning light
- BI Passenger's heated seat warning light
- 119A Connection between dashboard cable/right longitudinal cable
- 119B Connection between dashboard cable/right longitudinal cable
- 119C Connection between dashboard cable/right longitudinal cable
- 131 Earth on steering column mounting
- 138 Electronic control unit for driver's electrically-adjustable seat with memory
- 138A Pushbutton unit for driver's electrically-adjustable seat
- 138B Driver's squab adjustment motor
- 138C Driver's seat height adjustment motor
- 138D Driver's seat height adjustment motor
- 138E Driver's forward/backward adjustment motor
- 138F Pushbutton unit for driver's seat memory control
- A Boot switch and anti-theft device on switch
- B Boot lock/unlock motor
- 139 Driver's seat heating pad
- 140 Switch for driver's seat heating pad
- 148 Connection between left longitudinal cable/left seat cable
- 149 Connection between left longitudinal cable/left seat cable
- 156 Connection between right longitudinal cable/right seat cable


119C Dashboard cable/right longitudinal cable connection




148 Connection between left cable/right seat cable




157 Connection between right longitudinal cable/right seat cable



149 Connection between left longitudinal cable/left seat cable



156 Connection between right longitudinal cable/right seat cable




\* The relevant cables on the wiring diagram are marked with an asterisk

PAJ111101



Petrol versions

Automatic air conditioner - (See key following diagrams)



\* Variant connections for 1998/2446 model

\*\* Model 2959 only


\*\*\* See starting system diagram

\*▲ Model 1998 T only





55.




Petrol versions: Automatic air conditioner

### Key to components


- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 11 Air conditioner compressor coupling
- 17 1st engine cooling fan
- 18 Engine cooling fan speed resistor
- 22 Engine coolant temperature sender unit
- 26 Three-stage pressure switch
- 27 Front right earth
- 31 Peripheral control unit (engine compartment)
- E3 Compressor coupling relay
- E6 Engine cooling fan high speed relay
- E7 Engine cooling fan low speed relay
- 32A Connection between dashboard cable/fuel injection cable
- 32B Connection between dashboard cable/fuel injection cable
- 33A Dashboard cable/right engine bay cable connection
- 35 Connection between engine bay cable/electronic fuel injection cable
- 68 Connection between dashboard cable/fuel injection cable
- 69 Engine services cable connection
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- E1 Ignition switch discharge relay
- 78 Instrument panel

- W Water temperature gauge
- W1 Maximum coolant temperature warning light
- 80 Power earth on dashboard
- 81 Climate control fan (brushless)
- 82 Air recirculation motor
- 84 Single-stage pressure switch (3000 i.e.)
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 89 Left rearview mirror
- A Left rearview mirror tilting motor
- B Left rearview mirror vertical adjustment motor
- C Left rearview mirror horizontal adjustment motor
- D Left rearview mirror heating element
- 90 Connection between dashboard cable/front left door cable
- 96 Earth on carrier
- 97 Earth on floor
- 105 Ignition switch
- 109D Distribution / mixing motor
- 109M Distribution / mixing motor
- 110 Car interior air temperature sensor
- 111 Mixed air sensor 1
- 112 Mixed air sensor 2
- 131 Solar temperature sensor
- 131 Earth on steering column mounting
- N.D. Ultrasound-soldered joint taped in wiring loom


32B Connection between dashboard cable/left engine bay cable




33A Dashboard cable/right engine bay cable connection




68 Connection between dashboard cable/fuel injection cable



85D Infocenter control unit



88 Diagnostic socket for Fiat/Lancia tester




\* The relevant cables on the wiring diagram are marked with an asterisk



Diesel versions


Automatic air conditioner - (See key following diagrams)



\* See starting system wiring diagram



55.




Diesel versions: Automatic air conditioner


### Key to components

- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 11 Air conditioner compressor coupling
- 17 1st engine cooling fan
- 17A 2nd engine cooling fan
- 18 Engine coolant fan speed resistor
- 22 Engine coolant temperature sender unit
- 26 Three-stage pressure switch
- 27 Front right earth
- 31 Peripheral control unit (engine compartment)
- E3 Compressor coupling relay
- E6 Engine cooling fan high speed relay
- E7 Engine cooling fan low speed relay
- 32A Connection between dashboard cable/left engine bay cable
- 32B Connection between dashboard cable/right engine bay cable
- 33A Connection between dashboard cable/right engine bay cable
- 35 Connection between engine bay cable/electronic fuel injection cable
- 68 Connection between dashboard cable/fuel injection cable (T.D.)
- 72A Fuel pump electronic fuel injection control unit (2400 unit)
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- E1 Ignition switch discharge relay
- 78 Instrument panel
- W Water temperature gauge
- W1 Maximum coolant temperature warning light
- 80 Power earth on dashboard
- 81 Climate control fan (brushless)
- 82 Air recirculation motor
- 84 Single-stage pressure stage (3000 i.e.)
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 89 Left rearview mirror
- A Left rearview mirror tilting motor
- B Left rearview mirror vertical adjustment motor
- C Left rearview mirror horizontal adjustment motor
- D Left rearview mirror heating element
- 90 Connection between dashboard cable/front left door cable
- 96 Earth on carrier
- 97 Earth on floor
- 105 Ignition switch
- 109D Distribution / mixing motor
- 109M Distribution / mixing motor
- 110 Car interior air temperature sensor
- 111 Mixed air sensor 1
- 112 Mixed air sensor 2
- 113 Solar temperature sensor
- 131 Earth on steering column mounting
- N D. Ultrasound-soldered joint taped in wiring loom


32B Connection between dashboard cable/left engine bay cable




33A Dashboard cable/right engine bay cable connection




68 Connection between dashboard cable/fuel injection cable



17A 2nd engine cooling fan



88 Diagnostic socket for Fiat/Lancia tester




\* The relevant cables on the wiring diagram are marked with an asterisk



Model: 1998


Automatic transmission (Aisin) - (See key following diagrams)







55.




1998 model: Automatic transmission (Aisin)


### Key to components

- 3 Front left earth
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 13 Reversing lights switch
- 15 Starter motor
- 32B Connection between dashboard cable/left engine bay cable
- 68 Connection between dashboard cable/fuel injection cable
- 69 Engine services cable connection
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73C 30A fuse protecting ignition switch/anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- 75 Ignition switch discharge relay
- 78 Instrument panel
- 85 Infocenter control unit
- 90 Connection between dashboard cable/front left door cable
- 95 Front left door locking motor, front left door open indicator and anti-theft device on switch
- 105 Ignition switch
- 131 Earth on steering column mounting
- 171 Additional stop lights indicator
- 174 Rear right lights cluster on moving part
- 175 Connection between left longitudinal cable/boot cable
- 177 Rear left lights cluster on moving part
- 178 Rear left earth
- 306 Horn, electronic automatic transmission
- 307 Electronic automatic transmission horn switch
- 316 Electronic automatic transmission diagnostic socket
- 317 Connection between automatic gearbox cable/fuel injection cable
- 318 Connection between electronic automatic transmission cable/dashboard cable
- 319 Kick-Down wiring
- 320 Embellishments on electronic automatic transmission gearchange lever
- 343 40A starter relay
- 401 Electronic automatic transmission (AISIN) gear selection control unit
- 412 Earth on bodywork
- 413 Connection to solenoid assembly
- 414 Throttle valve position potentiometer
- 415 Gear position selector
- 416 Gear position selector
- 417 Engine rpm sensor
- 418 Vehicle speed sensor
- 420 Automatic transmission fluid temperature sensor
- N.D. Ultrasound-soldered joint taped in wiring loom


69 Engine services cable connection




175 Connection between left longitudinal cable/boot cable



317 Connection between electronic automatic transmission/fuel injection cable



318 Connection between electronic automatic transmission/dashboard cable




\* The relevant cables on the wiring diagram are marked with an asterisk

PSU122N07




Model: 2959

Automatic transmission (ZF) - (See key following diagrams)





55.




2959 model: Automatic transmission (ZF)

### Key to components


- 3 Front left earth
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 13 Reversing lights switch
- 15 Starter motor
- 32B Connection between dashboard cable/left engine bay cable
- 68 Connection between dashboard cable/fuel injection cable
- 69 Engine services cable connection
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73C 30A fuse protecting ignition switch/anti-theft device (engine compartment)
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- E1 Ignition switch discharge relay
- 78 Instrument panel
- U Electronic rev counter
- Y Electronic speedometer
- Z Electronic automatic transmission gear selection display
- 85 Infocenter control unit
- 90 Connection between dashboard cable/front left door cable
- 95 Front left door locking motor, front left door open indicator and anti-theft device on switch
- 96 Earth on carrier
- 105 Ignition switch
- 131 Earth on steering column mounting
- 174 Rear right lights cluster on moving part
- 175 Connection between left longitudinal cable/boot cable
- 178 Rear left lights cluster on moving part
- 301 Solenoids assembly
- 302 Switch control assembly
- 306 Horn, electronic automatic transmission

P3U128N01


68 Connection between dashboard cables/fuel injection cables




175 Connection between left longitudinal cable/boot cable



317 Connection between electronic automatic transmission cable/fuel injection cable



318 Connection between electronic automatic transmission cable/dashboard cable




\* The relevant cables on the wiring diagram are marked with an asterisk

P3U128N01



Anti-theft device - (See key following diagrams)



\* Variant connections for 1998 - 1998 16V - 2446 models

\*\* Variant connections for Turbo D model

\*\*\* See central door locking wiring diagram


▲▲ See direction indicators wiring diagram

\*\*\* See starting system wiring diagram






55.




P3UJ30N01


68 Connection between dashboard cable/fuel injection cable




100 Dashboard cable/left longitudinal cable connection



175 Connection between left longitudinal cable/boot cable



269 Connection between dashboard cable/receiver cable




\* The relevant cables on the wiring diagram are marked with an asterisk

P3UJ30N01




Complete Infocenter - (See key following diagrams)



\* Variant connections for 2959 model  
 \*\* Variant connections for 1998 16V Turbo model  
 \*\*\* Variant connections for 2446 Turbo D model  
 ▲ See symbol illumination wiring diagram  
 \*\*▲ Not present on 1998 T - 2959 model






### Complete Infocenter


#### Key to components

- 3 Front left earth
- 5 Front left brake pad wear sensor
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 21 Low engine oil level sensor
- 32A Connection between dashboard cable/left engine bay cable
- 32B Connection between dashboard cable/left engine bay cable
- 32C Connection between dashboard cable/left engine bay cable
- 33A Connection between dashboard cable/right engine bay cable
- 68 Connection between dashboard cable/fuel injection cable
- 69 Engine services cable connection
- 72 Fuel injection control unit
- 72A Fuel pump electronic control unit (2400 T.D.)
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboards)
- E2 Direction indicators / hazard lights intermittent switch
- 76 I.G.E. control unit
- 78 Instrument panel
- I Check panel summary warning light
- U Electronic rev counter
- Y Electronic speedometer
- Z Electronic automatic transmission gear selection display
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 90 Connection between dashboard cable/front left door cable
- 95 Front left door locking motor, front left door open indicator and anti-theft device on switch
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard cable/left longitudinal cable
- 101 Illumination brightness adjustment rheostat
- 105 Ignition switch
- 119D Connection between dashboard cable/right longitudinal cable
- 120 Connection between dashboard cable/front right door cable
- 126 Front right door locking motor, front right door open indicator and anti-theft device on switch
- 131 Earth on steering column mounting
- 137 Boot lock assembly
- 141 Connection between right longitudinal cable/rear right door cable
- 146 Rear left door locking motor, rear right door indicator and anti-theft device on switch
- 150 Connection between left longitudinal cable/rear left door cable
- 155 Rear left door locking motor, rear left door open indicator and anti-theft device on switch
- 173 Rear right earth
- 175 Connection between left longitudinal cable/boot cable
- 176 Boot cables connection
- 178 Rear left earth
- 200 Controlled damping suspension electronic control unit
- 340 Front right brake pad wear sensor
- 343 40A starter relay
- 346 Low engine coolant sensor
- 347 Turbo overpressure sender
- 386 Connection for cables to water-in-diesel filter sensor
- N.D. Ultrasound-soldered joint taped in wiring loom


32A Connection between dashboard cable/left engine bay cable




32B Connection between dashboard cable/left engine bay cable



33A Dashboard cable/right engine bay cable connection



175 Connection between left longitudinal cable/boot cable




\* The relevant cables on the wiring diagram are marked with an asterisk

PSU134N01



Complete I.G.E. unit connections - (See key following diagrams)




\* See heated rear window wiring diagram  
\*\* See towhook wiring diagram






55.



Complete I.G.E. unit connections

### Key to components


- 1 Front left lights cluster
- 2 Front left fog lamp
- 3 Front left earth
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 27 Front right earth
- 29 Front right fog lamp
- 30 Front right lights cluster
- 31 Peripheral control unit (engine compartment)
- E1 Dipped beam relay
- E5 Front fog lamp relay
- 32B Connection between dashboard cable/left engine bay cable
- 71 Towhook control unit
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- 76 I.G.E. control unit
- 78 Instrument panel
- C Heated rear window warning light
- D Front fog lamps warning light
- E Rear fog lamps warning light
- F Side lights warning light
- N Handbrake warning light / I.G.E. control unit
- U Electronic rev counter
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard cable/left longitudinal cable
- 102 External lights controls
- 103 Switches control assembly
- 104 Stalk unit
- 105 Ignition switch
- 117 Handbrake on warning light switch
- 119B Connection between dashboard cable/right longitudinal cable
- 131 Earth on steering column mounting
- 165 Heated rear window
- 165A Earth for heated rear window
- 166 Amplifier for aerial built into rear window
- 171 Additional stop lights indicator
- 172 Rear right lights cluster on fixed part
- 173 Rear right earth
- 174 Rear right lights cluster on moving part
- 175 Connection between left longitudinal cable/boot cable
- 175D Right number plate light
- 175S Left number plate light
- 177 Rear left lights cluster on moving part
- 178 Rear left earth
- 179 Rear left lights cluster on fixed part
- 180 Heated rear window relay
- 181 Connection between left longitudinal cable/right longitudinal cable
- 189 30A fuse protecting heated rear window
- 196 Trailer wiring
- 271 Braking light switch
- N.D. Ultrasound-soldered joint taped in wiring loom



\* The relevant cables on the wiring diagram are marked with an asterisk




Controlled damping suspension system (C.D.S.) - (See key following diagrams)






55.



Controlled damping suspension system (C.D.S.)

Key to components

- 7 Battery
  - 8 Main connector block
  - 9 Earth on body shell
  - 73 Secondary connector block
  - 73C 30A fuse protecting ignition switch/anti-theft device
  - 75 Junction unit (dashboard)
  - 78 Instrument panel
  - 85 Electronic speedometer
  - 105 Y1 C.D.S. switch unit
  - 114 Infocenter control unit
  - 119D Connection between dashboard cable/front right door cable
  - 119E Connection between right longitudinal cable/right engine bay cable
  - 173 Rear right earth
  - 200 Controlled damping suspension (C.D.S.) control unit
  - 220A 7.5A fuse protecting C.D.S. system
  - 221 Rear left controlled damping suspension motor
  - 222 Rear right controlled damping suspension motor
  - 321 Front left controlled damping suspension motor
  - 322 Front right controlled damping suspension motor
  - 323 Accelerometer for controlled damping suspension
- N.D. Ultrasound-soldered joint taped in wiring loom




\* The relevant cables on the wiring diagram are marked with an asterisk

P3U142N01



**Instrument panel connections - (See key following diagrams)**




\* Variant connections for 2959 model

\* Variant connections for Turbo D model

\* Variant connections for 1998 Turbo / 2959 model








Instrument panel connections

### Key to components


- 3 Front left earth
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 12 Low brake fluid level sensor
- 14 Pulse generator for speedometer signal
- 20 Alternator
- 22 Engine coolant temperature sender unit
- 23 Low engine oil pressure sensor
- 26 Three-stage pressure switch
- 31 Peripheral control unit (engine compartment)
- E1 Dipped beam relay
- E4 Main beam relay
- E6 Engine cooling fan high speed control relay
- E7 Engine cooling fan low speed control relay
- 32A Connection between dashboard cable/left engine bay cable
- 32B Connection between dashboard cable/left engine bay cable
- 33A Dashboard cable/right engine bay cable connection
- 34 Anti-lock braking system (A.B.S.) electrohydraulic control unit
- 68 Connection between dashboard cable/fuel injection cable
- 69 Engine services cable connection
- 72 Fuel injection control unit
- 72A Fuel pump electronic control unit (2400 T.D.)
- 73 Secondary connector block
- 73B 60A fuse protecting I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/anti-theft device
- 75 Junction unit (dashboard)
- E2 Direction indicators / hazard lights intermittent switch
- 76 I.G.E. control unit
- 78 Instrument panel
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard cable/left longitudinal cable
- 101 Illumination brightness adjustment rheostat
- 105 Ignition switch
- 119B Connection between dashboard cable/right longitudinal cable
- 119C Connection between dashboard cable/right longitudinal cable
- 119D Connection between dashboard cable/right longitudinal cable
- 131 Earth on steering column mounting
- 167 Fuel gauge sender unit
- 183 Driver's seat heating pad relay
- 184 Passenger seat heating pad relay
- 198 Servotronic electronic control unit
- 200 Controlled damping suspension (C.D.S.) electronic control unit
- 271 Stop lights switch
- 274 Dashboard cable/Air Bag cable connection
- 275 Air Bag control unit
- 302 Switches control assembly
- 315 Electronic automatic transmission (ZF) gear selection control unit
- 318 Connection between electronic automatic transmission cable/dashboard cable
- 320 Embellishments on electronic automatic transmission gearchange lever
- 344 Connection between dashboard cable/anti-lock braking system (A.B.S.) cable
- 401 Electronic automatic transmission (AISIN) gear selection control unit

N.D. Ultrasound-soldered joint taped in wiring loom


32B Connection between dashboard cable/left engine bay cable




119D Dashboard cable/right longitudinal cable connection




274 Connection between dashboard cable/Air Bag cable



344 Connection between dashboard cable/anti-lock braking system (A.B.S.) cable



318 Connection between electronic automatic transmission cable/dashboard cable




\* The relevant cables on the wiring diagram are marked with an asterisk

PAUT17NOT




Junction unit (on dashboard) - (See key following diagrams)



P3U149N01

# 55.

Peripheral control unit (on engine compartment) - (See key following diagrams)



P3U150N01

## CONNECTOR BLOCKS - CONTENTS

	page
- INTRODUCTION	80
- Interpretation of the codes on the connector blocks	80
- Wiring colour code	80
- Connector blocks	81






**CONNECTOR BLOCKS - CONTENTS**

	page
- INTRODUCTION	80
- Interpretation of the codes on the connector blocks	80
- Wiring colour code	80
- Connector blocks	81

55.

### INTRODUCTION

#### Interpretation of the codes on the connector blocks



P3U152N01

- A Connector block identification number referring to the wiring diagrams
- B Cable colour identification code (see table at bottom of page)
- C Identification number of the destination block of the cable marked with the relevant code
- D The code n.d. identifies a connector block taped into the wiring loom


#### Cable colour codes

A	Light blue	BG	White-Yellow	LB	Blue-White
B	White	BL	White-Blue	LG	Blue-Yellow
C	Orange	BN	White-Black	LN	Blue-Black
G	Yellow	BR	White-Red	LR	Blue-Red
H	Grey	BV	White-Green	LV	Blue-Green
L	Blue	BZ	White-Violet	MB	Brown-White
M	Brown	CA	Orange-Light blue	MN	Brown-Black
N	Black	CB	Orange-White	NZ	Black-Violet
R	Red	CN	Orange-Black	RB	Red-White
S	Pink	GN	Yellow-Black	RG	Red-Yellow
V	Green	GL	Yellow-Blue	RN	Red-Black
Z	Violet	GR	Yellow-Red	RV	Red-Green
AB	Light blue-White	GV	Yellow-Green	SN	Pink-Black
AG	Light blue-Yellow	HG	Grey-Yellow	VB	Green-White
AN	Light blue-Black	HN	Grey-Black	VN	Green-Black
AR	Light blue-Red	HR	Grey-Red	VR	Green-Red
AV	Light blue-Green	HV	Grey-Green	ZB	Violet-White




### Connector blocks


#### 1 Front left lights cluster




#### 2 Front left fog lamp




#### 3 Front left earth




#### 3A Front left earth for anti-lock braking system (A.B.S.)



#### 5 Front left brake pad wear sensor











#### 4 Electric horns











P3U153N01

55.









<p><b>6</b> Left side repeater</p>  <p>L 75I N 3</p>	<p><b>7</b> Battery</p>  <p>R 15 R 8 N 9</p>
<p><b>8</b> Main connector block</p>  <p>R 64 (TDs) R 7 R 161 (3000) R n.d. R 74</p>	<p><b>9</b> Earth on body shell</p>  <p>N n.d. N 58 N 7</p>
<p><b>9A</b> Earth on side for anti-lock braking system (A.B.S.)</p>  <p>N n.d.</p>	<p><b>10</b> Button on bonnet for switching on anti-theft device</p>  <p>CN 32A N 3</p>
<p><b>11</b> Air conditioner compressor coupling</p>  <p>VG 31</p>	<p><b>11</b> Air conditioner compressor coupling (1998 T only)</p>  <p>VG 69</p>

P3U154N01

<p><b>12</b> Low brake fluid level sensor</p> 	<p><b>13</b> Reversing lights switch</p> 
<p><b>14</b> Pulse generator for speedometer signal</p> 	<p><b>15</b> Starter motor</p> 
<p><b>17</b> 1st engine cooling fan</p> 	<p><b>17A</b> 2nd engine cooling fan</p> 
<p><b>18</b> Engine cooling fan speed resistor</p> 	<p><b>19</b> Sensor on front left wheel for anti-lock braking system (A.B.S.)</p> 

P3U155N01


55.

<p><b>20</b> Alternator (1998 - 2446 - Tds only)</p> 	<p><b>20</b> Alternator (2959 - 1998 T only)</p> 
<p><b>21</b> Low engine oil level sensor (1998 - 2446 - Tds only)</p> 	<p><b>21</b> Low engine oil level sensor (2959 - 1998 T only)</p> 
<p><b>22</b> Engine coolant temperature sender unit</p> 	<p><b>23</b> Low engine oil pressure sensor</p> 
<p><b>23</b> Low engine oil pressure sensor (1998 T only)</p> 	<p><b>24</b> Barometric capsule (1998 T only)</p> 

P3U156N01


**25**

Air temperature sensor (1998 - 2446 - 2959 - 1998 T only)




**26**

Three-stage pressure switch




**27**

Front right earth




**28**

Headlamp washer pump




**30**

Front right lights cluster








**29**

Front right fog lamp




55.

<div><div>31</div><div>Peripheral control unit</div><div><div><div>M 2</div><div>HN 1</div><div>Z 4</div><div>NZ 35</div><div>RN 32A</div><div>V 30</div><div>AV 32B</div><div>H 30</div><div>HV 32B</div><div>GR n.d.</div></div><div><div>MB 29</div><div>N 3</div><div>LV 1</div><div>LR 32B</div><div>HR 76D</div><div>AR 32B</div><div>BR 32B</div><div>B 76D</div><div>BN 32B</div></div></div></div>	
<div><div>31</div><div>Peripheral control unit</div><div><div><div>VG 11</div><div>VN 18</div></div><div></div></div></div>	<div><div>31</div><div>Peripheral control unit (1998 T only)</div><div><div><div>VG 69</div><div>VN 18</div></div><div></div></div></div>
<div><div>31</div><div>Peripheral control unit</div><div><div><div>V 18</div><div>V 17</div></div><div></div></div></div>	<div><div>31</div><div>Peripheral control unit (Tds only)</div><div><div><div>V 17A</div><div>V 17</div><div>V 18</div></div><div></div></div></div>
<div><div>31</div><div>Peripheral control unit</div><div><div><div>R n.d.</div></div><div></div></div></div>	


P3U158N01

## 32A Connection between dashboard cable/left engine bay cable


(1998 - 2446 only)



(2959 - 1998 T only)




(Tds only)




## 32B Connection between dashboard cable/left engine bay cable

(1998 - 2446 - 2959 - Tds only)




(1998 T only)




55.


### 32C Connection between dashboard cable/left engine bay cable



### 33A Connection between dashboard cable/right engine bay cable



### 34 Anti-lock braking system (A.B.S.) electrohydraulic control unit




P3U160N01



**35**

Connection between engine bay cable/fuel injection cable


(1998 - 2446 - 1998 T only)



**35**


Connection between engine bay cable/fuel injection cable (Tds only)

(2959 only)




**36**

Heated Lambda probe (1998 - 2446 only)




**36**

Heated Lambda probe (2959 only)




**36**

Heated Lambda probe (1998 T only)











**37**









Idle adjustment actuator



55.

<p><b>39</b> Inertial switch relay</p>  <p>VN n.d. V 358 BN 369 B 72</p>	<p><b>40</b> E.G.R. solenoid</p>  <p>RN n.d. GV 72</p>
<p><b>40</b> E.G.R. solenoid (Tds only)</p>  <p>R n.d. M 72</p>	<p><b>41</b> Petrol vapour shut-off solenoid</p>  <p>ZB 72 RN n.d.</p>
<p><b>42</b> 30A fuse protecting electronic fuel injection</p>  <p>R n.d. R 73</p>	<p><b>43</b> Electronic earth (1998 - 2446 - 2959 only)</p>  <p>N 55 N 54 N 53 N 56 N 57</p>
<p><b>43</b> Electronic earth (1998 T only)</p>  <p>N 68 N 36 N 72 N 65 N 72</p>	<p><b>43</b> Electronic earth (Tds only)</p>  <p>N 68 N n.d.</p>


P3U162N01

<p><b>44</b> Power earth (1998 - 2446 only)</p> 	<p><b>44</b> Power earth (2959 only)</p> 
<p><b>44</b> Power earth (1998 T only)</p> 	<p><b>45</b> Air flow meter (1998 - 2446 only)</p> 
<p><b>45</b> Air flow meter (2959 only)</p> 	<p><b>45</b> Air flow meter (1998 T only)</p> 
<p><b>45</b> Air flow meter (Tds only)</p> 	<p><b>46</b> 7.5A fuse protecting electronic fuel injection</p> 


P3U163N01

55.


- 47** Sensor on front right wheel for anti-lock braking system (A.B.S.)




- 48** 10A fuse protecting heated Lambda probe and air flow meter relay (1998 - 2446 - 1998 T only)




- 48** 10A fuse protecting heated Lambda probe and air flow meter relay (2959 only)




- 49** Relay for electric fuel pump and heated Lambda probe (1998 - 2446 - 1998 T)




- 49** Relay for electric fuel pump and heated Lambda probe (2959)




- 50** Electronic fuel injection relay (1998 - 2446 - 2959 only)



- 50** Electronic fuel injection relay (1998 T only)




- 50** Electronic fuel injection relay (Tds only)








P3U164N01

### 51 Air flow meter relay (2959 only)









### 53-54-55-56-57

Ignition coils (1998 - 2446 only)



### 52-53-54-55-56-57






Ignition coils (2959 only)



### 55.







#### 58

Fuel injectors (1998 - 2446 only)




#### 58

Fuel injectors (2959 only)




P3U166N01


### 58 Fuel injectors (1998 T only)




### 59 1st knock sensor




### 60 2nd knock sensor




### 61 Engine coolant temperature sensor for electronic fuel injection




### 61 Engine coolant temperature sensor for electronic fuel injection (Tds only)



### 62 Rpm sensor




### 62 Rpm sensor (Tds only)




55.


### 63 Potentiometer on throttle valve




### 63 Potentiometer on throttle valve (2959 only)




### 64 40A fuse protecting plug preheating (Tds only)




### 65 Power module (1998 T only)




### 66 Timing sensor (1998 - 2446 - 1998 T only)



### 66 Timing sensor (2959 only)









### 67 Fuel injection cables connection (1998 T only)



P3U168N01




	<p><b>68</b> Connection between dashboard cable/fuel injection cable (1998 - 2446 only)</p> 
<p><b>68</b> Connection between dashboard cable/fuel injection cable</p> 	<p><b>68</b> Connection between dashboard cable/fuel injection cable (2959 only)</p>  <p><b>68</b> Connection between dashboard cable/fuel injection cable (1998 T only)</p> 
<p><b>70</b> H.T. distributor (1998 T only)</p> 	<p><b>68</b> Connection between dashboard cable/fuel injection cable (Tds only)</p> 


P3U169N01

55.


**69** Engine services cable connection (1998 - 2446 - Tds only)




**69** Engine services cable connection (1998 - 2446 only)




**69** Engine services cable connection (Tds only)



**69** Engine services cable connection (2959 only)




**69** Engine services cable connection (1998 T only)



P3U170N01


72

Fuel injection control unit (1998 - 2446 only)



72

Fuel injection control unit (2959 only)




P3U171N01

55.


72

Fuel injection control unit (1998 T only)









72A

Fuel pump electronic control unit (Tds only)




P3U172N01


### 73 Secondary connector block




### 73A 80A fuse protecting rear services




### 73B 60A fuse protecting I.G.E. control unit/junction unit



### 73C 30A fuse protecting ignition switch/anti-theft device




### 74 60A fuse protecting peripheral control unit




P3U173N01

55.


**75A** Junction unit (dashboard)




**75B** Junction unit (dashboard)




**75C** Junction unit (dashboard)




**75E** Junction unit (dashboard)




**75F** Junction unit (dashboard)




**75G** Junction unit (dashboard)



**75H** Junction unit (dashboard)




**75I** Junction unit (dashboard)




P3U174N01


### 76A I.G.E. control unit




### 76B I.G.E. control unit




### 76C I.G.E. control unit




### 76D I.G.E. control unit




### 76E I.G.E. control unit



### 77 10A fuse protecting anti-lock braking system (A.B.S.)




### 78A Instrument panel




55.


### 78B Instrument panel




### 78C Instrument panel



### 78D Instrument panel




### 78Y1 Instrument panel







### 79 Connection between dashboard cable/courtesy light cable




### 80 Power earth on dashboard




### 81 Climate control fan (brushless)





### 82 Air recirculation motor



### 84 Single-stage pressure switch (2959 only)




### 83 Windscreen wiper control assembly




P3U177N01

55.


### 85A Infocenter control unit




### 85B Infocenter control unit




### 85C Infocenter control unit




### 85D Infocenter control unit




### 85E Infocenter control unit




### 85F Infocenter control unit





### 86 Power earth on dashboard







### 88 Diagnostic socket for Fiat/Lancia tester



### 87 Glove compartment light/boot unlock controls




### 89 Left rearview mirror




55.


### 90 Connection between dashboard cable/front left door cable



### 91 Loudspeaker on front left door




### 92 Front/rear electric windows pushbutton unit on front left door




P3U180N01



**93** Puddle light on front left door




**94** Front left electric window motor




**95** Front left door locking motor, front left door open indicator and anti-theft device on switch




**96** Earth on carrier




**97** Earth on floor



**98** Ashtray light




**99** Cigar lighter




55.


### 100 Connection between dashboard cable/left longitudinal cable




### 101 Illumination brightness adjustment rheostat




### 102 External lights controls



### 103 Switch control assembly




### 104A Stalk unit




P3U182N01


**104B** Stalk unit




**104C** Stalk unit




**104D** Stalk unit




**105** Ignition switch




**106** Immobilizer aerial



**107A** Anti-theft device control unit





**107B** Anti-theft device control unit




55.


### 108 Immobilizer control unit




### 109D Distribution/mixing motor




### 109M Distribution/mixing motor




### 110 Car interior air temperature sensor




### 111 Mixed air sensor 1



### 112 Mixed air sensor 2




### 113 Solar temperature sensor




P3U184N01




### 114 Sensor on steering




### 115 Electrically-adjustable rearview mirror control assembly




### 116 Electric sunroof electronic control unit




### 117 Hand brake on warning light switch




### 118 Electric sunroof motor



### 119A Connection between dashboard cable/right longitudinal cable




### 119C Connection between dashboard cable/right longitudinal cable




P3U185N01

55.


### 119B Dashboard cable/right longitudinal cable connection



### 119D Dashboard cable/right longitudinal cable connection




### 119E Right longitudinal cable/right engine bay cable connection




P3U186N01

## 120 Connection between dashboard/front right door cable




## 121 Right rearview mirror




P3U187N01

55.


### 122 Loudspeaker on front right door




### 123 Front right electric window pushbutton unit on front right door





### 124 Puddle light on front right door




### 125 Front right electric window motor



### 126 Front right door locking motor, front right door open indicator and anti-theft device on switch




### 127 Seat belts unfastened indicator switch




P3U188N01


### 128 Front courtesy light timer




### 129 Electric sunroof limit switch




### 130 Electric sunroof button




### 131 Earth on steering column mounting




### 134 Servotronic solenoid




### 135 Earth on floor (Air Bag signal)



### 136A Electric rear windows control unit




### 136B Electric rear windows control unit




55.


**136C** Electric rear windows control unit




**136D** Electric rear windows control unit




**136E** Electric rear windows control unit




**138** Electronic control unit for driver's electrical-adjustable seat with memory




**138B** Driver's seat squab adjustment motor



**138C** Driver's seat rear height adjustment motor




**138D** Driver's seat front height adjustment motor




P3U190N01


### 138E Driver's seat forward/backward adjustment motor




### 138F Driver's seat memory control pushbutton unit




### 139 Driver's seat heating pad



### 140 Switch for driver's seat heating pad









### 141 Connection between right longitudinal cable/rear right door cable



[3U191N01


55.

<p><b>143</b> Rear right electric window pushbutton unit on rear right door</p> <p>HG 141 GR 141 G 141 NZ 141</p> 	<p><b>144</b> Puddle light on rear right door</p> <p>R 141 B n.d.</p> 
<p><b>145</b> Rear right electric window motor</p> <p>HN 141 HR 141</p> 	<p><b>146</b> Rear right door locking motor, rear right door open indicator and anti-theft device on switch</p> <p>GN 141 HV 141 VN 141 B n.d. N 141</p> 
<p><b>148</b> Connection between left longitudinal cable/left seat cable</p> <p>N n.d. RG 186 R 138 N 138</p> 	
<p><b>149</b> Connection between left longitudinal cable/left seat cable</p> <p>B 183 G n.d. AR 183 N n.d. N n.d. AR 139 G 140 B 140</p> 	


P3U192N01




### 150 Connection between left longitudinal cable/rear left door cable




### 152 Rear left electric window pushbutton unit on rear left door




### 153 Puddle light on rear left door



### 154 Rear left electric window motor




### 155 Rear left door locking motor, rear left door open indicator and anti-theft device on switch




P3U193N01

55.


### 156 Connection between right longitudinal cable/right seat




### 157 Connection between right longitudinal cable/right cable




### 158A Passenger seat forward/backward adjustment motor




### 158B Passenger seat rear height adjustment motor




### 158C Passenger seat front height adjustment motor



### 158D Passenger seat squab adjustment motor




### 159 Switch for passenger seat heating pad




P3U194N01


### 160 Passenger seat heating pad




### 161 100A fuse protecting alternator (2959 - 1998 T only)




### 162 Boot light




### 163 Rear left courtesy light




### 164 Rear left loudspeaker




### 165 Heated rear window











### 165A Earth for heated rear window



### 166 Amplifier for aerial on rear window




55.


<p><b>166A</b> Rear cables connection on rear window</p>  <p>RN 181 RV 119B RV 166</p>	<p><b>167</b> Fuel gauge sender unit</p>  <p>MG 100 AG 100</p>
<p><b>168</b> Electric fuel pump</p>  <p>H 75C HN 192</p>	<p><b>169</b> Rear right loudspeaker</p>  <p>AN 100 A 100</p>
<p><b>170</b> Rear right courtesy light</p>  <p>B 141 R n.d. N n.d.</p>	<p><b>171</b> Additional stop lights indicator</p>  <p>RN 100 N n.d.</p>
<p><b>172</b> Rear right lights cluster on fixed part</p>  <p>RN 76E GL 76E AB n.d. GN 76E N n.d.</p>	<p><b>173</b> Rear right earth</p>  <p>N n.d.</p>

P3U196N01


### 174 Rear right lights cluster on moving part




### 175S Left number plate light




### 175 Connection between left longitudinal cable/boot cable




### 175D Right number plate light




### 176 Boot lock/unlock motor



### 176A Boot lock/unlock motor




### 177 Rear left lights cluster on moving part




55.


**178** Rear left earth




**179** Rear left lights cluster on fixed part




**180** Heated rear window relay




**183** Relay for driver's seat heating pad




**181** Connection between left longitudinal cable/right longitudinal cable



**183A** 7.5A fuse protecting relay on driver's seat heating pad




**184** Relay for passenger seat heating pad




P3U198N01


**184A** 7.5A fuse protecting relay on passenger seat heating pad




**185** Relay for electrically-adjustable driver's seat




**185A** 30A fuse protecting electrically-adjustable passenger seat




**186** Relay for electrically-adjustable passenger seat




**186A** 30A fuse protecting electrically-adjustable driver's seat




**187** 25A fuse protecting electric rear windows control unit



**188** 25A fuse protecting boot unlock electromagnet




**189** 30A fuse protecting heated rear window




55.


### 190 Boot lock/unlock relay




### 191 Inertial switch earth




### 192 Inertial switch




### 192 Inertial switch (2400 Turbo D only)




### 193 Sensor on rear left wheel for anti-lock braking system (A.B.S.)




### 194 Sensor on rear right wheel for anti-lock braking system (A.B.S.)



### 195 Fuel flap lock motor




### 196 Trailer wiring




P3U200N01




**198** Servotronic electronic control unit




**198A** Diagnostic socket




**199** Anti-theft siren





**219** Earth on central console (Tds only)











**200** Controlled damping suspension (C.D.S.) electronic control unit



**220A** 7.5A fuse protecting controlled damping suspension system (C.D.S.)




55.


<p><b>221</b> Rear left controlled damping suspension (C.D.S.) motor</p>  <p>HV 200 GV 200 BV 200 N n.d.</p>	<p><b>222</b> Rear right controlled damping suspension (C.D.S.) motor</p>  <p>HL 200 GL 200 BL 200 N n.d.</p>
<p><b>225</b> Left floor light</p>  <p>R n.d. B n.d.</p>	<p><b>226</b> Right floor light</p>  <p>R n.d. B n.d.</p>
<p><b>227</b> Front right loudspeaker</p>  <p>NZ n.d. SN n.d.</p>	<p><b>228</b> Front left loudspeaker</p>  <p>BN n.d. RN n.d.</p>
<p><b>266</b> Infrared receiver for anti-theft device</p>  <p>L 269 BG 269 AG 269 R 269 GR 269 N n.d.</p>	<p><b>267</b> Volumetric sensors for anti-theft device</p>  <p>N n.d. SN 269 S 269</p>

P3U202N01


### 269 Connection between dashboard cable/receiver cable




### 270 Earth on steering column




### 271 Stop lights switch




### 272 Driver's Air Bag connection




### 273 Passenger's Air Bag connection



### 274 Connection between dashboard cable/Air Bag cable











### 275 Air Bag control unit




P3U203N01

55.


<p><b>276</b> Left seat belt pretensioner</p>  <p>M n.d. L 275</p>	<p><b>277</b> Right seat belt pretensioner</p>  <p>M n.d. C 275</p>
<p><b>278</b> Diagnostic socket for Air Bag</p>  <p>BR 275 AB n.d. N n.d.</p>	<p><b>281</b> Front courtesy light</p>  <p>R 79 Z 79 N n.d.</p>
<p><b>282</b> Internal electrochromic rearview mirror</p>  <p>NL 79 N n.d. H n.d.</p>	<p><b>283</b> Illuminated passenger shade</p>  <p>RV n.d. N n.d.</p>
<p><b>284</b> Wiring for electric sunroof</p>  <p>GN 79 N n.d. 130 130 130</p>	<p><b>290</b> Illumination for front left air vent controls</p>  <p>N n.d. G n.d.</p>

P3U204N01


**291** Illumination for central left air vent controls




**292** Illumination for central right air vent controls




**293** Illumination for front right air vent controls




**295** Radio cables connection




**296** Radio cables connection




**297** Warning light for anti-theft device/Immobilizer device










**298A** Electric front windows control unit







**298B** Electric front windows control unit



55.

<p><b>298C</b> Front electric windows control unit</p>  <p>R n.d. N 97</p>	<p><b>298D</b> Front electric windows control unit</p>  <p>AR 120 AN 120 HR 90 HN 90</p>
<p><b>298E</b> Front electric windows control unit</p>  <p>RN 75A N n.d.</p>	<p><b>301</b> Solenoids assembly</p>  <p>CN 315 M 315 B 315 H 315 GN 315 GV 315 HV 315</p>
<p><b>300</b> Central door locking electronic control unit</p>  <p>GN n.d. AG n.d. BG n.d. HV n.d. S 75A</p>  <p>N 97 V n.d. VN n.d.</p>	
<p><b>302</b> Switches control assembly</p>  <p>N n.d. N n.d. V n.d. G n.d. BN n.d. BR 318 NZ 318 GV 318</p>	


P3U206N01

**315** Electronic automatic transmission gear selection control unit (2959 only))**316** Diagnostic socket for electronic automatic transmission (2959 only)**316** Diagnostic socket for electronic automatic gearbox (1998 only)**317** Connection between electronic automatic transmission cable/fuel injection cable (2959 only)


P3U207N01

55.


### 317 Connection between electronic automatic transmission cable/fuel injection cable (1998 only)




### 318 Connection between electronic automatic transmission cable/dashboard cable




### 318 Connection between electronic automatic transmission/dashboard cable (2959 only)




### 318 Connection between electronic automatic transmission cable/dashboard cable (1998 only)



### 319 Kick-Down wiring (1998 only)




### 321 Front left controlled damping suspension (C.D.S.) motor




P3U208N01




### 322 Front right controlled damping suspension (C.D.S.) motor




### 323 Accelerometer for controlled damping suspension (C.D.S.)




### 334 Connection between fuel injection cable/fuel injector flange (2959 only)











### 340 Front right brake pad wear sensor



### 341 Right side repeater




55.


<p><b>342</b> Electric windscreen washer pump</p> 	<p><b>342</b> Electric windscreen washer pump (Tds only)</p> 
<p><b>343</b> 40A starter relay</p> 	<p><b>344</b> Connection between dashboard cable/anti-lock braking system (A.B.S.) cable</p> 
<p><b>345</b> Front right earth</p> 	<p><b>346</b> Low engine coolant level sensor</p> 
<p><b>347</b> Turbo overpressure sender unit (Tds only)</p> 	<p><b>354</b> Diesel fuel pump (Tds only)</p> 

P3U210N01


### 355 Intrumented injector (Tds only)




### 356 Solenoid on diesel pump (Tds only)




### 357 Plug preheating control unit (Tds only)




### 361 Switch on clutch pedal (Tds only)




### 362 Switch on pedal (Tds only)




### 364 Potentiometer on accelerator pedal (Tds only)



### 367 Left headlamp adjuster




### 368 Right headlamp adjuster




55.


### 369 Connection between fuel injection cable/left longitudinal cable (Tds only)




### 371 25A fuse protecting anti-lock braking system (A.B.S.)




### 372 50A fuse protecting anti-lock braking system (A.B.S.)




### 374 Diagnostic socket for Fiat/Lancia tester




### 376 Modular manifold solenoid



### 377 Timing variator




### 378 Modular manifold relay




P3U212N01


**380** Timing variator relay




**382** Relay for heated diesel filter (Tds only)




**383** 15A fuse protecting heated diesel filter (Tds only)




**384** Heated diesel filter thermal contact (Tds only)




**385** Diesel filter heating resistor (Tds only)




**386** Cable connection to water in diesel filter sensor (Tds only)



**413** Connection to solenoid assembly (1998 only)





**414** Throttle valve position potentiometer (1998 only)




P3U213N01

55.


### 401 Electronic automatic transmission gear selection control unit (1998 only))




### 415 Gear position selector (1998 only)




### 416 Gear position selector (1998 only)




### 417 Engine rpm sensor (1998 only)



### 418 Vehicle speed sensor (1998 only)



### 420 Automatic transmission fluid temperature sensor (1998 only)



P3U214N01

- 1 Front left lights cluster
- 2 Front left fog lamp
- 3 Front left earth
- 3A Front left earth for anti-lock braking system (A.B.S.)
- 4 Electric horns
- 5 Front left brake pad wear sensor
- 6 Left side repeater
- 7 Battery
- 8 Main connector block
- 9 Earth on body shell
- 9A Earth on side for anti-lock braking system (A.B.S.)
- 10 Button on bonnet for switching on anti-theft device
- 11 Air conditioner compressor coupling
- 12 Sensor for low brake fluid level indicator
- 13 Reversing lights switch
- 14 Pulse generator for speedometer signal
- 15 Starter motor
- 16 Spark plugs
- 17 1 Engine cooling fan
- 17A 2 Engine cooling fan
- 18 Resistor for engine cooling fan speed
- 19 Sensor on front left wheel for anti-lock braking system (A.B.S.)
- 20 Alternator
- 21 Sensor for low engine oil level indicator
- 22 Engine coolant temperature sender unit
- 23 Sensor for low engine oil pressure indicator
- 24 Barometric capsule
- 25 Air temperature sensor
- 26 Three-stage pressure switch
- 27 Front right earth
- 28 Headlamp washer pump
- 29 Front right fog lamp
- 30 Front right lights cluster
- 31 Peripheral control unit (engine compartment)
  - E1 Dipped beam relay
  - E2 Horn relay
  - E3 Compressor coupling control relay
  - E4 Main beam relay
  - E5 Front fog lamps relay
  - E6 Relay controlling engine cooling fan high speed
  - E7 Relay controlling engine cooling fan low speed
- 32A Connection between dashboard cable/left engine compartment cable
- 32B Connection between dashboard cable/left engine compartment cable
- 32C Connection between dashboard cable/left engine compartment cable
- 33A Connection between dashboard cable/right engine compartment cable
- 34 Electrohydraulic control unit for anti-lock braking system (A.B.S.)

- 35 Connection between engine compartment cable/electronic fuel injection cable
- 36 Heated Lambda probe
- 37 Engine idle adjustment actuator
- 38 Earth for electronic fuel injection
- 39 Relay for inertial switch
- 40 E.G.R. solenoid
- 41 Petrol vapour shut-off solenoid
- 42 30A fuse protecting electronic fuel injection
- 43 Electronic earth
- 44 Power earth
- 45 Air flow meter
- 46 7.5A fuse protecting electronic fuel injection
- 47 Sensor on front right wheel for anti-lock braking system (A.B.S.)
- 48 10A fuse protecting heated Lambda probe and air flow meter relay
- 49 Relay controlling electric fuel pump and heated Lambda probe
- 50 Relay controlling electronic fuel injection
- 51 Relay controlling air flow meter
- 52 Ignition coil
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Fuel injectors
- 59 1 Knock sensor
- 60 2 Knock sensor
- 61 Engine coolant temperature sensor for electronic fuel injection
- 62 Rpm sensor
- 63 Potentiometer on throttle valve
- 64 40A fuse protecting plug preheating
- 65 Power module
- 66 Timing sensor
- 67 Electronic fuel injection cables connection
- 68 Connection between dashboard cable/electronic fuel injection cable
- 69 Engine services cable connection
- 70 H.T. distributor
- 71 Towhook control unit
- 72 Fuel injection control unit
- 72A Electronic control unit for fuel pump (2400 T.D.)
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A fuse protecting I.G.E. control unit / fuse and relay unit
- 73C 30A fuse protecting ignition switch / anti-theft device
- 74 60A fuse protecting peripheral control unit (engine compartment)
- 75 Fuse and relay unit (dashboard)
  - E1 Ignition switch discharge relay
  - E2 Indicators / hazard warning lights intermittent switch
  - E3 Headlamp washer timer
- 76 I.G.E. control unit





mpartment ca- ble	77 10A fuse protecting anti-lock braking system (A.B.S.)	C Motor for horizontal adjustment of left re- arview mirror	119A Connection between dashboard cable/right longitudinal cable	143 Rear right electric window pushbutton unit on rear right door
on	78 Instrument panel	D Heating element for left rearview mirror	119B Connection between dashboard cable/right longitudinal cable	144 Puddle light on rear right door
fuel injection	B1 Driver's heated seat warning light	E External temperature sensor	119C Connection between dashboard cable/right longitudinal cable	145 Rear right electric window motor
fuel injection	C Heated rear window warning light	90 Connection between dashboard cable/front left door cable	119D Connection between dashboard cable/front right door cable	146 Rear right door locking motor and rear right door open / anti-theft device "on" indicator
fuel injection	D Front fog lamps warning light	91 Loudspeaker on front left door	119E Connection between right longitudinal cable/right door cable	147 Front left seat cables connection
fuel injection	E Rear fog lamps warning light	92 Front / rear electric windows pushbutton unit on front left door	120 Connection between dashboard cable/front right door cable	148 Connection between left longitudinal cable/left seat cable
fuel injection	F Parking lights warning light	93 Puddle light on front left door	121 Right rearview mirror	149 Connection between left longitudinal cable/left seat cable
fuel injection	G Dipped beam headlights warning light	94 Front left electric window motor	A Motor for folding right rearview mirror	150 Connection between left longitudinal cable/left boot cable
fuel injection	H Main beam headlights warning light	95 Front left door locking motor and front left door open / anti-theft device "on" indicator	B Motor for vertical adjustment of right rearview mirror	151 Radio amplifier
fuel injection	I Check panel summary warning light	96 Earth on carrier	C Motor for horizontal adjustment of right rearview mirror	152 Rear left electric window pushbutton unit on rear left door
fuel injection	L Left direction indicator warning light	97 Earth on floor	D Heating element for right rearview mirror	153 Puddle light on rear left door
fuel injection	L1 Right direction indicator warning light	98 Ashtray light	122 Loudspeaker on front right door	154 Rear left electric window motor
fuel injection	J Seat belt undone warning light	99 Cigar lighter	123 Front right electric window pushbutton unit on front right door	155 Rear left door locking motor and rear left door open and anti-theft device "on" indicator
fuel injection	K Low generator charging warning light	100 Connection between dashboard cable/left longitudinal cable	124 Puddle light on front right door	156 Connection between right longitudinal cable/right seat cable
fuel injection	M Low engine oil pressure warning light	101 Lighting brightness adjustment rheostat	125 Front right electric window motor	157 Connection between right longitudinal cable/right seat cable
fuel injection	N Handbrake / I.G.E. control unit warming light	102 External lights controls unit	126 Front right door locking motor and front right door open / anti-theft device "on" indicator	158 Pushbutton unit controlling passenger's electrically-adjustable seat
fuel injection	O Low brake fluid level warning light	B Side lights / number plate lights switch	127 Switch for seat belts unfastened indicator	158A Passenger's seat forward-backward adjustment motor
fuel injection	P Anti-lock braking system fault warning light	C Dipped beam headlights / main beam headlights switch	128 Front courtesy light timer	158B Passenger's seat height adjustment motor
fuel injection	Q A.S.R. fault warning light	D Parking lights switch	129 Electric sunroof limit switch	158C Passenger's seat height adjustment motor
fuel injection	R Air Bag system fault warning light	E Symbols lights control switch	130 Electric sunroof control button	158D Passenger's seat squab adjustment motor
fuel injection	S Heater plugs warning light	103 Switch control unit	131 Earth on steering column mounting	159 Switch for passenger's seat heating pad
fuel injection	T Voltmeter	A Front fog lamps switch	132 Stop lights switch	160 Passenger's seat heating pad
fuel injection	U Electronic rev counter	B Rear fog lamps switch	133 Earth on floor (Air Bag signal)	161 100 A fuse protecting alternator
fuel injection	V Fuel gauge	C Headlamp adjustment control unit	134 Wervotronic solenoid	162 Boot light
fuel injection	X Total mileage / trip recorder display	A Windscreen washer / headlamp washer switch	135 Earth on windows control unit	163 Rear left courtesy light
fuel injection	Y Electronic speedometer	B Windscreen wiper switch	136 Rear electric windows control unit	164 Rear left loudspeaker
fuel injection	Y1 S.C.S. switches unit	C Horn button	137 Boot lock assembly	165 Heated rear window
fuel injection	W1 Maximum coolant temperature warning light	D Direction indicators / parking lights switch	A Boot light and anti-theft device "on" switch	165A Earth for heated rear window
fuel injection	Z Electronic transmission gear selection display	E Main beam headlamp flasher button	B Boot lock/unlock motor	166 Amplifier for aerial on rear window
fuel injection	Z1 Trip computer reset button	105 Ignition switch	138 Electronic control unit for driver's electrically-adjustable seat with memory	166A Rear cables connection on rear window
fuel injection	79 Dashboard cable/courtesy light cable connection	106 Immobilizer aerial	138A Driver's electrically-adjustable seat control pushbutton unit	167 Fuel gauge sender unit
fuel injection	80 Power earth on dashboard	107 Anti-theft device control unit	138B Driver's seat squab adjustment motor	168 Electric fuel pump
fuel injection	81 Climate control fan (Brushless)	108 Immobilizer control unit	138C Driver's seat height adjustment motor	169 Rear right loudspeaker
fuel injection	82 Air recirculation motor	109D Distribution / mixing motor	138D Driver's seat height adjustment motor	170 Rear right courtesy light
fuel injection	83 Windscreen wiper control assembly	109M Distribution / mixing motor	138E Driver's seat forward/backward adjustment motor	171 Additional stop lights warning light
fuel injection	84 Single-stage pressure switch (3000 i.e.)	110 Car interior air temperature sensor	138F Driver's seat memorization control pushbutton unit	172 Rear right lights cluster on fixed part
fuel injection	85 Infocenter control unit	111 Mixed air temperature sensor 1	139 Driver's seat heating pad	173 Rear right earth
fuel injection	86 Power earth on dashboard	112 Mixed air temperature sensor 2	140 Driver's seat heating pad switch	174 Rear right lights cluster on moving part
fuel injection	87 Lighting for glove compartment / controls for unlocking boot	113 Solar temperature sensor	141 Connection between right longitudinal cable/rear right door cable	175 Connection between left longitudinal cable/boot cable
fuel injection	88 Diagnostic socket for Fiat / Lancia tester	114 Sensor on steering column		175D Left number plate light
fuel injection	89 Left rearview mirror	115 Electrically-adjustable rearview mirrors control unit		
fuel injection	A Motor for folding left rearview mirror	116 Electronic control unit for electric sunroof		
fuel injection	B Motor for vertical adjustment of left rearview mirror	117 Hand brake on warning light switch		
fuel injection		118 Electric sunroof motor		




175S Right number plate light	274 Dashboard cable/Air Bag cable connection	346 Sensor for low engine coolant level	Cable colour codes
176 Boot lock / unlock motor	275 Air Bag control unit	347 Turbo overpressure sender unit	
177 Rear left lights cluster on moving part	276 Left seat belt pretensioner	354 Diesel fuel pump	
178 Rear left earth	277 Right seat belt pretensioner	355 Instrumented fuel injector	
179 Rear left lights cluster on fixed part	278 Diagnostic socket for Air Bag	356 Solenoid on diesel fuel pump	
180 Heated rear window relay	281 Front courtesy light	357 Plug preheating control unit	
181 Connection between left longitudinal cable/right longitudinal cable	282 Internal electrochromic rearview mirror	358 Engine cut out solenoid on injection pump	
182 Rear connector block	283 Passenger's illuminated shade	359 Heater plugs	
183 Relay for driver's seat heating pad	284 Wiring for electric sunroof	360 Heater plugs flange	
183A 7.5 A fuse protecting driver's seat heating pad	289 Light for front left air vent controls	361 Switch on clutch pedal	
184 Relay for passenger's seat heating pad	291 Light for central left air vent controls	362 Switch on pedal	
184A 7.5 A fuse protecting passenger's seat heating pad relay	292 Light for central right air vent controls	364 Potentiometer on accelerator pedal	
185 Relay for driver's electrically-adjustable seat	293 Light for front right air vent controls	367 Left headlamp adjuster	
185A 30A fuse protecting passenger's electrical-ly-adjustable seat	294 Light for rear air vent controls	368 Right headlamp adjuster	
186 Relay for passenger's electrical seat	295 Radio cables connection	369 Connection between electronic fuel injection cable/left longitudinal cable	
186A 30A fuse protecting driver's electrically-adjustable seat	296 Radio cables connection	371 25A fuse protecting anti-lock braking system (A.B.S.)	
187 25A fuse protecting rear electric windows control unit	297 Warning light for anti-theft device / immobilizer device	372 50A fuse protecting anti-lock braking system (A.B.S.)	
188 25A fuse protecting boot unlock solenoid	298 Front electric windows control unit	374 Diagnostic socket for Fiat / Lancia tester	
189 30A fuse protecting heated rear window	300 Central door locking electronic control unit	376 Modular manifold solenoid	
190 Relay for boot lock/unlock control	301 Solenoids assembly	377 Timing variator	
191 Earth for inertial switch	302 Switch assembly	378 Modular manifold relay	
192 Inertial switch	306 Electronic automatic transmission acoustic signal	379 Secondary air pump relay	
193 Sensor on rear left wheel for anti-lock braking system (A.B.S.)	307 Electronic automatic transmission acoustic signal switch	380 Relay for timing variator	
194 Sensor on rear right wheel for anti-lock braking system (A.B.S.)	308 Wiring for mapping	381 30A fuse protecting air pump	
195 Fuel flap unlock motor	315 Gear selection control unit for electronic automatic transmission (Z.F.)	382 Relay controlling heated diesel filter (P.T.C.)	
196 Trailer wiring	316 Diagnostic socket for electronic automatic transmission	383 15A fuse protecting heated diesel filter (P.T.C.)	
197 Electronic aerial	317 Connection between electronic automatic transmission cable/electronic fuel injection cable	384 Heated diesel filter (P.T.C.) thermal switch	
198A Servotronic electronic control unit	318 Connection between electronic automatic transmission cable/dashboard cable	385 Diesel filter (P.T.C.) heating element	
199 Anti-theft siren	319 Kick-down wiring	386 Connection for water in diesel filter sensor cables	
200 Electronic control unit for controlled-damping suspension (C.D.S.)	320 Embellishments on electronic automatic transmission gearchange lever	401 Gear selection control unit for electronic automatic transmission (A.I.S.I.N.)	Cable colour codes
219 Earth on central console	321 Motor for front left controlled-damping suspension (C.D.S.)	409 Electronic injection cable connection	
220A 7.5 A fuse protecting C.D.S. system	322 Motor for front right controlled-damping suspension (C.D.S.)	411 Connection between dashboard cable/electronic automatic transmission cable	
221 Motor for rear left controlled-damping suspension (C.D.S.)	323 Accelerometer for controlled damping suspension (C.D.S.)	412 Earth on bodywork	
222 Motor for rear right controlled-damping suspension (C.D.S.)	333 FIS relay	413 Connection to solenoid assembly	
225 Left floor light	334 Connection between electronic fuel injection cable/fuel injectors flange	414 Throttle valve position potentiometer	
226 Right floor light	340 Front right brake pad wear sensor	415 Gear position selector	
227 Front right loudspeaker	341 Right side repeater	416 Gear position selector	
228 Front left loudspeaker	342 Electric windscreen washer pump	417 Engine rpm sensor	
266 Infrared receiver for anti-theft device	343 40A starting relay	418 Vehicle speed sensor	
267 Volumetric sensors for anti-theft device	344 Connection between dashboard cable/anti-lock braking system (A.B.S.) cable	420 Auto. transmission fluid temperature sensor	
269 Dashboard cable/receiver cable connection	345 Front right earth		
270 Earth on steering column			
271 Stop lights switch			
272 Driver's Air Bag connection			
273 Passenger's Air Bag connection			



## Analytical charts

### Electrical equipment fault diagnosis



P3M000N01



COPYRIGHT Fiat Auto S.p.A.

Reproduction of all or part of the text and illustrations is prohibited.


The information in this publication is intended as a guide and could be superseded by modifications introduced by the Manufacturer at any time for technical and commercial reasons or in accordance with local regulations.



Fiat Auto S.p.A.  
Direzione Marketing Commerciale  
Direzione Post-Vendita - Servizi - Assistenziali  
10134 TURIN (Italy) - Corso E. Giambone, 33  
Print no. 506.475 - Ottobre 1994 - 500  
Printed in Italy - Tip. Europrint - Torino

## Analytical charts

### Electrical equipment fault diagnosis



P3M000N01

COPYRIGHT Fiat Auto S.p.A.

Reproduction of all or part of the text and illustrations is prohibited.

The information in this publication is intended as a guide and could be superseded by modifications introduced by the Manufacturer at any time for technical and commercial reasons or in accordance with local regulations.




Fiat Auto S.p.A.  
Direzione Marketing Commerciale  
Direzione Post-Vendita - Servizi - Assistenziali  
10134 TURIN (Italy) - Corso E. Giambone, 33  
Print no. 506.475 - Ottobre 1994 - 500  
Printed in Italy - Tip. Europrint - Torino



Chart No.	Functions concerned
<b>Chart 1</b> (page 1)	<b>1998 Motronic - 2446 Motronic version</b> Starting system - Motronic 2.10.3 electronic ignition and fuel injection - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light
<b>Chart 2</b> (page 9)	<b>2959 Motronic version</b> Starting system - Motronic electronic ignition and fuel injection - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light
<b>Chart 3</b> (page 17)	<b>2387 Turbo D version</b> Starting system - MSA 11.310 fuel pump electronic control unit - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light - Plug preheating warning light
<b>Chart 4</b> (page 23)	Car interior lighting
<b>Chart 5</b> (page 33)	Electric front windows
<b>Chart 6</b> (page 41)	Electric rear windows
<b>Chart 7</b> (page 49)	Air Bag and fault warning light - Seat belt pretensioners - Servotronic device
<b>Chart 8</b> (page 53)	Central door locking and doors open indicators
<b>Chart 9</b> (page 67)	Anti-lock braking system (A.B.S.)
<b>Chart 10</b> (page 73)	Electrically-adjustable and heated front seats



Starting system - Motronic 2.10.3 electronic ignition and fuel injection - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light - (See key following diagrams)




\* See air conditioner wiring diagram  
\*\* See automatic transmission wiring diagram



55.


Starting system - Motronic 2.10.3 electronic ignition and fuel injection - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light - (See key following diagrams)



\* See air conditioner wiring diagram


30222N





**Alternator not recharging**

### 55D.


**Battery recharging warning light stays off**






**Starter motor does not work****Preliminary checks before connecting Fiat Lancia Tester**


## 55D.








Starting system - Motronic electronic ignition and fuel injection - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light - (See key following diagrams)




\* See automatic transmission wiring diagram

\*\* See air conditioner wiring diagram





**Alternator not recharging**


#### Battery recharging warning light stays off






**Starter motor does not work****Preliminary checks before connecting Fiat Lancia Tester**


## 55D.








Starting system - MSA11-310 fuel pump electronic control unit - Recharging system and warning light - Low engine oil pressure warning light - Fuel injection fault warning light - Plug preheating warning light - (See key following diagrams)



\* See air conditioner wiring diagram


\*\* See stop lights wiring diagram





**Alternator not recharging**

## 55D.


### Battery recharging warning light stays off






**Starter motor does not work****Preliminary checks before connecting Fiat Lancia Tester**



### 55D.




**Car interior lighting - (See key following diagrams)**








**Car interior lighting does not work****Car interior courtesy light does not work**


## 55D.





### Ceiling spot light does not work




### Front courtesy light does not work when operated manually




**Front left courtesy light does not work when operated manually**


**55D.**



**Rear right courtesy light does not work**











### 55D.

#### Front courtesy light does not work in time-lagged condition




#### Glove compartment light does not work




**Luggage compartment light does not work**


55D.




Electric front windows - (See key following diagrams)






**Electric front windows do not work**


## 55D.




### Front left electric window does not work









#### Front right electric window does not work








Electric rear windows - (See key following diagrams)




\* See symbol illumination wiring diagram




**Rear electric windows do not work**


### 55D.




#### Rear left electric window does not work when controlled from either pushbutton unit




#### Rear right electric window does not work when controlled from either pushbutton unit









**Rear left electric window does not work when controlled from front pushbutton unit**




Not OK




**Rear left electric window does not work when controlled from rear left pushbutton unit**




Not OK




**Rear right electric window does not work when controlled from front pushbutton unit**




## 55D.









Air Bag and fault warning light - Seat belt pretensioners - Servotronic device - (See key following diagrams)






**Preliminary checks on the Air Bag system**

#### Preliminary checks on the SERVOTRONIK








Central door locking and doors open indicators - (See key following diagrams)









**Central door locking system does not work****Central door locking system is not actuated by the receiver**

### 55D.




### Central door locking system does not lock the doors






**Central door locking system does not lock the doors via the receiver****Central door locking system does not lock the doors via the left lock**



### 55D.






#### Central door locking system does not lock the doors via the right lock




#### Central door locking system does not unlock the doors




**Central door locking system does not unlock the doors via the receiver****Central door locking system does not unlock the doors via the left lock**


## 55D.



### Central door locking system does not unlock the doors via the right lock



### Front left door locking motor does not work





**Front right door locking motor does not work**

Check condition of wires colour GN and HV between front right lock 126 and ultra-sound-soldered joint



Not OK



Repair wire colour GN or HV



OK



Check condition of front right lock assembly 126



Not OK



Overhaul or replace lock 126

**Rear left door locking motor does not work**

Check condition of wires colour GN and HV between rear left lock 155 and ultra-sound-soldered joint



Not OK



Repair wire colour GN or HV



OK



Check condition of rear left lock assembly 155



Not OK



Overhaul or replace lock 155

**Rear right door locking motor does not work**

Check condition of wires colour GN and HV between rear right lock 146 and ultra-sound-soldered joint



Not OK



Repair wire colour GN or HV



OK



Check condition of rear left lock assembly 146




Not OK




Overhaul or replace lock 146

## 55D.


### Fuel flap lock/unlock motor does not work




### Boot lock/unlock motor does not work




3U282N




## 55D.






### Infocenter does not indicate front left door open




### Infocenter does not indicate front right door open



**Infocenter does not indicate rear left door open****Infocenter does not indicate rear right door open****Infocenter does not indicate boot open**




Anti-lock braking system (A.B.S.) - (See key following diagrams)










**A.B.S. does not work**

#### A.B.S. fault warning light stays on




#### A.B.S. fault warning light does not work









Electrically-adjustable and heated front seat - Driver's seat with memory - (See key following diagrams)




\* See symbol illumination wiring diagram  
\*\* See starting system wiring diagram




**Electrically-adjustable and heated seats do not work****Left electrically-adjustable seat does not work**


### 55D.







**Right electrically-adjustable seat does not work**

**55D.**







### 55D.




### Right seat heating pad does not work







55D.



**Right seat heating pad warning light does not work**



3U302N








page

- Electrical symbols	1
- Explanation of how to read wiring diagrams	4
- Wiring diagrams	5
- Connector blocks	27
- Key	30









































DESCRIPTION	ENGINE TYPE				
	1998	2446	1995T	2959	2387 Td
Preparation for medium level radio	5	5	5	5	5
Preparation for high level radio	7	7	7	7	7
Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light				9	
Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light					11
Direction indicators and warning light - Hazard warning lights and warning light - Braking lights - Reversing lights	13	13	13	13	13
Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer and trip meter and zeroing button - Rev counter - Current socket - Voltmeter	15	15	15	15	15
Ideogram lights - Heated rear windscreen and warning light	17	17	17	17	17
Version with alarm: central locking and doors ajar signal	19	19	19	19	19
Version without alarm: central locking and doors ajar signal - Doors locked device	21	21	21	21	21
Complete inforcenter	23	23	23	23	23
Air-bag and failure warning light - Seat belt pre-tensioners - Servotronic	25	25	25	25	25

NOTE The numbers in the table correspond to the electrical equipment page number in the manual

200011







































**Electrical symbols**

	Positions		Cold starting (choke)		Switch discharge
	Main beam h/lamps		Water in fuel filter		Dipped headlamps
	Heated seat		Heater plugs		Direction indicators signalling with central locking
	Seat belts		Turbocharging pressure		Electric horns
	Heated r. w/screen		Rear fog lamp		Left direction ind.
	Handbrake applied and insufficient brake fluid level		Fog light		Right direction ind.
	A.B.S.		Brake pad wear		Engine cooling
	Hazard warning		Turbocharging pressure		Windscreen wiper
	Direction ind.		Automatic gearbox oil temperature		Electric sun roof
	Handbrake and insufficient brake fluid level		Speed limits		Catalytic silencer temperature
	Recharging		Fuel level		Resistance
	Engine oil pressure		Engine coolant temperature		Diode

P3U001N01

### 55.

#### Electrical symbols

	Warning light		Trip computer		Differential lock
	Bulb		Electronic injection		Automatic gearbox oil temperature
	Fuse with reference number		Engine oil level		Temperature
	Switch open		Brake fluid level (Japanese version)		Anti-theft device
	Selector switch		Doors ajar		Electric windows
	Button open		Central locking		Earth
	Switch operated by coil (Relay)		Controlled damping suspension Sport Function		Number plate lights
	Motor		Transistor		Impulse generator (Timer)
	Rearscreen wiper		Air-Bag		Analogue clock
	Headlamp washer		A.B.S. (Japanese Version)		Digital clock
	W/screen wash/wipe		Vehicle brake light failure		Speedometer
	Rearscreen wash/wipe		Windscreen wiper		Rev counter

P3U002N01



Digital speedometer



Digital rev counter



Digital fuel level gauge



Analogue fuel level gauge



Analogue engine coolant temperature gauge



Econometer



Digital engine temperature gauge



Engine oil temperature




Engine oil pressure gauge



Voltmeter

### 55.

#### Interpretation of wiring diagram






#### Reference key


- A Component number
- B Connection number
- C Identification of connector at component
- D Connecting pin number
- E Ultrasound welding taped in cable loom

P3U004N01





55.




### Preparation for medium level radio

#### Components key


- |   |  |
|---|--|
| 7 Battery   | 164 Left rear speaker                      |
| 8 Main connector block  | 166 Amplifier for aerial in rear screen    |
| 9 Earth on body/shell   | 166A Rear cables connection in rear screen |
| 73 Secondary connector block                                    | 169 Right rear speaker                     |
| 73B 60A protective fuse for I.G.E. control unit/junction unit   | 227 Right front speaker                    |
| 73C 30A fuse protecting ignition switch / anti-theft device     | 228 Left front speaker                     |
| 75 Junction unit (dashboard)                                    | 295 Radio cables connection                |
| 90 Connection between dashboard and left front door cables      | 296 Radio cables connection                |
| 91 Speaker in left front door                                   |  |
| 100 Connection between dashboard and left longitudinal cables   |  |
| 105 Ignition switch   |  |
| 119B Connection between dashboard and right longitudinal cables |  |
| 120 Connection between dashboard and right front door cables    |  |
| 122 Speaker in right front door                                 |  |
| 131 Earth on steering column support                            |  |

N.D. Ultrasound welding taped in cable loom


### 90 Connection between dashboard and left front door cables






### 100 Connection between dashboard and left longitudinal cables




### 119B Connection between dashboard and right longitudinal cables



\* The cables in the wiring diagram are marked with an asterisk



55.







### Preparation for high level car radio

#### Components key

- |      |   |      |  |
|------|---|------|--|
| 7    | Battery   | 164  | Left rear speaker  |
| 8    | Main connector block  | 166  | Amplifier for aerial in rear screen                                |
| 9    | Earth on body/shell   | 166A | Rear cables connection in rear screen                              |
| 73   | Secondary connector block                                   | 169  | Right rear speaker   |
| 73B  | 60A protective fuse for I.G.E. control unit / junction unit | 178  | Left rear earth  |
| 73C  | 30A fuse protecting ignition switch / alarm device          | 181  | Connection between left longitudinal and right longitudinal cables |
| 75   | Junction unit (dashboard)                                   | 227  | Right front speaker  |
| 90   | Connection between dashboard and left front door cables     | 228  | Left front speaker   |
| 91   | Speaker in left front door                                  | 295  | Radio cables connection  |
| 100  | Connection between dashboard and left longitudinal cables   | 296  | Radio cables connection  |
| 105  | Ignition switch   | 422  | Connection between dashboard and left longitudinal cables          |
| 119B | Connection between dashboard and right longitudinal cables  |      |  |
| 120  | Connection between dashboard and right front door cables    |      |  |
| 122  | Speaker in right front door                                 |      |  |
| 131  | Earth on steering column support                            |      |  |
| 151  | Amplifier for radio   |      |  |

N.D. Ultrasound welding taped in cable loom

PJ01101




\* The cables in the wiring diagram, are marked with an asterisk


PJ0105001

Version: 2959

Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light -



\* See automatic transmission diagram  
\*\* See air conditioner diagram




PSU-4101

Version 2959: Starting - Motronic electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light


### Components key

- 3 Left front earth
- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 15 Starter motor
- 16 Spark plugs
- 20 Alternator
- 23 Engine oil minimum pressure sensor
- 26 Air temperature sensor
- 31 Three stage pressure switch
- 32A Compressor coupling relay feed
- 32B Connection between dashboard and left engine compartment cables
- 32C Connection between dashboard and left engine compartment cables
- 33A Connection between dashboard and right engine compartment cables
- 35 Connection between engine compartment and electronic injection cables
- 36 Heated Lambda sensor
- 37 Idle adjustment actuator
- 38 Earth for electronic injection
- 40 E.G.R. solenoid valve
- 41 Petrol vapour cut out solenoid valve
- 42 30A fuse protecting electronic injection
- 44 Power earth
- 45 Air flow meter
- 46 7.5A fuse protecting electronic injection
- 48 10A fuse protecting heated Lambda sensor and air flow meter relay
- 49 Electric fuel pump and heated Lambda sensor relay feed
- 50 Electronic injection system relay feed
- 51 Air flow meter relay feed
- 52 Ignition coil
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Injectors
- 59 1st Deformation sensor
- 60 2nd Deformation sensor
- 61 Electronic injection engine coolant temperature sensor
- 62 Rpm sensor
- 63 Potentiometer on butterfly valve
- 65 Timing sensor
- 68 Connection between dashboard and electronic injection cables
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73B 60A protective fuse for I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/alarm device
- 74 60A protective fuse for peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- 76 E1 ignition discharge relay
- 78 Instrument panel
- K Battery recharging warning light
- M Insufficient engine oil pressure warning light
- U Electronic rev counter
- Y Electronic tachometer
- 85 Infocenter control unit
- 88 Diagnostic socket for Fiat / Lancia tester
- 97 Earth on floor
- 105 Ignition switch
- 107 Alarm control unit
- 108 Lancia CODE control unit
- 119B Connection between dashboard and right longitudinal cables
- 168 Electric fuel pump
- 191 Earth for inertia switch
- 192 Inertia switch
- 317 Connection between automatic transmission and electronic injection cables
- 334 Connection between electronic injection cable and injector bridge
- 343 40A starter relay
- 432 20A protective fuse ignition switch relay feed
- N.D. Ultrasound welding taped in cable loom


### 35 Connection between engine compartment and electronic injection cables




### 68 Connection between dashboard and electronic injection cables



### 317 Connection between automatic transmission and electronic injection cables




### 334 Connection between electronic injection cable and injector bridge



\* The cables in the wiring diagram, are marked with an asterisk

Version: 2387 Td

Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs control unit and warning light




\* See air conditioner diagram

PAUTILLON

PAUTILLON

**55.**



P3U/18LGN


Version 2387 Td: Starting - MSA11 310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs control unit and warning light

### Components key


- |  |  |
|--|--|
| 3 Left front earth   | 78 Instrument panel  |
| 7 Battery  | K Battery recharging warning light                                       |
| 8 Main connector block   | M Insufficient engine oil pressure warning light                         |
| 9 Earth on body/shell  | S Heater plugs warning light   |
| 15 Starter motor   | U Electronic rev counter   |
| 20 Alternator  | Y Electronic tachometer  |
| 23 Switch signalling minimum engine oil pressure                         | 85 Infocenter control unit   |
| 26 Three stage pressure switch   | 88 Diagnostic socket for Fiat/Lancia tester                              |
| 31 Peripheral control unit (engine compartment)                          | 97 Earth on floor  |
| E3 Compressor coupling relay feed  | 105 Ignition switch  |
| 32A Connection between dashboard and left engine compartment cables      | 107 Alarm control unit   |
| 32B Connection between dashboard and left engine compartment cables      | 108 Lancia CODE control unit   |
| 32C Connection between dashboard and left engine compartment cables      | 191 Earth for inertia switch   |
| 32A Connection between dashboard and left engine compartment cables      | 192 Inertia switch   |
| 33A Connection between dashboard and right engine compartment cables     | 343 40A starter relay  |
| 35 Connection between engine compartment and electronic injection cables | 354 Electric diesel pump   |
| 39 Relay for inertia switch  | 355 Solenoid valve on diesel pump  |
| 40 E.G.R. solenoid valve   | 357 Heater plugs control unit  |
| 42 30A fuse protecting electronic injection                              | 358 Engine cut out solenoid on injection pump                            |
| 43 Electronic earth  | 359 Heater plugs   |
| 45 Air flow meter  | 361 Switch on clutch pedal   |
| 50 Electronic injection system relay feed                                | 362 Switch on pedal  |
| 61 Electronic injection engine coolant temperature sensor                | 369 Potentiometer on accelerator pedal                                   |
| 62 Rpm sensor  | 369 Connection between electronic injection and left longitudinal cables |
| 64 40A fuse protecting heater plugs                                      | 382 Heated diesel filter relay feed (P.T.C.)                             |
| 68 Connection between dashboard and electronic injection cables          | 383 15A fuse protecting heated diesel filter (P.T.C.)                    |
| 69 Fuel pump control unit  | 384 Heated diesel filter thermal contact (P.T.C.)                        |
| 72A Secondary connector block  | 385 Heated diesel filter resistance (P.T.C.)                             |
| 73 60A protective fuse for I.G.E. control unit / junction unit           | 386 Connection for cables to water in fuel filter sensor                 |
| 73C 30A fuse protecting ignition switch/alarm device                     | 432 20A protective fuse ignition switch relay feed                       |
| 74 60A protective fuse for peripheral control unit (engine compartment)  |  |
| 75 Junction unit (dashboard)   |  |
| Et Ignition discharge relay  |  |

N.D. Ultrasound welding taped in cable loom


**32B** Connection between dashboard and left engine compartment cables (only for 2387 Tds)




**35** Connection between engine compartment and electronic injection cables




**382** Heated diesel filter relay feed (P.T.C.)



**68** Connection between dashboard and electronic injection cables



**69** Connection for engine services cables




\* The cables in the wiring diagram, are marked with an asterisk


P3U059MOT



Direction indicators and warning light - Hazard warning lights and warning light - Braking lights - Reversing lights - Direction indicators/hazard warning lights towing warning light



55.




Direction indicators and warning light - Hazard warning lights and warning light - Braking lights - Reversing lights - Direction indicators/hazard warning warning lights for trailer

Components key


- |   |  |
|---|--|
| 1 Left front light cluster  | 104 Steering column switch unit                              |
| 3 Left front earth  | D Switch for direction indicators/parking lights             |
| 6 Left side direction indicator                                       | E Flasher  |
| 7 Battery   | F Main beam headlamps control switch                         |
| 8 Main connector block  | 105 Ignition switch  |
| 9 Earth on bodyshell  | 131 Earth on steering column support                         |
| 13 Reversing lights switch  | 171 Additional brake lights indicator                        |
| 27 Right front earth  | 172 Right rear light cluster on fixed section                |
| 30 Right front light cluster  | 174 Right rear light cluster on movable section              |
| 33A Connection between dashboard and right engine compartment cables  | 175 Connection between left longitudinal and tailgate cables |
| 73 Secondary connector block  | 177 Left rear light cluster on movable section               |
| 73B 60A protective fuse for I.G.E. control unit / junction unit       | 178 Left rear earth  |
| 73C 30A fuse protecting ignition switch/anti-theft device             | 179 Left rear light cluster on fixed section                 |
| 75 Junction unit (dashboard)  | 271 Brake lights switch                                      |
| E2 Intermittent device for direction indicators/hazard warning lights | 341 Right side direction indicator                           |
| 76 I.G.E. control unit  | 343 40A starter relay  |
| 78 Instrument panel   | 345 Right front earth  |
| A Trailer direction indicators warning light                          |  |
| L Left direction indicator warning light                              |  |
| L1 Right direction indicator warning light                            |  |
| 85 Infocenter control unit  |  |
| 97 Earth on floor   |  |

N.D. Ultrasound welding taped in cable loom


33A Connection between dashboard and right engine compartment cables




75E Junction unit (dashboard)




78A Instrument panel




104B Steering column switch unit



105 Ignition switch




175 Connection between left longitudinal and tailgate cables




\* The cables in the wiring diagram, are marked with an asterisk

Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer/trip meter and zeroing button - Rev counter - Current socket - Voltmeter



55.




Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Mileometer/trip meter and zeroing button - Rev counter - Current socket - Voltmeter

Components key


- 3 Left front earth
- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 12 Insufficient brake fluid level sensor
- 14 Impulse generator for speedometer signal
- 32B Connection between dashboard and left engine compartment cables
- 68 Connection between dashboard and electronic injection cables
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73A 60A fuse protecting services
- 73B 60A protective fuse for I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/alarm device
- 75 Junction unit (dashboard)
- 76 I.G.E. control unit
- 78 Instrument panel
- J Seat belts not fastened warning light
- N Handbrake applied / I.G.E. control unit warning light
- O Insufficient brake fluid level warning light
- T Voltmeter
- U Electronic rev counter
- V Fuel level gauge
- V1 Fuel reserve warning light
- X Mileometer/trip meter
- Y Electronic tachometer
- Z1 Trip meter zeroing button

- 88 Diagnostic socket for Fiat/Lancia tester
- 96 Earth on carrier
- 97 Earth on floor
- 99 Cigar lighter
- 100 Connection between dashboard and left longitudinal cables
- 105 Ignition switch
- 117 Switch signalling handbrake applied
- 119A Connection between dashboard and right longitudinal cables
- 119B Connection between dashboard and right longitudinal cables
- 119D Connection between dashboard and right front door cables
- 131 Earth on steering column support
- 167 Fuel level gauge
- 173 Right rear earth
- 200 Controlled damping suspension electronic control unit (S.C.S.)
- 271 Brake lights switch
- 430 Handbrake applied/insufficient brake fluid system connecting diode
- 434 15A fuse protecting current socket
- 435 Current socket relay feed
- 436 Current socket
- N.D. Ultrasound welding taped in cable loom


32B Connection between dashboard and left engine compartment cables




68 Connection between dash. & electronic injection cables



100 Connection between dashboard and left longitudinal cables




119D Connection between dashboard and right longitudinal cables



\* The cables in the wiring diagram, are marked with an asterisk

Ideogram lights - Heated rear windscreen and warning light -



**55.**





Diagram lights - Heated rear windscreen and warning light


### Components key

- |   |   |
|---|---|
| 7 Battery   | 105 Ignition switch   |
| 8 Main connector block                                    | 119A Connection between dashboard and right longitudinal cables |
| 9 Earth on body/shell                                     | 119B Connection between dashboard and right longitudinal cables |
| 73 Secondary connector block                              | 131 Earth on steering column support                            |
| 73A 80A fuse protecting rear services                     | 165 Heated rear windscreen                                      |
| 73C 30A fuse protecting ignition switch/anti-theft device | 165A Earth for heated rear windscreen                           |
| 75 Junction unit (dashboard)                              | 180 Heated rear windscreen relay feed                           |
| 76 I.G.E. control unit                                    | 189 30A fuse protecting heated rear windscreen                  |
| 78 Instrument panel                                       | 291 Left front air vent controls light                          |
| C Heated rear windscreen warning light                    | 292 Left centre air vent controls light                         |
| F1 Instrument panel light bulbs                           | 293 Right centre air vent controls light                        |
| U Electronic rev counter                                  | 295 Radio cables connection                                     |
| 85 Infocenter control unit                                |   |
| 96 Earth on carrier                                       |   |
| 97 Earth on floor   |   |
| 98 Ashtray light  |   |
| 99 Cigar lighter  |   |
| 101 Light dimmer  |   |
| 102 External light controls                               |   |
| B Side lights / no. plate lights switch                   |   |
| C Dipped beam headlamps / main beam headlamps switch      |   |
| D Parking lights switch                                   |   |
| E Ideogram lights switch                                  |   |
| Switch control unit                                       |   |
| A Fog lights switch                                       |   |
| B Rear fog lamps control switch                           |   |
| C Headlamp alignment corrector unit                       |   |
|   | N.D. Ultrasound welding taped in cable loom                     |


**101** Light dimmer




**102** External light controls




**119A** Connection between dashboard and right longitudinal cables




**165** Heated rear windscreen




**119B** Connection between dashboard and right longitudinal cables



**180** Heated rear windscreen relay feed




**290** Left front air vent controls light



\* The cables in the wiring diagram, are marked with an asterisk


Version with alarm

Central locking and doors ajar signal -



• See levels diagram

### 55.




Version with alarm: Central locking and doors ajar signal

#### Components key


- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A protective fuse for I.G.E. control unit/junction unit
- 73C 30A fuse protecting ignition switch/alarm device
- 75 Junction unit (dashboard)
- 78 Instrument panel:
- 85 V Electronic tachometer
- 85 Infocenter control unit
- 87 Glove compartment / boot lid release light
- 90 Connection between dashboard and left front door cables
- 95 Left front central locking geared motor and left front door ajar signal and alarm device on
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard and left longitudinal cables
- 105 Ignition switch
- 107 Alarm control unit
- 119A Connection between dashboard and right longitudinal cables
- 119B Connection between dashboard and right longitudinal cables
- 120 Connection between dashboard and right front door cables
- 126 Right front central locking geared motor and right front door ajar signal and alarm device on
- 131 Earth on steering column support

- 137 Tailgate lock assembly
- 141 A Luggage compartment courtesy light switch and alarm on
- 141 B Tailgate locking/unlocking motor
- 141 Connection between right longitudinal and right rear door cables
- 146 Right rear door central locking geared motor and right rear door ajar signal and alarm device on
- 150 Connection between left longitudinal and left rear door cables
- 155 Left rear door central locking geared motor and left rear door ajar and alarm device on
- 173 Right rear earth
- 175 Connection between left longitudinal and tailgate cables
- 176 Tailgate cables connection
- 178 Left rear earth
- 181 Connection between left longitudinal and tailgate cable diol cables
- 188 25A fuse protecting luggage compartment release etc. to-magnet
- 190 Tailgate locking / unlocking relay
- 195 Fuel filler flap release motor
- 266 Infra red receiver for alarm device
- 266 Connection between dashboard and receiver cables
- 300 Central locking electronic control unit
- N D. Ultrasound welding taped in cable loom


#### 100 Connection between dashboard and left longitudinal cables




#### 119B Connection between dashboard and right longitudinal cables



#### 175 Connection between left longitudinal and tailgate cables



#### 269 Connection between dashboard and receiver cables




\* The cables in the wiring diagram, are marked with an asterisk




Version without alarm

Central locking and doors ajar signal - Doors locked device -



\* See direction indicators diagram  
\*\* See levels diagram

### 55.



P3U38101


### Version without alarm: Central locking and doors ajar signal - Doors locked device

#### Components key


- |      |   |     |  |
|------|---|-----|--|
| 7    | Battery   | 131 | Earth on steering column support   |
| 8    | Main connector block  | 137 | Tailgate lock assembly   |
| 9    | Earth on bodyshell  | 141 | A Luggage compartment courtesy light switch and alarm on   |
| 73   | Secondary connector block   | 146 | B Tailgate locking/unlocking motor   |
| 73A  | 80A fuse protecting rear services   | 150 | Connection between right longitudinal and right rear door cables                                 |
| 73B  | 60A fuse protecting rear services   | 155 | Right rear door central locking geared motor and right rear door ajar signal and alarm device on |
| 73C  | 30A fuse protecting ignition switch/alarm device  | 173 | Connection between left longitudinal and left rear door cables                                   |
| 75   | Junction unit (dashboard)   | 175 | Left rear door central locking geared motor and left rear door ajar signal and alarm device on   |
| 78   | E2 Intermit. device for direction ind./hazard w/lights  | 176 | Right rear earth   |
| 85   | Instrument panel:   | 177 | Connection between left longitudinal and tailgate cables   |
| 87   | Y Electronic tachometer   | 178 | Tailgate cables connection   |
| 88   | Infocenter control unit   | 181 | Left rear earth  |
| 90   | Glove compartment / boot release light  | 188 | Connection between left longitudinal and right longitudinal cables                               |
| 95   | Connection between dashboard and left front door cables                                       | 190 | 25A fuse protecting boot release electro-magnet  |
| 96   | Left front central locking geared motor and left front door ajar signal and alarm device on   | 195 | Tailgate locking / unlocking relay   |
| 97   | Earth on carrier  | 199 | Fuel filler flap release motor   |
| 100  | Earth on floor  | 266 | Infra red receiver for alarm device  |
| 105  | Connection between dashboard and left longitudinal cables                                     | 269 | Connection between dashboard and receiver cables   |
| 108  | Ignition switch   | 297 | Anti-theft device/Lancia CODE warning light  |
| 119A | Immobilizer control unit  | 300 | Central locking electronic control unit  |
| 119B | Connection between dashboard and right longitudinal cables                                    | 431 | Direction indicators operation with doors locked device  |
| 120  | Connection between dashboard and right longitudinal cables                                    |     |  |
| 126  | Right front central locking geared motor and right front door ajar signal and alarm device on |     |  |

N.D. Ultrasound welding taped in cable loom


### 100 Connection between dashboard and left longitudinal cables




### 119B Connection between dash and right longitudinal cables



### 175 Connection between left longitudinal and tailgate cables



### 269 Connection between dashboard and receiver cables




\* The cables in the wiring diagram, are marked with an asterisk

P3U38101

22

Complete infocenter -



- \* Variant connections for the 2959 version
- \*\* Variant connections for the 1998 16V Turbo version
- \*\*\* Variant connections for the 2446 Turbo D version
- ▲ See ideogram lights diagram
- ▲▲ Non-existent for the 1998 T - 2959 version

### Location of components

**LANCIA K**  
96 range



### Components key

### Components key

- 97 Earth on floor

- N.D. Ultrasound welded taped in cable loom



Connection between dash. & left engine comp. cables



Connection between dash. & left engine comp. cables



Connection between dash. & right engine comp. cables



\* The cables in the wiring diagram, are marked with an asterisk

DESCRIPTION	ENGINE TYPE					
	1998	2446	1995T	2959	2387 Td	
Preparation for middle range radio	5	5	5	5	5	
Preparation for top of the range radio	7	7	7	7	7	
Starting - Motronic electronic ignition and injection - Recharging and warning light -Insufficient engine oil pressure warning light - Injection system failure warning light				9		
Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light					11	
Direction indicators and warning light - Hazard warning lights and warning light - Braking lights - Reversing lights	13	13	13	13	13	
Fuel level gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer/trip meter and zeroing button - Rev counter - Current socket - Voltmeter	15	15	15	15	15	
Ideogram lights - Heated rear windscreen and warning light	17	17	17	17	17	
Version with alarm: central locking and signalling of doors open	19	19	19	19	19	
Version without alarm: central locking and signalling of doors open - Doors locked de- vice	21	21	21	21	21	
Complete Inforcenter	23	23	23	23	23	
Air-bag and failure warning light - Seat belt pre-tensioners - Servotronic	25	25	25	25	25	
Preparation for middle range radio - Preparation for radiotelephone	26/1	26/1	26/1	26/1	26/1	
Preparation for top of the range radio	26/3	26/3	26/3	26/3	26/3	

**NOTE** The numbers in the table correspond to the electrical equipment page number in the manual

Cont  
55


55.

DESCRIPTION	ENGINE TYPE				
	1998	2446	1995T	2959	2387 Td
Version with radiofrequency receiver and alarm: Central locking and signalling of doors open	26/5	26/5	26/5	26/5	26/5
Version without alarm: Operation device Central locking and signalling of doors open - Doors locked signal	26/7	26/7	26/7	26/7	26/7
Alarm with radiofrequency receiver	26/9	26/9	26/9	26/9	26/9
Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs warning light (version with hot wire flow meter)					26/11

NOTE The numbers in the table correspond to the electrical equipment page number in the manual

Version with alarm and radio frequency receiver


Central locking and doors ajar signal



\* See levels diagram

PS047106


**55.**



PJ3027108


**100**

Connection between dashboard and left longitudinal cables




**119B**

Connection btwn dash. and right longitudinal cables




**175**

Connection between left longitudinal and tailgate cables



**269**

Connection between dashboard and radio frequency receiver cables



Version with alarm and radio frequency receiver. Central locking and doors ajar signal


Components key

- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A protective fuse for I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/alarm device
- 75 Junction unit (dashboard)
- 78 Instrument panel
- Y Electronic tachometer
- 85 Infocenter control unit
- 87 Glove compartment light / controls for boot release
- 90 Connection between dashboard and left front door cables
- 95 Left front central locking geared motor and left front door ajar signal and alarm device on
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard and left longitudinal cables
- 105 Ignition switch
- 107 Alarm device control unit
- 119A Connection between dashboard and right longitudinal cables
- 119B Connection between dashboard and right longitudinal cables
- 120 Connection between dashboard and right front door cables
- 126 Right front central locking geared motor and right front door ajar signal and alarm device on
- 131 Earth on steering column support
- 137 Tailgate lock assembly
- A Luggage compartment courtesy light switch and alarm engagement
- B Tailgate locking/unlocking motor
- 141 Connection between right longitudinal and right rear door cables
- 146 Right rear door central locking geared motor and right rear door open signal and alarm on
- 150 Connection between left longitudinal and left rear door cables
- 155 Left rear door central locking geared motor and left rear door open signal and alarm on
- 173 Right rear earth
- 175 Connection between left longitudinal and tailgate cables
- 176 Tailgate cables connection
- 178 Left rear earth
- 181 Connection between left longitudinal and right longitudinal cables
- 188 25A fuse protecting boot release electro-magnet
- 190 Tailgate locking / release relay
- 195 Fuel filler flap release motor
- 266A Radio frequency receiver for alarm device
- 269 Connection between dashboard and receiver cables
- 300 Central locking electronic control unit
- N D. Ultrasound welding taped in cable loom



Version without alarm

Central locking and doors open signal - Door closing device



\* See direction indicators wiring diagram  
.. See levels diagram


## 96 range



P3U671L11

## P3U671L11

- P3U671L11



# 100



## Connection between dashboard and left longitudinal cables

Diagram illustrating the connection between the dashboard and left longitudinal cables for a vehicle with 100 seats. The diagram shows the routing of various cables (e.g., C 296, A 296, AN 296, NZ 90, G.n.d., AB.n.d., M 75F, N 107A, N 107A, R.n.d., GR 90, AG 78G, MG 78D, Z.n.d., MG 167, GR n.d., AG 167, HG.n.d., C 164, CN 164, A 169, AN 169, Z.n.d., G 150, NZ.n.d., G 150, AB 195, A 8171, M 195, B 199) through a series of connectors and junctions. A large arrow indicates the flow of the connection from the dashboard area towards the rear of the vehicle.

# 100

## Connection between dashboard and left longitudinal cables

Diagram illustrating the connection between the dashboard and left longitudinal cables for a vehicle with 100 seats. The diagram shows the routing of various cables (e.g., C 296, A 296, AN 296, NZ 90, G.n.d., AB.n.d., M 75F, N 107A, N 107A, R.n.d., GR 90, AG 78G, MG 78D, Z.n.d., MG 167, GR n.d., AG 167, HG.n.d., C 164, CN 164, A 169, AN 169, Z.n.d., G 150, NZ.n.d., G 150, AB 195, A 8171, M 195, B 199) through a series of connectors and junctions. A large arrow indicates the flow of the connection from the dashboard area towards the rear of the vehicle.



Technical drawing of two mechanical components, A 176A and A 181, showing their internal structure and dimensions.

**Component A 176A:**

- S.n.d.
- H 174
- \* A 176A
- Z 176 \*
- HR 177
- \* N.n.d.
- GV 175S
- G 175D

**Component A 181:**

- \* A 181
- \* Z.n.d.
- HR 76E
- G 76E
- GV 76E
- \* N 178
- S 75C
- H 76E


Technical drawing of two mechanical components, A 176A and A 181, showing their internal structure and dimensions.

**Component A 176A:**


- S.n.d.
- H 174
- \* A 176A
- Z 176 \*
- HR 177
- \* N.n.d.
- GV 175S
- G 175D

**Component A 181:**


- \* A 181
- \* Z.n.d.
- HR 76E
- G 76E
- GV 76E
- \* N 178
- S 75C
- H 76E



Alarm device with radiofrequency receiver



**55.**



Alarm device with radio frequency receiver


### Components key

- 1 Left front light cluster
- 3 Left front alarm
- 5 Left side direction indicator
- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 10 Button on bonnet lid for engaging alarm device
- 27 Right front earth
- 30 Right front light cluster
- 32A Connection between dashboard and left engine compartment cables
- 33A Connection between dashboard and right engine compartment cables
- 44 Power earth
- 68 Connection between dashboard and electronic injection cables
- 72 Fuel injection control unit
- 73 Secondary connector block
- 73B 60A protective fuse for I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch/alarm device
- 75 Junction unit (dashboard)
- E1 Ignition discharge relay
- E2 Inherent device for direction indicators / hazard warning lights
- 88 Diagnostic socket for Fiat / Lancia tester
- 90 Connection between dashboard and left front door cables
- 95 Left front central locking gear motor and left front door open signal and alarm device on
- 96 Earth on carrier
- 97 Earth on floor
- 100 Connection between dashboard and left longitudinal cables
- 105 Ignition switch
- 107 Alarm control unit
- 108 Lancia CODE control unit

- 119B Connection between dashboard and right longitudinal cables
- 120 Connection between dashboard and right front door cables
- 126 Right front central locking geared motor and right front door open signal and alarm device on
- 131 Earth on steering column support
- 137 Tailgate lock assembly
- A Luggage compartment courtesy light switch and alarm on
- 141 Connection between right longitudinal and right rear door cables
- 146 Right rear door central locking geared motor and right rear door open signal and alarm device on
- 150 Connection between left longitudinal and left rear door cables
- 155 Left rear door central locking geared motor and left rear door open signal and alarm device on
- 172 Right rear light cluster on fixed section
- 173 Right rear earth
- 175 Connection between left longitudinal and tailgate cables
- 176 Tailgate cables connection
- 177 Left rear light cluster on moving section
- 178 Left rear earth
- 179 Left rear light cluster on fixed section
- 189 Alarm frequency receiver for alarm device
- 257 Volume sensors for alarm device
- 259 Connection between dashboard and receiver cables
- 297 Alarm / LANCIA CODE warning light
- 300 Central locking electronic control unit
- 341 Right side direction indicator
- 345 Right front earth
- N.D. Ultrasound welding taped in cable loom


**68**

Connection between dash. & electronic injection cables




**100**

Connection between dashboard and left longitudinal cables




**175**

Connection between left longitudinal and tailgate cables



**269**


Connection between dashboard and radio frequency receiver cables



\* The cables in the wiring diagram, are marked with an asterisk

Version: 2387 Td

Starting - MSA11-310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs control unit and warning light (version with hot wire flow meter)




\* See air conditioner diagram

2387T

P3467115


**55.**



**2387 Td version: Starting - MSA11 - 310 fuel pump electronic control unit - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Heater plugs control unit and warning light**  
**Components key**

- 3 Left front earth
  - 7 Battery
  - 8 Main connector block
  - 9 Earth on bodyshell
  - 15 Starter motor
  - 20 Alternator
  - 23 Switch signalling low engine oil pressure
  - 26 Three stage pressure switch
  - 31 Peripheral control unit (engine compartment)
  - E3 Compressor coupling relay feed
  - 32A Connection between dashboard and left engine compartment cables
  - 32B Connection between dashboard and left engine compartment cables
  - 32C Connection between dash. & left engine comp. cables
  - 33A Connection between dash. & right engine comp. cables
  - 35 Connection between engine compartment and electronic injection cables
  - 39 Relay for inertia switch
  - 40 E.G.R. solenoid valve
  - 42 30A fuse protecting electronic injection
  - 43 Electronic earth
  - 45 Air flow meter
  - 50 Electronic injection system relay feed
  - 61 Electronic injection engine coolant temperature sensor
  - 64 40A fuse protecting heater plugs
  - 68 Connection between dash. & electronic injection cables
  - 69 Engine services cables connection
  - 72A Fuel pump control unit
  - 73 Secondary connector block
  - 73B 60A protective fuse for I.C.E. control unit / junction unit
  - 74 60A protective fuse for peripheral control unit (engine compartment)
  - 75 Junction unit (dashboard)
  - E1 Ignition discharge relay
- 
- 78 Instrument panel
  - K Battery recharging warning light
  - M Insufficient engine oil pressure warning light
  - S Heater plugs warning light
  - U Electronic rev counter
  - V Electronic tachometer
  - 85 Infocenter control unit
  - 88 Diagnostic socket for Fiat/Lancia tester
  - 97 Earth on floor
  - 105 Ignition switch
  - 107 Alarm control unit
  - 108 Lancia CODE control unit
  - 191 Earth for inertia switch
  - 192 Inertia switch
  - 343 40A starter relay
  - 354 Electric diesel pump
  - 355 Instrument injector
  - 356 Solenoid valve on diesel pump
  - 357 Heater plugs control unit
  - 358 Engine cut out solenoid on injection pump
  - 359 Heater plugs
  - 361 Switch on clutch pedal
  - 364 Potentiometer on accelerator pedal
  - 369 Connection between electronic injection and left longitudinal cables
  - 382 Heated diesel filter relay feed (P.T.C.)
  - 383 15A fuse protecting heated diesel filter (P.T.C.)
  - 384 Heated diesel filter thermal contact (P.T.C.)
  - 385 Heated diesel filter resistance (P.T.C.)
  - 386 Connection for cables to water in fuel filter sensor
  - 432 20A protective fuse for ignition switch relay
  - 475 Air temperature sensor
- 
- N.D. Ultrasound welding taped in cable loom


**55.**




**32B** Connection between dashboard and left engine compartment cables (only for 2387 Tds)

- AV 104A
- BN 104D
- HV n.d.
- AN 78D
- NZ n.d.
- \*HN n.d.
- VB 85B
- V 78D
- C 103
- GR 103
- LR 78A
- L 78D
- GN 78D
- M 78D
- BL 78C
- AR 78C
- Z 105 \*
- BY 78D
- GN 14
- L 14
- M 14
- BR 31A
- AR 31A
- \*Z 343
- BY 22
- GR n.d.
- C n.d.
- AV 31
- BN 31
- HV 31
- AN 12
- HN 69 \*
- VB 5
- V 22


**35** Connection between engine compartment and electronic injection cables




**382** Heated diesel filter relay feed (P.T.C.)



**68** Connection between dashboard and electronic injection cables










**69** Engine services cables connection



\* The cables in the wiring diagram, are marked with an asterisk


Anti-lock brakes (A.B.S.) - (See key at end of wiring diagrams)

Anti-lock brakes (A.B.S.)



### 55.

#### Location of components



#### Anti-lock brakes (A.B.S. 53)

##### Components key

- 3A Left front earth for anti-lock brakes (A.B.S.)
- 7 Battery
- 8 Main connector block
- 9 Earth on bodysell
- 9A Earth on side panel for anti-lock brakes (A.B.S.)
- 19 Sensor on left front wheel for anti-lock brakes (A.B.S.)
- 19A Connection for cable for sensor on left front wheel for anti-lock brakes (A.B.S.)
- 34 Anti-lock braking system electronic control unit (A.B.S.)
- 47 Sensor on right front wheel for anti-lock brakes (A.B.S.)
- 47A Connection for cable for sensor on right front wheel for anti-lock brakes (A.B.S.)
- 73 Secondary connector block
- 73C 30A fuse protecting ignition switch / anti-theft device
- 75 Junction unit (dashboard)
- 77 10A fuse protecting anti-lock brakes (A.B.S.)
- 78 Instrument panel
- P Anti-lock braking system failure warning light (A.B.S.)
- 105 Ignition switch
- 193 Sensor on left rear wheel for anti-lock brakes (A.B.S.)
- 193A Connection for cable for sensor on left rear wheel for anti-lock brakes (A.B.S.)
- 194 Sensor on right rear wheel for anti-lock brakes (A.B.S.)
- 194A Connection for cable for sensor on right rear wheel for anti-lock brakes (A.B.S.)
- 271 Brake lights switch
- 344 Connection between dashboard and anti-lock brakes cables (A.B.S.)
- 372 50A fuse protecting anti-lock brakes (A.B.S.)
- 374 Diagnostic socket for Fiat / Lancia Tester
- N.D. Ultrasound welding taped in cable loom

<b>19</b> Sensor on left front wheel for anti-lock brakes (A.B.S.)	<b>75B</b> Junction unit (dashboard)
<b>34</b> Anti-lock brakes electro-hydraulic control unit (A.B.S.)	
* G 47A * G 47A * B 194A * B 194A * N 9A * R n.d. * R n.d. * N 3A	V 193A * V 193A * V 193A * BR 374 * AB 374 * RN 344 * A 344 * R 19A * R 19A * 16 19 20 27 31 26 15

<b>75H</b> Junction unit (dashboard)	<b>78A</b> Instrument panel
N n.d. RN 99 V 76C * VN 271	AV 119C AG 119C LG 75E CN 76B NZ 101 Z 85D * A n.d. BN 76B HV n.d. GN 76B CB 76B AN n.d. RV 85B LR 32B G n.d.
<b>78D</b> Instrument panel	<b>344</b> Connection between dashboard and anti-lock brakes cables (A.B.S.)
MG 100 AG 100 BV 32B V 32B L 32B M 32B AR 85E BR 76B AN 32B LN 344 * LB n.d. AB 274 MB 68	* LN 34 * A 34 * RN 34 * RN n.d. * A 77 LN 78D *

\* The cables in the wiring diagram, are marked with an asterisk



**COMPONENTS KEY:**

- 1 Left front light cluster  
3 Left front earth  
3A Left front earth for anti-lock brakes (A.B.S.)  
5 Left front brake pad wear sensor  
6 Left side direction indicator  
7 Battery  
8 Main connector block  
9 Earth on bodyshell  
9A Earth on bodyshell  
12 Insufficient brake fluid level sensor  
13 Reversing lights switch  
14 Impulse generator for speedometer signal  
15 Starter motor  
16 Spark plugs  
19 Sensor on left front wheel for anti-lock brakes (A.B.S.)  
19A Connection for cable for sensor on left front wheel for anti-lock brakes (A.B.S.)  
20 Alternator  
21 Minimum engine oil level sensor  
23 Sensor signalling minimum engine oil pressure  
25 Air temperature sensor  
26 Three stage pressure switch  
27 Right front earth  
30 Right front light cluster  
31 Peripheral control unit (engine compartment)  
E3 Compressor coupling relay feed  
32A Connection between dashboard and left engine compartment cables  
32B Connection between dashboard and left engine compartment cables  
32C Connection between dashboard and left engine compartment cables  
33A Connection between dashboard and right engine compartment cables  
34 Anti-lock brakes electronic control unit (A.B.S.)  
35 Connection between engine compartment and electronic injection cables  
36 Heated Lambda sensor  
37 Idle adjustment actuator  
38 Earth for electronic injection  
39 Relay for inertia switch  
40 E.G.R. solenoid valve  
41 Petrol vapour cut out solenoid valve  
42 30A fuse protecting electronic injection  
43 Electronic earths  
44 Power earth  
45 Air flow meter  
46 7.5A protecting electronic injection  
47 Sensor on right front wheel for anti-lock brakes (A.B.S.)  
47A Connection for cable for sensor on right front wheel for anti-lock brakes (A.B.S.)  
48 10A fuse protecting heated Lambda sensor and air flow meter relay  
49 Electric fuel pump and heated Lambda sensor relay feed  
50 Electronic injection system relay feed  
51 Air flow meter relay feed  
52 Ignition coil  
53 Ignition coil  
54 Ignition coil  
55 Ignition coil  
56 Ignition coil  
57 Ignition coil  
58 Injectors  
59 1st Detonation sensor  
60 2nd Detonation sensor  
61 Engine coolant temperature sensor for electronic injection  
62 Rpm sensor  
63 Potentiometer on butterfly valve  
64 40A fuse protecting heater plugs  
66 Timing sensor  
68 Connection between dashboard and electronic injection cables  
69 Engine services cable connection  
72 Fuel injection control unit  
72 Fuel pump electronic control unit (2378 Td)  
73 Secondary connector block  
73A 80A fuse protecting rear services  
73B 60A protective fuse for I.G.E. control unit / junction unit  
73C 30A fuse protecting ignition switch / alarm  
74 60A protective fuse for peripheral control unit (engine compartment)  
75 Junction unit (dashboard)  
E1 Ignition discharge relay  
E2 Intermittent device for direction indicators / hazard warning lights  
76 I.G.E. control unit  
77 10A fuse protecting anti-lock brakes (A.B.S.)  
78 Instrument panel  
A Trailer direction indicator warning light  
B1 Passenger's side heated seat warning light  
C Heated rear windscreen warning light  
F1 Instrument panel light bulbs  
I Check summary warning light  
L Left direction indicator warning light  
L1 Right direction indicator warning light  
J Seat belts not fastened warning light  
K Battery recharging warning light  
M Insufficient engine oil pressure warning light  
N Handbrake warning light / I.G.E. control unit  
O Insufficient brake fluid level warning light  
P Warning light signalling anti-lock brakes failure (A.B.S.)  
S Heater plugs warning light  
T Voltmeter  
U Electronic rev counter  
V Fuel level gauge  
V1 Fuel reserve warning light  
X Milometer/trip meter  
Y Electronic tachometer  
Z Electronic automatic transmission gear selector display  
Z1 Trip computer zeroing button  
85 Infocenter control unit  
87 Light for glove compartment/controls for boot release  
88 Diagnostic socket for Fiat/Lancia tester  
90 Connection between dashboard and left front door cables  
91 Speaker in left front door  
95 Left front central locking geared motor and signalling of left front door open and alarm on  
96 Earth on carrier  
97 Earth on floor  
98 Ashtray light  
99 Cigar lighter  
100 Connection between dashboard and left longitudinal cables  
101 Light dimmer  
102 Exterior lights control unit  
B Switch for side lights/number plate lights  
C Switch for dipped beam headlights/main beam headlights  
D Switch for parking lights  
E Switch for ideogram lights  
103 Switch control unit  
A Fog lights switch  
B Rear fog lamps control switch  
C Headlamp alignment unit  
104 Steering column switch unit  
D Switch for direction indicators /parking lights  
E Main beam headlights flasher button  
F Switch for main beam head-lamps  
105 Ignition switch  
107 Alarm control unit  
108 Lancia CODE control unit  
117 Switch signalling handbrake applied  
119A Connection between dashboard and right longitudinal cables  
119B Connection between dashboard and right longitudinal cables  
119D Connection between dashboard and right longitudinal cables  
120 Connection between dashboard and right front door cables  
122 Speaker in right front door  
126 Right front central locking geared motor and signalling of right front door open and alarm on  
131 Earth on steering column support  
134 Servotronic solenoid valve  
135 Earth on floor for AIR-BAG signal  
137 Tailgate lock assembly  
A Switch for luggage compartment courtesy light switch and alarm  
B Tailgate locking/unlocking motor  
141 Connection between right longitudinal and right rear door cables  
146 Right rear door central locking geared motor and signalling of right rear door open and alarm on  
150 Connection between left longitudinal and left rear door cables  
151 Amplifier for radio  
153 Light in left rear door  
155 Left rear door central locking geared motor and signalling of left rear door open and alarm on  
164 Left rear speaker  
165 Heated rear windscreen  
165A Earth for heated rear windscreen  
166 Amplifier for aerial in rear screen  
166A Rear cables connection in rear screen  
167 Fuel level gauge  
168 Electric fuel pump  
169 Right rear speaker  
171 Additional brake lights warning light  
172 Right rear light cluster on fixed section  
173 Right rear earth  
174 Right rear light cluster on moving section  
175 Connection between left longitudinal and tailgate cables



119A	Connection between dashboard and right longitudinal cables	176	Tailgate cables connection	341	Right side direction indicator	GN	Yellow/Black
119B	Connection between dashboard and right longitudinal cables	177	Left rear light cluster on moving section	343	40A starter relay	GL	Yellow/Blue
119D	Connection between dashboard and right longitudinal cables	178	Left rear earth	344	Connection between dashboard and anti-lock brakes cables (A.B.S.)	GR	Yellow/Red
120	Connection between dashboard and right front door cables	179	Left rear light cluster on fixed section	345	Right front earth	GV	Yellow/Green
122	Speaker in right front door	180	Heated rear windscreen relay feed	347	Excess turbocharging pressure sender unit	HG	Grey/Yellow
126	Right front central locking geared motor and signalling of right front door open and alarm on	181	Connection between left longitudinal and right longitudinal cables	354	Electric diesel pump	HN	Grey/Black
131	Earth on steering column support	188	25A fuse protecting boot release electro-magnet	355	Instrument injector	HR	Grey/Red
134	Servotronic solenoid valve	189	30A fuse protecting heated rear windscreen	356	Solenoid valve on diesel pump	LB	Blue/White
135	Earth on floor for AIR-BAG signal	190	Tailgate locking/unlocking relay feed	357	Heater plugs control unit	LG	Blue/Yellow
137	Tailgate lock assembly	191	Earth for inertia switch	359	Heater plugs	LN	Blue/Black
141	Connection between right longitudinal and right rear door cables	192	Inertia switch	361	Switch on clutch pedal	LR	Blue/Red
146	Right rear door central locking geared motor and signalling of right rear door open and alarm on	193	Sensor on left rear wheel for anti-lock brakes (A.B.S.)	364	Potentiometer on accelerator pedal	LV	Light blue/White
150	Connection between left longitudinal and left rear door cables	194	Connection for cable for sensor on left rear wheel for anti-lock brakes (A.B.S.)	369	Connection between electronic injection and left longitudinal cables	MB	Blue/Green
151	Amplifier for radio	195	Connection for cable for sensor on right rear wheel for anti-lock brakes (A.B.S.)	374	Diagnostic socket for anti-lock braking system (A.B.S.)	MN	Brown/White
153	Light in left rear door	198	Fuel filler flap release motor	382	Heated diesel filter relay feed (P.T.C.)	NZ	Brown/Black
155	Left rear door central locking geared motor and signalling of left rear door open and alarm on	198A	Servotronic electronic control unit	384	Heated diesel filter thermal contact (P.T.C.)	RB	Black/Violet
164	Left rear speaker	200	Controlled damping suspension electronic control unit (S.C.S.)	385	Heated diesel filter resistance (P.T.C.)	RG	Red/Yellow
165A	Heated rear windscreen	227	Right front speaker	386	Connection for cables to water in fuel filter sensor	RN	Red/Black
166	Amplifier for aerial in rear screen	228	Left front speaker	422	Connection between dashboard and left longitudinal cables	RV	Red/Green
166A	Rear cables connection in rear screen	266	Infra red receiver for alarm	430	Diode connecting handbrake applied/insufficient brake fluid level	SN	Pink/Black
167	Fuel level gauge	269	Connection between dashboard and receiver cables	431	Direction indicators operation with doors locked	VB	Green/White
168	Electric fuel pump	271	Brake lights switch	432	20A protective fuse for ignition switch relay	VN	Green/Black
169	Right rear speaker	272	Driver's AIR-BAG connection	434	15A fuse protecting current socket	ZB	Violet/White
171	Additional brake lights warning light	273	Passenger AIR-BAG connection	435	Current socket relay feed	GN	Orange/Black
172	Right rear light cluster on fixed section	273A	Connection for clock spring	436	Current socket		
173	Right rear earth	274	Connection between dashboard and AIR-BAG cables				
174	Right rear light cluster on moving section	275	AIR-BAG control unit				
175	Connection between left longitudinal and tailgate cables	276	Left seat belt pre-tensioner				
		277	Right seat belt pre-tensioner				
		278	Diagnostic socket for AIR-BAG				
		290	Left front air vent controls light				
		291	Left centre air vent controls light				
		292	Right centre air vent controls light				
		293	Right front air vent controls light				
		295	Radio cables connection				
		296	Radio cables connection				
		297	Warning light for alarm/LANCIA Code				
		300	Central locking electronic control unit				
		317	Connection between electronic automatic transmission and electronic injection cables				
		334	Connection between electronic injection cable and injector bridge				
		340	Right front brake pad wear sensor				




**CONNECTOR BLOCKS**

page


**INTRODUCTION 25**

- Interpretation of the codes at the connector blocks 26
- Cable colour code 26
- Connector blocks 27






Air-bag and failure warning light - Seat belt pre-tensioners - Servotronic device - (See key at end of wiring diagrams)



### 55.




Air-bag and failure warning light - Seat belt pre-tensioners - Servotronic device


#### Components key

- |      |  |     |  |
|------|--|-----|--|
| 7    | Battery  | 272 | Driver's AIR-BAG connection              |
| 8    | Main connector block   | 273 | Passenger AIR-BAG connection             |
| 9    | Earth on bodyshell   | 274 | Connection btwn dash. and AIR-BAG cables |
| 73C  | Secondary control block  | 275 | AIR-BAG control unit                     |
| 73C  | 30A fuse protecting ignition switch/anti-theft device          | 276 | Left seat belt pre-tensioner             |
| 75   | Junction unit (dashboard)                                      | 277 | Right seat belt pre-tensioner            |
| 78   | Instrument panel   | 278 | Diagnostic socket for AIR-BAG            |
| 105  | Electronic rev counter   |     |  |
| 119B | Ignition switch  |     |  |
| 134  | Connection between dashboard and right longitudinal cables     |     |  |
| 135  | Servotronic solenoid valve                                     |     |  |
| 173  | Earth on floor (signal for AIR-BAG)                            |     |  |
| 198  | Right rear earth   |     |  |
| 198A | Servotronic electronic control unit                            |     |  |
| 200  | Diagnostic socket  |     |  |
|      | Controlled damping suspension electronic control unit (S.C.S.) |     |  |


N.D. Ultrasound welding taped in cable loom




**173** Right rear earth




**198** Servotronic electronic control unit




**198A** Diagnostic socket




**274** Con. btwn dash. & AIR-BAG cables



**275** AIR-BAG control unit



**278** Diagnostic socket for AIR-BAG




The cables in the wiring diagram, are marked with an asterisk





### INTRODUCTION

### Interpretation of the codes at the connector blocks




P3U152N01

- A** Identification N° of connector block with reference to wiring diagrams
- B** Cable colour identification code (see table at the foot of the page)
- C** Identification N° of connector block for cable marked with appropriate code
- D** The n.d. code (connector block) identifies ultrasound welding taped in the cable loom


### Cable colour code

<b>A</b>	Light blue	<b>BG</b>	White-Yellow	<b>LB</b>	Blue-White
<b>B</b>	White	<b>BL</b>	White-Blue	<b>LG</b>	Blue-Yellow
<b>C</b>	Orange	<b>BN</b>	White-Black	<b>LN</b>	Blue-Black
<b>G</b>	Yellow	<b>BR</b>	White-Red	<b>LR</b>	Blue-Red
<b>H</b>	Grey	<b>BV</b>	White-Green	<b>LV</b>	Blue-Green
<b>L</b>	Blue	<b>BZ</b>	White-Violet	<b>MB</b>	Brown-White
<b>M</b>	Brown	<b>CA</b>	Orange-Light blue	<b>MN</b>	Brown-Black
<b>N</b>	Black	<b>CB</b>	Orange-White	<b>NZ</b>	Black-Violet
<b>R</b>	Red	<b>CN</b>	Orange-Black	<b>RB</b>	Red-White
<b>S</b>	Pink	<b>GN</b>	Yellow-Black	<b>RG</b>	Red-Yellow
<b>V</b>	Green	<b>GL</b>	Yellow-Blue	<b>RN</b>	Red-Black
<b>Z</b>	Violet	<b>GR</b>	Yellow-Red	<b>RV</b>	Red-Green
<b>AB</b>	Light blue-White	<b>GV</b>	Yellow-Green	<b>SN</b>	Pink-Black
<b>AG</b>	Light blue-Yellow	<b>HG</b>	Grey-Yellow	<b>VB</b>	Green-White
<b>AN</b>	Light blue-Black	<b>HN</b>	Grey-Black	<b>VN</b>	Green-Black
<b>AR</b>	Light blue-Red	<b>HR</b>	Grey-Red	<b>VR</b>	Green-Red
<b>AV</b>	Light blue-Green	<b>HV</b>	Grey-Green	<b>ZB</b>	Violet-White


### 266A Radio frequency receiver for alarm device




### 434 15A protective fuse for current socket




### 435 Current socket relay feed




### 436 Current socket




### 437 Preparation for radio telephone




### 438 Two function speaker for radio and radio telephone in right front door



### 455 Radio telephone aerial



### 456 Connector for radio telephone aerial



P3U511L01



#### COMPONENTS KEY:

- 1 Left front light cluster
- 3 Left front earth
- 5 Left front brake pad wear sensor
- 6 Left side direction indicator
- 7 Battery
- 8 Main connector block
- 9 Earth on bodyshell
- 12 Insufficient brake fluid level sensor
- 13 Reversing lights switch
- 14 Impulse generator for speedometer signal
- 15 Starter motor
- 16 Spark plugs
- 20 Alternator
- 21 Minimum engine oil level sensor
- 23 Minimum engine oil pressure sensor
- 25 Air temperature sensor
- 26 Three stage pressure switch
- 27 Right front earth
- 30 Right front light cluster
- 31 Peripheral control unit (engine comp.)
- 32A Connection between dashboard and left engine compartment cables
- 32B Connection between dashboard and left engine compartment cables
- 32C Connection between dashboard and left engine compartment cables
- 33A Connection between dashboard and right engine compartment cables
- 35 Connection between engine compartment and electronic injection cables
- 36 Heated Lambda sensor
- 37 Idle adjustment actuator
- 38 Earth for electronic injection
- 39 Relay for inertia switch
- 40 E.G.R. solenoid valve
- 41 Petrol vapour cut out solenoid valve
- 42 30A fuse protecting electronic injection
- 43 Electronic earths
- 44 Power earth
- 45 Air flow meter
- 46 7.5 A fuse protecting electronic injection

- 48 10A fuse protecting heated Lambda sensor and air flow meter relay
- 49 Electric fuel pump and heated Lambda sensor relay feed
- 50 Electronic injection system relay feed
- 51 Air flow meter relay feed
- 52 Ignition coil
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Injectors
- 59 1st Detonation sensor
- 60 2nd Detonation sensor
- 61 Engine coolant temperature sensor for electronic injection
- 62 Rpm sensor
- 63 Potentiometer on butterfly valve
- 64 40A fuse protecting heater plugs
- 66 Timing sensor
- 68 Connection between dashboard and electronic injection cables
- 69 Engine service cables connection
- 72 Fuel injection control unit
- 72 Fuel pump electronic control unit (2378 Td)
- 73 Secondary connector block
- 73A 80A fuse protecting rear services
- 73B 60A protective fuse for I.G.E. control unit / junction unit
- 73C 30A fuse protecting ignition switch / alarm device
- 74 60A protective fuse for peripheral control unit (engine compartment)
- 75 Junction unit (dashboard)
- E1 Ignition discharge relay
- E2 Intermittent device for direction indicators / hazard warning lights
- 76 I.G.E. control panel
- 78 Instrument panel
- A Trailer direction indicators warning light
- B1 Passenger's side heated seat warning light
- C Heated rear windscreen warning light
- F1 Instrument panel light bulbs
- I Check summary warning light
- L Left direction indicator warning light
- L1 Right direction indicator warning light

- J Seat belts not fastened warning light
- K Battery recharging warning light
- M Insufficient engine oil pressure warning light
- N Handbrake applied / I.G.E. control unit warning light
- O Insufficient brake fluid level warning light
- S Heater plugs warning light
- T Voltmeter
- U Electronic rev counter
- V Fuel level gauge
- V1 Fuel reserve warning light
- X Mileometer/trip meter
- Y Electronic tachometer
- Z Electronic automatic transmission gear selector display
- Z1 Trip computer zeroing button
- 85 Infocenter control unit
- 87 Glove compartment/boot release controls light
- 88 Diagnostic socket for Fiat/Lancia tester
- 90 Connection between dashboard and left front door cables
- 91 Speaker in left front door
- 95 Left front central locking geared motor and left front door ajar signal and alarm on
- 96 Earth on carrier
- 97 Earth on floor
- 98 Ashtray light
- 99 Cigar lighter
- 100 Connection between dashboard and left longitudinal cables
- 101 Light dimmer
- 102 External light controls
- B Side lights/no. plate lights switch
- C Dipped headlights/main beam headlights control switch
- D Parking lights control switch
- E Ideogram light switch
- 103 Switch control unit
- A Fog lights switch
- B Rear fog lamps control switch C Headlamp alignment control panel
- Steering column switch unit
- 104 D Direction indicators / parking lights control switch
- E Main beam headlights flasher
- F Main beam headlights control switch

- 105 Ignition switch
- 107 Alarm control
- 108 Lancia CODE
- 117 Switch signal
- 119A Connection right longitudinal
- 119B Connection right longitudinal
- 119D Connection right longitudinal
- 120 Connection front door cable
- 122 Speaker in right front door
- 126 Right front door and right front door
- 131 Earth on steel
- 134 Servotronic sensor
- 135 Earth on floor signal
- 137 Tailgate lock
- A Luggage compartment switch and alarm
- B Tailgate lock
- 141 Connection between left rear door and right rear door
- 146 Right rear door motor and right alarm on
- 150 Connection between left rear door and left rear door
- 151 Amplifier for Road illumination
- 153 Road illumination
- 155 Left rear door and left rear door
- 164 Left rear door
- 165 Heated rear window
- 165A Earth for heater
- 166 Amplifier for Rear cables control
- 166A Rear cables control
- 167 Fuel level gauge
- 168 Electric fuel pump
- 169 Right rear door
- 171 Additional brake
- 172 Right rear door
- 173 Right rear door




105	Ignition switch	174	Right rear light cluster on movable section	341	Right side direction indicator	A	Light blue	GN	Yellow/Black
107	Alarm control unit	175	Connection between left longitudinal and tailgate cables	343	40A starting relay	B	White	GL	Yellow/Blue
108	Lancia CODE control unit	176	Tailgate cables connection	345	Right front earth	C	Orange	GR	Yellow/Red
117	Switch signalling handbrake applied	177	Tailgate cables connection	347	Excess turbocharger pressure sender unit	G	Yellow	GV	Yellow/Green
119A	Connection between dashboard and right longitudinal cables	178	Left rear light cluster on movable section	354	Electric diesel pump	H	Grey	HG	Grey/Yellow
119B	Connection between dashboard and right longitudinal cables	179	Left rear light cluster on fixed section	355	Instrument injector	L	Blue	HN	Grey/Black
119D	Connection between dashboard and right longitudinal cables	180	Heated rear windscreen relay feed	356	Solenoid valve on diesel pump	M	Brown	HR	Grey/Red
120	Connection between dashboard and right front door cables	181	Connection between left longitudinal and right longitudinal cables	357	Heater plugs control unit	N	Black	HV	Grey/Green
122	Speaker in right front door	188	25A fuse protecting boot release electric	358	Engine cut out solenoid on injection pump	R	Red	LB	Blue/White
126	Right front central locking geared motor and right front door ajar signal and alarm on	189	30A fuse protecting heated rear windscreen	359	Heater plugs	S	Pink	LG	Blue/Yellow
131	Earth on steering column support	190	Tailgate locking/unlocking relay feed	361	Switch on clutch pedal	V	Green	LN	Blue/Black
134	Servotronic solenoid valve	191	Earth for inertia switch	362	Switch on pedal	Z	Violet	LR	Blue/Red
135	Earth on floor for AIR-BAG signal	192	Inertia switch	364	Potentiometer on accelerator pedal	AB	Light blue/White	LV	Blue/Green
137	Tailgate lock assembly	195	Fuel filler flap release motor	365	Connection between electronic injection and left longitudinal cables	AG	Light blue/Yellow	MB	Brown/White
141	Connection between right longitudinal and right rear door cables	198	Servotronic electronic control unit	369	Heated diesel filter thermal contact (P.T.C.)	AN	Light blue/Black	MN	Brown/Black
146	Right rear door central locking geared motor and right rear door ajar signal and alarm on	200	Controlled damping suspension electric control unit (S.C.S.)	382	Heated diesel filter relay feed (P.T.C.)	AR	Light blue/Red	NZ	Black/Violet
150	Connection between left longitudinal and left rear door cables	227	Right front speaker	383	15A fuse protecting heated diesel filter (P.T.C.)	AV	Light blue/Violet	RB	Red/White
151	Amplifier for radio	228	Left front speaker	384	Heated diesel filter thermal contact (P.T.C.)	BG	White/Yellow	RG	Red/Green
153	Road illumination light in left rear door	266	Infra red receiver for alarm device	422	Connection between dashboard and left longitudinal cables	BL	White/Blue	RN	Red/Black
155	Left rear door central locking geared motor and left rear door ajar signal and alarm on	269	Connection between dashboard and receiver cables	430	Diode connecting handbrake applied/sufficient brake fluid system	BN	White/Black	RV	Pink/Black
164	Left rear speaker	271	Brake lights switch	431	Direction indicators with doors closed device	BR	White/Red	SN	Green/White
165	Heated rear windscreen	272	Driver's AIR-BAG connection	432	20A protective fuse ignition switch relay feed	BV	White/Green	VB	Green/Black
165A	Earth for heated rear windscreen	273	Passenger AIR-BAG connection	434	15A fuse protecting current socket	CA	Orange/Light blue	VR	Green/Red
166	Amplifier for aerial in rear screen	273A	Connection for device with clock spring	435	Current socket relay feed	CB	Orange/White	ZB	Violet/White
166A	Rear cables connection in rear screen	274	Connection between dashboard and AIR-BAG cables	436	Current socket	CN	Orange/Black		
167	Fuel level gauge	275	AIR-BAG control unit						
168	Electric fuel pump	276	Left seat belt pre-tensioner						
169	Right rear speaker	277	Right seat belt pre-tensioner						
171	Additional brake lights indicator	278	Diagnostic socket for AIR-BAG						
172	Right rear light cluster on fixed section	290	Left front air vent controls light						
173	Right rear earth	291	Left centre air vent controls light						
		292	Right centre air vent controls light						
		293	Right front air vent controls light						
		295	Radio cables connection						
		296	Radio cables connection						
		297	Alarm device / LANCIA code warning light						
		300	Central locking electronic control unit						
		317	Connection between electronic automatic transmission and electronic injection cables						
		334	Connection between electronic injection cable and injector bridge						
		340	Right front brake pad wear sensor						





CONNECTOR BLOCK CONTENTS

	page
- INTRODUCTION	40
- Explanation of codes on connector blocks	40
- Wiring colour code	40
- Connector blocks	41



### CONNECTOR BLOCK CONTENTS


	page
- INTRODUCTION	40
- Explanation of codes on connector blocks	40
- Wiring colour code	40
- Connector blocks	41



55.

### INTRODUCTION

#### Interpretation of codes on connection blocks








P3U152N01

- At** Identification no. of connection block for wiring diagrams
- B** Wiring colour identification code (see table at end of page)
- C** Identification number of target block of cable marked with the relavent code
- D** The code n.d. identifies a connection block taped into the wiring harness

#### Cable colour codes

<b>At</b>	Light blue	<b>BG</b>	White-Yellow	<b>LB</b>	Blue-White
<b>B</b>	White	<b>BL</b>	White-Blue	<b>LG</b>	Blue-Yellow
<b>C</b>	Orange	<b>BN</b>	White-Black	<b>LN</b>	Blue-Black
<b>D</b>	Yellow	<b>BR</b>	White-Red	<b>LR</b>	Blue-Red
<b>H</b>	Grey	<b>BV</b>	White-Green	<b>LV</b>	Blue-Green
<b>L</b>	Blue	<b>BZ</b>	White-Violet	<b>MB</b>	Brown-White
<b>M</b>	Brown	<b>CA</b>	Orange-Light blue	<b>MN</b>	Brown-Black
<b>N</b>	Black	<b>CB</b>	Orange-White	<b>NZ</b>	Black-Violet
<b>R</b>	Red	<b>CN</b>	Orange-Black	<b>RB</b>	Red-White
<b>S</b>	Pink	<b>GN</b>	Yellow-Black	<b>RG</b>	Red-Yellow
<b>V</b>	Green	<b>GL</b>	Yellow-Blue	<b>RN</b>	Red-Black
<b>Z</b>	Violet	<b>GR</b>	Yellow-Red	<b>RV</b>	Red-Green
<b>AB</b>	Light blue-White	<b>GV</b>	Yellow-Green	<b>SN</b>	Pink-Black
<b>AG</b>	Light blue-Yellow	<b>HG</b>	Grey-Yellow	<b>VB</b>	Green-White
<b>AN</b>	Light blue-Black	<b>HN</b>	Grey-Black	<b>VN</b>	Green-Black
<b>AR</b>	Light blue-Red	<b>HR</b>	Grey-Red	<b>VR</b>	Green-Red
<b>AV</b>	Light blue-Green	<b>HV</b>	Grey-Green	<b>ZB</b>	Violet-White

**422** Connection between facia lead and left longitudinal lead**429** 7.5A heated door mirror fuse**430** Handbrake on/low brake fluid level connection diode**431** Turn signal and door closure control device**432** 20A ignition switch control relay fuse

P3U75AN01



K

3  
3  
3  
3





# KEY TO COMPONENTS:

- 1 Left front light cluster
- 2 Left fog lamp
- 3 Left front earth
- 6 Left side turn signal
- 7 Battery
- 8 Main junction unit
- 9 Earth on body
- 10 Button on bonnet for activation of alarm
- 12 Low brake fluid level indication sensor
- 13 Reversing lights switch
- 14 Pulse generator for speedometer signal
- 15 Starter motor
- 16 Spark plugs
- 20 Alternator
- 22 Engine coolant temperature sender unit
- 23 Minimum engine oil pressure indicator sensor
- 24 Barometric capsule
- 25 Air temperature sensor
- 26 Three stage pressure switch
- 27 Right front earth
- 29 Right fog lamp
- 30 Right front light cluster
- 31 Peripheral ECU (engine bay)
- E1 Dipped beam relay
- E3 Compressor coupling control relay
- E4 Main beam relay
- E5 Fog lamp relay
- E6 Cooling fan high speed relay
- E7 Engine fan low speed relay
- 32A Connection between facia cable and left engine bay cable
- 32B Connection between facia cable and left engine bay cable
- 32C Connection between facia cable and left engine bay cable
- 33A Connection between facia cable and right engine bay cable
- 34 Anti-lock brake hydraulic control unit (A.B.S.)
- 35 Connection between engine bay cable and electronic injection cable
- 36 Hot Lambda probe
- 37 Idle adjustment actuator
- 38 Earth for electronic injection
- 39 Relay for inertia switch
- 40 EGR device control solenoid
- 41 Fuel vapour cut-off solenoid
- 42 30A fuse for electronic injection system
- 43 Electronic earths
- 44 Power earth
- 45 Air flow meter (Debimeter)
- 46 7.5A electronic injection system fuse
- 48 10A hot lambda probe and air flow meter relay fuse (Debimeter)

- 49 Fuel pump control relay and hot Lambda probe
- 50 Electronic injection system control relay
- 51 Air flow meter control relay (Debimeter)
- 52 Ignition coil
- 53 Ignition coil
- 54 Ignition coil
- 55 Ignition coil
- 56 Ignition coil
- 57 Ignition coil
- 58 Injectors
- 59 1 Knock sensor
- 60 2 Knock sensor
- 61 Engine coolant temperature sensor for electronic injection
- 62 Rpm sensor
- 63 Potentiometer on throttle valve
- 64 40A glow plug fuse
- 66 Timing sensor
- 68 Connection between facia lead and electronic injection lead
- 69 Engine service lead connection
- 70 HT distributor
- 71 Tow hook control unit
- 72 Fuel injection control unit
- 72A Fuel pump ECU (2378 Td)
- 73 Secondary junction unit
- 73A 30A rear service fuse
- 73B 60A fuse protecting I.G.E. control unit/junction unit
- 73C 30A switch protection fuse for ignition/alarm device
- 74 60A fuse protecting peripheral control unit (engine bay)
- 75 Junction unit (facia)
- E1 Switch discharge connector
- E2 Turn signal/hazard warning light flasher
- 76 IGE control unit
- 78 Instrument panel
- A Trailer turn signal warning light
- B Driver's side heated seat warning light
- B1 Passenger side heated seat warning light
- C Heated rear windscreen warning light
- D Fog lights warning light
- E Rear fog lamps warning light
- F Side lights warning light
- F1 Instrument panel light bulb
- G Dipped beam warning light
- H Main beam headlamps warning light
- I Check warning light
- L Left turn signal warning light
- L1 Right turn signal warning light
- J Seat belt undone warning light
- K Battery recharging warning light

- M Insufficient engine oil pressure warning light
- N Handbrake warning light / I.G.E. ECU
- O Insufficient brake fluid level warning light
- P ABS failure warning light (A.B.S.)
- Q ASR failure warning light
- R Air-bag failure warning light
- S Heater plugs warning light
- T Voltmeter
- U Electronic rev counter
- V Fuel level gauge
- V1 Fuel reserve warning light
- X Mileometer/trip counter display
- Y Electronic tachometer
- Y1 SCS switch unit
- W Water temperature gauge
- W1 Maximum coolant temperature warning light
- Z Electronic automatic transmission gear selection display
- Z1 Trip computer reset button
- 79 Connection between facia cable and courtesy light cable
- 85 Infocenter ECU
- 87 Glove compartment / boot release control lighting
- 88 Tester socket for Fiat/Lancia tester
- 89 Left door mirror
- A Left door mirror fold-down motor
- B Left door mirror vertical positioning motor
- C Left door mirror horizontal positioning motor
- D Left door mirror heater coil
- E Outdoor temperature sensor
- 90 Connection between facia cable and left front door cable
- 91 Speaker on left hand front door
- 93 Puddle light on left front door
- 95 Left front door lock motor and left front door open indicator and alarm activation
- 96 Earth on carrier
- 97 Earth on floor pan
- 99 Cigar lighter
- 100 Connection between facia lead and left longitudinal lead
- 101 Lighting dimmer
- 102 Exterior lighting unit
- B Side light/number plate light switch
- C Dipped beam/main beam switch
- D Parking light switch
- E Symbol light control switch

- 103 Switch control unit
- A Fog lamp switch
- B Rear fog lamp switch
- C Headlamp alignment corrector control unit
- 104 Stalk unit
- A Windscreen washer / headlamp washer control stalk
- B Windscreen wiper control stalk
- C Horn button
- D Turn signal/parking light stalk
- E Main beam flasher button
- F Main beam control switch
- 105 Ignition switch
- 106 Lancia CODE device aerial
- 107 Alarm control unit
- 108 Lancia CODE control unit
- 115 Electrically-adjustable door mirror control unit
- 117 Hand brake warning light switch
- 119A Connection between facia cable and right longitudinal cable
- 119B Connection between facia cable and right longitudinal cable
- 119C Connection between facia cable and right longitudinal cable
- 119D Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- 121 Right door mirror
- A Right door mirror fold-down motor
- B Right door mirror horizontal positioning motor
- C Right door mirror horizontal positioning motor
- D Right door mirror heater coil
- 122 Speaker on right hand front door
- 124 Puddle light on right front door
- 126 Right front door lock motor and right front door open indicator and alarm device activation
- 128 Timer controlling front/boot courtesy light
- 131 Earth on steering column mount
- 137 Luggage compartment tail-gate lock assembly
- A Luggage compartment light switch and alarm activation
- B Tail-gate lock/release motor
- 141 Connection between right longitudinal cable and right rear door cable
- 144 Puddle light on right rear door
- 146 Right rear door lock motor and right door open/car alarm activated w/light

- 150 Comm and le
- 151 Ampl
- 153 Puddle
- 155 Left r open
- 161 100A
- 162 Lugga
- 163 Left r
- 164 Left h
- 165 Heate
- 165A Earh
- 166 Ampl
- 166A Rear
- 167 Fuel
- 168 Electr
- 169 Right
- 170 Right
- 171 Suppl
- 172 Right
- 173 Right
- 174 Right
- 175 Comm
- 175S Left r
- 175D Right
- 176 Lugga
- 176h Left r
- 178 Left r
- 179 Left r
- 180 Heate
- 181 Comm
- 183 Relay
- 184 Relay
- 188 25A h
- 189 30A h
- 190 Lugga
- 191 Earth
- 192 Inertu
- 195 Fuel
- 196 Provi
- 198 Servo
- 199 Alarm
- 200 Electr
- 225 Left f
- 226 Right
- 227 Right
- 228 Left f
- 266 Infra-
- 267 Volun
- 269 Comm
- cable



warning	103 Switch control unit A Fog lamp switch B Rear fog lamp switch C Headlamp alignment corrector control unit	150 Connection between left longitudinal cable and left rear door cable 151 Amplifier for car radio 153 Puddle light on left rear door 155 Left rear door lock motor and left rear door open/car alarm activated w/light and alarm activation	271 Braking light switch 274 Connection between facia cable and air bag lead 275 Air-bag ECU 281 Front courtesy light for car interior 282 Interior chrome-plated mirror 283 Lighted panel on passenger side 295 Radio cable connection 296 Radio cable connection 297 Alarm / Lancia CODE device warning light 300 Central locking electronic control unit 301 Solenoid unit 302 Switch control assembly 306 Electronic automatic transmission acoustic alarm 307 Electronic automatic transmission acoustic alarm switch 315 Electronic automatic transmission speed selection control unit (ZF) 316 Electronic automatic transmission tester socket 317 Connection between electronic automatic transmission and injection lead 318 Connection between electronic automatic transmission lead and facia lead 319 Provision for Kick-Down 320 Electronic automatic transmission speed selection lever display 334 Connection between electronic injection lead and injector braid 341 Right side turn signal 343 40A starter relay 344 Facia cable connection with anti-lock brake cable (At.B.S.) 345 Right front earth 354 Diesel pump 355 Injector with controls 356 Solenoid on diesel pump 357 Glow plug system control unit 358 Engine cut out solenoid on injection pump 359 Glow plugs 361 Switch on clutch pedal 362 Switch on pedal 364 Potentiometer on accelerator pedal 369 Connection between electronic injection lead and left longitudinal lead 376 Modular manifold solenoid 377 Timing variator 378 Modular manifold control relay 380 Relay for timing variator 382 Hot diesel filter control relay (P.T.C.) 383 15A hot diesel filter fuse (P.T.C.) 384 Thermal contact for hot diesel filter (P.T.C.) 385 Diesel filter heater coil (P.T.C.) 386 Cable connection to water in diesel filter sensor	401 Electronic automatic transmission speed selection control unit (AISIN) 412 Earth on bodywork 413 Connection to solenoid assembly 414 Throttle valve position potentiometer 415 Speed position selector 416 Speed position selector 417 Engine rpm sensor 418 Vehicle speed sensor 420 Automatic transmission fluid temperature sensor 422 Connection between facia cable and left longitudinal cable 429 7.5A heated door mirror fuse 430 Handbrake on/low brake fluid level connection diode 431 Turn signal and door closure control device 432 20A ignition switch control relay fuse
CU	104 Stalk unit A Windscreen washer / headlamp washer control stalk B Windscreen wiper control stalk C Horn button D Turn signal/parking light stalk E Main beam flasher button F Main beam control switch	161 100A alternator fuse 162 Luggage compartment lighting 163 Left rear courtesy light for car interior 164 Left hand rear speaker 165 Heated rear windscreen 165A Earth for heated rear windscreen 166 Amplifier for aerial on back window 166A Rear cable connection on rear window 167 Fuel level gauge 168 Electric fuel pump 169 Right hand rear speaker 170 Right rear courtesy light for vehicle interior 171 Supplementary stop light indicator 172 Right tail-light cluster on fixed part 173 Right rear earth 174 Right tail-light cluster on mobile part 175 Connection between left longitudinal cable and tail-gate cable 175S Left number plate light 175D Right number plate light 176 Luggage compartment tail-gate cable connection 176A Left tail-light cluster on mobile part 178 Left rear earth 179 Left tail-light cluster on fixed part 180 Heated back window relay 181 Connection between left longitudinal cable and right longitudinal cable 183 Relay for driver's side heat pad 184 Relay for passenger's side heat pad 188 25A luggage compartment release electromagnetic fuse 189 30A heated rear window fuse 190 Luggage compartment tail-gate lock/release control relay 191 Earth for inertia switch 192 Inertia switch 195 Fuel flap release motor 196 Provision for trailer 198 Servotronic device electronic control unit 199 Alarm siren 200 Electronic variable rate suspension control unit 225 Left floor light 226 Right floor light 227 Right front speaker 228 Left front loudspeaker 266 Infra-red ray receiver for alarm device 267 Volumetric sensors for alarm device 269 Connection between facia cable and receiver cable	303 Switch control unit A Fog lamp switch B Rear fog lamp switch C Headlamp alignment corrector control unit 104 Stalk unit A Windscreen washer / headlamp washer control stalk B Windscreen wiper control stalk C Horn button D Turn signal/parking light stalk E Main beam flasher button F Main beam control switch 105 Ignition switch 106 Lancia CODE device aerial 107 Alarm control unit 108 Lancia CODE control unit 115 Electrically-adjustable door mirror control unit 117 Hand brake warning light switch 119A Connection between facia cable and right longitudinal cable 119B Connection between facia cable and right longitudinal cable 119C Connection between facia cable and right longitudinal cable 119D Connection between facia cable and right longitudinal cable 120 Connection between facia cable and right front door cable 121 Right door mirror A Right door mirror fold-down motor B Right door mirror horizontal positioning motor C Right door mirror horizontal positioning motor D Right door mirror heater coil 122 Speaker on right hand front door 124 Puddle light on right front door 126 Right front door lock motor and right front door open indicator and alarm device activation 128 Timer controlling front/boot courtesy light 131 Earth on steering column mount 137 Luggage compartment tail-gate lock assembly A Luggage compartment light switch and alarm activation B Tail-gate lock/release motor 141 Connection between right longitudinal cable and right rear door cable 144 Puddle light on right rear door 146 Right rear door lock motor and right door open/car alarm activated w/light	At Light blue B White C Orange D Yellow H Grey L Blue M Brown N Black R Red S Pink V Green Z Violet AB Light blue-White AG Light blue-Yellow AN Light blue-Black AR Light blue-Violet AV Light blue-Violet BG White-Yellow BL White-Blue BN White-Black BR White-Red BV White-Green BZ White-Violet CA Orange-Light blue CB Orange-White CN Orange-Black GN Yellow-Black GL Yellow-Blue GR Yellow-Red GV Yellow-Green HG Grey-Yellow HN Grey-Black HR Grey-Red HV Grey-Green LB Blue-White LG Blue-Yellow LN Blue-Black LR Blue-Red LV Blue-Green MB Brown-White MN Brown-Black NZ Black-Violet RB Red-White RG Red-Yellow RN Red-Black RV Red-Green SN Pink-Black VB Green-White VN Green-Black VR Green-Red ZB Violet-White
g	117 Hand brake warning light switch			
se-	119A Connection between facia cable and right longitudinal cable 119B Connection between facia cable and right longitudinal cable 119C Connection between facia cable and right longitudinal cable 119D Connection between facia cable and right longitudinal cable			
courtesy	120 Connection between facia cable and right front door cable 121 Right door mirror A Right door mirror fold-down motor B Right door mirror horizontal positioning motor C Right door mirror horizontal positioning motor D Right door mirror heater coil			
ol light-	122 Speaker on right hand front door 124 Puddle light on right front door 126 Right front door lock motor and right front door open indicator and alarm device activation			
mirror	128 Timer controlling front/boot courtesy light 131 Earth on steering column mount 137 Luggage compartment tail-gate lock assembly A Luggage compartment light switch and alarm activation B Tail-gate lock/release motor			
g motor	141 Connection between right longitudinal cable and right rear door cable 144 Puddle light on right rear door 146 Right rear door lock motor and right door open/car alarm activated w/light			
ing mo-				
eft front				
nt door				
longitu-				



	page		page
<b>BUMPERS</b>		<b>WINDOW GLASSES</b>	
- Front bumper	1	- Replacing front window (windscreen)	33
- Rear bumper	2	- Sticking car interior rear view mirror support plate	34/1
<b>BONNET LID</b>		- Replace rear window glass (rearscreen)	35
- Removing-refitting and adjustments	3	<b>REPLACING BODY PANELS</b>	
<b>BOOT LID</b>		- Replacing roof panel	37
- Removing-refitting boot lid and hinge	5	- Replacing front cross member cover	41
- Adjustments	6	- Replacing rear wing	45
- Removing-refitting boot lid lock	7	- Replacing rear cross member lining	49
- Replacing lock barrel	8	- Replacing underdoor side member	53
<b>FRONT DOOR</b>		- Partial replacement of rear floor area	57
- Removing-refitting front door	9	- Replacing partial front panel	61
- Removing-refitting door panel and protective cover	10	- Replacing centre pillar	65
- Dismantling-reassembling door panel	11	- Replacing front pillar	69
- External rear view mirror	12	- Replacing front panel	73
- Removing-refitting door lock	13	- Diagram for checking underbody	77
- Removing-refitting outer door handle	13	- Reaplcng fixed hinges	72/1
- Replacing door lock barrel	13	<b>SUN ROOF</b>	
- Removing-refitting lowering window glass	14	- Operation of sun roof	79
- Removing-refitting window opening device	14	<b>SOUND INSULATION PANELS</b>	
<b>REAR DOOR</b>		- Removing-refitting	83
- Removing-refitting lowering window glass	15		
- Removing-refitting fixed window	16		
<b>SEATS</b>			
- Removing-refitting front seat	17		
- Dismantling-reassembling front seat	18		
- Removing-refitting rear seat	21		
<b>INTERIOR FITTINGS</b>			
- Removing-refitting roof lining	22		
- Removing-refitting front belts	24		
- Removing-refitting rear belts	25		
- Removing-refitting dashboard	26		
- Replacing glove compartment flap lock barrel	32/1		

#### COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A.  
D.M.C. - M.P.S.  
Servizi Post Vendita - Tecnologie Assistenziali  
Largo Senatore G. Agnelli, 5 - 10040 Volvera - To (Italia)  
Publication no. 506.475/19 - Gennaio 1998 - 400  
Printed in Italy - Tip. Stampart - Torino  
order no. 60445103



	page		page
<b>BUMPERS</b>		<b>WINDOW GLASSES</b>	
- Front bumper	1	- Replacing front window (windscreen)	33
- Rear bumper	2	- Sticking plate supporting interior rear view mirror	34/1
<b>BONNET LID</b>		- Replace rear window glass (rearscreen)	35
- Removing-refitting and adjustments	3	<b>REPLACING BODY PANELS</b>	
<b>BOOT LID</b>		- Replacing roof panel	37
- Removing-refitting boot lid and hinges	5	- Replacing front cross member cover	41
- Adjustments	6	- Replacing rear wing	45
- Removing-refitting boot lid lock	7	- Replacing rear cross member lining	49
- Replacing lock barrel	8	- Replacing underdoor side member	53
<b>FRONT DOOR</b>		- Partial replacement of rear floor area	57
- Removing-refitting front door	9	- Partial replacement of front side panel	61
- Removing-refitting door panel and protective cover	10	- Replacing centre pillar	65
- Dismantling-reassembling door panel	11	- Replacing front pillar	69
- External rear view mirror	12	- Replacing front side panel	73
- Removing-refitting door lock	13	- Diagram for checking underbody	77
- Removing-refitting outer door handle	13	- Replacing fixed hinges	72/1
- Replacing door lock barrel	13	<b>SUN ROOF</b>	
- Removing-refitting lowering window glass	14	- Operation of sun roof	79
- Removing-refitting window opening device	14		
<b>REAR DOOR</b>			
- Removing-refitting lowering window glass	15		
- Removing-refitting fixed window	16		
<b>SEATS</b>			
- Removing-refitting front seat	17		
- Dismantling-reassembling front seat	18		
- Removing-refitting rear seat	21		
<b>INTERIOR FITTINGS</b>			
- Removing-refitting roof lining	22		
- Removing-refitting front belts	24		
- Removing-refitting rear belts	25		
- Removing-refitting dashboard	26		
- Replacing glove compartment lock barrel	32/1		








P3U001M01


## FRONT BUMPER

## Removing-refitting


- Remove the light clusters and the front fog lights as described in section 55 of this manual;
- under the upper bolts fixing the front bumper;




P3U001M02



P3U001M03



P3U001M04



P3U001M05

- loosen the nut fixing the bumper to the wheel arch liner;
- move the wheel arch liner aside to gain access to the fixing bolt underneath;

- undo the bolts fixing the rear bumper located in the fog lamp housings;
- remove the front bumper from the bodyshell, disconnecting the pipe for the headlamp wiper unit.

**NOTE** To refit, simply reverse the order of the operations carried out for the removal.

70.

### REAR BUMPER

#### Removing-refitting


- Raise the boot lid;
- undo the plastic fixing plugs for the trim inside the luggage compartment;
- remove the trim;

- move the luggage compartment lining aside, then undo the nuts fixing the bumper to the rear cross member;


**NOTE** *The inset shows the section of the rear bumper (1), the rear cross member (2) and the fixings (3).*

- undo the bolts and the nuts fixing the rear bumper to the wheel arch liners;
- remove the rear bumper from the bodyshell.

**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*




P3U002M01




P3U002M03

P3U002M02




P3U002M04



P3U003M01


## REMOVING-REFITTING

- Raise the bonnet lid, then using tool 1878077000, remove the buttons fixing the windscreen washer pipe shield;
- disconnect the windscreen washer pipes;



P3U003M02

- disconnect the supporting shock absorbers, then undo the bolts fixing the hinges to the bonnet lid;
- remove the bonnet lid, with the help of a second operator;
- when the refitting is complete, fully tighten the bolts fixing the hinges to the bonnet lid.



P3U003M03

## ADJUSTMENTS


## Adjusting position of bonnet lid

- Loosen the bolts fixing the hinges, then adjust the position of the bonnet lid;

**NOTE** *The arrows indicate the points for fixing the bumper to the bodyshell.*

- when the adjustment is complete, fully tighten the bolts fixing the hinges.


70.



P3U004M01

### Adjusting bonnet lid vertical position device


Working as illustrated in the diagram, adjust the vertical position of the bonnet lid; it is possible to carry out the same adjustment by rotating the rubber mountings located at the edges of the engine compartment.



P3U004M02

### Removing-refitting bonnet lid closing device


Remove the closing device by undoing the fixing bolts shown by the arrows.



P3U004M03

### Removing-refitting grille


Raise the bonnet lid, then remove the grille by undoing the fixing bolts shown by the arrows.



P3U005M01

**REMOVING-REFITTING BOOT LID AND HINGE****Removing**


- Raise the boot lid, then using tool 1878077000, remove the buttons fixing the boot lid interior lining;
- remove the lining from the boot lid;
- disconnect the supply connectors for the light clusters and the lock;
- remove the cable loom from inside the boot lid box section;



P3U005M02

P3U005M03

- disconnect the shock absorbers supporting the boot lid;
- undo the bolts fixing the hinges to the boot lid;
- remove the boot lid, with the help of a second operator;
- remove the hinge for the boot lid undoing the fixing bolts shown in the right inset.




P3U005M04

**Refitting**

Simply reverse the order of the operations carried out for the removal, then adjust the boot lid (see page 6).

**NOTE** Tighten the bolts fixing the hinges to the boot lid to a torque of 0.8 da Nm and the bolts fixing the hinges to the bodyshell to a torque of 2.7 da Nm.

70.



P3U006M01


### ADJUSTMENTS

#### Adjusting position of boot lid buffers

Suitably rotate the rubber buffers located at the edges of the boot lid.




*If the buffers are not correctly adjusted then either the boot lid may be forced or the clearance for the closing mechanism will be too large causing damage to the lid.*



P3U006M02

#### Adjusting vertical and horizontal position of boot lid


**NOTE** *The arrows indicate the possible movements for the adjustment.*




P3U006M03

#### Removing-refitting and adjusting position of boot lid lock striker


**NOTE** *The arrows indicate the possible movements for the adjustment.*



P3U007M01



P3U007M02



P3U007M03

**REMOVING-REFITTING BOOT LID LOCK****Removing**

Before removing the boot lid lock it is necessary to:

- raise the boot lid, then using tool 1878077000, remove the fixing buttons and remove the boot lid interior lining, as described on page 5;
- release the rod opening/closing the boot lid from its housing;
- disconnect the electrical connectors supplying the central locking motor;

- remove the lock for the boot lid undoing the fixing bolts shown in the diagram.

**Refitting**


**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*

**Removing-refitting boot lid lock rod and central locking motor**

Before removing the boot lid lock rod it is necessary to:

- remove the lock as described above;
- release the rod from the lock attachment system;
- remove the rod from the lock attachment system, then undo the bolts fixing the central locking motor;
- disconnect the band for the electric cables, then separate the central locking motor.

70.




P3U008M01

### REPLACING LOCK BARREL

#### Order of operations


Before replacing the lock barrel it is necessary to:

- raise the boot lid, then using tool 1878077000, remove the fixing buttons and remove the boot lid interior lining, as described on page 5;
- release the rod and undo the bolts bolts the lock barrel to the boot lid;



P3U008M02

- insert the key in the barrel, then extract the circlip shown;




P3U008M03

- extract the barrel, then replace it.

**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*




## REMOVING - REFITTING FRONT DOOR



P3U009M01

- Disconnect the connector supplying the door electrical devices;
- remove the flexible pin for the door check strap using tool 1878081000;
- remove the door undoing the fixing bolts shown.

**NOTE** To refit, simply reverse the order of the operations carried out for the removal, fully tightening the bolts fixing the hinges to the door (torque figure: 1.5 daNm).




P3U009M02

## Adjusting front door

- Loosen the nuts fixing the hinge to the door;
- adjust the position of the door;
- when the adjustment is complete, tighten the nuts fixing the hinge to the door to the recommended torque (2 da Nm).

**NOTE** The arrows indicate the possible movements for the adjustment.




P3U009M03

## Removing-refitting and adjusting position of door lock striker


- Loosen the bolts fixing the striker and adjust its position;
- when the adjustment is complete, fully tighten the bolts fixing the striker (torque figure: 2.5 daNm).

**NOTE** The arrows indicate the possible movements for the adjustment.

70.




P3U010M01




P3U010M02

### REMOVING-REFITTING DOOR PANEL AND PROTECTIVE LINING


1. Undo the bolts shown then remove the window opening device after having disconnected the connector.
2. Working on the retaining tabs, extract the escutcheon releasing it from the door opening control lever.
3. Remove the external rear view mirror trim using tool 1878077000, then remove the lens cover and the trims shown in the diagram.
4. Remove the door lining panel from the bodysell, undoing the fixing bolts shown and the lower courtesy light connector.
5. Remove the brackets, move the interior handle aside undoing the bolt then unstick the protective door lining.




P3U010M03




P3U010M04




P3U010M05




P3U011M01




P3U011M02



P3U011M03



P3U011M04




P3U011M05

**DISMANTLING-REASSEMBLING  
DOOR PANEL**

1. Working from the inside of the panel, undo the bolts shown and remove the oddments pocket.
2. Undo the bolts shown, then remove the window opening supporting bracket.
3. Undo the bolts shown and remove the arm-rest trim.
4. Undo the bolts shown then remove the external rear view mirror air duct.
5. Undo the bolts shown then remove the glass scraper trim complete with the relevant guide.



*These dismantling operations should be carried out with the panel removed from the door, except for the speaker grille and the lower courtesy light.*




P3U012M01

#### EXTERNAL REAR VIEW MIRROR

##### Removing-refitting

- Remove the door lining panel as described on page 10;
- partly unstick the protective door panel;
- disconnect the mirror connectors.

1. Remove the external rear view mirror undoing the fixing nuts shown.




P3U012M02


##### Replacing mirror adjustment motor

2. Remove the lining from the mirror undoing the fixing bolts shown.
3. Press on the retaining spring and separate the mirror from the support underneath.
4. Undo the bolts fixing the motor to the support, then disconnect the supply connector for the motor for adjusting the rear view mirror and remove it from the support.


**NOTE** When refitting suitably reverse the order of the operations carried out for the removal.




P3U012M03




P3U012M04




P3U013M01



P3U013M02



P3U013M03



P3U013M04

### REMOVING - REFITTING DOOR LOCK

Remove the door panel lining as described on page 10.

1. Move the door opening control lever aside, then disconnect the lock control rods releasing them from the attachment points.
2. Disconnect the connector operating the central locking then remove the lock undoing the fixing bolts shown.

### REMOVING - REFITTING DOOR OUTER HANDLE

3. Remove the door lock then undo the bolts fixing the handle to the door.

### REPLACING DOOR LOCK BARREL

4. Remove the door handle, insert the key in the lock barrel then remove the pin (A) and the lock retaining spring (B) and extract the barrel from its housing.

**NOTE** When refitting suitably reverse the order of the operations carried out for the removal.

### 70.


#### REMOVING-REFITTING LOWERING WINDOW

Remove the door panel and protective cover, following the instructions given on page 10, then lower the window until it is in the end of travel position.

Undo the bolts (10) fixing the left window guide, then move it slightly away from its housing, undo the bolts (11) fixing the window to the lower guide and then extract the window from the door.


#### REMOVING-REFITTING WINDOW OPENING DEVICE

The vehicle is equipped with electrically operated pantograph type windows (1); once the door lining panel has been removed and the electrical parts disconnected the window opening device (6) can be removed; the latter is fixed to the bodyshell of the door by six nuts: two on the upper guide (5) and four on the window opening motor support (6), then remove the window opening device from the vehicle.




P3U014M01


- |                                  |   |
|----------------------------------|---|
| 1. Pantograph                    | 7. Left hand drive                                |
| 2. Glass scraper                 | 8. Right lower guide                              |
| 3. Trim                          | 9. Right upper guide                              |
| 4. Window attachment lower guide | 10. Bolts fixing left window guide                |
| 5. Upper guide                   | 11. Bolts fixing window to pantograph lower guide |
| 6. Window opening motor          |   |



P3U015M01



P3U015M02




P3U015M03


### REMOVING - REFITTING LOWERING WINDOW GLASS

1. Remove the panel and the protective door lining.
2. Remove the lower window guide undoing the fixing bolt shown.
3. Remove the window housing perimeter trim.
4. Undo the bolts fixing the window to the lower pantograph guide.
5. Extract the window from its housing.

**NOTE** *To refit suitably reverse the order of the operations carried out for the removal.*




P3U015M04




P3U015M05


70.



P3U015M01



P3U015M02




P3U016M01


### REMOVING-REFITTING FIXED WINDOW

1. Remove the door panel and protective lining.
2. Remove the lower guide undoing the fixing bolt shown and releasing it from the internal trim.
3. Remove the window housing perimeter trim, releasing it from the retaining springs, then remove the upper window guide undoing the bolts shown.
4. Remove the glass scraper trim.
5. Extract the window from its housing as appropriate.

**NOTE** To refit suitably reverse the order of the operations carried out for the removal.



P3U016M02



P3U016M03




## REMOVING - REFITTING FRONT SEAT


**NOTE** *As far as front seats with Side bags are concerned, refer to the LANCIA k Service Manual 4th Volume Section 55 - Electrical equipment - Air-bag new features (Print no. 506.475/25)*

## Order of operations

- Undo the bolt fixing the seat belt to the seat;




P3U017M01



P3U017M02


- place the seat in the "completely forwards" end of travel position, then undo the bolts fixing the seat guides to the floor;




P3U017M03

- place the seat in the "fully retracted" end of travel position, then remove the seat from the vehicle undo the bolts fixing the seat guides to the floor and disconnecting the connections.


**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*




P3U018M01




P3U018M02



P3U018M03




P3U018M04




P3U018M05

## DISMANTLING - REASSEMBLING FRONT SEAT


1. Remove the controls for operating the seat, extracting them from the seat then, acting on the retaining tabs and disconnecting the connector, remove the seat memorizing control panel.
2. Remove the lower trim for the seat, undoing the fixing bolts.
3. Remove the seat electronic control unit, undoing the bolts and disconnecting the connections shown.
4. Remove the flexible washer shown.
5. Remove the motor assembly for moving the seat in a rear vertical direction, disconnecting the connections and the bolts shown and moving the seat guide slightly outwards.




P3U019M01




P3U019M02



P3U019M03




P3U019M04




P3U019M05


1. Remove the motor for moving the seat in a frontwards vertical and lengthwise direction, undoing the fixing bolts, the connections and the flexible washer shown in the inset.
2. Remove the seat belt attachment system, undoing the fixing bolt, then remove the right guide.
3. Remove the left hand drive undoing the nut fixing the guide to the frame, then remove the seat cover acting on the attachment systems, to remove the upholstery, then disconnect the connection on the backrest upholstery.
4. Remove the backrest cover, undoing the fixing bolts shown.
5. Remove the motor for adjusting the seat backrest, undoing the fixing bolts and disconnecting the relevant connection.



P3U020M01




P3U020M02




P3U020M03

1. Remove the lumbar adjustment knob releasing it from the retaining spring.
2. Remove armrest and housing, undoing the fixing bolts shown.
3. Working from inside the backrest, remove the head restraint raising the springs attaching it to the frame.
4. Remove the backrest cover removing the head restraint housings releasing it from the attachment system, then remove the upholstery.
5. Remove the head restraint operating assembly undoing the motor fixing bolts and the rivets shown.

**NOTE** When refitting suitably reverse the order of the operations carried out for the removal.



P3U020M04




P3U020M05


REMOVING-REFITTING REAR  
SEAT

## Order of operations

- Remove the rear cushion acting on the attachment system as shown in the diagram;




P3U021M01



P3U021M02

- remove rear backrest undoing the fixing bolts shown, then lift it up from the attachment points on the rear parcel shelf;




P3U021M03


- remove the head restraints acting on the pins shown (this operation can only be carried out with the backrest removed).

**NOTE** *To refit simply reverse the order of the operations carried out for the removal.*

70.




P3U022M01




P3U022M02

### REMOVING - REFITTING ROOF LINING


1. Remove the sun visors after having undone the appropriate fixing bolts.
2. Remove the courtesy light after having removed the lens cover, undone the bolts fixing the courtesy light to the lining and disconnected the appropriate connectors.
3. Remove the front courtesy light for the ultrasound sensors, acting on the retaining tabs and disconnecting the appropriate connectors.
4. ~~Remove~~ Remove the courtesy light for the right sun visor mirror, acting on the appropriate tabs and disconnecting the connector.
5. Using tool 1878077000 remove the front pillar covers after having partly remove the door housing trims.




P3U022M03




P3U022M04




P3U022M05




P3U023M01




P3U023M02



P3U023M03



P3U023M04




P3U023M05


1. Partly remove the centre pillar covers using tool 1878077000.
2. Remove the courtesy lights in the rear pillar covers, removing the lens covers, the fixing bolts and the connectors.
3. Using tool 1878077000 move the rear pillar covers away from the roof lining.
4. Remove the attachments for the sun blind and the passenger grab handles, undoing the appropriate fixing bolts.
5. Remove the roof lining extracting it from the rear door of the vehicle.

**NOTE** When refitting, suitably reverse the order of the operations carried out for the removal.

70.



P3U024M01




P3U024M02


### REMOVING-REFITTING FRONT SEAT BELTS

1. Remove the bolt fixing the belt to the seat as illustrated on page 17, then remove the door panel linings, releasing them from the fixing springs, using tool 1878077000.
2. Remove the pillar cover using tool 1878077000, after having moved the door seals aside.
3. Remove the lower lining shown.
4. Undo the upper bolt fixing the belt, then remove the retaining spring and release the belt.
5. Remove the seat belt, removing the connection and the fixing bolt shown.


**NOTE** When refitting, simply reverse the order of the operations carried out for the removal, fully tightening the bolts fixing the reel to the door pillar (torque figure: 5 daNm).



P3U024M03




P3U024M04



P3U024M05






P3U025M01


**REMOVING-REFITTING REAR SEAT BELTS****Order of operations**

- Remove the rear seat backrest as described on page 21, then undo the bolt fixing the seat belt to the rear wheel arch;



P3U025M02

- raise the speaker grille, undo the bolts shown and remove the reel cover removing the belt;




P3U025M03


- remove the reel from the bodyshell, undoing the bolts shown.

**NOTE** To refit simply reverse the order of the operations carried out for the removal, fully tightening the bolts fixing the reel to the bodyshell (torque figure: 5 daNm).


70.




P3U026M01




P3U026M02



P3U026M03




P3U026M04




P3U026M05

### REMOVING-REFITTING DASHBOARD


1. Undo the bolts shown, then remove the upper and lower covers for the steering column.
2. Undo the bolts fixing the air bag to the steering wheel.
3. Remove the air bag from the steering wheel, following the instructions given in section 55 - Electrical equipment.
4. Using leverage, remove the cover shown and the boot lid/fuel filler flap opening controls, then disconnect the supply connector.
5. Undo at the points shown and remove the passenger air bag.




P3U027M01




P3U027M02



P3U027M03




P3U027M04




P3U027M05

1. Remove the steering wheel using an appropriate extractor, then disconnect the connector for the spiral device (clock-spring).
2. Remove the plate supporting the steering column covers, after having undone the relevant bolts, then remove the steering column switch unit and disconnect the connectors.
3. Remove the protective boot.
4. Remove the instrument panel, disconnecting the connectors and undoing the bolts shown.
5. Undo at the points shown and remove the front tunnel cover.


70.



P3U028M01




P3U028M02




P3U028M03


1. Remove the rear air ventilation vents.
2. Undo the rear bolts fixing the tunnel cover.
3. Fold back the seat, then remove the tunnel cover, undoing the bolts shown.
4. Remove the upper centre air vent grille from the dashboard.
5. Remove centre air vent grille from the dashboard.




P3U028M04




P3U028M05



P3U029M01




P3U029M02




P3U029M03

1. Remove the radio housing and the ashtray, then undo the bolts underneath.
2. Undo the fixing bolts and remove the centre cowling.
3. Undo at the points shown and disconnect the connectors, then remove the "Infocenter" control unit.
4. Remove the driver's side air vent grille, disconnecting the connectors, then remove the headlamp adjustment knob.
5. Disconnect the connector for the vehicle interior air temperature sensor.




P3U029M04




P3U029M05


70.



P3U030M01




P3U030M02




P3U030M03


1. Undo the fixing bolts and disconnect the connectors, then remove the fuse control box and the IGE control unit.
2. Remove the driver and passenger side speaker grilles.
3. Remove the passenger side air vent.
4. Remove the side vent, acting on the fixing bolt; also remove the fixing cover shown; these operations are carried out on the driver and passenger sides.
5. Undo the fixing bolts underneath; proceed in the same way for the passenger side.




P3U030M04




P3U030M05




P3U031M01




P3U031M02



P3U031M03




P3U031M04




P3U031M05

1. Undo the nut fixing the dashboard support, remove the two plugs shown in order to remove the driver side protective partition, disconnect the connector for the pedals courtesy light and undo the bolt located above the brake pedal.
2. Undo at the points shown and remove the tunnel cover.
3. Remove the passenger side protective partition, working at the points shown.
4. Undo the fixing bolts shown in the lower part of the dashboard.
5. Undo the fixing bolts located in the upper centre part of the dashboard.

## 70.




P3U032M01




P3U032M02

1. Undo the fixing bolt located in the lower part of the dashboard, driver side.
2. Remove the sun radiation sensor, after having disconnected the appropriate connector.
3. Undo the fixing bolts, located in the passenger air bag housing.
4. Loosen the bolts shown, remove the wind-screen pillar covers; with the help of a second operator, remove the dashboard and extract it from the vehicle.




P3U032M03





P3U032M04







P3U321M01



P3U321M02




P3U321M03





## REPLACING GLOVE COMPARTMENT LOCK BARREL

1. Open the glove compartment flap.
2. Undo the bolts fixing the glove compartment flap to the dashboard cover.
3. Insert the key in the lock barrel.
4. Move the lock barrel circlip, working via the opening shown by the arrow.
5. Extract the barrel, then replace it.

**NOTE** *To refit, simply reverse the order of the operations carried out for the removal.*




P3U321M04




P3U321M05






P3U033M01



P3U033M02



P3U033M03


**REPLACING FRONT WINDOW (WIND-SCREEN))**

*Use a cloth to protect the dashboard and the parts which could be damaged during the cutting operations and fitting of the window and protect the area along the edge of the window housing with adhesive tape to prevent the paintwork from being damaged.*

Before starting the operation of replacing the window, disconnect the negative battery lead and remove the following components: bonnet lid, windscreen wiper blades, door seals, pillar covers, lower window lining, courtesy light, sun visors, grab handles and interior rear view mirror, then lower the roof lining and move it away using special wedges, then proceed as described below:


**Order of operations**

1. Introduce one end of the wire through the sealant bead, then fix the retaining tool and the traction handle.
2. With the help of a second operator working from inside the vehicle, position the retaining tool at the edge of the window housing about 30 cm from the wire fixing point, suitably manoeuvre the traction handle following the window surround and cut the sealant bead, then remove the window using the special suction pads.
3. Remove the traces of sealant from the window housing using a special scraper, then using heptane and disposable paper, degrease the part which was treated previously.
4. De-grease the window using heptane and disposable paper.



P3U033M04

### 70.



P3U034M01


- using a spray gun apply the sealant to the pressed window seal;

**NOTE** The distances relating to the size of the bead and the distance to be maintained from the bodyshell are given in the inset (B) in the diagram below, polyurethane single-component type sealant helps in eliminating the possibility of water penetration.


- position the window in its housing; there are two housings (2) stuck in the two upper corners of the window for inserting the finned pins (3) which act as a reference for fitting the windscreen; using the special suction pads and belts, keep the window under pressure for at least 6 hours.

The diagram below illustrates the elements of which the windscreen is composed

- Section of pressed seal (1) on the lower edge of the window
- Sealant distances
- Section of housings (2) and window and pressed seal (1) finned adjustment pins (3) in the upper corners of the window
- Section of the pillar for the pressed seal (1)



P3U034M02




P3U034M03

**STICKING THE INTERIOR REAR VIEW MIRROR SUPPORT PLATE**

If the support plate becomes unstuck, proceed with refitting it, following the procedure described below.


1. Remove any residues of adhesive from the plate. Thoroughly degrease the surface of the plate which matches with the window using disposable paper soaked in heptane.



P3U034M04



2. Remove any residues of adhesive from the window. Thoroughly degrease the surface of the window which matches with the plate using disposable paper soaked in heptane.



P3U034M05



3. Cut the treated nylon fabric to the dimensions of the plate.




**NOTE** *The fabric should be handled with clean, not greasy hands.*

Distribute the adhesive evenly on the plate (2-3 drops). Then place the fabric, which has been cut to size, on top.



**Use ADHESIVE KIT RVM n°16914 LOCTITE (part n° 71712580) or a similar product.**


## 70.




P3U034M06

4. Position the plate on the window within 30 seconds and keep it in place for at least 30 seconds, exerting gentle manual pressure.


**NOTE** *The body of the rear view mirror can be fitted on the plate after 15-30 minutes.*



P3U035M01



P3U035M02



P3U035M05

### REPLACING REAR WINDOW GLASS (REARSCREEN)




*Using a cloth protect the parts which could be damaged during the operations of cutting and fitting the window glass and, using adhesive tape, protect the area of the window glass housing to prevent the paintwork from being damaged.*

Before beginning the operations of replacing the window glass, disconnect the negative battery lead and remove the following components:

rear seat, rear pillar covers, seat belt reel cover, rear passenger grab handles, hooks for sun blinds, disconnect the connections for the heated rear windscreen, lower the roof lining and move it away using special wedges, then proceed as described below:


### Order of operations

1. Working from inside the luggage compartment disconnect the connections for the additional brake lights and undo the bolts fixing the rear parcel shelf to the bodyshell.
2. Remove the rear parcel shelf using tool 1878077000 to remove the fixing buttons.
3. Working from inside the passenger compartment using a vibrating knife and blades 1878091000, then cut the sealant using blade (A) in the areas shaded in the diagram and blade (B) in the remaining areas.
4. Remove the traces of sealant from the window glass housing using a special scraper, then using heptane and disposable paper, degrease the previously treated area.



P3U035M04


70.



P3U036M01

- Using a spray gun apply the sealant to the pressed window seals;


**NOTE** *The distances relating to the dimensions of the bead and the distance to maintain from the bodyshell are given in the diagram inset, the sealant is a single-component, polyurethane type which contributes to eliminating the possibility of water penetration.*



P3U036M02

- Position the crystal in its housing; there are two housings in the top two corners of the window for the finned pins which act as references when fitting the rearscreen;


**NOTE** *The section of rear windscreen components, pressed seal (1), housing for inserting the finned pin (2), finned pin (3) are shown.*



P3U036M03

- Using the special suction pads and belts, keep the window glass under pressure for at least 6 hours.





P3U037M01

**REPLACING VEHICLE  
ROOF PANEL (7090A 58)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**


Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are intact.

**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the vehicle roof panel using a power saw following the dotted lines shown in the diagram below. The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U037M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

### 70.

#### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell using a special cutter, with the exception of the section by the front and rear pillars.
2. Remove the metal off cuts using pliers.
3. Remove the metal off cuts by the front and rear pillars using an oxyacetylene canister and brush.
4. Straighten the edges with a hammer and dolly block.
5. Remove the weld residues using a disc grinder.
6. Apply IVI Epox epoxide primer or an electro-weldable galvanized paint or an equivalent product, to the previously ground areas.



P3U038M01

#### Preparing the spare part


1. Apply a base coat using a spray gun.
2. Remove the anti-corrosion treatment from the entire perimeter of the inner and outer part of the replacement part using a disc grinder.
3. Use the electro-galvanized paint on the edges in contact with the bodyshell.



P3U038M02

### Positioning the replacement part


1. Renew the sealant on the bodyshe'll ribs, using IVI acrylic type sealant 854210 or an equivalent product.
2. Carefully place the replacement part in position.
3. Check that the roof panel is perfectly positioned on the bodyshe'll.
4. Fix the replacement part to the bodyshe'll using special self-locking clamps.






P3U039M01

### Welding the spare part

1. Carry out the brass welding using an oxyacetylene canister at the corners of the front and rear roof pillars.
2. Use a MIG welder on the edge of the rear roof pillars.
3. Using a spot welder continue the operation along the entire contact edge between the roof panel and the bodyshe'll.




P3U039M02

-  MIG welding
-  Spot welding
-  Brass welding

## 70.

### Finishing operations


1. Using a hammer and dolly block correct any distortions to the panel.
2. Remove any weld slag using a disc grinder.
3. Fit the threaded rivets and the bolts for the roof rack attachments in the holes shown in the diagram using the special tool.




P3U040M01

### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joints between the roof panel and the bodysell using IVI 854210 type transparent acrylic sealant or an equivalent product.
3. Proceed with the painting and waxing stages.



P3U040M02



P3U041M01

**REPLACING FRONT CROSS MEMBER LINING (7090G 07)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**


Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using the appropriate methods (jigs, templates and gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are in tact.

**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the front cross member cover using a power saw following the dotted lines shown in the diagram below. The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U041M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

## 70.

### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U042M01

### Preparing the replacement parts


1. Outer cross member lining (A). Inner cross member lining (B). Headlamp housings (C).
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter on the inside and the outside of the replacement parts.
3. Use electro-galvanizing paint on the edges in contact with the bodyshell.



P3U042M02

### Positioning and first welding and sealing stage for the internal cross member lining


1. Carefully position the internal cross member lining on the bodyshell.
2. Check that the replacement part is perfectly positioned in relation to the side members.
3. Fix the replacement part to the bodyshell using special self-locking clamps.
4. Carry out the spot welding between the replacement part and the bodyshell side members.
5. Remove any weld slag using a disc grinder.
6. Apply IVI 854210 transparent acrylic sealant or an equivalent product to the previously treated areas.



P3U043M01

### Continuation of positioning replacement parts and final welding

1. Position the external cross member lining on the bodyshell using the special self-locking clamps.
2. Carry out the spot welding by the edges in contact with the internal cross member lining.
3. Position the headlamp housings in the bodyshell, using the special self-locking clamps.
4. Use the spot welder on the contact edges between the headlamp housing, the internal cross member lining and the bodyshell.




P3U043M02

● ● ● Spot welding

## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.



P3U044M01


### Protection

1. Apply the electro-phoretic treatment to the areas previously welded.
2. Seal the joints between the roof panel and the bodyshell using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting and waxing stage.



P3U044M02





P3U045M01

**REPLACING REAR  
WING (7090A 54)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodyshell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodyshell before cutting the component. After this operation check that the components not being replaced are intact.


**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the rear wing using a power saw following the dotted lines shown in the diagram below.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U045M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

## 70.

### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U046M01

### Adjusting the replacement part


1. Cut the upper part of the replacement part then place it in position so that it adheres perfectly to the bodyshell.
2. Check that the when the wing is superimposed on the bodyshell is projects about 50 - 60 mm.
3. Check that the centering holes, shown by the arrows, are correctly positioned.
4. Fix the replacement part using the special self-locking clamps.
5. Cut the two edges of the panel so that the join line is perfect.



P3U046M02

**Preparing the spare part and checking the correct positioning on the bodyshell**


1. Make equidistant openings in the edges of the replacement part as shown in the diagram.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement part.
3. Use electro-galvanizing paint on the edges in contact with the bodyshell.
4. Position the replacement part in place and check the adjustment openings shown by the arrows.
5. Tack the replacement part carrying out several spot welds.
6. Fit the boot lid, close the door and check the alignment and uniformity of the surrounding opening.







P3U047M01

**Welding the spare part**

1. Carry out spot welding on the edges of the door seal, wheel arch, rear cross member and rearscreen housing.
2. Use a MIG welder between the underdoor side member and the wing and between the wing and the bodyshell.
3. Carry out brass welding using an oxyacetylene canister by the rearscreen and luggage compartment housing.




P3U047M02

-  MIG welding  
 MIG welding for filling in  
 Spot welding  
 Brass welding

## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.




P3U048M01

### Protection

1. Apply the electro-phoretic protection to the areas previously welded.
2. Seal the joints between the wing and the bodyshell using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Apply the damping panels.
4. Proceed with the painting and waxing stage.



P3U048M02



P3U049M01

### REPLACING REAR CROSS MEMBER LINING (7090A 46)\*

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

### PRELIMINARY PROCEDURES

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are intact.


### PRELIMINARY DISMANTLING

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

### REMOVING

Cut the rear cross member cover using a power saw following the dotted lines shown in the diagram below, remove the weld points for the floor panel side members.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U049M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.


## 70.

### Removing off cuts and preparing edges of bodyshell

1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.




P3U050M01




### Preparing the spare part

1. Make equidistant holes in the edges of the replacement part as shown in the diagram.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement part.
3. Use electro-galvanizing paint on the previously treated edges.




P3U050M02



## Positioning the replacement part


1. Carefully place the replacement part in position .
2. Check that the cross member lining is perfectly positioned.
3. Fix the replacement part to the bodyshell using the special self-locking clamps.
4. Tack the replacement part using several spot welds.
5. Close the boot lid and check the alignment and uniformity of the surrounding opening.



P3U051M01

## Welding the spare part

1. Carry out spot welding by the light clusters.
2. Continue the spot welding on the contact edges near the spare wheel housing and the rear wings.
3. Using a MIG welder fill the holes made previously in the replacement part.
4. Carry out brass welding using an oxyacetylene canister by the contact edges between the cross member and the wings.




P3U051M02

## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.



P3U052M01


### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joins between the rear cross member cover and the bodyshell using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting and waxing stage.



P3U052M02





P3U053M01

**REPLACING UNDERDOOR  
SIDE MEMBER (7090G 50)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodyshell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodyshell before cutting the component. After this operation check that the components not being replaced are intact.


**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the underdoor side member using a chisel and hammer (upper area) and power saw (lower area), following the dotted lines shown in the diagram below.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U053M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

## 70.

### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U054M01

### Adjusting replacement part and finishing bodyshell pillars


1. Place the replacement part in position and fix it using the special self-locking clamps.
2. Trace the profile of the replacement part on the bodyshell using a brush by the pillars, leaving a distance of 1 mm between the profile of the replacement part and the bodyshell.
3. Remove the replacement part and using body panel shears cut the excess from the edges of the bodyshell along the previously created line.



P3U054M02

## Preparing the spare part and checking the correct positioning on the bodyshell


1. Make equidistant holes along the entire lower edge of the replacement part.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement part.
3. Use electro-galvanizing paint on the edges in contact with the bodyshell.
4. Position the replacement part in place and fix it using the special self-locking clamps.
5. Fit the doors and check the alignment and uniformity of the surrounding opening.



P3U055M01

## Welding the spare part

1. Carry out spot welding on the upper and lower edges of the underdoor side member and the bodyshell.
2. Use a MIG welder by the bodyshell pillars.
3. Use a MIG welder to fill the openings previously made in the replacement part.




P3U055M02

- ⌘ MIG welding
- Spot welding
- MIG welding for filling in

## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.




P3U056M01

### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joins between the underdoor side member and the bodyshell, using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Apply high consistency filler to the area in contact with the wing.
4. Proceed with the painting and waxing stage.



P3U056M02



P3U057M01

**PARTIAL REPLACEMENT OF REAR FLOOR PANEL (7090G 90)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are intact.


**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the floor panel using a power saw following the dotted lines shown in the diagram below, finish the cutting of the floor panel using a circular blade saw offset in relation to the internal floor reinforcement as shown in the inset (A).

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U057M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.


## 70.

### Removing off cuts and preparing edges of bodyshell

1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the previously ground areas.




P3U058M01




### Preparing the replacement part

1. Cut the floor panel and remove the part shown in the diagram.
2. Make equidistant holes in the edges of the side members and the internal reinforcements.
3. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement parts.
4. Use electro-galvanizing paint on the previously ground areas.




P3U058M02




### Positioning the replacement part

1. Carefully place the replacement part in position inserting it between the two edges of the bodyshell, (see section A).
2. Position the side members, after having fitted the internal reinforcements.
3. Fix the replacement parts to the bodyshell using the special self-locking clamps.



### Welding the spare part


1. Using a MIG welder fill the holes previously made in the bodyshell.
2. Continue the continuous welding on the edges in contact with the side member reinforcements and the holes made previously in the replacement parts.
3. Using a MIG welder fill the holes in the side members and the reinforcements.
4. Using a spot welder weld the entire perimeter in contact with the bodyshell and the contact edges between the side members and the floor panel, then renew the brackets under the floor and the spare wheel.



## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.



P3U060M01


### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joints between the side member and the floor panel and all the previously made welds, using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting stage.
4. Apply the wax based oil protection to the inside of the side members.



P3U060M02





P3U061M01

**PARTIAL REPLACEMENT OF FRONT SIDE PANEL (7080G 12)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**


Establish the extent of the damage, check if there are distortions to the connected components by checking the bodyshell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodyshell before cutting the part. After this operation check that the components not being replaced are intact.

**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the front side panel using a power saw following the dotted lines shown in the diagram below, cut the front side panel from the inside of the vehicle in a position which is offset in relation to the outside cut.



P3U061M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

### 70.

#### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Make equidistant holes in the contact edge of the front cross member cover.
5. Remove the weld residues using a disc grinder.
6. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U062M01

#### Adjusting the replacement part


1. Measure the distances for the remaining panel on the bodyshell, ( $A = 280\text{mm}$ )-( $B = 500\text{mm}$ ).
2. Cut the replacement parts on the basis of the distances previously measured on the bodyshell.



P3U062M02

## Preparing the replacement part


1. Make equidistant holes in the attachment edge of the front cross member.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement parts.
3. Use electro-galvanizing paint on the edges in contact with the bodysell.



P3U063M01

## Welding the spare part

1. Using a MIG welder fill the holes previously made in the bodysell and the replacement part.
2. Continue the welding using the MIG welder on the bodysell and the internal panel.
3. Using a spot welder complete the welding operation along the entire contact edge between the side panel, the front cross member cover and the headlamp housing.



P3U063M02

ØØ MIG welding


●●● Spot welding

■ MIG welding for filling in

### 70.

#### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.




P3U064M01

#### Protection

1. Apply the electro-phoretic protective treatment to the area previously welded.
2. Seal the joints between side panel, the front cross member cover, the headlamp housing and the bodysell using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting stage.
4. Apply the wax based protective inside the side panel.



P3U064M02



P3U065M01

## REPLACING CENTRE PILLAR (7090G 40)\*

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

### PRELIMINARY PROCEDURES

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysheet alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysheet before cutting the component. After this operation check that the components not being replaced are intact.


### PRELIMINARY DISMANTLING

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

### REMOVING

Cut the centre pillar using a power saw following the dotted lines shown in the diagram below.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U065M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

### 70.

#### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U066M01

#### Adjusting the replacement parts on the bodyshell


1. Outer pillar (A), intermediate pillar (B), inner pillar (C).
2. Position the outer pillar on the bodyshell using self-locking clamps and check that when the replacement part is superimposed on the bodyshell it projects around 50 mm.
3. Cut the edges of the panel and remove the excess (shown by the shaded area in the diagram) so that the join for the outer pillar is perfect, leaving about 70 mm of the bodyshell intermediate pillar.



P3U066M02

## Preparing the spare part and checking the correct positioning on the bodyshell


1. Make equidistant holes in the edges of the replacement part as shown in the diagram.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement parts.
3. Use the electro-galvanizing paint on the edges in contact with the bodyshell.
4. Offer up the replacement parts using the special self-locking clamps.
5. Fit the front door and the door seal and check the alignment and the uniformity of the surrounding opening.






P3U067M01

## Welding the replacement parts

1. Position the intermediate pillar and using a MIG welder fill the previously made holes and continuously weld the upper edge of the bodyshell.
2. Position the outer pillar and using the MIG welder fill the previously made holes and continuously weld the upper edge and the edges in contact with the underdoor side member.
3. Position the inner pillar and using a MIG welder fill the previously made holes, use the spot welder on the side edges and the joint between the three pillars, then weld the door hinges, using the MIG welder, section A-A represents the weld between the bodyshell and the replacement parts. A = Outer pillar, B = Intermediate pillar, C = Inner pillar, S = Bodyshell.




P3U067M02

-  MIG welding
-  Spot welding
-  MIG welding for filling in

### 70.

#### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.



P3U068M01


#### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joints between the pillars and the bodyshell using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting stage.
4. Apply wax based oil protective to the inside of the centre pillar.



P3U068M02





P3U069M01

**REPLACING FRONT  
PILLAR (7090G 30)\***

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

**PRELIMINARY PROCEDURES**

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are intact.


**PRELIMINARY DISMANTLING**

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

**REMOVING**

Cut the centre pillar using a power saw following the dotted lines shown in the diagram below.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U069M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.



### 70.

#### Removing off cuts and preparing edges of bodyshell

1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.




P3U070M01






#### Adjusting the replacements parts on the bodyshell

1. Outer pillar (A), inner pillar (B), reinforcement (C).
2. Position the outer pillar on the bodyshell and cut the edges of the panel and remove the excess (shown in the diagram by the shaded area) so that the join is perfect.




P3U070M02



### Preparing the spare part and checking the correct positioning on the bodyshell


1. Make equidistant holes in the edges of the replacement part as shown in the diagram.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter on the inside and outside of the replacement parts.
3. Use electro-galvanizing paint on the edges in contact with the bodyshell.
4. Offer up the replacement parts using the special self-locking clamps and weld the hinges.
5. Fit the front door and the door seal and check the alignment and the uniformity of the surrounding opening.






P3U071M01

### Welding the replacement parts

1. Position the inner pillar and using a MIG welder fill the previously made holes, continuously weld the upper edge of the bodyshell.
2. Position the outer pillar and using the MIG welder fill the previously made holes, continuously weld the upper edge and the edges in contact with the underdoor side member, then using a spot welder weld along the door seal.
3. Position the reinforcement and using a MIG welder fill the previously made holes, use the spot welder for the lower edge.




P3U071M02

-  MIG welding
-  Spot welding
-  MIG welding for filling in


## 70.

### Finishing operations

1. Correct any distortions to the panel using a hammer and dolly bloc.
2. Remove any weld slag using a disc grinder.




P3U072M01







### Protection

1. Apply the electro-phoretic protective treatment to the previously welded areas.
2. Seal the joints between the pillars and the bodyshell, using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting stage.
4. Apply wax based oil protective and foam inside the front pillar.



P3U072M02






P3U072M03

**REPLACING THE FIXED HINGES**

If the doors are being replaced, proceed as described below:


- remove the front wheel arch liner and the wing following the procedures given in the appropriate pages in the "LANCIA k" Service Manual (specific operation for the front doors);
- offer up the door, fitted with hinges (1) and (2), to be welded to the pillar, on the bodyshell;
- temporarily position the hinges (1) and (2) on the pillar, following the distances given in diagrams A and B; check that the alignment with the bodyshell is correct;
- remove the door and complete the welding of the hinges (1) and (2);
- refit the door.



P3U072M04

**Reference distances for positioning half-hinges on bodyshell front pillar**

1. Upper hinge
2. Lower hinge
3. Upper opening for fixing cable conduit




P3U072M05

**Reference distances for positioning hinges on bodyshell centre pillar**

4. Upper hinge
5. Lower hinge
6. Opening for cable conduit





P3U073M01

## REPLACING FRONT SIDE PANEL (7090G 10)\*

(\*) This number indicates the operation code contained in the Flat rate manual.

The component for which the replacement procedure is given is highlighted in the diagram at the side.

### PRELIMINARY PROCEDURES

Establish the extent of the damage, check if there are distortions to the connected components by checking the bodysell alignment figures given on page 77, using suitable methods (jigs, templates or gauges). Carry out any straightening operations required to the bodysell before cutting the component. After this operation check that the components not being replaced are intact.


### PRELIMINARY DISMANTLING

Remove the moving parts of the bodywork and interior fittings, which could impede the repair operations or be damaged during them.

### REMOVING

Cut the centre pillar using a power saw following the dotted lines shown in the diagram below.

The most important sections of the body panel are shown in order to allow the operator to adjust the position and the depth of the cutting so as not to damage the panels underneath.



P3U073M02




When carrying out the operations described, adhere strictly to the safety procedures. Protective shoes, ear-muffs and gloves should be worn during the cutting operations, welding masks and gloves during the welding operations, and a protective mask and gloves during the painting operations.

## 70.

### Removing off cuts and preparing edges of bodyshell


1. Remove the weld points along the entire perimeter of the edge of the bodyshell, using a special cutter.
2. Remove the metal off cuts using pliers.
3. Straighten the edges with a hammer and dolly block.
4. Remove the weld residues using a disc grinder.
5. Apply the IVI Epox epoxide type primer or an electro-weldable galvanized paint or an equivalent product, to the areas previously ground.



P3U074M01

### Preparing the spare part

1. Make equidistant holes in the edges of the replacement part as shown in the diagram.
2. Using a disc grinder, remove the anti-corrosion treatment from the entire perimeter of the inside and outside of the replacement part.
3. Use electro-galvanizing paint on the previously treated edges.




P3U074M02



### Positioning the replacement part


1. Carefully place the lower replacement part in position, after having made the equidistant holes in the edges of the bodyshell.
2. Place the upper replacement part in position.
3. Check that the cross member lining is perfectly positioned.
4. Fix the replacement part to the bodyshell using the special self-locking clamps.
5. Tack the replacement part using several spot welds.






P3U075M01

### Welding the spare part

1. Carry out spot welding by the light clusters.
2. Continue the spot welding on the contact edges near the spare wheel housing and the rear wings.
3. Using a MIG welder fill the holes previously made in the replacement part.
4. Using a MIG welder carry out continuous welding on the contact edge between the reinforcement and the bodyshell.




P3U075M02

-  MIG welding
-  Spot welding
-  MIG welding for filling in

## 70.

### Finishing operations


1. Correct any distortions to the panel using a hammer and dolly block.
2. Remove any weld slag using a disc grinder.



P3U076M01


### Protection

1. Apply the electro-phoretic protective treatment to the areas previously welded.
2. Seal the joints between the side member and the bodyshell, using IVI 854210 transparent acrylic sealant or an equivalent product.
3. Proceed with the painting stage.
4. Apply wax based oil protective to the inside of the side member.



P3U076M02

DIAGRAM FOR CHECKING UNDERBODY



NOTE Valid for points D - N - A - B

- α, β Centering holes for fixing right side strut
- α1, β1 Centering holes for fixing left side strut
- D Longitudinal strut attachment
- B Fixings for silencer and exhaust pipe
- N Attachment for rear suspension cross member
- Centering holes for attaching rear suspension cross member

- C Attachment for engine support frame
- H Primary hole
- H1 Between primary hole and points C2-C3

- I0 Attachment for rear suspension shock absorber
- P Attachment for front suspension shock absorber
- A1 Fixings for fuel tank


- Centering holes for fuel tank, right side
- Centering holes for fuel tank, left side
- F-1 Attachment for handbrake lever support

P3U/5AM01



# LANCIA k

**70.**



P3U078M01


1910  
 1911  
 1912  
 1913  
 1914  
 1915  
 1916  
 1917  
 1918  
 1919  
 1920  
 1921  
 1922  
 1923  
 1924  
 1925  
 1926  
 1927  
 1928  
 1929  
 1930  
 1931  
 1932  
 1933  
 1934  
 1935  
 1936  
 1937  
 1938  
 1939  
 1940  
 1941  
 1942  
 1943  
 1944  
 1945  
 1946  
 1947  
 1948  
 1949  
 1950  
 1951  
 1952  
 1953  
 1954  
 1955  
 1956  
 1957  
 1958  
 1959  
 1960  
 1961  
 1962  
 1963  
 1964  
 1965  
 1966  
 1967  
 1968  
 1969  
 1970  
 1971  
 1972  
 1973  
 1974  
 1975  
 1976  
 1977  
 1978  
 1979  
 1980  
 1981  
 1982  
 1983  
 1984  
 1985  
 1986  
 1987  
 1988  
 1989  
 1990  
 1991  
 1992  
 1993  
 1994  
 1995  
 1996  
 1997  
 1998  
 1999  
 2000  
 2001  
 2002  
 2003  
 2004  
 2005  
 2006  
 2007  
 2008  
 2009  
 2010  
 2011  
 2012  
 2013  
 2014  
 2015  
 2016  
 2017  
 2018  
 2019  
 2020  
 2021  
 2022  
 2023  
 2024  
 2025  
 2026  
 2027  
 2028  
 2029  
 2030  
 2031  
 2032  
 2033  
 2034  
 2035  
 2036  
 2037  
 2038  
 2039  
 2040  
 2041  
 2042  
 2043  
 2044  
 2045  
 2046  
 2047  
 2048  
 2049  
 2050  
 2051  
 2052  
 2053  
 2054  
 2055  
 2056  
 2057  
 2058  
 2059  
 2060  
 2061  
 2062  
 2063  
 2064  
 2065  
 2066  
 2067  
 2068  
 2069  
 2070  
 2071  
 2072  
 2073  
 2074  
 2075  
 2076  
 2077  
 2078  
 2079  
 2080  
 2081  
 2082  
 2083  
 2084  
 2085  
 2086  
 2087  
 2088  
 2089  
 2090  
 2091  
 2092  
 2093  
 2094  
 2095  
 2096  
 2097  
 2098  
 2099  
 2100  
 2101  
 2102  
 2103  
 2104  
 2105  
 2106  
 2107  
 2108  
 2109  
 2110  
 2111  
 2112  
 2113  
 2114  
 2115  
 2116  
 2117  
 2118  
 2119  
 2120  
 2121  
 2122  
 2123  
 2124  
 2125  
 2126  
 2127  
 2128  
 2129  
 2130  
 2131  
 2132  
 2133  
 2134  
 2135  
 2136  
 2137  
 2138  
 2139  
 2140  
 2141  
 2142  
 2143  
 2144  
 2145  
 2146  
 2147  
 2148  
 2149  
 2150  
 2151  
 2152  
 2153  
 2154  
 2155  
 2156  
 2157  
 2158  
 2159  
 2160  
 2161  
 2162  
 2163  
 2164  
 2165  
 2166  
 2167  
 2168  
 2169  
 2170  
 2171  
 2172  
 2173  
 2174  
 2175  
 2176  
 2177  
 2178  
 2179  
 2180  
 2181  
 2182  
 2183  
 2184  
 2185  
 2186  
 2187  
 2188  
 2189  
 2190  
 2191  
 2192  
 2193  
 2194  
 2195  
 2196  
 2197  
 2198  
 2199  
 2200  
 2201  
 2202  
 2203  
 2204  
 2205  
 2206  
 2207  
 2208  
 2209  
 2210  
 2211  
 2212  
 2213  
 2214  
 2215  
 2216  
 2217  
 2218  
 2219  
 2220  
 2221  
 2222  
 2223  
 2224  
 2225  
 2226  
 2227  
 2228  
 2229  
 2230  
 2231  
 2232  
 2233  
 2234  
 2235  
 2236  
 2237  
 2238  
 2239  
 2240  
 2241  
 2242  
 2243  
 2244  
 2245  
 2246  
 2247  
 2248  
 2249  
 2250  
 2251  
 2252  
 2253  
 2254  
 2255  
 2256  
 2257  
 2258  
 2259  
 2260  
 2261  
 2262  
 2263  
 2264  
 2265  
 2266  
 2267  
 2268  
 2269  
 2270  
 2271  
 2272  
 2273  
 2274  
 2275  
 2276  
 2277  
 2278  
 2279  
 2280  
 2281  
 2282  
 2283  
 2284  
 2285  
 2286  
 2287  
 2288  
 2289  
 2290  
 2291  
 2292  
 2293  
 2294  
 2295  
 2296  
 2297  
 2298  
 2299  
 2300  
 2301  
 2302  
 2303  
 2304  
 2305  
 2306  
 2307  
 2308  
 2309  
 2310  
 2311  
 2312  
 2313  
 2314  
 2315  
 2316  
 2317  
 2318  
 2319  
 2320  
 2321  
 2322  
 2323  
 2324  
 2325  
 2326  
 2327  
 2328  
 2329  
 2330  
 2331  
 2332  
 2333  
 2334  
 2335  
 2336  
 2337  
 2338  
 2339  
 2340  
 2341  
 2342  
 2343  
 2344  
 2345  
 2346  
 2347  
 2348  
 2349  
 2350  
 2351  
 2352  
 2353  
 2354  
 2355  
 2356  
 2357  
 2358  
 2359  
 2360  
 2361  
 2362  
 2363  
 2364

**OPERATION OF SUN ROOF**

The sun roof fitted is the metal type and it is electrically operated.

The sliding mechanisms for the roof allow it to assume to different types of position:

- one "retracted" position which allows the opening (partial or complete) of the roof with it sliding until it disappears completely into the housing between the roof lining and the roof panel;
- one "hinged" position which allows the rear of the roof to be raised and the flow of air into the passenger compartment with a gentle ventilation effect.



**Location of push button for operating the sun roof**

The sun roof is operated by a push button located on the front trim of the roof lining and the operation is described in the table below:

Initial position	Operation	Position obtained	
Retracted opening	Press "B"	Closed	
Closed	Press "B"	Hinged opening	
Hinged opening	Press "A"	Closed	
Closed	Press "A"	Retracted opening	

**Operations of removing-refitting sun roof components on the vehicle**

The following components can be removed-refitted with the assembly fitted in the vehicle:

- Metal panel
- Sun roof lining
- Electric motor
- Spoiler

### 70.


#### Removing/refitting metal panel and sun roof lining

In order to replace the metal panel proceed as follows:


- Position the roof in the retracted position (about 100 mm) and release the roof lining (1) retaining springs;
- position the roof in the hinged position and push the roof lining towards the rear of the vehicle;
- undo the bolts fixing the metal panel (2) from the pantograph device;
- extract the sun roof lining from the assembly;
- break the two front supporting springs (3);
- rotate the lining and release the two retaining springs (4) positioned at the rear;

In order to remove the spoiler (5) undo the fixing bolts;

The water/air/dust seal (6) around the metal panel is fitted along the perimeter of the panel.



P3U080M01



P3U080M02

#### Electric operating motor

If the electric motor (G) has to be removed, when refitting, adjust the control devices:

- Manually position the metal panel for the sun roof in the hinged position.
- Act on the control button for the motor (A) in the hinged position (B) as shown in the diagram, then proceed to re-fit the motor in its housing.

#### Motor components:

- |                       |                    |
|-----------------------|--------------------|
| A. Control button     | E. Operating cam   |
| B. Hinged position    | F. Relay           |
| C. Retracted position | G. Motor           |
| D. Microswitch        | H. Closed position |

#### Removing-refitting sun roof assembly


In order to remove the assembly the roof lining has to be removed from the vehicle, undo the bolts fixing the assembly and release the electric operating motor wiring.



**Operations of removing and refitting sun roof components with the assembly removed**

In order to remove the sun roof components, carry out the operations already described on the previous pages (operations on the vehicle) then proceed as follows:

- Remove the guide/water drain terminals (7) stuck with betaseal type polyurethane sealant.
- Undo the two worm screws (13).
- Release the water drip channel (8) from the two pantographs,
- Using a lever push the pantographs towards the rear part (10).
- Remove the flexible racks (6).



P3U081M01


**Sun roof components**

- |                   |                          |                       |
|-------------------|--------------------------|-----------------------|
| 1. Metal panel    | 5. Spoiler               | 9. Upper guide        |
| 2. Roof lining    | 6. Flexible rack         | 10. Pantograph device |
| 3. Seal           | 7. Guide/drain terminals | 11. Lower guide       |
| 4. Electric motor | 8. Drip channel          | 12. Frame             |
|                   |                          | 13. Worm screws       |



*When refitting lubricate the sliding components with MOLYKOTE PG 30 L type grease or an equivalent product.*

70.




P3U082M01

### Emergency manoeuvre

The electric device for opening the sun roof is fitted with a manually operated system for use in emergencies. Proceed as follows in such cases:

- Remove the plug (1);
- Insert a "T" spanner (2) and rotate in a clockwise or anti-clockwise direction, as required.




P3U083M01

**REMOVING-REFITTING**

Position the vehicle on a lift and loosen the bolts fixing the front wheels. Raise the vehicle and remove the wheels.

**Lower engine compartment panel**


- 1 Undo the bolts shown and remove the lower engine compartment panel.



P3U083M02



2. Check that the sound insulation lining is intact; if this is not the case, the panel must be replaced; to refit it, proceed reversing the order of the operations carried out for the removal.




P3U083M03

**Left wheel arch lower sound insulation lining**


3. Undo the bolts shown and remove the lining, detaching the left wheel arch liner without actually removing it.

70.



P3U084M01


1. Check that the lining is intact; if this is not the case, it must be replaced; to refit, reverse the order of the operations carried out for the removal.



P3U084M02

### Right wheel arch liner lower sound insulation lining

2. Undo the bolts shown and remove the lining, without removing the right wheel arch liner.



P3U084M03

3. Check that the lining is intact; if this is not the case, it must be replaced; to refit, reverse the order of the operations carried out for the removal.