




TECHNICAL SERVICE MANUAL COMPOSITION



At present, June 2001, the Marea-Marea Weekend 4th volume manual is composed of the following sections


Print N°	Sections	Page Nos.	Notes
506.763/18 (XI/1999)	00	1 - 12	Marea bipower technical data (99 range)
	10	1 - 59	Marea bipower fuel system (99 range)
	55	1 - 2	Marea bipower wiring diagram (99 range)
506.763/21 (IX/2000)	10	1 - 38	Marea bipower (99 range) fault diagnosis
		60 - 61	Marea bipower (99 range) fuel system Replacing solenoid valve on methane canister
506.763/23 (IX/2000)	00	1 - 51	2000 range technical data
	10	1 - 7	Fuel system  16v 2000 range
		1 - 7	Fuel system  20v 2000 range
	50	1 - 4	2000 range climate control
	55	1 - 18	2000 range electrical equipment
		1 - 141	2000 range wiring diagrams
506.763/24 (XII/2000)	00	15 - 16	2000 range technical data update
		1 - 3	Marengo 2000 range technical data
	10	1 - 29	Fuel system  JTD 2000 range
	55	5 - 8 19 - 52	2000 range electrical equipment update

Print N°	Sections	Page Nos.	Notes
506.763/24 (XII/2000)	55	Index 11 - 14 27 - 28 47 - 48 83 - 88 99 - 100 103 - 104	2000 range wiring diagrams update
506.763/25 VI/2001)	00	1 - 2	Marea Weekend 1910 JTD – 100 CV Introduction – Technical data
	10	5 - 6 25 - 26 29 - 37	1910 JTD 2000 range fuel system update

TECHNICAL SERVICE MANUAL COMPOSITION



As of December 2000, the Marea-Marea Weekend 4th volume manual is composed of the sections listed below

Print N°	Sections	Page Nos.	Notes
506.763/18 (XI/1999)	00	1 - 12	Marea bipower technical data (99 range)
	10	1 - 59	Marea bipower fuel system (99 range)
	55	1 - 2	Marea bipower wiring diagram (99 range)
506.763/20 (IV/2000)	00	1 - 15	Marea GPL technical data
	10	1 - 26	Marea GPL fuel system
	55	1 - 9	Marea GPL wiring diagram
506.763/21 (IX/2000)	10	1 - 38	Marea bipower fault diagnosis (99 range)
		60 - 61	Marea bipower fuel system (99 range) Replacing solenoid on methane canister
506.763/23 (IX/2000)	00	1 - 50	2000 range technical data
	10	1 - 7	2000 range  16v fuel system
		1 - 7	2000 range  20v fuel system
	50	1 - 4	2000 range climate control system
	55	1 - 18	2000 range electrical equipment
		1 - 141	2000 range wiring diagrams

506.763/24 (XII/2000)	00	15 - 16	2000 range technical data update
		1 - 3	2000 range Marengo technical data
	10	1 - 29	Fuel system  JTD 2000 range
	55	5 - 8 19 - 52	Updated 2000 range electrical equipment
		Contents 11 - 14 27 - 28 47 - 48 83 - 88 99 - 100 103 - 104	Update to wiring diagrams - 2000 range

TECHNICAL SERVICE MANUAL COMPOSITION

At present, September 2000, the Marea-Marea Weekend 4th volume manual is composed of the following booklets

Print N°	Sections	Page Nos.	Notes
506.763/18 (XI/1999)	00	1 - 12	Technical data on Marea bipower (99 range)
	10	1 - 59	Marea bipower fuel system (99 range)
	55	1 - 2	Marea bipower electrical equipment wiring diagrams (99 range)
506.763/20 (IV/2000)	00	1 - 15	Marea GPL technical data
	10	1 - 26	Marea GPL fuel system
	55	1 - 9	Marea GPL electrical equipment wiring diagram
506.763/21 (IX/2000)	10	1 - 38	Marea bipower fault diagnosis (99 range)
		60 - 61	Marea bipower fuel system (99 range) Replacing solenoid valve on methane canister
506.763/23 (IX/2000)	00	1 - 50	Technical data 2000 range
	10	1 - 7	Fuel system  16v 2000 range
		1 - 7	Fuel system  20v 2000 range
	50	1 - 4	Climate control system 2000 range
	55	1 - 18	Electrical equipment 2000 range
		1 - 141	Electrical equipment wiring diagrams 2000 range

INTRODUCTION

- Identification data	1
- Weights	3
- Performance - Fuel consumption	4
- Dimensions	5
- Capacities	7
- Product specifications	9
FL Group	

TECHNICAL DATA

Engine 1ev 20v

- Specifications	10
- Typical curves	11
- Cylinder block/crankcase and associated components	12
- Auxiliary shaft	17
- Cylinder head and valve gear components	18
- Timing diagrams	22
- Counter-balance shaft	23
- Lubrication	24
- Cooling system	26
- Fuel feed system	26
- Special tools	27

Engine JTD

- Specifications	29
- Timing diagrams	30
- Supercharging	31

CLUTCH 32

GEARBOX AND DIFFERENTIAL 33

AUTOMATIC TRANSMISSION DIFFERENTIAL 35

BRAKING SYSTEM 36

STEERING 39






WHEELS 40

FRONT SUSPENSION 42

REAR SUSPENSION 44

ELECTRICAL EQUIPMENT 46

- Ignition	47
- Recharging	48
- Electronic injection/ignition	50


	CHASSIS	ENGINE	VERSION	MAREA	MAREA WEEKEND	GEARBOX	
							
	ZFA 185 000	182B6.000	185AXR1A 25	●		●	
			185BXR1A 26		●		
			185AXR11 27	●			●
			185BXR11 28		●		
		185A8.000	185AXS1A 29	●		●	
			185BXS1A 30		●		
		186A6.000	185AXT1A 31	●		●	
			185BXT1A 32		●		

NOTE


This section deals with the EEC F3 2000 range engine types.

For the subjects not dealt with, refer to the Marea-Marea Weekend manual print n° 506.763 and subsequent updates.


00.o



4F002PA01






4F002PA02

















4A02HA02

- A. Vehicle type identification code and chassis number
- B. V.I.N. Plate (EEC regulations)
- C. Engine type and number.

	A		
	B		
	C	D	
	E	kg	
	F	kg	
	1-	G	kg
	2-	H	kg
	MOTORE - ENGINE		I
	VERSIONE - VERSION		L
N° PER RICAMBI N° FOR SPARES		M	

P3F003A01

- A. Manufacturer's name
- B. Homologation number
- C. Vehicle type identification code
- D. Chassis manufacture number
- E. Maximum authorised vehicle weight when fully laden
- F. Maximum authorised weight of fully laden vehicle plus trailer
- G. Maximum authorised weight on first axle (front)
- H. Maximum authorised weight on second axle (rear)
- I. Engine type
- L. Body version code
- M. Spares number
- N. Correct value of smoke absorption coefficient (for Diesel engines only)

ENGINE TYPE		 16v	 20v	 JTD
	Marea	1140 1165 (▼)	1255	1215
	Marea Weekend	1200 1225 (▼)	1315	1275
	Marea +590= (575)*    *	1730 1755 (▼)	1830	1805
	Marea Weekend +595= (580)*    *	1795 1820 (▼)	1895	1870
Permissible loads on the axles ■		1000	1000	1000
		1000	1000	1000
Maximum permitted load on roof		80	80	80
Load on tow hook ball (trailer with braking system)		70	70	70
	Without braking system	400	400	400
	With braking system	1200	1300 (1400)●	1300

■ Loads that should never be exceeded














(*) Specific figures for 1998 20v version

(●) Specific figures for the Marea Weekend

(▼) Specific figures for the 1596 16v automatic transmission version

NOTE FOR VERSIONS WITH ACCESSORIES: In the presence of special equipment (non standard air conditioning, sun roof, trailer towing device, etc.), the empty weight increases and therefore the carrying capacity may decrease in relation to the maximum permissible loads.

00.0


		ENGINE TYPE	 16v	 16v C.A.	 20v	 JTD
<div>Speed km/h (half laden)</div> 		46	MAX 187 (185)*	59	36	
		80		94	52	
		124		139	97	
		173		182	136	
		187 (185)*		208 (206)*	188 (186)*	
		46		54	36	
(*) For Marea Weekend						
	Max. clima- ble gradient fully laden	<i>Marea</i>	36	32	39	40
		<i>Marea Weekend</i>	33	30	36	37
	Urban	<i>Marea</i>	11.2	12.2	13.7	7.0
		<i>Marea Weekend</i>	11.3	12.4	13.8	7.2
	Out-of-town	<i>Marea</i>	6.3	6.7	7.6	4.5
		<i>Marea Weekend</i>	6.5	6.7	7.7	4.5
	Combined	<i>Marea</i>	8.1	8.7	9.8	5.4
		<i>Marea Weekend</i>	8.2	8.8	9.9	5.5
Fuel consumption in accor- dance with directive 1999/100/CE (litres/100 km)						
CO ₂ exhaust emissions (g/km)		<i>Marea</i>	192	207	234	144
		<i>Marea Weekend</i>	195	210	237	146

The fuel consumption figures in accordance with directive 1999/100/CE have been defined during the course of homologation tests which include:

- An urban cycle which includes a cold start followed by a simulated varied urban cycle.
- A non-urban cycle which includes frequent acceleration in all gears simulating normal out-of-town use of the vehicle. The speed varies between 0 and 120 km/h.
- The average combined consumption includes 37% urban cycle and 63% non-urban cycle.





The type of route, traffic conditions, driving style, weather conditions, trim level/equipment/accessories, presence of special equipment and the state of the vehicle in general can lead to different fuel consumption figures from those established using the above mentioned procedures.

The CO₂ exhaust emissions (in g/km) are measured during the average combined cycle.




P4F008A01

Luggage compartment capacity (VDA regulations): 430 dm³
 The height refers to an unladen vehicle





Engine types	Wheel rim	A	B	C	D	E	F	G	H
 16v	5½Jx14-43 6Jx15-43	884	2540	969	4393	1470 1470	1440 1440	1741	1425
 16v C.A.	5½Jx14-43 6Jx15-43	884	2540	969	4393	1470 1470	1440 1440	1741	1425
 20v	6Jx15-49	884	2540	969	4393	1475	1430	1741	1428
 JTD	5½Jx14-43 6Jx15-43	884	2540	969	4393	1470 1470	1440 1440	1741	1425



















00.0



4F009A01















Luggage compartment capacity with vehicle unladen (V.D.A. standards): 500 dm³ (1540 dm³ with seats folded)

Engine types	Wheel rim	A	B	C	D	E	F	G	H
 16v	5½Jx14-43 6Jx15-43	884	2540	1066	4490	1470 1470	1440 1440	1741	1510
 16v C.A.	5½Jx14-43 6Jx15-43	884	2540	1066	4490	1470 1470	1440 1440	1741	1510
 20v	6Jx15-49	884	2540	1066	4490	1475	1435	1741	1510
 JTD	5½Jx14-43 6Jx15-43	884	2540	1066	4490	1470 1470	1440 1440	1741	1510

Product		Parts to be filled		dm ³ (l)	Kg	 16v	 20v	 JTD
	Petrol ≥ O.R. 95 Unleaded			•		63	63	-
	diesel					-	-	63
 50% + (▲)		 		•		7 (6.7 ■)	7.6 (7.4 ■)	6 (5.6 ■)
						Total capacity of cooling system		
	Petrol engines SELENIA 20K (SAE 10W/40) (●)			•		4.5	5.5	4.8
					•	4	4.7	4.25
	Diesel Engines: SELENIA TURBO DIESEL (SAE 10W/40) (●●)			•		3.8 (3.5*)	5 (4.5*)	4.3 (4*)
					•	3.4 (3.1*)	4.45 (4*)	3.75 (3.55*)
	TUTELA CAR ZC 75 Synth 			•		1.98	1.98	1.65
					•	1.8	1.8	1.5
	TUTELA GI/2 			•		4.3	-	-
					•	3.9	-	-

- (▲) Distilled water
- (●) For versions with air conditioning
- (*) Engine sump only
- (●) For temperatures below -20°C the use of SELENIA PERFORMER SAE 5W-30 is recommended
- (●●) For temperatures below -15°C the use of SELENIA WR DIESEL 5W-40 is recommended

00.0









Product		Parts to be filled			Quantity		
					dm³ (l)	Kg	
	TUTELA GI/A				-	0.8	
	TUTELA MRM2				-	0.003	
	TUTELA TOP4				without ABS	0.40	-
					with ABS	0.45	-
Total capacity							
 + 			30%			5	-
		- 10°C	50%				
		- 20°C	100%				
					 + 	6.8	-


Name of product	Description International designation	Application
SELENIA 20K	Synthetic SAE 10W40 multigrade engine oil. Exceeds specifications ACEA A3-96/CCMC G5 and API SJ	
SELENIA PERFORMER	Synthetic SAE 5W-30 multigrade engine oil. Exceeds specifications ACEA A1 and API SJ	Temperatures below - 20°C
SELENIA Turbo Diesel	Synthetic SAE 10W40 multigrade engine oil Exceeds specifications ACEA B3 and API CD	
SELENIA WR DIESEL	Synthetic SAE 5W-40 multigrade engine oil. Exceeds specifications ACEA B3 and API CF	Temperatures below - 15°C
TUTELA CAR ZC 75 SYNTH	SAE 75W-80 EP oil. Satisfies standards MIL-L-2105 D LEV and API GL 5	Manual gearboxes and differentials
TUTELA GI/A	«ATF DEXRON II D LEV» SAE 10W type oil for hydraulic power assisted steering	Hydraulic power assisted steering
TUTELA GI/2	« ATF DEXRON II D LEV» SAE 10W type oil for automatic transmissions	Automatic gearboxes
TUTELA MRM2	Water repellent, lithium soap based grease containing molybdenum disulphide, consistency NLGI = 2	Constant velocity joints
TUTELA TOP 4	Synthetic fluid NHTSA n° 116 DOT4, ISO 4925, SAE J-1703 and CUNA NC 956-01	Hydraulic brakes and hydraulically operated clutches
DP1	Mixture of alcohol, water and surface active agents CUNA NC 956-11	To be used undiluted or diluted in windscreen washer systems
Paraflu ¹¹	Anti-freeze for cooling systems with mono-ethylene glycol base CUNA NC 956-16	Cooling circuits Percentage to be used 50% up to -35°C
Diesel Mix	Additive for diesel fuel with protective action for Diesel engines	To be mixed with diesel fuel (25 cc per 10 litres)

00.10




SPECIFICATIONS

	Cycle	OTTO 4 stroke	
	Timing gear	TOHC	
	Fuel system type	Integrated electronic injection - ignition	
 Number of cylinders		4	5
 Cylinder liner (bore)	mm	80.5	82
 Stroke	mm	78.4	75.65
 Displacement	Cm ³	1596	1998
 Compression ratio		10.50 ± 0.15	10.5 ± 0.15
 Maximum power CEE	kW (bhp)	76 (103)	110 (150)
	rpm	5750	6500
 Maximum torque CEE	daNm (kgm)	14.5 (14.8)	18.1 (18.5)
	rpm	4000	3750



4F011PA01



4F011PA02

Typical engine curves obtained using the EC method


The power curves illustrated are those obtained using overhauled engines which have been run in, without a fan and with an exhaust silencer and air filter fitted, at sea level.








Technical Data












Marea- Marea Weekend

Engine: cylinder block/crankcase, crankshaft and associated 2000 range 

00.10



		 16v	 20v
DESCRIPTION		Values in mm	
 Main journals	L	—	21.72-21.80
	L ₁	22.14-22.20	—
	Ø	54.507-54.520	63.705-63.718
 Auxiliary shaft bush housings	Ø ₁	38.700-38.730	—
	Ø ₂	35.036-35.066	—
 Cylinder liner	A	80.500-80.510	82.000-82.010
	B	80.510-80.520	82.010-82.020
	C	80.520-80.530	82.020-82.030
 Piston	X	9.7	12.5
	A	80.452-80.462	81.952-81.962
	B	80.459-80.471	81.959-81.971
	C	80.468-80.478	81.968-81.978
		0.4	


		 16v	 20v
DESCRIPTION		Values in mm	
3	 Difference in weight between pistons	± 5 g	
3-1	 Piston Cylinder liner/bon \varnothing	A 0.038-0.058 B 0.039-0.061 C 0.042-0.062	
3	 Gudgeon pin housing	\varnothing 20.997-21.001	20.002-20.007
4	 Gudgeon pin	\varnothing 20.990-20.995	19.996-20.000
		0.2	
4-3	 Gudgeon pin - Housing	0.002-0.011	
3	 Piston ring grooves	1 1.225-1.245 2 1.210-1.230 3 2.010-2.030	1.220-1.240 1.210-1.230 2.010-2.030
5	 Piston rings	L 1 1.175-1.190 2 1.175-1.190 3 1.975-1.990	1.180-1.160 1.190-1.170 1.990-1.970
		0,4	








Technical Data












Marea- Marea Weekend

Engine: cylinder block/crankcase, crankshaft and associated 2000 range 


00.10












		 1596 16v	 1998 20v
DESCRIPTION		Values in mm	
5-3  Piston rings Piston ring grooves 	1	0.035-0.070	0.040-0.080
	2	0.020-0.055	0.020-0.050
	3	0.020-0.055	0.020-0.080
5-1  Piston ring gap in cylinder liner 	1	0.150-0.350	0.200-0.350
	2	0.200-0.400	0.250-0.500
	3	0.200-0.450	0.250-0.500
6  Small end bush or pin housing \varnothing_1 Big end bearing housing \varnothing_2	\varnothing_1	23.939-23.972	22.939-22.972
	\varnothing_2	48.630-48.642	51.354-51.366

							
MEASUREMENTS AND FITTINGS		Values in mm					
7  Small end bush	\varnothing_1	24.016-24.041	23.007-23.027				
	\varnothing_2 	21.004-21.009	20.006-20.012				
4-7 	Gudgeon pin Small end bush	0.009-0.019	0.006-0.020				
7-6 	Small end bush Bush housing	0.044-0.102	0.035-0.088				
8 	Crank journals \varnothing_1	1	50.794-50.800	59.994-60.000			
		2	50.787-50.793	59.988-59.990			
		3	50.780-50.786	59.982-59.980			
	Crank pins \varnothing_2	A	45.518-45.523	48.238-48.240			
		B	45.510-45.517	48.232-48.230			
		C	45.503-45.509	48.226-48.230			
	L	26.975 - 27.025	—				
	L ₁	—	26.575-26.625				
9  \varnothing  $<$	Crankshaft bearings			1	1.840-1.844	1.836-1.840	
				2	1.844-1.848	1.839-1.843	
				3	1.850-1.854	1.842-1.846	
			0.127				
9-8 	Main bearings - Journals	0.019-0.046	0.025-0.052				

00.10









		 16v	 20v
MEASUREMENTS AND FITTINGS		Values in mm	
10  Big end pins 	A	1.537-1.541	1.536-1.540
	B	1.540-1.544	1.539-1.543
	C	1.544-1.548	1.542-1.546
	$\varnothing \frac{FIAT}{A} <$	0.127	
10-8  Crankshaft bearings - Main journals		0.025-0.050	0.030-0.056
11  Thrust washers 	S	2.310-2.360	2.342-2.358
	$S \frac{FIAT}{A} >$	0.127	
11-8  Crankshaft endfloat		0.055-0.265	0.059-0.161










DESCRIPTION

Values in mm

23		\varnothing_1 	35.664-35.684
	Bushes for auxiliary drive shaft	\varnothing_2 	32.000-32.020
24		\varnothing_1	35.593-35.618
	Auxiliary drive shaft bearings	\varnothing_2	31.940-31.960
23-1	 Shaft bushes Crankcase seats		should always be interference
24-23	 Shaft bearings Bushes	\varnothing_1	0.046-0.091
		\varnothing_2	0.040-0.080





















00.10




		 16v  20v	
DESCRIPTION		Values in mm	
Camshaft supports in cylinder head 	Ø	—	26.045-26.070
	L (*)	—	19.100-19.150
 Valve guide bore in cylinder head	Ø	12.950-12.977	
12  Valve seat	α	45°±5'	
	L	approximately 2	
 Volume of combustion chamber in cylinder head	cm ³	33.3 (●)	38.2









(*) Cap measurement
















(●) Indicative value

		 1596 1ev		 1998 20v	
DESCRIPTION		Values in mm			
12	 Tappet housing in cylinder head \varnothing	—		33.000 - 33.025	
13	 Valve guide	\varnothing_1 	7.022-7.040		
		\varnothing_2 	13.010-13.030		
		\varnothing_2 	0.05-0.10-0.25		
13-12	 Valve guide Bore in cylinder head	 	0.088-0.080		
14	 Valve	 	\varnothing_1	6.982-7.000	6.975-6.990
			\varnothing_2	30.200-30.500	29.900-30.200
			α	45° 30' ± 5'	
		 	\varnothing_1	6.974-6.992	6.960-6.975
			\varnothing_2	29.750-30.050	25.900-26.200
			α	45° 30' ± 5'	
14-13	 Valve Valve guide	 	0.022-0.058 0.030-0.066	0.082-0.065 0.047-0.080	
15	 Inner valve spring	P ₁	—	11.08-12.07daN	
		H ₁	—	29.5	
		P ₂	—	21.58-23.54 daN	
		H ₂	—	20	
16	 Outer valve spring	P ₁	25.00-28.00 daN	27.07-29.43 daN	
		H ₁	34.6	34	
		P ₂	59.2-65.0 daN	48.46-52.38 daN	
		H ₂	26	24.5	

00.10




		 16v		 20v	
DESCRIPTION		Values in mm			
17a 	Camshaft bearings	\varnothing_1	29.944-29.960	—	
		\varnothing_2	52.400-52.415	—	
		\varnothing_3	52.800-52.815	—	
		\varnothing_4	53.200-53.215	—	
		\varnothing_5	53.600-53.615	—	
17c 		\varnothing	—	26.000-26.015	
		L	—	19.250-19.330	
17a 	Cam lift		8.5	9	
			8	9	
12b-c 17b-c 	Camshaft bearings	radial	0.030-0.070		
	Cylinder head supports	axial	0.100-0.230		





		 16v	 20v
DESCRIPTION		Values in mm	
18  Camshaft supports in camshaft housing	\varnothing_1	29.989-30.014	—
	\varnothing_2	52.445-52.470	—
	\varnothing_3	52.845-52.870	—
	\varnothing_4	53.245-53.270	—
	\varnothing_5	53.645-53.670	—
	\varnothing	33.000-33.025	—
17-18	 Camshaft bearings Camshaft housing supports	0.030-0.070	—
19	 Tappet	\varnothing	32.959-32.975
19-12	 Tappet Bore in cylinder head	0.025-0.066	—
19-18	 Tappet - Housing in camshaft housing	0.025-0.066	—
17-20	Clearance for timing check 		0.45
			0.45
			Hydraulic tappets
	Operational clearance 		

00.10


TIMING DIAGRAMS



4A023A01





			 16v	 20v
A Intake		opens before T.D.C.	0°	9° (*) after T.D.C.
		closes after B.D.C.	34°	49° (*)
C Exhaust		opens before B.D.C.	24°	40°
		closes after T.D.C.	0°	0°

(*) With phase transformer on: A - opens before T.D.C.: = 9°
B - closes after B.D.C.: = 31°



DESCRIPTION

Values in mm








25	Counter-balance shaft operation		through oil pump driven gear
27	 Ball bearings for counter-balance shaft	Ø ₁	19.900 - 20.000
		Ø ₂	46.989 - 47.000
25	 Counter-balance shaft bearings	Ø	19.980 - 19.993
1	Bearing seats in cylinder block/crankcase	Ø	46.975 - 47.000
27-1	 Ball bearings Crankcase seats		+0.011 - -0.025
25-27	 Shaft bearings Ball bearings		+0.020 - -0.003

00.10



LUBRICATION - DESCRIPTION








Values in mm

Engine lubrication circuit	forced circulation, via geared pump with cartridge oil filter in series	
Oil pump: type	gears	
Pump operated	through auxiliary shaft	
Oil pressure relief valve	incorporated in the oil pump	
Full flow filter	cartridge	
Low oil pressure transmitter	electrical	
 between the edge of the gears and the pump casing	0.110 – 0.180	
 between the upper edge of the gears and the pump cover	0.040 – 0.106	
Clearance between the bearing and the driven gear	0.015-0.048	
Clearance between the drive gear shaft and the housing in the pump casing	0.016-0.048	
 between drive gear and driven gear	0.30	
   Operating pressure at a temperature of 100°C	when idling > 1 bar at 4000 rpm > 4.5 bar	
	P ₁	9.0-9.8 daN
	H ₁	31
	P ₂	6.92-7.21 daN
	H ₂	21









LUBRICATION - DESCRIPTION



Values in mm

Engine lubrication circuit	forced circulation, via geared pump with cartridge oil filter in series
Oil pump: type	geared located in the crankshaft front cover
Pump operated	by chain driven by crankshaft
Oil pressure relief valve	incorporated in crankshaft front cover
Full flow filter	cartridge
Low oil pressure transmitter	electrical
 between the edge of the gears and the pump casing	0.110 - 0.180
 between upper edge of gears and pump cover	0.016 - 0.086
 between drive gear and driven gear	0.30
   Operating pressure at a temperature of 100°C	when idling 1 bar at 4000 rpm > 4 bar
	P ₁ 11.73-12.51
Oil pressure relief valve spring	H ₁ 35

00.10

COOLING			
Cooling circuit		coolant circulation via centrifugal pump, radiator and two speed fan operated by engine control unit	
Water pump operated		via belt	
 Engagement of fan Operated by control unit	 stage 1	90°÷94°C	96°÷97°C
	stage 2	95°÷99°C (■)	101°÷102°C
	 stage 1	85°÷89°C	93°÷94°C
	stage 2	90°÷94°C (■)	98°÷99°C
Engine coolant thermostat	opening starts	81° - 85°C	
	max opening	99°÷103°C	101°C÷105°C
	valve travel	9.5 mm	
Fitting clearance between impeller vanes and pump casing		0.3÷1.1 mm	0.4 + 0.95 mm
Pressure for checking system water tightness		0.98 bar	
Pressure for checking exhaust valve on expansion tank cap		0.98 bar	

(■) Versions with climate control

FUEL FEED SYSTEM			
Make		Electronic integrated injection-ignition MPI – I.A.W. Weber-Marelli	Electronic integrated injection-ignition MPI – BOSCH Motronic
Pump		electric immersed in the tank	
Output		≥ 120 l/h	
Fuel pressure regulator setting		3 bar	

INTEGRATED ELECTRONIC INJECTION/IGNITION SYSTEM COMPONENTS

Electronic control unit	Manual gearbox	I.A.W. 4EF. B3
	Automatic transmission	I.A.W. 4EF. L1
Air pressure sensor		M. Marelli TPRT 05
Fuel vapour solenoid valve		M. Marelli EC2
Throttle case		M. Marelli 46 SX F2
Idle adjustment actuator		M. Marelli IB 02
Injector		M. Marelli IWP 109
Fuel pressure regulator		MARWALL RPM 84
Coolant temperature sender unit		SYLEA 402.386.01
Top Dead Centre and rpm sensor		M. Marelli CVM 02
Throttle position sensor (potentiometer)		M. Marelli IPF 2C
Detonation sensor		NGK KNE 11
Electric fuel pump (*)		MARWALL ESS 291
Lambda sensor upstream of catalyzer		NTK OZA 534 A1
Lambda sensor downstream of catalyzer		NTK OZA 532 A1
Fuel filter		MARWALL FA 5325 IN
Timing sensor		SYLEA SFA 200
Ignition coil		Champion BAE 920A/ BERU 0.040.100.029

SPECIAL TOOLS

(*) Use tool 1870736000 for removing-refitting the fuel pump retaining ring nut

00.10

INTEGRATED ELECTRONIC INJECTION/IGNITION SYSTEM COMPONENTS












Injection/ignition system electronic control unit	Bosch ME31F001
Motorized throttle body	Bosch 0.250.003.052
Injector	Bosch 0.280.155.770
Electric fuel pump (*)	Bosch 0.580.313.011
Air flow meter	Bosch 0.281.002.199
Engine coolant temperature sensor	ELTH 2690350 – SYLEA 402.183.01
Lambda sensor (one upstream and one downstream of the catalyzer)	Bosch LS F4 0.258.006.193
Fuel vapour solenoid valve	Bosch 0.280.142.340
Detonation sensor	Bosch 0.261.231.131
Hall effect injection timing sensor	Bosch 0.232.101.036
Top Dead Centre and rpm sensor	Bosch 0.261.210.160
Ignition coil	Bosch 0.221.504.014

SPECIAL TOOLS

(*) Use tool 1870736000 for removing-refitting the fuel pump retaining ring nut



SPECIFICATIONS


	Cycle	Diesel 4 stroke	
	Timing gear	single overhead camshaft	
	Fuel system type	Direct injection Turbocharger + intercooler	
	Number of cylinders	4 in line	
	Cylinder liner (bore)	mm	82
	Stroke	mm	90.4
	Displacement	cm ³	1910
	Compression ratio	18.45 ± 0.5	
 Max power CEE 		kW (bhp)	81 (110)
		rpm	4000
 Max torque CEE		daNm (kgm)	20 (20.4)
		rpm	1500

00.10

CYLINDER HEAD GASKET ENGINE  JTD

Average - maximum piston projection (mm)	Head gasket size (mm)	Head gasket no. of refs.
0.014 0.104	0.770-0.870	0
0.105-0.205	0.870-0.970	1
0.206-0.294	0.970-1.070	2



TIMING DIAGRAMS



4A023A01

TIMING ANGLES




A	Intake 	opens before TDC	0°
		ends after BDC	32°
C	Exhaust 	opens before BDC	40°
		ends after TDC	-2°

SUPERCHARGING Turbocharger operated by exhaust gases with waste-gate pressure valve and air/air heat exchanger (intercooler)

COOLING














Turbocharger: type	Garret GT 17 variable geometry
Maximum supercharging pressure	1 bar




4F031PA01

1. Compressor inlet
2. Oil inlet
3. Turbine outlet
4. Oil outlet
5. Turbine inlet
6. Oil inlet
7. Oil outlet
8. Compressor outlet


















		 1596 16v  1998 20v  1910 JTD		
		Values in mm		
Make		  dry, single plate with bearing contact		
Operating mechanism		 Spring		
Spring loading	daN	400	600	485
 Pressure plate	Ø ₁	200	230	215
	Ø ₂	137	155	147
 Distance between pedal in end of travel position and pedal in rest position		163	144.5	
Clutch operation		mechanical	Hydraulic	
 Clutch operating pump	Ø	—	16.05 (3/4»)	
 Operating cylinder	Ø	—	25.4 (1»)	

		
--	---	---

























Make	C.513.5.13	C.510.5.21
------	------------	------------

GEARBOX

 Synchronizers	snap ring (Porsche type) 	-		
	baulk ring 			
 Gears	straight teeth 			
	spur teeth 			
  Gear ratios		3.909	3.545	3.909
		2.238	2.238	2.238
		1.444	1.520	1.444
		1.029	1.156	1.029
		0.872	0.919	0.767
		3.909	3.909	3.909

00.21- 27

DIFFERENTIAL

DIFFERENTIAL					
		Ratio crown wheel and pinion reduction	3.823 (17/65)	3.733 (15/56)	3.150 (20/63)
			14.944	13.233	12.313
			8.556	8.354	7.050
			5.520	5.674	4.549
			3.934	4.315	3.241
			3.334	3.431	2.416
			14.944	14.592	12.313
					
Differential internal housing bearing			conical roller bearings		
					
Adjustment of bearing pre-loading			with snap rings		
			1.70 -2.60		
Spare snap ring thickness					
			bearings not loaded = 0.12 bearings loaded (350 daN) = 0.08		
Recommended interference for exact bearing pre-loading					
			≤ 0.10		
Clearance between planet/satellite gears					
			no adjustment		
Adjustment of clearance between planet/satellite gears					
			0.80 - 1.25		
Spare snap ring thickness					

GEARBOX
AUTOMATIC AISIN


ENGINE TYPE



Speeds



2 2 2 2 R



Gear ratios



2 0 0 0 0

2.807

0 2 0 0 0

1.479

0 0 2 0 0

1.000

0 0 0 2 0

0.735

0 0 0 0 R

2.769



Idler ratio

1.019 (54/53)

Torque converter

ø mm

216



Drive torque ratio

2.150

Quantity of
oilTotal, with gearbox con-
verter, radiator and pipes
empty


6 litres (5.4 kg)

Replacement only

4.3 litres (3.9 kg)

GI/2


DIFFERENTIAL

Ratio crown wheel
and pinion
reduction

3.505 (82/23)

Final drive ratio

3.633 (54/53x82/23)



Ratio at the wheels



2 0 0 0 0

10.198

0 2 0 0 0

5.373

0 0 2 0 0

3.633

0 0 0 2 0




2.670









0 0 0 0 R

10.060

00.33





FRONT BRAKES

 16v	 16v *	 JTD
Values in mm		

	Disc	<div>S {  permitted</div>	Ø	257	
			11.80-12.10	19.80-20.10	
			11.10	18.55	
			10.20	18.20	
	Brake pads	S  permitted	1.5		
	Shoe	Ø	54		
	Master cylinder (pump)	Ø	22.225 (7/8")		
	Brake servo	L			Iso-Vac 8" pneumatic vacuum acting on all four wheels
	Distance of hydraulic piston control rod from master cylinder support plate				22,45 ÷ 22,65

(*) For version with automatic transmission

REAR BRAKES









 Drum	\varnothing	203.10 - 203.40	
		204.10	
		204.70	
 Shoes	S	permitted	1.5
 Cylinders	\varnothing	22.00	
 Reduction ratio	$\left\{ \begin{array}{l} \text{Pressure regulators (●)} \\ \text{Load proportioning valves (●)} \end{array} \right.$	0.36	—
		—	0.36

(●) Not fitted on versions with ABS









FRONT BRAKES

Values in mm

 Disc	\varnothing		257
			19.80-20.10
			18.55
		 permitted	18.20
 Brake pads		$S <$ allowed	1.5
 Caliper	\varnothing		54
 Master cylinder (pump)	\varnothing		22.225 (7/8")
 Brake servo			Iso-Vac 8" pneumatic vacuum acting on all four wheels
 Distance of hydraulic piston push rod from master cylinder support plate	L		22.45 - 22.65

REAR BRAKES

 Drum	\varnothing		228.30-228.60
			229.30
		 permitted	230.00
 Shoes		$S <$ permitted	1.5
 Cylinders	\varnothing		22.00
	Load proportioning valve (●)		acting on rear wheels
	Ratio (reduction)		0.36








(●) Not fitted on versions with ABS

00.33








FRONT BRAKES











Values in mm

 <p>Disc</p> <p>S</p>	 <p>permitted</p>	Ø	283.800 - 284.200
			21.800 - 22.100
			20.55
			20.20
 <p>Brake pads</p> <p>S</p>	allowed		1.5
 <p>Caliper</p>	Ø		54
 <p>Master cylinder (pump)</p>	Ø		23.81 (15/16")
 <p>Brake servo</p>			Iso-Vac 8" + 7" pneumatic vacuum acting on all four wheels
 <p>Distance of hydraulic piston push rod from master cylinder support plate</p> <p>L</p>			22.45 - 22.65








REAR BRAKES

 <p>Disc</p> <p>S</p>	 <p>allowed</p>	Ø	240
			10.80 ÷ 11.10
			10.10
			9.20
 <p>Brake pads</p> <p>S</p>	allowed		1.5
 <p>Shoe</p>	Ø		34
 <p>Load proportioning valve (●)</p>			acting on rear wheels
Ratio (reduction)			0.36

(●) Not fitted on versions with ABS

ENGINE TYPE		 16v  JTD	 20v
Make		 Rack and pinion power assisted	
Wheel	 steering wheel	3	2.9
	 rack and pinion travel	142±1.5 mm	137±1.5 mm
	Minimum turning circle m	10.7	11
 Steering angle	outer wheel α_1	31° ± 30'	
	inner wheel α_2	38° ± 30'	
	Steering column	 with two universal joints	

00.44

ENGINE TYPE	<div></div> <div>Wheel rim</div>		<div></div> <div>Tyre Tubeless radial, type</div>	<div></div> <div>Tyre pressure in bar</div>			
	pressed steel	light alloy		Front		Rear	
				average load	heavy load	average load	heavy load
<div> 16v</div>	5½J×14H-43	6J×15" H2-43	185/65 R14 86H 195/55 R15 84V(**) 185/65 R14 86Q (●) 195/55 R15 88Q (●) (**)	2.1 bar	2.2 bar	2.3 bar	2.5 bar
<div> 20V</div>	—	6J×15" H2-49	195/60 R15 88V 195/60 R15 88Q (●)	2.1 bar	2.2 bar	2.3 bar	2.5 bar
<div> JTD</div>	5½J×14H-43	6J×15" H2-43	185/65 R14 86H 195/55 R15 84V (**) 185/65 R14 86Q (●) 195/55 R15 88Q (●) (**)	2.1 bar	2.2 bar	2.3 bar	2.5 bar
SPARE WHEEL (*)	5½×14"-43 (▲) 4.00B×15»M-35	—	185/65 R14 86H (▲) 125/80 R15 95M	4.2 bar			

With the tyres warm, the inflation pressure should be increased by +0.3 bar in relation to the recommended figure.


With winter tyres the inflation pressure should be + 0.2 higher than the recommended figure for the standard tyres.

(*) Speed limit: 80 km/h

(**) Optional








(●) Winter tyres

(▲) For the TAXI version



unladen vehicle (■)

WHEEL ALIGNMENT

 front suspension	camber (**)		- 36' 24» ± 30'
	caster (**)		1° 57' ± 30'
	toe-in		-1 - 1 mm
	offset front wheels ▲		0°
 rear suspension	camber (**)		-0° 45' ± 30'
	toe-in (**)		2 ± 2 mm
	thrust angle rear wheels ▲		0°

(**) Angles not adjustable




(●) With the tyres inflated to the correct pressure and the vehicle in running order with 5 litres of fuel

(▲) Angular values, which cannot be adjusted, used for the correct alignment of the vehicle

00.44

Front suspension independent, Mac Pherson type with transverse lower track control arms secured to an auxiliary crossmember. Offset coil springs and double acting, telescopic, hydraulic shock absorbers. Anti-roll bar connected to the telescopic damper.

CLASSIFICATION OF SPRINGS ACCORDING TO VARIOUS VERSIONS AND ENGINE TYPES

VERSIONS	ENGINE TYPES		
	 16v	 20v	 JTD
Standard	E		C
Standard with ABS	E		C
With air conditioning	D		B
With air conditioning, ABS and all options	D		B
With air conditioning and ABS	D		B
Standard with automatic transmission	D		
Standard with automatic transmission and ABS	D		
With air conditioning and automatic transmission	C		
With air conditioning, ABS and all options	C		
With ABS (fitted as standard)		B	
With ABS (fitted as standard) and air conditioning		A	
With ABS (fitted as standard), air conditioning and all options		A	

SPECIFICATIONS OF VARIOUS SPRINGS

Coil springs	A	B	C	D	E
Wire diameter mm	13.6±0.05	13.5±0.05		13.2±0.05	13.2±0.05
Number of effective coils	3.75				
Coil direction	Clockwise				
Released spring height mm	449	448	434	425	413
Load under which spring height is 173 mm daN	432±17	417±17	397±16	353-383	336-364
The springs have been divided into two categories identifiable by a mark yellow (*) for those with a height of >173 mm under a load of: green (*) for those with a height of ≤173 mm under a load of:	432 daN	417 daN	397 daN	368 daN	350 daN

(*) Springs of the same type must be fitted

ENGINE TYPE



Dampers

Make		Double acting, telescopic, hydraulic	
Open (start of buffering)	mm	508 \pm 2.5	501 \pm 2.5
Closed (iron against iron)	mm	361 \pm 2.5	354 \pm 2.5
Stroke	mm	147	

Anti-roll bar

Anti-roll bar diameter	mm	18
------------------------	----	----

00.44

Rear suspension independent with track control arms anchored to an auxiliary crossmember. Variable flexibility coil springs and anti-roll bar. Gas shock absorbers with low friction coefficient lower bushes.

ENGINE TYPE	 1596 1ev	 1998 20v	 1910 JTD
-------------	--	--	--

Coil springs

Wire diameter	mm	12.3 ± 0.1
Number of effective coils		5.93
Coil direction		clockwise
Released spring height	mm	316
Height of spring under a load of: 347-373 daN	mm	184
Spring are divided into two categories, identified by markings		> 184
yellow (1) for those: 360 daN height of mm under a load of		
green (1) for those: 360 daN height of mm under a load of:		≤ 184

(1) Springs of the same type must be fitted.




Dampers

Make		double acting, telescopic, gas
Open (start of damping action)	mm	321 ± 2
Closed (iron against iron)	mm	224 ± 2
Stroke	mm	97

Anti-roll bar

Anti-roll bar diameter	mm	17
------------------------	----	----

Rear suspension independent with track control arms anchored to an auxiliary crossmember. Variable flexibility coil springs and anti-roll bar. Gas shock absorbers with low friction coefficient lower bushes.

ENGINE TYPE	 16v  20v	 JTD
--------------------	---	---

Coil springs

Wire diameter	mm	12.3±0.1	12.8±0.1
Number of effective coils		5.93	5.93
Coil direction		clockwise	
Released spring height	mm	320	322
Spring height under a load of:	419-445 daN mm	184	—
	432 daN mm	—	184
Spring are divided into two categories, identified by markings			
yellow (1) for those under a load of	412 daN a height of mm	>184	—
	432 daN a height of mm	—	>184
green (1) for those under a load of:	412 daN a height of mm	≤184	—
	432 daN a height of mm	—	≤184

(1) Springs of the same type must be fitted.




Dampers

Make		double acting, telescopic, gas
Open (start of damping action)	mm	321 ± 2
Closed (iron against iron)	mm	224 ± 2
Stroke	mm	97

Anti-roll bar

Anti-roll bar diameter	mm	17
------------------------	----	----

00.55

	 16v	 20v	 JTD
STARTER MOTOR	Bosch DW -12V -1.1 kW Valeo DGRA -12V-1,3 kW (■)	Bosch ø 74.5-1.1/12V	Bosch ø 78.5-2 kW/12V
ALTERNATOR	Bosch KCB1 -14V-45/80A Bosch KCB2-14V-50/90A (●) (*)	M. Marelli A127IR-14V-55/100A	M. Marelli A115IM-14V-55/105A M. Marelli A115IR-14V-70/120A (●)
VOLTAGE REGULATOR	BUILT IN ELECTRONIC		
BATTERY	12V-50Ah-250A 12V-60Ah-380A (▲) (*)	12V-50Ah-250A	12V-60Ah-380A 12V-70Ah-450A (▲)
IGNITION SYSTEM	Integrated electronic injection-ignition MPI I.A.W. Weber-Marelli	Injection-ignition Bosch Motronic MPI integrated electronic	—
IGNITION COIL	M. Marelli BAE 920 A	Bosch 0.221.504.014	—
SPARK PLUGS	NGK BKR5EZ Champion RC10YCC	Champion RC8BYC	—
CONTROL UNIT INJECTION ADVANCE ELEC- TRONIC	—	—	Bosch EDC 15 C7




(●) For vehicles with climate control system

(*) North European version

(▲) For the TAXI version

(■) Alternative

STARTER MOTOR




		 16v	 20v	 JTD
Make		Bosch DW -12V -1,1 kW	Bosch ø 74.5-1.1/12	Bosch ø 78.5-2 KW/12
Voltage	V	12		
Nominal power	kW	1.1	1.1	2
Rotation, pinion side		clockwise		
No. of poles		6	4	6
Winding		windings in series		permanent magnets
Engagement		free wheel		
Operation		solenoid		
End float of armature shaft	mm	0.1-0.5	0.1-0.5	0.1-0.5
Data for bench test				
Operating test (*):				
current	A	—	360-380	500
speed	rpm	—	1150	1950
voltage	V	—	8.15	7.30
torque developed	daNm	—	1.30	1.30
Engagement test (*):				
current	A	—	680-700	1200
voltage	V	—	4.9	5.5
torque developed	daNm	—	3.11	3.0
Idle test (*):				
current	A	—	60-80	70-80
voltage	V	—	4.9	11.5
speed	rpm	—	4040	5450-5750
Relay Winding resistance (*)	pull in Ω	—	0.33-0.37	0.4
	hold in Ω	—	1.13-1.27	1.7
Lubrication		VS ⁺ SAE 10W		
Internal splines and shaft bushes				
Engagement sleeve and intermediate disc		TUTELA MR3		

(*) Data obtained at an ambient temperature of 20°C.

NOTE When overhauling it is not necessary to undercut the insulator between the commutator bars

00.55

ALTERNATOR

				
Make		Bosch KCB1-14V-45/80A	M. Marelli A127IR-14V-55/100A	M. Marelli A115IM-14V-55/105A
		Bosch KCB2-14V- 50/90A (●) (*)		M. Marelli A127IR-14V-70/120A (●)
Nominal voltage of system	V	14	14	14
Maximum current	A	80 (90)(*)(●)	100	105 (120)(●)
Nominal current at 1800 rpm	rpm	45 (50)(*)(●)	55	55 (70)(●)
Nominal current at 6000 rpm	A	80 (90)(*)(●)	100	105 (120)(●)
Field winding resistance between the two slip rings (▲)	Ω	2.66-2.94 (2.47-2.73)(*)(●)	2.66-2.94	—
Direction of rotation (seen from control side)		Clockwise		
Diode power rectifiers		preconstituted bridge		

(▲) Data obtained at an ambient temperature of 20°C.

(●) For vehicles with climate control system


(*) For the TAXI version

VOLTAGE REGULATOR

		Electronic, built-in		
Make		BR1	RTM 151 B	RTM 151A
Alternator speed for test	rpm	7000		
Thermal stabilization corrector	A	—		
Test current	A	—		
Regulation voltage (▲)	V	14.3 - 14.6		

(▲) Data obtained at an ambient temperature of 23°C.


Alternator wiring diagram



4F077A01


Bosch KCB1-14V-45/80A
 Bosch KCB2-14V-50/90A
 M. Marelli A127IR-14V-55/100A
 M. Marelli A115IM-14V-55/105A

Typical voltage regulator curves



4F077A02

M. Marelli RTM 151 A



4F077A03

M. Marelli RTM 151 B

Technical Data

Marea-Marea Weekend

Electrical equipment: electronic injection-ignition

2000 range 

00.55

INTEGRATED ELECTRONIC INJECTION/IGNITION SYSTEM



Make	I.A.W. M.P.I. WEBER - MARELLI
Firing order	1 - 3 - 4 - 2

INJECTION/IGNITION CONTROL UNIT

Make type	and	versions with manual gearbox	I.A.W. 4EF. B3
		versions with automatic transmission	I.A.W. 4EF. L1

IGNITION COIL WITH 4 HIGH TENSION INTAKES

Make	Champion
Type	BAE 920 A
Ohmic resistance of primary winding at 20°C	Ω 0.580
Ohmic resistance of secondary winding at 20°C	Ω 9100

SPARK PLUGS

Make and type	NGK BKR5EZ CHAMPION RC10YCC
Thread on engine	M14×1.25
Spark gap	mm 0.8

TOP DEAD CENTRE AND RPM SENSOR

Make	M. Marelli
Type	CVM 02
Sensor winding resistance at 20°C	Ω 575-750
Distance (gap) between sensor and crankshaft pulley tooth	mm 0.5 + 1.5

ADVANCE ON ENGINE

With engine idling 700±50/min	4°
-------------------------------	----

**INTEGRATED ELECTRONIC
INJECTION/IGNITION SYSTEM**

Make	Bosch ME31 F001
Firing order	1 - 2 - 4 - 5 - 3

IGNITION COIL (1 PER SPARK PLUG)

Make	Bosch
Type	0.221.504.014
Ohmic resistance of primary winding at 20°C	Ω 0,4
Ohmic resistance of secondary winding at 20°C	Ω 8500

TOP DEAD CENTRE AND RPM SENSOR

Make and type	Bosch 0.281.002.102
Sensor winding resistance at 20°C	Ω 774 \div 946
Distance (gap) between sensor and crankshaft pulley tooth	mm 0.8 \div 1.5

DETONATION SENSOR

Make	Bosch
Type	0.261.231.095

SPARK PLUGS

Make and type	CHAMPION RC8BYC
Thread on engine	M 14 x 1.25
Spark gap	mm 0.8

page

INTRODUCTION

- Identification data	1
- Dimensions	1
- Weights	2
- Performance	2
- Fuel consumption	2




TECHNICAL DATA


- Front suspension	3
- Rear suspension	3

NOTE

This section gives technical data for the Fiat Marengo 2000 range equipped with a 1910 JTD EC F3 engine. For further information, see the Fiat Marea - Fiat Marea Weekend manual publication no. 506.763 and subsequent updates


00.0

	CHASSIS	ENGINE	VERSION	GEARBOX
				
	ZFA 185.000	186A6000	185CXT1A 03	



- Load carrying capacity 1590 dm³

P4G001A1

Engine type	DIMENSIONS (mm)							
	A	B	C	D	AND	F	G	H
	4490	1741	1510	2540	1470	1440	884	1066

Introduction

Weights - Performance – Fuel consumption

Marengo  **JTD**
2000 range






00.

WEIGHTS









(values expressed in kg)

ENGINE TYPE



		1275
 + 500 = 		1845
		1060
Permissible loads on the axles ■ 		1060

Performance – Fuel consumption

Speed km/h (average load) 		36
		52
		97
		136
		186
		36
 Fuel consumption figures as per EC directive 1999/100 (litres/100 km)		5.0

Wheels:

Tubeless tyres with radial tread, type 185/65R14-86H

Pressed steel wheel rim, type 5½J x 14" - 43

00.0

Rear suspension independent with track control arms anchored to an auxiliary crossmember. Variable rate coil springs and antiroll bar. Gas shock absorbers with low friction coefficient lower bushes.

ENGINE TYPE	
--------------------	---

Coil springs

Diameter of wire	mm	13.9 ± 0.1
Number of coils		5.93
Direction of coil		clockwise
Height of spring released	mm	323
Height under a load of: 424 ± 456 daN	mm	207
The springs are divided into two categories, identifiable by a mark:		
yellow (1) for those under a load of:	440 daN having a height of mm	> 207
green (1) for those under a load of:	440 daN having a height of mm	≤ 207

(1) When fitting, match springs of the same type.

Shock absorbers

Make		double acting, telescopic, gas
Open (start of damping action)	mm	321 ± 2
Closed (metal against metal)	mm	224 ± 2
Travel	mm	97

Anti-roll bar

Anti-roll bar diameter	mm	19
------------------------	----	----

FRONT SUSPENSION

Anti-roll bar

Anti-roll bar diameter	mm	18
------------------------	----	----

page



INTRODUCTION


- | | |
|----------------------------------|---|
| - Identification data | 1 |
| - Performance – Fuel consumption | 1 |
| - Fuel consumption | 2 |










TECHNICAL DATA

ENGINE

- | | |
|------------------|---|
| - Specifications | 2 |
|------------------|---|

	CHASSIS	ENGINE	VERSION	GEARBOX
 JTD 100 CV	ZFA 185.000	182B9.000	185BXU1A	

ENGINE TYPE	 JTD 100 CV
-------------	--

	Speed km/h (medium load)		36
			62
			97
			136
			184
			36
	Maximum climable gradient fully laden		-
	Urban		7.2
	Extra-urban		4.4
	Combi		5.5
CO ₂ exhaust emissions (g/km)			145

The fuel consumption figures in accordance with 1999/100 EC standards were determined during the course of homologation tests which include:

- an urban cycle which includes a cold start followed by a simulated varied urban cycle.
- an extraurban cycle which includes frequent acceleration in all gears simulating normal out of town usage of the vehicle. The speed varies between 0 and 120 km/h.
- the average combined consumption figure includes 37% of the urban cycle and 63% of the non-urban cycle.

The type of route, traffic conditions, driving style, weather conditions, trim level/equipment/accessories, presence of special equipment and the state of the vehicle in general can lead to different fuel consumption figures from those established using the above mentioned procedures.

The CO₂ exhaust emissions (in g/km) are measured during the combined average cycle.

Technical data

Marea Weekend  JTD 100 cv









Engine

2000 range 

00.10



SPECIFICATIONS

	Cycle	Diesel 4 stroke	
	Timing	single overhead camshaft	
	Type of fuel system	Direct injection Turbocharger + intercooler	
	No. of cylinders	4 in line	
	Cylinder liner (bore)	mm	82
	Stroke	mm	90.4
	Capacity	cm ³	1910
	Compression ratio	18.45 ± 0.5	
	Max power CEE	kW (bhp)	74 (100)
		rpm	4000
	Max torque CEE	daNm (kgm)	20 (20.4)
		rpm	1500

FUEL FEED SYSTEM

- Engine management system	1
- Diagram showing engine exhaust assembly	1
- Fuel anti-evaporation system	2
- Location of diagnostic socket	2
- Location of injection/ignition system components in the engine compartment	3
- Front Lambda sensor	4
- Rear Lambda sensor	4
- Catalytic converter heat shield	5
- Catalytic converter	5
- Exhaust manifold	6
- Electric fuel pump with level sender unit	7


ENGINE MANAGEMENT SYSTEM

The Marea-Marea Weekend 1596 16v has a 4 cylinder in line engine, with 16 valves, 1596 cc, twin over-head camshaft and a Marelli IAW 4EF integrated electronic injection/ignition system.

The fuel system differs from the one described for the 1581 16v "99 range" version through the addition of several variants to make it compatible with the EEC Stage 3 EOBD regulations.

The main modifications to the system can be summarized as follows:

- Engine management control unit with IAW 4EF
- Catalytic converter near the exhaust manifold to take maximum advantage of the heat of the gases.
- Two Lambda sensors, one upstream (front) and one downstream (rear) which check the quality of the exhaust gases and the operation of the catalyzer.
- Adoption of a timing sensor on the inlet side timing pulley.

DIAGRAM SHOWING ENGINE EXHAUST ASSEMBLY

4F001UJ01

Key

1. Exhaust manifold
2. Catalytic converter
3. Front Lambda sensor
4. Rear Lambda sensor
5. Silencers

10.


FUEL ANTI-EVAPORATION SYSTEM

The fuel anti-evaporation system has several improvements, compared with previous versions, aimed at sealing the fuel vapours on the outside.

In particular, the following measures have been adopted:

- multi-purpose valve on the tank to prevent leaks.
- New anti-evaporation solenoid valve and the adoption of rapid attachment connectors for the anti-evaporation system pipes.
- Plug on the fuel filler with attachment cable.

For further information on the fuel system, refer to publication: 507137.



Key


1. Filler
2. Multi-purpose valve
3. Active charcoal filter
4. Anti-evaporation solenoid valve
5. Fuel vapour intake on inlet manifold
6. Fuel tank
7. Engine management electronic control unit

4F002UJ01


LOCATION OF DIAGNOSTIC SOCKET

The diagnostic socket for the analysis of the engine management system is located under the junction unit in the dashboard. This socket also makes the connection with the diagnostic equipment (Examiner or other instruments) for the other electronic control units on the vehicle.

In effect, it is a "standardized" 16-way diagnostic socket which can be connected to the diagnostic equipment using the "MPX97" adaptor.



P4F013LL01


10.**LOCATION OF INJECTION/IGNITION SYSTEM COMPONENTS IN THE ENGINE COMPARTMENT**

4f003UJ01

Key

- | | |
|---|------------------------|
| 1. Active charcoal filter | 15. Rpm and TDC sensor |
| 2. Anti-evaporation solenoid valve | 16. Timing sensor |
| 3. Intake air pressure and temperature sensor | 17. Spark plugs |
| 4. Engine idle adjustment stepping motor on throttle casing | |
| 5. Throttle valve position sensor on throttle casing | |
| 6. System relay feed | |
| 7. Protective fuse | |
| 8. Throttle case | |
| 9. Maxi-fuse protecting I.E. system (EFI) | |
| 10. Speedometer sensor | |
| 11. Engine management control unit | |
| 12. Coolant temperature sensor | |
| 13. Ignition coil | |
| 14. Injectors | |

10.




FRONT LAMBDA SENSOR

Removing

- Disconnect the negative battery terminal.
- 1. Disconnect the electrical connection (1a), release the wiring from the retaining band (2) and disconnect the Lambda sensor (3).

Refitting


- Position the sensor and tighten it to torque avoiding forcing the component which would damage it irreparably.
Apply special grease (e.g. Bosch 5 964080112) to the threaded part of the sensor.



REAR LAMBDA SENSOR

Removing

- Position the vehicle on a lift.
- Disconnect the negative battery terminal.
- 2. Disconnect the electrical connection (1) and release the wiring from the retaining bands.




- 3. Raise the vehicle and disconnect the Lambda sensor.


Refitting

- Position the sensor and tighten it to torque avoiding force on the component which would damage it irreparably.
Apply special grease (e.g. Bosch 5 964080112) to the threaded part of the sensor.
- Connect the connector and renew the Lambda sensor cable fastenings.


10.



4F005UJ01



4F005UJ02



4F005UJ03

CATALYTIC CONVERTER HEAT SHIELD


Removing-refitting

- Position the vehicle on a lift and disconnect the negative battery terminal.
- 1. Raise the vehicle and undo the bolts (1) fixing the heat shield for the driveshaft boot, then detach the heat shield (2); undo the other lower bolt for the catalyzer heat shield.
- Lower the vehicle and detach the front Lambda sensor as described in the relevant paragraph.
- 2. Loosen the bands shown and detach the air hose from the filter to the throttle casing, complete with resonator.
- 3. Undo the upper bolts fixing the heat shield and detach it.

CATALYTIC CONVERTER


Removing-refitting

- Position the vehicle on a lift and disconnect the negative battery terminal.
- Disconnect the front Lambda sensor as described in the relevant paragraph.
- Detach the catalytic converter heat shield as described in the relevant paragraph.
- 4. Undo the nuts fixing the catalytic converter to the exhaust manifold.



4F005UJ04

10.





1. Loosen the band securing the catalyzer acting on the bolt (1) and undo the bolts (2) fixing the band to the bracket.
2. Disconnect the connector for the rear Lambda sensor and release the cable from the retaining bands along the routing.
3. Raise the vehicle, undo the bolts fixing the catalytic converter to the rear exhaust pipe and detach the converter, complete with rear Lambda sensor.


EXHAUST MANIFOLD

Removing-Refitting

- Position the vehicle on a lift, disconnect the negative battery terminal and disconnect the following components, as described in the relevant paragraphs.
 - Front Lambda sensor
 - Catalytic converter heat shield
 - Catalytic converter.
4. Remove the protective cover for the power assisted steering pump drive belt.




4F006UJ03



4F006UJ04

10.



4F007UJ01




1. Loosen the belt tension using the lock nut (2) and the adjustment screw (1); then release the belt from the pulley.
 2. Undo the bolts fixing the bracket for the power assisted steering pump mounting and detach the pump.
 3. Undo the nuts fixing the exhaust manifold to the cylinder head and detach the manifold.
- To refit, reverse the order of the operations carried out for the removal; tension the power assisted steering pump drive belt, using the adjustment screw; use tool 189576200 to check that the tension is between 32 and 45 daN.

ELECTRIC FUEL PUMP WITH LEVEL SENDER UNIT


Removing-refitting

- Disconnect the negative battery terminal.
 - Lift up the lining in the luggage compartment and remove the fuel pump protective cover.
 - Disconnect the electrical connection for the electric pump assembly and the fuel supply and breather pipes.
4. Undo the ring nut fixing the electric fuel pump to the tank using tool 1870736000. The gasket on the tank housing should be replaced each time the pump drip tray is removed-refitted.


NOTE The position of the fuel pump is fixed and is established by a reference in the housing in the tank which should correspond to the projection on the pump drip tray.



4F007UJ02



4F007UJ03



4F007UJ04

FUEL FEED SYSTEM

- Engine management system	1
- Location of injection/ignition system components	2
- Location of diagnostic socket	2
- Removing-refitting accelorometer	3
- Removing-refitting front Lambda sensor	3
- Removing-refitting rear Lambda sensor	4
- Removing-refitting heat shield	5
- Removing-refitting catalytic converter	7

ENGINE MANAGEMENT SYSTEM

Foreword

The Marea-Marea Weekend 1998 20v is equipped with a 5 cylinder in line engine with 20 valves, 1998 cc, twin overhead camshaft and a Bosch ME3.1 integrated electronic injection/ignition system.


The fuel system differs from the one described for the 1998 20v "99 range" version through the addition of several variants to make it compatible with the **EEC Stage 3 EOBD** regulations.

The main modifications to the system can be summarized as follows:

- Catalytic converter near the exhaust manifold to take maximum advantage of the heat of the gases.
- Two Lambda sensors, one upstream (front) and one downstream (rear) which check the quality of the exhaust gases and the operation of the catalyzer.
- Adoption of an accelerometer sensor on the right shock absorber turret, used to distinguish between engine torque variations due to the unevenness of the road surface and those due to failed ignition in the combustion chamber (misfire).
- Adoption of a timing sensor on the inlet side timing pulley.
- Multi-purpose valve on the tank to prevent leaks.
- Adoption of rapid attachment connectors for the anti-evaporation system pipes.
- Cap on the fuel filler with an attachment cable.

For further information on the fuel system, refer to publication 507137.

DIAGRAM SHOWING ENGINE EXHAUST ASSEMBLY




4F001WJ01

Key

1. Exhaust manifold
2. Catalytic converter
3. Front Lambda sensor
4. Rear Lambda sensor
5. Silencers

10.

LOCATION OF INJECTION/IGNITION SYSTEM COMPONENTS



4F002WJ01


Key

- | | |
|---|--|
| 1. Variable valve timing control solenoid | 9. Vehicle speed sensor |
| 2. Injectors | 10. Variable geometry manifold actuator solenoid valve |
| 3. Fuel vapour cut-out solenoid valve | 11. RPM sensor |
| 4. Injection/ignition control unit | 12. Front Lambda sensor connector |
| 5. General system protective fuse | 13. Ignition coil |
| 6. Flow meter/air temperature sensor | 14. Timing sensor |
| 7. Motorized throttle body | 15. Rear Lambda sensor connector |
| 8. Engine coolant temperature sensor | 16. Detonation sensors |
| | 17. Accelerometer |


LOCATION OF DIAGNOSTIC SOCKET

The diagnostic socket for the analysis of the engine management system is located under the junction unit in the dashboard. This socket also makes a connection with the diagnostic equipment (Examiner or other instruments) for the other electronic control units on the vehicle.

It is a "standardized" 16-way diagnostic socket which can be connected to the diagnostic equipment using the "MPX97" adaptor.



P4f013LL01



REMOVING-REFITTING ACCELEROMETER

Removing

- Disconnect the negative battery terminal.
- 1. Disconnect the electrical connector (1a), undo the fixing bolts (1b) and remove the device (1c).




Refitting

- Reverse the order of the operations carried out for the removal.


REMOVING-REFITTING FRONT LAMBDA SENSOR

Removing

- Position the vehicle on a lift.
- Disconnect the negative battery terminal.
- Raise the lift.
- 2. Undo the lower fixing bolts (1a) and the side fixing bolts (1b) and remove the shield (1c) under the engine.
- 3. Undo the fixing nuts (1a) and remove the lower section (1b) of the heat shield.
- 4. Disconnect the electrical connector (1a) and undo the front Lambda sensor (1b).



10.



- Release the electrical wiring for the front Lambda sensor from the retaining bands and remove the sensor.

Refitting


NOTE Apply special grease (e.g. Bosch VS 14016- FT) to the threaded part of the sensor

- Place the Lambda sensor in position and tighten to torque.



Lambda sensor : 4.5 daNm

- Reverse the order of the operations described for the removal.



REMOVING-REFITTING REAR LAMBDA SENSOR

Removing

- Position the vehicle on a lift.
 - Disconnect the negative battery terminal.
1. Disconnect the electrical connector (1a) and release the electrical wiring from the retaining bands.
- Raise the lift.
2. Undo the lower fixing bolts (1a) and the side fixing bolts (1b) and remove the shield (1c) under the engine.
3. Use tool USAG 875 (1a), shown in the diagram or a similar tool to undo the rear Lambda sensor.

Refitting


NOTE Apply special grease (e.g. Bosch VS 14016- FT) to the threaded part of the sensor.

- Place the Lambda sensor in position and tighten to torque.




Lambda sensor : 4.5 daNm

- Reverse the order of the operations carried out for the removal.



10.




4F005WJ01



REMOVING-REFITTING HEAT SHIELD

Removing


- Position the vehicle on a lift.
 - Disconnect the negative battery terminal.
1. Undo the fixing bolts (1a) and remove the air duct (1b).




4F005WJ02



2. Open the retaining band (1a) and place the engine coolant return pipe to the radiator (1b) at the side in order to undo the bolts (1c) fixing the upper section of the heat shield.
3. Undo the upper bolts (1a) fixing the fan and disconnect the electrical connector (1b).




4F005WJ02




4F005WJ03


10.




4F006WJ01



4F006WJ02



4F006WJ03



4F006WJ04

- Raise the lift.


1. Undo the upper fixing bolts (1a) and the side fixing bolts (1b) and remove the shield (1c) under the engine.

2. Undo the lower bolts (1a) and remove the fan (1b).

3. Undo the fixing nuts (1a) and remove the lower part (1b) of the heat shield.

4. Remove the upper part (1a) of the heat shield.

10.



REMOVING-REFITTING CATALYTIC CONVERTER


Removing

- Position the vehicle on a lift.
- Disconnect the negative battery terminal.
- Remove: the upper and lower heat shields, the front and rear Lambda sensors, carrying out the operations described in the relevant chapters.
- Lower the lift.

1. Undo the fixing nuts (1a) and separate the catalytic converter (1b) from the exhaust manifold (1c).



Nuts 1a: 3.2 daNm



- Raise the lift.
2. Undo the fixing nuts (1a) and separate the exhaust pipe (1b).



Nuts 1a: 4.2 daNm


3. Undo the nuts (1a) and the bolts (1b) and remove the bracket (1c).



Nuts 1a: 2.5 daNm



Bolts 1b: 2.5 daNm



Refitting

- Reverse the order of the operations carried out for the removal.

	page		page
FUEL SYSTEM	1	THROTTLE CASING	
- Introduction	1	- Removing-refitting	30
- System management strategies	1	E.G.R. VALVE	
- Fuel system functional diagram	2	- Removing-refitting	31
- Diagram showing information entering/leaving the control unit and sensors/actuators	7	E.G.R. VALVE SELF-ADJUSTMENT MOTOR	
INJECTION SYSTEM WIRING DIAGRAM	8	- Removing-refitting	32
- Injection electronic control unit	10	E.G.R. VALVE HEAT EXCHANGER	
- Rpm sensor	12	- Removing-refitting	32
- Timing sensor	13	SOLENOID VALVE ON VACUUM RESERVOIR FOR THROTTLE CASING PNEUMATIC VALVE	
- Air flow meter	13	- Removing-refitting	34
- Injectors	14	VACUUM RESERVOIR	
- Engine coolant temperature sensor	15	- Removing-refitting	34
- Fuel temperature sensor	15	SUPERCHARGING PRESSURE CONTROL SOLENOID VALVE	
- Fuel pressure sensor	15	- Removing-refitting	35
- Heater plugs control unit	16	FUEL FILTER	
- Accelerator pedal potentiometer	16	- Removing-refitting	35
- Brake pedal switch	17	PRESSURE REGULATOR	
- Clutch pedal switch	17	- Removing-refitting	36
- Excess pressure sensor	17		
- Atmospheric pressure sensor	17		
FUEL SUPPLY CIRCUIT	18		
- Immersed (auxiliary) pump and fuel gauge assembly	19		
- Fuel filter	19		
- Pressure pump	20		
- Fuel pressure regulator	20		
- Multifunction valve	21		
- Supply manifold (rail)	21		
- Inertia safety switch	22		
AIR SUPPLY CIRCUIT	23		
- Throttle case	24		
- Turbocharger	25		
EMISSION CONTROL DEVICES	27		
- Oxidizing catalytic converter	27		
- Exhaust gas recirculation circuit (EGR)	27		
- Recirculation circuit for crankcase vapours (blow-by)	29		

FUEL SYSTEM

INTRODUCTION

Marea and Marea Weekend 1.9 JTD cars are equipped with a 4 cylinder in line, 1910 cc turbodiesel engine with two valves per cylinder, an overhead camshaft, turbocharger and intercooler and electronic injection.

The fuel system ensures correct engine operation and can be divided into the following subsystems:

- Fuel feed circuit with common rail injection;
- air feed circuit;
- exhaust circuit;
- blow by vapour recirculation circuit;
- Exhaust Gas Recirculation (EGR) circuit

Operation of the various circuits making up the fuel system is optimised by an electronic control system managed by a special control unit.

The main feature of the fuel system is common rail fuel injection. Common rail is a higher pressure electronic injection system for fast direct injection diesel engines.

The main features of the common rail system are as follows:

- availability of high injection pressures (up to 1350 bars);
- possibility of modulating these pressures (from a minimum of 150 bars to a maximum of 1350 bars) independently of engine speed (rpm) and engine load;
- ability to operate at high engine speeds (up to 6000 rpm);
- precise injection control (injection advance and duration);
- reduced fuel consumption;
- reduced emissions.

FUEL SYSTEM MANAGEMENT STRATEGIES

The management program (software) is stored inside the control unit memory and consists of a series of strategies, each of which manages a precise system control function.

Through the use of information provided by the various sensors (input), each strategy processes a set of parameters based on data stored in special control unit memory areas. It then controls system actuators (output), i.e. the devices that allow the engine to operate.


The main purpose of these management strategies is to determine the exact amount of fuel to be injected into the cylinders with timing (injection advance) and pressure designed to achieve the best possible engine performance in terms of power, fuel consumption, fumes, emissions and handling.

The main system management strategies are essentially as follows:

- control of injected fuel quantity;
- control of injection advance;
- control of injection pressure;
- control of auxiliary fuel pump;
- control of injection during over-run (cut-off);
- control of idle speed;
- control of maximum speed limitation;
- control of maximum torque limitation;
- control of fuel temperature;
- control of engine coolant temperature;
- control of air turbocharging pressure;
- control of glow plugs;
- control of exhaust fumes;
- control of exhaust gas recirculation (EGR);
- control of climate control system activation;
- control of engine immobiliser operation (Fiat CODE);
- self-diagnosis

10.

FUEL SYSTEM OPERATING DIAGRAM



4F002X.J01

- | | |
|---|--|
| 1. Pressure pump | 23. Glow plug preheating warning light |
| 2. Electrically-controlled EGR valve | 24. System failure warning light |
| 3. Flow meter | 25. Pressure relief sensor |
| 4. Pressure regulator | 26. Fuel temperature sensor |
| 5. Fuel filter | 27. Throttle valve |
| 6. Instrument panel | 28. Variable geometry actuator |
| 7. Glow plug preheating control unit | 29. Vacuum tank |
| 8. Electronic control unit | 30. Exhaust gas heat exchanger |
| 9. Injection system relay | |
| 10. Return manifold (low pressure) | |
| 11. RPM sensor | |
| 12. Glow plugs | |
| 13. Engine coolant temperature sensor | |
| 14. Potentiometer on accelerator pedal | |
| 15. Switch on brake pedal | |
| 16. Switch on clutch pedal | |
| 17. Variable geometry turbocharger | |
| 18. Timing sensor | |
| 19. Injectors | |
| 20. Fuel pressure sensor | |
| 21. Variable geometry turbocharger control solenoid | |
| 22. Auxiliary fuel pump | |

Control of injected fuel quantity

The control unit controls the fuel pressure regulator and injectors on the basis of output signals from the accelerator pedal potentiometer, flow meter and rpm sensor.

The timing and thus the injection sequence are determined when the engine is started up using signals from the rpm and timing sensor (synchronisation stage); injection timing is then implemented using the rpm sensor signal alone and considering a injection sequence of 1-3-4-2.

The control unit inhibits injection in the following cases:

- fuel pressure level greater than 1500 bars;
- fuel pressure level lower than 120 bars;
- engine speed higher than 6000 rpm.

When the engine has warmed up, maximum injection duration (injector opening time) is 1500 ns, but it can reach 3000 ns during the start-up stage.

Control of injection advance

The electronic control unit determines injection advance mainly on the basis of the quantity of fuel to be injected.

The injection advance is then corrected on the basis of coolant temperature and speed in order to compensate for ignition delays due to low temperatures in the combustion chamber during warm-up.

The optimum injection point is also processed to ensure driving comfort and emission limits laid down by Euro 3 legislation.

Control of injection pressure

This control is of particular importance because injection pressure influences the following parameters:

- amount of fuel taken into the cylinders for the same injection time duration;
- injected fuel nebulation;
- spray penetration;
- lag between electrical control to injection and actual injection start and end times.

The above parameters engine behaviour significantly, particularly in terms of power output, exhaust emissions, noise levels and handling.

The injection control unit controls the pressure governor on the basis of engine load to obtain an optimal line pressure at all times.

When the engine is cold, injection pressure is corrected on the basis of engine speed and engine coolant temperature to meet engine needs at different operating temperatures.

Control of auxiliary fuel pump

The auxiliary fuel pump submerged in the tank is supplied by the injection control unit by means of a relay when the ignition key is turned on.

Fuel supply to the pump is inhibited when one of the following condition occurs:

- when the ignition has been turned on for a certain length of time without the engine running;
- if the inertia switch cuts in.

Control of injection during over-run (cut-off)

The fuel cut-off strategy is implemented when the injection control unit receives information that the accelerator pedal has been released from the potentiometer.

Under these conditions, the control unit cuts off the fuel supply to the injectors and restores it before idle speed is reached.

10.

Control of idle speed

On the basis of signals from the rpm sensor and engine coolant temperature sensor, the injection control unit controls the pressure governor and alters the injector control times to maintain idle speed stable at all times.

Under certain conditions, the idle speed control unit also considers battery voltage.

Control of maximum speed limitation

According to rpm level, the injection control unit limits maximum speed by means of two types of intervention:

- as maximum speed approaches, it reduces the amount of fuel injected to reduce line pressure;
- when maximum speed is exceeded, it inhibits operation of the auxiliary pump and injectors.

Control of maximum torque limitation

On the basis of rpm level, the injection control unit computes limit torque and maximum permitted fume index parameters on the basis of predefined, stored maps.

It then corrects the above parameters using engine coolant temperature and car speed data. The resulting values are then used to modulate the amount of fuel to be injected by adjusting the pressure regulator and injectors.

Control of fuel temperature

The injection control unit is kept constantly informed of fuel temperature by a sensor on the return manifold.

If fuel temperature exceeds a set value (about 110 °C), the control unit reduces line pressure by adjusting the pressure governor, leaving injection times unaltered.

Control of coolant temperature

The injection control unit is constantly informed of coolant temperature by a sensor on the thermostat.

If engine coolant temperature or air conditioning fluid pressure exceeds certain levels, the control unit performs the following actions:

- It reduces the amount of fuel injected by adjusting the pressure governor and injectors (power reduction);
- it controls the engine radiator cooling fan.

Control of glow plugs

The injection control unit controls operation of the glow plug preheating control unit to bring the temperature in the combustion chambers up to levels that promote fuel self-ignition and thus make start-up easier.

The control unit controls the operation of the glow plug control unit for a certain time both before (preheating) and after (postheating) engine start-up and also controls activation of the warning light on the control panel.

Preheating, postheating and glow plug warning light activation times vary according to engine coolant temperature.

Exhaust fumes control

Through this function the injection control unit limits any exhaust fumes that could be produced during transition speeds.

To satisfy these requirements the control unit processes the signals supplied by the accelerator pedal potentiometer, the rpm sensor and the air flow meter and controls the fuel pressure regulator and the injectors to meter the correct amount of fuel to inject.

Exhaust gas recirculation control

On the basis of the signals supplied by the rpm sensor, intake air quantity sensor, engine coolant temperature sensor and accelerator pedal position sensor, the control unit calculates the operating times for the EGR valve so that the exhaust gases are partly recirculated in certain engine operating conditions in line with Euro 3 pollution control standards.

Air conditioning system engagement control

The injection control unit manages the operation of the air conditioning system compressor electromagnet coupling following a logic aimed at preventing operating conditions that would adversely affect engine performance.

- When the compressor is switched on the injection control unit increases the quantity of fuel during idling to allow the engine to adjust to the increased power requirements and momentarily interrupts the supply to the compressor in high engine power requirement conditions (strong acceleration).

Engine immobilizer function control

The system is equipped with an engine immobilizer function. This function is achieved through the presence of a specific control unit (Fiat CODE), capable of conversing with the injection control unit and an electronic key with a special transmitter for sending a recognition code.

Each time the key is turned to the OFF position, the Fiat CODE system completely deactivates the injection control unit.

When the key is turned to the ON position the following operations take place, in order:

1. the injection control unit (whose memory contains a secret code) sends the Fiat CODE control unit a request to send the secret code to deactivate the immobilizer functions;
2. the Fiat CODE control unit responds by only sending the secret code after, in turn, having received the recognition code transmitted by the ignition key;
3. the recognition of the secret code allows the deactivation of the injection control unit immobilizer function and its normal operation.

Autodiagnosis

The complete electronic fault diagnosis of the injection system is carried out by connecting the special equipment (EXAMINER or EXAMINER PLUS) to the standardized diagnostic socket (EOBD).

The system is also equipped with a self-diagnostic function which recognizes, memorizes and signals any faults.

If a fault is detected in the sensors or actuators, the recovery strategy is immediately activated in order to ensure that the engine functions at an acceptable level. The vehicle can be driven to a service centre for the appropriate repairs to be carried out.

10.

The control unit autodiagnostic system checks the signals coming from the sensors and compares them with the figures allowed:

- signalling faults during starting
- warning light on for 4 seconds indicates test stage
- warning light off after 4 seconds indicates no fault with components that could alter the pollution control standard figures
- warning light on after 4 seconds indicates fault.
- signalling faults during operation
- warning light on indicates fault
- warning light off indicates no fault with components that could alter the pollution control standard figures.
- recovery
- from time to time, the control unit defines the type of recovery according to the components which are faulty
- the recovery parameters are managed by components which are not faulty.

Control of cylinder balancing during idling

According to the signals coming from the sensors, the injection control unit controls the idle speed torque, altering the injector operating times.

Control of irregular operation

Depending on the signals coming from the sensors, the injection control unit corrects the amount of fuel to be injected in order to improve driveability and reduce jerking whilst driving.

The correction is achieved through the fuel pressure regulator and by varying the injector operating times.

Control of electrical balance

According to the battery voltage, the injection control unit alters the idle speed, to guarantee a sufficient current supply from the alternator in situations where the consumers are absorbing a great deal of power.

The variation in the idle speed is achieved by regulating the fuel pressure and altering the injector operating times.

VGT variable geometry turbocharger control (1910 JTD 110 CV)

The injection control unit processes the signal coming from the supercharging sensor, at the various engine operating speeds, and determines the quantity of fuel to be injected, acting on the fuel pressure regulator and the injector opening times.

In addition, through the solenoid valve, the control unit regulates the geometry of the turbine in order to ensure optimum performance in all operating conditions.

Turbocharger waste gate valve control (1910 JTD 100 CV)

At the various engine operating speeds, the injection control unit processes the signal coming from the supercharging sensor and determines the amount of fuel to inject, acting on the fuel pressure regulator and the injector opening times.


In addition, the control unit controls the opening of the turbocharger waste gate valve, via the solenoid valve, in order to ensure excellent performance in all operating conditions.

Control of throttle closing when engine is switched off

When the engine is switched off (ignition key in OFF position) the injection control unit closes the throttle valve located on the air intake duct via the special solenoid valve.

This action makes it possible to limit the tiresome shuddering of the engine whilst it is switching off.

DIAGRAM SHOWING INFORMATION FLOW BETWEEN THE INJECTION CONTROL UNIT AND SENSORS/ACTUATORS




4F007XJ01

- | | |
|--|--|
| 1. Auxiliary fuel pump | 18. Battery |
| 2. Variable geometry turbocharger control solenoid | 19. Four stage pressure switch |
| 3. Climate control compressor | 20. Fiat CODE control unit |
| 4. Electric EGR valve | 21. Diagnostic socket |
| 5. Rev counter | 22. Fuel pressure regulator |
| 6. Engine radiator fan | 23. Injectors |
| 7. Glow plug preheating control unit | 24. Throttle valve control solenoid |
| 8. Potentiometer on accelerator pedal | 25. Glow plug preheating warning light |
| 9. Brake and clutch pedal switches | 26. Injection system failure warning light |
| 10. Fuel pressure sensor | |
| 11. Intake air flow and temperature sensor (debimeter) | |
| 12. Coolant temperature sensor | |
| 13. Fuel temperature sensor | |
| 14. Pressure relief sensor | |
| 15. Timing sensor | |
| 16. Rpm sensor | |
| 17. Vehicle speed signal | |

10.

INJECTION SYSTEM WIRING DIAGRAM



4F008XJ01

Compents of injection system wiring diagram

1. Vehicle speed
2. Rev counter
3. Engine radiator fan low speed relay
4. Radiator fan high speed activation relay
5. Potentiometer on accelerator pedal
6. Timing sensor
7. Fuel pressure sensor
8. EGR system modulator solenoid
9. Fuel pressure regulator
10. Glow plug preheating warning light on control panel
11. Injection system failure warning light
12. Air conditioning system relay
13. Coolant temperature sensor
14. Rpm sensor
15. Fuel temperature sensor
16. Diagnostic socket
17. Fiat CODE control unit
18. Four stage pressure switch
19. Injection electronic control unit
20. Pressure relief sensor
21. 7.5A fuse protecting electronic injection system (+15 power supply from ignition switch)
22. 7.5A fuse protecting electronic injection system (+30 power supply from ignition switch)
23. Main injection system relay
24. 30A fuse protecting injection system
25. Auxiliary fuel pump relay
26. Glow plug preheating control unit
27. Intake air flow and temperature sensor (debimeter)
28. Brake pedal switch
29. Clutch pedal switch
30. Ignition switch
31. Battery
32. Inertia switch
33. Auxiliary fuel pump (submerged in tank)
34. 60A fuse protecting glow plug control unit
35. Cylinder no. 1 glow plug
36. Cylinder no. 2 glow plug
37. Cylinder no. 3 glow plug
38. Cylinder no. 4 glow plug
39. Cylinder no. 1 injector
40. Cylinder no. 2 injector
41. Cylinder no. 3 injector
42. Cylinder no. 4 injector
43. Throttle valve control solenoid
44. Variable geometry turbocharger control solenoid
45. Diesel filter heater relay

10.


ELECTRONIC INJECTION CONTROL UNIT

The control unit processes signals from the various sensors by applying software algorithms and controls the actuators accordingly (particularly the injectors and pressure regulator) to achieve the best possible engine service conditions.

The control unit is "flash E.P.R.O.M." type, i.e. it can be reprogrammed from outside without any need to adjust the hardware.

The injection control unit contains a built-in absolute pressure sensor and is connected to the wiring by means of a 121 pin connector.

Control unit connection identification (PIN-out)




4F010XJ01


- | | |
|-------------------------------------|------------------|
| 1 Earth | 25 Not connected |
| 2 Earth | 26 Not connected |
| 3 Earth | 27 Not connected |
| 4 Actuator power supply | 28 Not connected |
| 5 Injector/ECU power supply | 29 Not connected |
| 6 Not connected | 30 Not connected |
| 7 Not connected | 31 Not connected |
| 8 Not connected | 32 Not connected |
| 9 Not connected | 33 Not connected |
| 10 Not connected | 34 Not connected |
| 11 Fiat CODE | 35 Not connected |
| 12 Not connected | 36 Not connected |
| 13 Injection relay | |
| 14 Glow plug control | |
| 15 Throttle body solenoid | |
| 16 EGR valve | |
| 17S VGT solenoid | |
| 18 Air conditioner relay | |
| 19 Radiator fan high speed relay | |
| 20 Radiator fan low speed relay | |
| 21 Diagnostic warning light control | |
| 22 Glow plug activation control | |
| 23 Not connected | |
| 24 Auxiliary fuel pump relay | |

37 Not connected	93 Turbo pressure sensor (pin 1)
38 Not connected	94 Turbo pressure sensor (pin 3)
39 Not connected	95 Turbo pressure sensor (pin 2)
40 Not connected	96 Not connected
41 Not connected	97 Air flow meter (pin 4)
42 Not connected	98 Not connected
43 Not connected	99 RPM sensor (pin 1)
44 Not connected	100 RPM sensor (pin 2)
45 Not connected	101 RPM sensor (pin 3)
46 Not connected	102 RPM sensor (pin 1)
47 Engine rpm signal output	103 Timing sensor (pin 2)
48 Diagnostic line k	104 Timing sensor (pin 3)
49 Vehicle speed signal input	105 Not connected
50 Not connected	106 Not connected
51 Activation signal from 4-stage pressure switch	107 Not connected
52 Activation signal from 3-stage pressure switch	108 Fuel pressure regulator
53 Not connected	109 Fuel pressure regulator
54 Not connected	110 Not connected
55 Not connected	111 Heater relay control Fuel filter
56 Not connected	112 Not connected
57 Not connected	113 Not connected
58 Key ON signal	114 Cylinder 4 injector control
59 Brake switch	115 Not connected
60 Air conditioner activation request	116 Not connected
61 Clutch switch	117 Cylinder 1 and 2 injector power supply
62 Glow plug diagnosis	118 Cylinder 3 and 4 injector power supply
63 Not connected	119 Cylinder 1 injector control
64 Not connected	120 Cylinder 2 injector control
65 Not connected	121 Cylinder 3 injector control
66 Not connected	
67 Not connected	
68 Not connected	
69 Not connected	
70 Not connected	
71 Not connected	
72 Not connected	
73 Not connected	
74 Not connected	
75 Not connected	
76 Accelerator pedal 1 earth	
77 Accelerator pedal 1 signal	
78 Accelerator pedal 1 power supply	
79 Accelerator pedal 2 earth	
80 Accelerator pedal 2 signal	
81 Accelerator pedal 2 power supply	
82 Diesel temperature sensor (pin 1)	
83 Diesel temperature sensor (pin 2)	
84 Coolant temperature sensor (pin 1)	
85 Coolant temperature sensor (pin 2)	
86 Air flow meter (pin 1)	
87 Not connected	
88 Air flow meter (pin 3)	
89 Air flow meter (pin 5)	
90 Fuel pressure sensor (pin 3)	
91 Fuel pressure sensor (pin 2)	
92 Fuel pressure sensor (pin 1)	


10.



4F012XJ01



4F012XJ02



4F012XJ03

RPM SENSOR

The rpm sensor is fitted to the engine crankcase and faces the phonic wheel on the crankshaft.

The sensor is inductive type, i.e. it works by varying a magnetic field generated when the phonic wheel teeth (60-2 teeth) pass in front of the sensor element.

The injection control unit uses the rpm sensor signal to determine crankshaft speed and angular position.

Operation

The changeover from full to empty due to the presence or absence of teeth sets up a magnetic flux change sufficient to generate an induced alternating voltage proportional to the number of teeth on the phonic wheel.

The peak sensor output voltage value, all things being equal, depends on the distance between the sensor and the tooth (gap).

1. Steel bush
2. Permanent magnet
3. Sensor case
4. Winding
5. Core
6. Phonic wheel
7. Electrical connection

To obtain the correct signal, the specified gap between phonic wheel and sensor should be between 0.8 and 1.5 mm

This distance is not adjustable. When the gap is not as specified, check the condition of the sensor and phonic wheel.

Winding resistance
860 Ohm $\pm 110\%$ at 20 °C

1. Maximum magnetic flux
2. Minimum magnetic flux
3. Induced alternate voltage

TIMING SENSOR

The Hall effect sensor is fitted to the cylinder head and faces the camshaft pulley.

An opening on the pulley allows the timing sensor to detect the engine timing position and indicate it to the injection control unit.

The injection control unit uses the timing sensor signal to detect TDC at the end of compression.

Operation


A semi-conductor layer, through which a current passes, immersed in a magnetic field (lines of force perpendicular to the direction of the current), produces a difference in power, known as Hall voltage.

If the intensity of the current remains constant, the voltage produced only depends on the intensity of the magnetic field. The intensity of the field can simply be altered periodically to produce a modulated electrical signal. Signal frequency is proportional to the speed with which the magnetic field changes.

To achieve this change, the sensor is crossed by a metal ring (inner part of the pulley) with an opening.

When it moves, the metal part of the ring covers the sensor to magnetic field and the output signal is therefore low; Conversely, the sensor generates a high signal at the opening when the magnetic field is present.

This signal, together with the rpm and TDC signals, allows the injection control unit to identify piston position and determine injection point.



4F013XJ01

AIR FLOW METER (DEBIMETER)

The debimeter is located on the air intake sleeve and is hot film type.

The debimeter contains an intake air temperature sensor.

Operation

The principle of operation is based on a heated membrane fitted into a measurement channel through which engine intake air flows.


The hot film membrane is maintained at a constant temperature (about 120 °C higher than incoming air) by the heater coil.

The mass of air flowing through the measurement channel tends to take heat from the membrane. To keep the membrane at constant temperature, a certain current level must flow through the resistance.

Because this current is proportional to the mass of air that flows to the engine, it can be measured with a Wheatstone bridge and the resulting signal is sent to the injection control unit.

1. Covers
2. Electronic card
3. Sensor
4. Mounting plate
5. Mount
6. o-ring
7. Temperature sensor

10.



4F014XJ01

1. Pressure rod
2. Pin
3. Nozzle
4. Coil
5. Pilot valve
6. Ball plunger
7. Control area
8. Supply volume
9. Control volume
10. Fuel outlet connector (low pressure)
11. Control port
12. Supply port
13. Electrical connection
14. Fuel input connector (high pressure)
15. Spring

INJECTORS

The injectors are fitted to the cylinder head and are electromagnetic in type. They are controlled directly by the injection control unit.

The injectors come with a high-pressure supply port and a recirculation pipe at environmental pressure; The supply port is connected to a delivery manifold (rail) with pipes designed to withstand the high service pressures.

The injector can be divided into two parts:

- Actuator/spray made up of a pressure rod (1), pin (2) and nozzle (3);
- control solenoid made up of coil (4) and pilot valve (5).

Operation

Injector operation may be divided into three stages:

1. rest position


Coil (4) is deactivated and plunger (6) is in closed position to prevent fuel entering the cylinder: $F_c > F_a$ where F_c is the force generated by pressure acting on the control area (7) of pressure rod (1) and F_a is the force due to the pressure acting on supply volume (8).

2. Start of injection


Coil (4) is excited and causes plunger (6) to rise. Fuel flows from control volume (9) to the return manifold to bring about a pressure drop in control area (7). Simultaneously, line pressure through supply port (12) exerts a force $F_a > F_c$ on supply volume (8) to cause pin (2) to rise and thus allow fuel into the cylinders.

3. end of injection


Coil (4) is deactivated and causes plunger (6) to return to closed position. The resulting balance of forces makes pin (2) return to rest position and injection therefore ends.



4F015XJ01



4F015XJ02



4F015XJ03

ENGINE COOLANT TEMPERATURE SENSOR

The sensor is fitted to the thermostat and measures the temperature of the engine coolant by means of an NTC thermistor with a negative resistance coefficient.

Because the sensor is made using semiconductor technology, the resistance falls if sensor element temperature rises with increasing coolant temperature.

Because resistance does not change in linear manner, it is higher at low temperatures than at high temperatures for the same temperature increase.

1. NTC resistance
2. Sensor case
3. Electrical connector

FUEL TEMPERATURE SENSOR

The sensor is fitted on the return manifold and measures fuel temperature by means of an NTC thermistor with a negative resistance coefficient.


Refer to the previous description of the coolant temperature sensor for sensor operation.

FUEL PRESSURE SENSOR

The sensor is fitted in the middle of the fuel delivery manifold (rail) and is responsible for providing a return signal (feedback) to the control unit in order to:

- adjust injection pressure;
- regulator injection duration.

10.



4F016XJ01

GLOW PLUG PREHEATING CONTROL UNIT

The glow plugs are controlled by means of a preheating control unit under the direct control of the injection control unit.

The preheating control unit contains a smart relay that sends a return response (feedback) to the injection control unit, which is thus informed of faults in the preheating control unit or glow plug short-circuits to earth.

The figure shows the connectors on the base of the preheating control unit and the pin-out

1. Earth
2. Injection control unit (pin 22)
3. Power supply from main injection relay
4. Not connected
5. Injection control unit (pin 62)
8. Positive from battery (+30)
- G. Glow plugs (only four outputs are used)


ACCELERATOR PEDAL POTENTIOMETER

Accelerator pedal position is converted to an electrical voltage signal and send to the injection control unit by a potentiometer connected to the accelerator pedal.


Accelerator pedal position is processed together with rpm information to provide injection times and pressure.

The sensor consists of a case (1) secured to the pedal by a flange, which contains an axially-positioned shaft (2) connected to two potentiometers (3): main and safety potentiometers.

A coil spring on the shaft ensures the correct resistance to pressure while a second spring ensures return upon release.



4F016XJ02



TEST

A switch (1) on the brake pedal controls the car brake lights; the same switch sends a signal to pin 59 of the injection control unit


The control unit uses the "brake pedal depressed" signal to:

- detect a situation of over-run;;
- check the plausibility of the signal from the accelerator potentiometer

CLUTCH PEDAL SWITCH

A switch (2) on the clutch pedal is connected to pin 61 of the injection control unit.

The injection control unit uses the "brake pedal operated" signal to distinguish gear engaged and gear shift conditions.



PRESSURE RELIEF SENSOR

The sensor is fitted to the intake manifold and the signal sent to the injection control unit is used to:

- regulate injection pressure;
- regulate injection duration.

The figure alongside shows the sensor and electrical connector with the following pin-out:

1. pressure signal
2. Earth
3. Fuel feed system

ATMOSPHERIC PRESSURE SENSOR

The atmospheric pressure signal is built into the injection control unit. It is responsible for measuring atmospheric pressure in order to correct measured air flow and reference air flow values to control the EGR function.


10.

FUEL SUPPLY CIRCUIT

Operationally-speaking, the fuel supply circuit is divided into a low pressure circuit and a high pressure circuit.

The low pressure circuit consists of a tank, multifunction valve, auxiliary fuel pump submerged in the tank and a return manifold.

The high pressure circuit consists of a radialjet pressure pump, delivery manifold and injectors.



4F018XJ01

- | | |
|--|--|
| 1. Fuel tank | 14. Fuel pressure sensor |
| 2. Submerged fuel pump (auxiliary) with fuel level gauge control | 15. Diesel heater |
| 3. Multifunction valve | 16. Fuel temperature sensor |
| 4. Pressure pump control pulley | 17. Sensor indicating presence of water in fuel filter |
| 5. Diesel filter cartridge | |
| 6. Pressure pump | |
| 7. High pressure pipe | |
| 8. Delivery manifold (rail) | |
| 9. Injectors | |
| 10. Fuel recirculation pipe (injector return) | |
| 11. Return manifold | |
| 12. Pressure regulator | |
| 13. Fuel temperature sensor | |

10.

SUBMERGED FUEL PUMP ASSEMBLY (AUXILIARY) AND LEVEL GAUGE CONTROL

The assembly consists mainly of:


- a roller-type fuel pump;
- a fuel level gauge;
- a fuel filter

The submerged fuel pump is volumetric type with rollers and a motor with brushes and permanent magnet excitation.

Impeller (1) is driven by the electric motor to turn and create volumes (2) that move from intake port (3) to outlet port (4).

These volumes are delimited by rollers (5) that adhere to outer race (6) as the motor turns.

The pump is fitted with two valves: a check valve to prevent the fuel circuit emptying (with the pump off); a second pressure relief valve (7) that short-circuits the outlet to the inlet when pressures exceed 5 bars.



4F019XJ01

1. Impeller
2. Volumes
3. Intake port
4. Outlet port
5. Rollers
6. Outer race
7. Pressure relief valve

FUEL FILTER


The fuel filter is located in the engine bay.

The filter is cartridge type with a filter element (1) made up of a pack of paper discs with a filtering area of some 5300 cm² and a filter gauge of 4 - 5 microns.

The filter is equipped with a fuel preheating device (2) controlled by the engine control unit via a relay.

The control unit activates or deactivates the diesel filter on the basis of a diesel temperature signal sent by sensor (3) on the filter.


A plug (4) screwed to the base of the fuel filter cartridge is used to drain off the water. The plug incorporates a sensor for the detection of water in the diesel filter connected to a warning light on the instrument panel.




4F019XJ02

1. Filter cartridge
2. Diesel preheating device
3. Diesel temperature sensor
4. Water drain plug with sensor to detect presence of water in diesel filter


10.



4F020XJ01



4F020XJ02



4F020XJ03

PRESSURE PUMP

The pressure pump is radialjet type with three radial pistons (total capacity 0.657 cc). It is controlled by a timing belt with or without timing requirements.

Each pump unit consists of:

a piston (5) operated by a cam (2) integral with the pump shaft (6);

a plate-type intake valve (3);

a delivery ball valve (4).

The pressure pump must be supplied at a pressure of at least 0.5 bars; and for this reason the fuel system is equipped with an auxiliary pump submerged in the tank.

The pressure pump is lubricated and cooled by the diesel fuel via channels and is able to deliver a maximum pressure of 1350 bars.


1. Cylinder
2. Cam
3. Plate-type intake valve
4. Ball-type delivery valve
5. Piston
6. Pump shaft
7. Diesel intake connection - low pressure - from fuel filter
8. Diesel delivery connection - high pressure - to manifold (rail)
9. Diesel delivery connection - low pressure - recirculation

PRESSURE REGULATOR FILTER

The fuel pressure regulator is fitted to the pressure pump and controlled directly by the injection control unit. It regulates fuel feed pressure to the injectors.

The pressure regulator consists mainly of the following parts:

1. Ball plunger
2. Pin
3. Valve
4. Preload spring
5. Coil
6. Body
7. Anchor



4F021XJ01

MULTIFUNCTION VALVE

The multifunction valve is located on the fuel tank and performs the following functions:

- tank pressurisation
- ventilation
- seal if the car rolls over

Tank pressurisation

Tank pressurisation is maintained at a level between 55 and 75 mbars by means of a valve mounted on a sealing rim.

The valve is supported by a steel plate and held in place by a spring.

When tank pressure exceeds a specified level, it overcomes spring resistance and allows the valve to rise so that vapours can flow out.

When the pressure returns to within specified limits, the valve closes again

Ventilation

Under certain car service conditions, a vacuum may build up in the tank due to the effect of:

- heat changes;
- fuel consumption

in this case, the valve's function is to make up pressure inside the tank by letting air into the tank.

If this function is not performed correctly, the car may judder or stall due to difficulties in supplying the pump.

Seal if the car rolls over

The roll-over function prevents fuel emerging from the tank if the car rolls over or tilts to a great extent. During normal car operation (bends, acceleration, braking etc.), the fuel slops about and may emerge. The highly-sensitive roll-over valve prevents this happening.

DELIVERY MANIFOLD (RAIL)


The delivery manifold (rail) is fitted to the cylinder head on the intake side.

Its volume damps fuel pressure fluctuations due mainly to:

- operation of the pressure pump;
- injector opening.

A fuel pressure sensor is fitted in the middle of the delivery manifold. Hydraulic connections (high pressure) are via special steel pipes.

10.



4F022XJ01

INERTIA SAFETY SWITCH

To increase car occupant safety in the case of impact, the car is fitted with an inertia switch located inside the passenger compartment secured to the inside of the left panel.

This sensor reduces the possibility of fire (due to emerging fuel) by deactivating the auxiliary fuel pump that supplies the injection circuit.


The switch consists of a steel ball, fitted in a tapered housing, kept in place by the attraction force of a permanent magnet.

In the case of violent impact, the ball is released from the magnetic detent and opens the normally closed (NC) electrical circuit to cut off the auxiliary fuel pump connection to earth, and as a consequence the supply to the injection system.

To restore the auxiliary pump earth connection, move back the seat and press the switch until a click is heard.



Even after an apparently slight impact, if there is a smell of fuel or there are leaks from the fuel system, do not turn the switch back on, but search for the fault and remedy it to prevent the risk of fire.



4F022XJ02

Inertia switch components

1. Inertia switch assembly
2. Sheath
3. Button
4. Upper side
5. Engagement side
6. Permanent magnet
7. Permanent magnet seat
8. Steel ball

C Common terminal
N.C. Normally closed contact
N.A. Normally open contact


AIR INTAKE CIRCUIT

The air intake circuit is turbocharged by means of a GARRET variable geometry turbocharger and an intercooler.

The turbocharger is low inertia type. Its design is based on a new principle of turbocharging whereby the turbocharger aims to increase torque within the range of most frequent use (e.g. at low speeds).

After passing through the filter (1), intake air is compressed by the exhaust gas-drive turbocharger (4), cooled by intercooler (5) and sent to throttle body (6) and the intake manifold from where it is distributed to the cylinders.

Air intake circuit diagram



4F023XJ01

1. Intake vent
2. Air filter
3. Intake air flow meter (debimeter)
4. Variable geometry turbocharger
5. Air-air intercooler
 - A. To turbocharger
 - B. To intake manifold
6. Throttle body

10.

THROTTLE BODY

To reduce engine noise during shut-down, a throttle has been added to the intake port with the aim of closing off the air flow to the cylinders.

Throttle valve opening or closure is controlled by an engine control unit (5) that manages a control actuator (3) on throttle body (4) via solenoid (2).


Operation

When the engine is off, the throttle is open because no vacuum is present.

When the engine is running, the throttle is open because the Pierburg solenoid is not activated and prevents the vacuum reaching the pneumatic actuator.


A vacuum builds up in the tank during engine operation.

During engine shut-down (when the ignition key is turned **OFF**), the control unit keeps the actuator supply relay activated for a further 4 or 5 seconds and simultaneously earths the Pierburg valve. The Pierburg valve opens to send the vacuum that has built up in the vacuum tank to the pneumatic actuator, which closes the throttle to cut off the flow of air to the cylinders.




4F024XJ01

1. Vacuum tank;
2. Pierburg solenoid controlling throttle body actuator;
3. Pneumatic actuator on throttle body
4. Throttle body
5. Engine control unit
6. Vacuum pump



4F025XJ01



4F025XJ02

TURBOCHARGER (1910 JTD 110 CV)

The turbocharger used in the application of the EURO 3 standards in the variable geometry type connected to the exhaust manifold.

The turbocharger is controlled by the engine management control unit via a duty-cycle solenoid valve.

The increased volumetric output for the engine is achieved, in the case of variable geometry compressors, through the use of:

- a centrifugal compressor (1)
- a turbine (2)
- a series of moving vanes (3)
- a pneumatic actuator (4) controlling the moving vanes.
- a solenoid valve (5) controlling the actuator

The variable geometry turbocharger makes it possible to:

- increase the speed of the exhaust gases in the turbine at low engine speeds
- slow down the speed of the exhaust gases in the turbine at high speeds.

The control of the speed (kinetic energy) of the exhaust gases makes it possible to produce increased engine torque at low speeds and greater maximum power at high speeds.

Operation at low rotation speeds

When the engine is operating at low speeds, the exhaust gases possess little kinetic energy: under these circumstances a conventional turbine would rotate slowly, supplying a limited supercharging pressure.


On the other hand, in the variable geometry turbine (1), the moving vanes are in the maximum closure position and the small passage sections between the vanes increase the speed (C) of the intake gases.

Increased intake speeds lead to increased peripheral speeds (U) of the turbine and, consequently, the compressor.

The speed of the gases inside the impeller is indicated by the vector (W).

1. Turbine
2. Moving vanes
3. Pneumatic actuator
4. Rotary seal

10.



4F026XJ01


Operation at high rotation speeds

When the engine speed is increased, the kinetic energy of the exhaust gases increases gradually.

As a result, the speed of the turbine (5) increases and consequently the supercharging pressure.

The VGT solenoid valve (2) operated by the injection control unit (1), through the actuator (4) causes the moving vanes to change position until the maximum opening position is reached.

1. Injection control unit
2. VGT solenoid valve
3. Vacuum reservoir
4. Pneumatic actuator
5. Turbine



4F026XJ02

There is therefore an increase in the passage sections and consequently a slowing down in the flow of exhaust gases which pass through the turbine (1) at the same speed or slower than the low speed conditions.

The speed of the turbine (1) decreases and settles down at a suitable value for the correct operation of the engine at high speeds.

1. Turbine
2. Moving vanes
3. Pneumatic actuator
4. Rotary seal


*TURBOCHARGER (1910 JTD 100 CV)

It basically consists of two impellers (1) on one shaft (2) which rotates on floating bearings lubricated by a duct (3) from the engine lubrication circuit.

The oil used dissipates some of the large amount of heat given off by the exhaust gases at the turbine.

There is a waste gate valve (4) fitted on the turbocharger, operated by a pneumatic actuator (5), that makes it possible to shutter the flow of exhaust gases to the turbine, according to the engine power/torque requirements. The pneumatic actuator is controlled by the engine management control unit via a solenoid valve.

* The turbocharger used on the 1910 JTD 100 CV version is the fixed geometry type.




4F026XJ02


EMISSION CONTROL DEVICES

The car is equipped with devices designed to reduce polluting emissions in accordance with Euro 3 requirements:

- Oxidising catalytic converter (1)
- Exhaust gas recirculation circuit (EGR) (2)
- Crankcase blow-by vapour recirculation circuit (3).



4F027XJ01



4F027XJ02

OXIDISING CATALYTIC CONVERTER

The oxidising catalytic converter is a post-treatment device used to oxidise CO, HC and particulate and convert them to carbon dioxide (CO₂) and water vapour (H₂O).

The catalytic converter consists of a ceramic honeycomb case (1) with its chambers impregnated with platinum, a substance that catalyses oxidation reactions.

Exhaust gases flow through the chambers and heat the catalytic converter where they trigger the conversion of pollutants to inert compounds.

The chemical reaction involved in oxidising the CO, HC and particulate is effective at temperatures between 200 °C and 350 °C.

Above 350 °C, the sulphur in the diesel begins to oxidise to produce sulphur dioxide and sulphuric acid.


EXHAUST GAS RECIRCULATION CIRCUIT (EGR)

This system sends a proportion of exhaust gases to the intake under certain engine service conditions. This dilutes the fuel mixture with inert gases to lower peak temperature in the combustion chamber; This helps limit the formation of nitrogen oxides (NO_x) and reduces exhaust levels by 30-50%.

10.

The EGR valve consists of:

- a Pierburg EGR solenoid (1) operated by engine management unit (2)
- a pipe from the exhaust manifold (4) (from which the exhaust gases flow)
- an air-water heat exchanger (3) (that lowers exhaust gas temperature)
- a pipe connected to throttle body (5) to which exhaust gases are admitted



4F028XJ01

Operation

With coolant temperature $> 20^{\circ}\text{C}$ and engine speeds between 800 and 3000 rpm, the engine management unit controls the EGR solenoid by means of a square wave signal.

Changes in this signal allow the EGR coil to move a plunger and thus modulate the flow of exhaust gas from the exhaust manifold to the intake manifold; this achieves two results:

- less air is taken in
- combustion temperature is lowered (due to the presence of inert gases), thus reducing the formation of NOx (nitrogen oxides).

The engine management control unit is constantly informed of recirculation gas quantity via data from the debimeter. If the intake of a given quantity of air (Q_{am}) is required for a given rpm and the level sent by the debimeter (Q_{ar}) is lower, the difference (Q_{gr}) is the amount of gas recirculated.

$$Q_{am} - Q_{ar} = Q_{gr}$$

Q_{am} = stored theoretical air quantity

Q_{ar} = actual air quantity

Q_{gr} = recirculated gas quantity

An atmospheric pressure signal is used in controlling the EGR valve to detect when the car is being driven at altitude. The recirculation gas quantity can then be reduced to prevent engine fumes.

10.

RECIRCULATION CIRCUIT FOR CRANK-CASE VAPOURS (BLOW-BY)


The control of the oil vapour emissions is achieved through a separator (1) (function carried out by the tappet cover) which collects the vapours released by the crankcase in the pipe (2).

The difference in temperature between the separator and the oil vapours causes partial condensation.


The vapours which have not condensed are sent, via the pipe (3), to the turbocharger air intake hose.

The adjustment valve, consisting of a spring (1) and a diaphragm (2), on the tappet cover makes it possible to prevent intake.

When the vacuum values inside the tappet cover exceed a pre-set limit, the diaphragm moves downwards sealing the duct from the crankcase.




4F029XJ01




4F029XJ02


10.



4F030XJ01



4F030XJ02



4F030XJ03

THROTTLE CASING



Removing-refitting


- Remove the battery from the engine compartment, then proceed as described below;

1. Remove the engine oil filler cap (1), then undo the fixing nuts (2) and remove the sound insulation cover (3).


2. Disconnect the vacuum intake pipe (1) from the vacuum unit acting on the retaining band. Also disconnect the pipe (2) connected to the vacuum reservoir.

3. Undo the bolts fixing the connector pipe between the throttle casing and the hose connected to the intercooler.

4. Disconnect the oil vapour recovery pipe from the tappet cover, acting on the retaining band.



4F030XJ04



1. Undo the bolts (1) fixing the expansion joint to the E.G.R. valve, disconnect the pipe connecting the pneumatic valve and the solenoid valve, then undo the bolts (3) and remove the throttle casing.

2. At the bench, undo the bolts (1) and separate the expansion joint from the throttle casing.

The pneumatic valve (2) is secured to the throttle casing.




E.G.R. VALVE

Removing-refitting


- Remove the throttle casing, following the description in the previous paragraph.

3. Loosen the bolts (1) fixing the pipe connecting the E.G.R. and the heat exchanger.

4. Disconnect the electrical connection (1) for the E.G.R. valve self-adjustment motor; undo the bolts (2) fixing the E.G.R. valve to the intake manifold, then lift up the valve and remove the bolts fixing the pipe connected to the heat exchanger (loosened previously).



10.



4f032XJ01



E.G.R. VALVE SELF-ADJUSTMENT MOTOR


Removing-refitting

- Disconnect the negative battery lead, then remove the sound insulation shield following the instructions in the previous paragraphs.
- 1. Disconnect the electrical connection (1), then loosen the bolts fixing the E.G.R. valve self-adjustment motor and remove it.


E.G.R. VALVE HEAT EXCHANGER

Removing-refitting


- Remove the throttle casing and the E.G.R. valve following the instructions in the previous paragraphs.
- 2. Remove the hose connecting the throttle casing to the intercooler.
- Drain the engine coolant.
- 3. Disconnect the pipes shown in the figure from the thermostat, acting on the retaining bands, then disconnect the electrical connection (1) for the engine coolant temperature sensor.
- 4. Undo the bolts fixing the heat exchanger pipe to the exhaust manifold.




4f032XJ02




4f032XJ03




4f032XJ04



4F033XJ01




4F033XJ02




4F033XJ03



1. Open the band (1) retaining the oil vapour recovery pipe, then undo the bolts (2) fixing the E.G.R. valve heat exchanger mounting bracket.
2. Undo the nut (1), located under the thermostat, fixing the heat exchanger.
3. Disconnect the band (1) retaining the coolant pipe for the heat exchanger.
4. Undo the bolts shown in the diagram and remove the thermostat to allow the subsequent extraction of the heat exchanger.
5. Remove the heat exchanger from the engine compartment.




4F033XJ04




4F033XJ05


10.



4F034XJ01



4F034XJ02



4F034XJ03



SOLENOID VALVE ON VACUUM RESERVOIR FOR THROTTLE CASING PNEUMATIC VALVE

Removing-refitting


- Disconnect the negative battery lead, then remove the sound insulation shield following the instructions in the previous paragraphs.
- 1. Disconnect the electrical connections (1) at the fuel filter and the supply and return pipes (2) at the reservoir and the supply pipe to the pump, then loosen the nuts (3) fixing the fuel filter mounting. Lift up the filter and disconnect the electrical connection (4) for the water in the diesel sensor.

- Release the power assisted steering fluid supply pipe from the reservoir to the pump from the retaining band.
- 2. Disconnect the pipe (1) connected to the vacuum reservoir and the pipe (2) connected to the vacuum intake pipe from the solenoid valve. Disconnect the electrical connector (3), then undo the fixing bolts (4) and remove the solenoid valve.


VACUUM RESERVOIR

Removing-refitting


- Disconnect the negative battery lead, then remove the sound insulation shield and the fuel filter, following the instructions in the previous paragraphs.
- Release the power assisted steering fluid supply pipe from the reservoir to the pump from the retaining band.
- 3. Disconnect the pipe (1) connected to the vacuum reservoir and the pipe (2) connected to the vacuum intake pipe from the solenoid valve. Disconnect the electrical connector (3), then undo the fixing bolts (4) and remove the bracket, complete with solenoid valve, for the throttle casing pneumatic valve.



4f035XJ01



4f035XJ02



4f035XJ03

1. Undo the fixing nuts (1) and remove the vacuum reservoir.

SOLENOID VALVE CONTROLLING SUPERCHARGING PRESSURE


Removing-refitting

- Position the vehicle on a lift, then disconnect the negative battery lead.
2. Working from underneath the vehicle, disconnect the electrical connector (1) and the pipes (2).
 3. Press the retaining tab on the rear of the mounting bracket and release the solenoid valve.

FUEL FILTER


Removing-refitting

4. Disconnect the electrical connections (1) from the fuel filter and the supply and return pipes to the tank and the supply pipes to the pump (2), then undo the nuts (3) fixing the fuel filter mounting. Lift up the filter and disconnect the electrical connection (4) for the water in the diesel sensor.



4f035XJ04

10.







PRESSURE REGULATOR

NOTE During the operations of removing-refitting the pressure regulator, work in extremely clean conditions.

Removing

- If the vehicle is equipped with a shield under the engine, remove it.
- 1. Remove the engine oil filler plug (1), then undo the fixing nuts (2) and remove the sound insulation cover (3).
- 2. Undo the bolts (1) fixing the retaining bands for the injector wiring. Disconnect the electrical connectors (2) for the injectors and place the wiring to the side.
- Release the injection cable loom from the retaining bands.
- 3. Undo the nuts (1) fixing the fuel return manifold pipe (2) to the intake manifold. Place the fuel return manifold pipe to the side.
- 4. Disconnect the electrical connector (1) for the pressure regulator, then undo the bolts (2) fixing the regulator to the pump.






4f037XJ01

1. Grip the outer casing of the regulator, partly extract it and, at the same time, rotate it so that the fins (1) which contain the openings for the fixing bolts are positioned horizontally.

NOTA Do not grip the pressure regulator by the electrical connector.

Insert the blades of two screwdrivers by the fins (1) and very carefully extract the pressure regulator.

NOTE Do not use a screwdriver or other tools in the seal areas between the regulator and the pressure pump.



4f037XJ02

2. Pressure regulator

1. High pressure seal (black or green)
2. Anti-extrusion seal (white)
3. Low pressure seal (black)

NOTE If the high pressure seal accidentally remains inside the pump casing, turn the ignition key to the ON position (engine switched off); this will operate the pump shaft and a small amount of fuel and the seal will come out.

NOTE Do not, under any circumstances, use any tools for extracting the high pressure seal and this could damage the inner surface of the pump.

Refitting

- Suction off any impurities present inside the pump casing.
- Check the condition of the three seals and make sure they are correctly positioned before fitting.
- Slightly lubricate the outer surface of the three seals using vaseline. Do not, under any circumstances, lubricate the other surfaces of the pressure regulator.
- Insert the pressure regulator in its housing on the pump, pressing gently and, at the same time, rotating the regulator until it is in contact with the surface of the pump.

NOTE Do not, under any circumstances, use a hammer or other tools when fitting the pressure regulator.

- Fit the two bolts fixing the pressure regulator to the pump casing, and tighten them to a torque of 0.9 ± 0.1 daNm.
- Reconnect the electrical connector and complete the refitting of the remaining components reversing the order of the operations carried out for the removal.


- Compressor (1596 engine)	1
- Compressor (1910 JTD)	2
- Compressor (1998 engine)	3
- Specifications	4

**FOR ANYTHING NOT DEALT WITH,
REFER TO THE BASIC MANUAL, SECTION 50.**

COMPRESSOR (1596 engine)

The compressor fitted on this version is the HR V5 variable capacity type, illustrated in the diagram below, and consists of:

- a crankcase (7) which contains the bores in which the pistons (4) slide;
- an assembly comprising a shaft on which an inclined plate (6) is fitted on which a disc (2) guided by a pin (5) integral with the five connecting rods (3) controlled by the pistons (4) rotates on roller bearings;
- a cylinder head which contains the intake and supply ducts as well as the housing for the regulation valve (9);
- a plate (8), between the crankcase and the cylinder head, which contains the inlet and supply valves;
- a pulley assembly with an electro-magnet coupling (1).



4F001EH01

1. Pulley with coupling
2. Disc
3. Connecting rod
4. Piston
5. Disc guide pin

6. Inclined plate
7. Crankcase
8. Valve holder plate
9. Regulation valve
10. Valve control bellows

Operation

The alternating drive required for the sliding of the pistons in the bores/liners is produced by the rotary motion of the inclined plate (6), whilst the variation in the capacity, dependent on the piston stroke, is achieved through the alteration in the angle of the disc (2) controlling the connecting rods (3).

The inclination of the above mentioned disc depends on the difference in pressure between the intake duct and the inside of the compressor. This difference, measured by the bellows (10), operates the regulation valve (9) and consequently causes the movement of the disc (2).

When the request for conditioned air is high, the regulation valve (9) is positioned in such a way that it uncovers an opening which places the intake side in contact with the inside of the compressor; as, in this case, there is no difference in pressure, the compressor operates at maximum capacity corresponding to the position of the disc illustrated in the previous section.

When the air request is less, the valve is positioned so that the supply section is in contact with the crankcase and, at the same time, it stops the flow between the latter and the intake side activated previously.

50


COMPRESSOR (1910 JTD)

The compressor fitted on this version is the SANDEN SD7V16 variable capacity type.

The capacity of the compressor varies starting from the maximum value ($161.3 \text{ cm}^3/\text{rev}$) and is gradually reduced (up to $10.4 \text{ cm}^3/\text{rev}$) according to the system load variations. - changed outside temperature and/or humidity conditions or sharp variations in the engine load.

This solution is defined as "unlimited variable capacity".

The compressor is the alternating piston type: the variation in capacity is achieved by tilting the connecting rod holder plate with a consequent variation of the piston stroke: the movement of the plate is activated by an internal regulation valve according to the balance of pressure upstream and downstream of the compressor. In particular, a low intake pressure involves the shuttering of the compressor (reduced capacity), whilst a high pressure involves operation at maximum power (maximum capacity).



4F002EH01

- | | |
|------------------------|-----------------------------------|
| 1 Diaphragm valve | 7 Arm |
| 2 Pistons | 8 Slide |
| 3 Connecting rods | 9 Guide |
| 4 Connecting rod plate | Pa Intake pressure |
| 5 Shaft | Pi Pressure inside the compressor |
| 6 Pin | Pm Supply pressure |

Operation

The SD7V16 compressor is illustrated in the diagram; it consists of seven pistons (2) and connecting rods (3) fastened to a connecting rod holder plate (4). The rotary motion of the plate (4), on the shaft (5) produces the alternating movement of the pistons.

A change in the plate angle allows an alteration in capacity: maximum inclination (as in the diagram) for maximum capacity; almost zero inclination (vertical position) for minimum capacity (virtually nil).

The plate (4) rotates around the pin (6) hinged on the shaft (5) arm (7).

The movement of the plate (4) in relation to the shaft (5) takes place by means of splining made from a low resistance material.

The plate (4) slides below along a guide (9) via a runner (8) made from a low friction material.

The diaphragm valve (1) controls the flow rate adjustment according to the difference between Pa (intake pressure) and Pi (pressure inside the compressor).

N.B. the solution adopted for this compressor is designed to keep the internal pressure Pi constant, with advantages in terms of ease of adjustment and quiet, smooth operation.


COMPRESSOR (1998 engine)

The compressor fitted on this version is the SANDEN SD6V12 variable capacity type.

The capacity of the compressor varies starting from the maximum value ($125.1 \text{ cm}^3/\text{rev}$) and is gradually reduced (up to $6.2 \text{ cm}^3/\text{rev}$) according to the system load variations. - changed outside temperature and/or humidity conditions or sharp variations in the engine load.

This solution is defined as "unlimited variable capacity".

The compressor is the alternating piston type: the variation in capacity is achieved by tilting the connecting rod holder plate with a consequent variation of the piston stroke: the movement of the plate is activated by an internal regulation valve according to the balance of pressure upstream and downstream of the compressor. In particular, a low intake pressure involves the shuttering of the compressor (reduced capacity), whilst a high pressure involves operation at maximum power (maximum capacity).



4F003EH01

- 1. Diaphragm valve
- 2. Pistons
- 3. Connecting rods
- 4. Connecting rod plate
- 5. Shaft

- 6. Pin
- 7. Arm
- 8. Slide
- 9. Guide

Operation

The operation is the same as described for the previous SANDEN 7V16 compressor.

50**SPECIFICATIONS****TABLE SHOWING QUANTITIES OF OIL AND GAS FOR CLIMATE CONTROL SYSTEM**

The table below summarizes the types of oil and the quantities of oil and coolant.

ENGINE TYPE	COMPRESSOR	TYPE OF OIL	QUANTITY OF OIL (cm ³)	QUANTITY OF GAS (g)
1596 16V	HR V5	UNICON RL 488	265	600 ± 25
1998 20V	SD 6V12	SP10	135	600 ± 25
1910 JTD	SD 7V16	SP10	135	600 ± 25

**FOR ANYTHING NOT DEALT WITH,
REFER TO THE BASIC MANUAL, ASSEMBLY 50.**

PROTECTION AND SAFETY DEVICES

- Protection and security devices	1
- Junction unit	4
- List of fuses and main protected circuits	5
- Supplementary fusebox	8

LOCATION OF VEHICLE COMPONENTS

- Location of vehicle relays and fuses.	9
- Location of control units and testing sockets	12

CONTROL PANEL

- Control panel (except AT)	14
- Control panel (AT)	17

RADIO SYSTEM

- General description	19
- Warnings	23
- Description of controls	24
- Operation	33
- EXPERT control level	40
- Coding	44
- Compact Disc Player	46
- Cassette Player	47
- Multiple Compact Disc player	49
- Advice and precautions	51

PROTECTION AND SAFETY DEVICES

All the vehicle supply lines were designed taking into account the most up-to-date directives in terms of safety and protection, especially to prevent fires.

There are 2 types of protection:

- active protection, aims to reduce the causes of faults "at source"
- passive protection, aims to limit the effects of a fault as much as possible

The first category includes a carefully designed wiring layout with wires positioned and carefully anchored on tracks that are repaired and protected if necessary.

The cables connected to the alternator and the motor were modified for this reason by adding protective caps etc. A strengthened sheath was also introduced for some of the more exposed sections of wiring.

The passive protection includes all interventions to reduce faults due to high current (overload, short circuit).

All system fuses were rated based on the nominal absorption of the loads activated at the same time, to ensure intervention in cases of a clear short circuit.

The introduction of a box containing 4 maxifuses with other fuses connected on the outside means all the supplies can be protected except for the cable that connects the battery to the starter motor and the cable that connects the starter motor to the recharging alternator. These cables are therefore protected by a strengthened supplementary sheath.

In "MAXI" fusebox A:

EFI electronic injection fuse (petrol)

GLOW: plug fuse (diesel)

IGN: ignition switch fuse

J/B2 fuse master supply


J/B1 fuse master supply

Next to the box.

B: fan fuse (see table)

C: ABS 60A fuse

D: second fan fuse: 40A (JTD)




4F001LL01

FUSE B	
30A	engine petrol without air conditioner
40A	1596 with air conditioning, JTD
50A	1998 with air conditioning

55.

Main supplies wiring diagram (petrol engine types)



4F002LL01

Component key


- 3B/C Power fusebox
- 3A/D Supplementary fusebox
- 4 Junction unit
- 10 Engine battery earth
- 10A Bodysheath battery earth.
- 11 Battery
- 12 Ignition switch

- 96 Power fuse protecting A.B.S
- 129 Engine cooling fan protection power fuse.
- 332 Ignition activated power relay.

(*) See table on previous page.

55.


Junction unit



Front view of control unit and location of fuses



The connectors cannot be connected incorrectly as each has its own unique shape. The letters identifying the connectors are the same as those used in the wiring diagrams.



Rear view of control unit and location of relays.

- E1. Switch discharge relay for starting (30A)
- E2. Horn relay (20A)
- E3. Heated rear windscreen relay (30A)

NOTE connectors A, C and D: are connected to the front lead.
connectors B, F, I, J and H are connected to the facia lead
connectors E and G are connected to the rear lead

DESCRIPTION OF WIRING AND CONNECTORS

CONNECTOR A		
N. No.	Wiring colour	Circuit involved
1	R	Supply (+30) from fuse box
2	BR	Supply (+30) from fuse box

CONNECTOR C		
N. No.	Wiring colour	Circuit involved
1	RN	Car interior fan power supply (with air conditioner), air conditioner control unit
2	MB	Fuel pump control, inertia switch
3	AN	Car interior fan power supply (only heater), air conditioner control unit
4	H	Right dipped beam headlamp
5	HN	Left dipped beam, headlamp enablement
6	VN	Left main beam
7	V	Right main beam

CONNECTOR E		
N. No.	Wiring colour	Circuit involved
1	RN	Right brake light
2	GR	Rear view mirror control light
3	RG	Left brake light
4	MN	Rear window power supply
5	MB	Fuel pump, inertia switch
6	-	N.C.
7	AN	Left rear turn signal
8	-	N.C.
9	GR	Right rear side light (without check panel)
10	HL	Left number plate light (without check panel)
11	-	N.C.
12	RG	N.C.
13	RN	N.C.
14	R	Supplementary brake light

CONNECTOR B		
N. No.	Wiring colour	Circuit involved
1	R	Power supply to electric windows, door lock, service control unit, main beam relay, fog lamp, sun-roof, heated seats, cigar lighter

CONNECTOR D		
N. No.	Wiring colour	Circuit involved
1	G	Left headlamp alignment
2	G	Right headlamp alignment
3	G	Headlamp alignment control
4	AN	Front and left side turn signal
5	AR	Alarm control unit power supply
6	HB	Right headlamp alignment power supply
7	H	Left headlamp alignment power supply
8	H	Headlamp alignment control
9	B	Reversing light control
10	Z	Horns.
11	Z	Horns.
12	-	N.C.
13	GV	Right front side light
14	AR	Brake light power supply
15	A	Front and right side turn signal
16	GL	Left front side light
17S	-	N.C.
18	RN	Brake light control

CONNECTOR F		
N. No.	Wiring colour	Circuit involved
1	HR	Dipped beam control
2	-	N.C.
3	LR	Main beam control
4	-	N.C.
5	G	Side light power supply from ignition

55.

55.

DESCRIPTION OF WIRING AND CONNECTORS (cont)
















CONNECTOR G		
N. No.	Wiring colour	Circuit involved
1	HB	Right number plate light (without check panel)
2	-	N.C.
3	AR	Rear view mirror power supply
4	-	N.C.
5	A	Right rear turn signal
6	BN	Left reversing light (only Marea)
7	B	Right reversing light
8	GN	Left rear side light (without check panel)
9	RG	Rear courtesy light power supply (left for Marea Weekend)
10	RN	Remote control receiver power supply
11	RN	Front courtesy light power supply
12	RN	Right rear courtesy light power supply (Marea Weekend)

CONNECTOR I		
N. No.	Wiring colour	Circuit involved
1	AN	Hazard warning light power supply
2	CB	+15 power supply from ignition
3	-	N.C.
4	CB	Stalk unit power supply
5	C	Power supply, windscreen wiper
6	N	Earth
7	LN	Horn signal
8	AG	+15 power supply from ignition (start-up excluded)
9	AB	Hazard warning light power supply
10	AB	Hazard warning lights and instrument panel power supply (from January 2001)
11	AB	Hazard warning light power supply
12	AR	Turn signal power supply
13	R	Instrument panel power supply
14	-	N.C.

CONNECTOR H		
N. No.	Wiring colour	Circuit involved
1	AN	Right turn signal warning light
2	C	Power supply, door lock, radio
3	AN	Right turn signal control
4	RN	Right brake light (versions with Check Panel)
5	A	Left turn signal control
6	A	Left turn signal control
7	A	Left turn signal warning light
8	AN	Right turn signal control
9	RV	Brake light control (versions with Check Panel)
10	MN	Mirror demister control

CONNECTOR J		
N. No.	Wiring colour	Circuit involved
1	RG	Left brake light (versions with check panel)
2	AG	Alarm and instrument panel power supply (to December 2000)
3	GN	Side light warning light, switch panel lighting, automatic transmission control lighting
4	BC	Rear window control
5	R	Power supply, radio
6	LB	Main beam warning light
7	RV	Radio phone power supply
8	-	N.C.
9	R	Radio power supply
10	GN	Radio lighting
11	GN	Instrument lighting dimmer
12	GN	Cigar lighter lighting

LIST OF FUSES AND MAJOR PROTECTED CIRCUITS


Fuse No.	Amp	Symbol	Protected circuit	Fuse No.	Amp	Symbol	Protected circuit
1	10(*)		Brake light - Supplementary brake light - Turn signal - Instrument power supply	6	10		Right main beam headlamp
2	10		Right front side light - Left rear side light - Right number plate light - Radio light - Instrument dimmer lighting - Side light warning light - Cigarette lighter light - Switch panel light - Automatic transmission control light - Carphone light - heater/air conditioner control lighting	7	10		Left main beam headlamp - main beam headlamp warning light
				8	20		Radio - Door lock - Boot light
				9	10		Hazard warning lamps - Instrument power supply (from January 2001)
				10	10		Internal lights (front and back) - Instrument supply (to December 2000) - remote control receiver and alarm control unit supply - Car phone power supply - Tester output power supply
3	10		left front side light - Right rear side light - Left number plate light - Mirror control light -	11	30		Heated rear windscreen - Mirror demisting
				12	30		Car interior climate control fan motor (air conditioned).
4	10		Right dipped beam headlamp	13	20		Air conditioner control unit - horns
				14	20		Windscreen wiper - Rear windscreen wiper - Windscreen / Rear windscreen wiper - Headlamp washer intermittence
5	10		Left dipped beam headlamp - Headlamp alignment corrector - Headlamp washers intermittence	15	20		Air conditioner control unit - Car interior climate control fan motor (heated).

(*) Replaced with 15A if tow-hook installed.



55.

SUPPLEMENTARY FUSEBOX



P4F008LL01

Many shunt fuses are found under the facia just above the junction control unit

The fuses are grouped in two special multiple connectors, one for the front wiring the other for the facia wiring, according to a pre-set position and located as shown in the figure:


3A: front wiring

Fuse	Protected circuit	Amp
- F1	Fuse protecting ignition activated services (15/54)	7.5
- F2	Fuse protecting headlamp washers	20
- F3	Fuse protecting injection and CODE, fan	7.5
- F4	Fuse protecting ABS	10
- F5	Fuse protecting compressor and air conditioner	7.5
- F6	Fuse protecting injection memory and CODE, fan	7.5

3D: facia wiring

Fuse	Protected circuit	Amp
- F1	Fuse protecting ignition activated services (INT)	7.5
- F2	Fuse protecting foglamps	15
- F3	Fuse protecting rear electric windows	25
- F4	Fuse protecting front electric windows	25
- F5	Fuse protecting sunroof, seats, cigarette lighter	30
- F6	Fuse protecting airbag	10

LOCATION OF RELAYS AND FUSES ON THE VEHICLE (BONNET - Petrol engine types)



P4F009LL01

3B-3C Power fusebox


- 96 Power fuse protecting ABS
- 98 Headlamp washer intermittent function
- 122 Engine cooling fan low speed relay
- 123 Engine cooling fan high speed timer
- 124 Air conditioning compressor control relay
- 129 Power fuse protecting engine cooling fan
- 150 Injection system relay feed
- 151 Lambda probe control relay for fuel pump and injectors
- 152 Fuse protecting injection system
- 152A Fuse protecting injection system
- 152B Fuse protecting injection system
- 273 Fuse protecting automatic transmission system
- 274 Fuse protecting automatic transmission system
- 276 Starter enablement relay

(••) Versions with air conditioning

(*) With automatic transmission

55.

LOCATION OF RELAYS AND FUSES ON THE VEHICLE (BONNET - Diesel engine types)




P4F010LL01

3B/C Power fusebox

- 96 Power fuse protecting A.B.S
- 98 Headlamp washer intermittent function
- 122 Engine cooling fan low speed relay
- 123 Engine cooling fan high speed timer
- 124 Air conditioning compressor control relay
- 129 Engine cooling fan protection power fuse
- 129A Power fuse protecting engine cooling fan no. 2
- 152 Fuse protecting injection system
- 303 Fuse protecting diesel preheating
- 304 Diesel preheating protection relay.
- 346 Additional heater relay
- 347 Additional heater relay
- 348 Additional heater remote control switch
- 349 Additional heater protection fuse
- 369 Engine cooling fan remote control switch

(••) Versions with air conditioning

LOCATION OF RELAYS AND FUSES ON THE CAR (PASSENGER COMPARTMENT)


P4F011LL01

- 3A/D Supplementary fusebox
- 4 Junction unit
- 5 Dipped headlamps relay feed
- 32 Fog lamp control relay
- 150 Injection system relay feed
- 151 Lambda probe control relay for fuel pump and injectors
- 152 Fuse protecting injection system
- 326 Additional heater control unit
- 328 Hazard warning lights relay

- 332 Ignition activated power relay.
- 344 I.E. protective fuse

55.


LOCATION OF CONTROL UNITS AND DIAGNOSTIC SOCKETS (PASSENGER COMPARTMENT)



P4f012LL01

- 114 Air bag electronic control unit
- 131 Fiat-CODE electronic control unit
- 238 Rear electric windows control unit
- 244 Integrated services control system
- 253 Air conditioner control unit
- 267 Automatic transmission control unit
- 333 Injection control unit (JTD)
- 375 Standardized diagnostic socket

55.



4F013LL01

The diagnostic equipment (Examiner or other instruments) is connected to it using a special adaptor known as "MPX 97". Using this adaptor it is possible to select the system the autodiagnosis is going to be carried out on.

Pin- out

Pin	System
1	ABS
2	N.C.
3	Air Bag
4	Power earth
5	Signal earth
6	N.C.
7	Engine management and FIAT CODE
8	N.C.
9	Climate control
10	N.C.
11	Alarm
12	N.C.
13	N.C.
14	N.C.
15	Automatic transmission.
16	Connector supply


55.

The vehicle is fitted with numerous electronic control units which have autodiagnostic functions.

When these control units are connected to diagnostic equipment (Examiner or other instruments) it is possible to read the autodiagnostic information (parameters, errors) or carry out active diagnosis.

On the version with EOBD (European On Board Diagnosis) which conforms to Directive 98/69/CE (EURO 3), there is not an individual diagnostic socket for each control unit, but a single, standardized 16-way diagnostic socket, on the left hand side of the dashboard, under the junction unit.


View of connector, cable entry side



4F013LL02

55.

INSTRUMENT PANEL (excluding C.A.)




P4F014LL01

Front side

- | | |
|--|---|
| 1. Fuel level gauge | 13. Air Bag fault warning light |
| 2. Fuel reserve warning light | 14. Brake light failure warning light |
| 3. Speedometer | 15. Doors open warning light |
| 4. ABS failure warning light | 16. Trip counter/mileometer/outdoor temperature gauge |
| 5. Brake pad wear warning light | 17. Low engine oil pressure warning light |
| 6. Left direction indicator warning light | 18. Generator warning light |
| 7. Side lights warning light | 19. Injection system failure warning light |
| 8. Right direction indicator warning light | 20. FIAT CODE system warning light |
| 9. Main beam warning light | 21. Heater plugs warning light |
| 10. Low brake fluid level and handbrake applied/EBD system failure warning light | 22. Seat belt warning light |
| 11. Rev counter | 23. Water in diesel filter warning light |
| 12. Engine coolant temperature gauge | 24. EOBD warning light |

Wiring diagram



P4F015LL01


(*) JTD

(**) TD 75 BHP

- | | |
|--|--|
| A. Battery recharging warning light | P. Seat belt warning light |
| B. Low engine oil pressure warning light | Q. Brake pad wear warning light |
| C. Left direction indicator warning light | R. Low brake fluid/handbrake on/EBD system failure warning light |
| D. Right direction indicator warning light | S. Brake light electronic control module |
| E. Side lights warning light | T. Brake light failure warning light |
| F. Instrument panel symbol lighting | U. Doors open warning light |
| G. Main beam warning light | V. Speedometer |
| H. Air Bag fault warning light | W. Rev counter |
| I. ABS failure warning light | X. Engine coolant temperature gauge |
| J. Fuel reserve warning light | Y. Electronic module |
| K. Fuel level gauge | Z. Milometer - trip meter/outside temperature gauge |
| L. FIAT CODE system warning light | Z1. Odometer reset button |
| M. Injection system failure warning light | |
| M1. EOBD warning light | |
| N. Water in diesel filter warning light | |
| O. Heater plugs warning light | |


* Short-circuit plugs

55.




4F061GL01

Rear side (the connector sockets are shown)



4F061GL02



4F061GL03

Connector A (on front lead)


Pin no.	Cable colour	Circuit involved
1	BV	EBD system failure
2	BN	Brake fluid level
3	BR	Brake pad wear
4	CL	Heater plugs (JTD)
5	MN	FIAT CODE
6	LN	Injection system failure (JTD)
7	HN	Battery recharging
8	HG	Engine oil minimum pressure
9	LN	EOBD (petrol only)
10	RV	ABS fault
11	GN	Reserve signal (petrol only)
12	VB	Speedometer signal
13	AG	+30 battery
14	CN	Speedometer generator power supply
15	HB	engine coolant temperature
16	HL	Outdoor temperature signal
17S	HM	Speedometer signal
18	L	Rev counter signal

(*) not connected in this version

Connector B (on facia lead)

Pin no.	Cable colour	Circuit involved
1	RG	Left brake light failure
2	RV	Brake light switch
3	RV	Brake light switch
4	C	Air Bag system fault
5	GV	Water in diesel filter (JTD)
6	M	Seat belt
7	-	N.C.
8	A	Left turn signal
9	AN	Right turn signal
10	-	N.C.
11	GN	Side lights
12	LB	Main beam headlamps
13	BN	Handbrake on
14	RN	Right brake light failure
15	H	Doors open
16	CN	Boot open
17S	-	N.C.
18	GR	Instrument panel light
19	N	Lighting earth
20	HG	Fuel level
21	GL	Outdoor temperature display
22	R	+15 from ignition
23	N	electronic earth
24	-	speedometer signal (*)
25	VN	Speedometer signal
26	-	speedometer signal (*)


INSTRUMENT PANEL FOR ELX, HLX TRIM LEVELS



4F017LLL01


Front side

1. Fuel reserve warning light
2. Fuel level gauge
3. Rev counter
4. Direction indicators warning light
5. Analogue speedometer and digital milometer
6. Engine coolant temperature gauge
7. Gears indicator for automatic transmission




4F017LL02

55.




4F018LL01

Rear side (the connector sockets are shown)



4F061GL02



4F061GL03

Connector A

N°	Cable colour	Circuit involved
1	HN	Generator (G)
2	BN	Brake fluid level (J)
3	-	Injection system failure (*)
4	AG	+30
5	LN	EOBD (E)
6	-	Not connected
7	-	Turbocharging (N)
8	BR	Brake pad wear (K)
9	MN	Fiat Code (L)
10	-	Heater plugs (*)
11	-	Not connected
12	HG	Minimum oil pressure (H)
13	HM	Speedometer signal
14	HL	Outside temperature signal
15	CN	Speedometer module supply
16	L	Rev counter signal
17	HB	Coolant temperature gauge
18	-	Not connected
19	RV	ABS failure (M)
20	-	Trailer lights (*)

Connector B

N°	Cable colour	Circuit involved
1	LB	Main beam headlamps (D)
2	GR	Instrument panel light
3	GN	Side lights (C)
4	-	Not connected
5	BN	Handbrake (J)
6	M	Seat belt (I)
7	N	Earth
8	-	Speedometer signal (*)
9	VB	Speedometer signal
10	A	Left turn signal
11	AN	Right turn signal
12	-	Not connected
13	CA	Automatic transmission (A)
14	N	Earth (electronic)
15	GL	Outside temperature switch
16	HG	Fuel level
17	R	+15
18	C	Air Bag failure (B)
19	GN	Fuel reserve
20	-	Speedometer signal

(*) not used


GENERAL DESCRIPTION

The car radio reception and playing system has been developed with the acoustic properties of the passenger compartment in mind to offer outstanding sound reproduction at all times.

The system is installed on the car directly during production, without subsequent interventions. All wires are integral with the car wiring.

The system includes:

- radio
- front speakers (with separate tweeters)
- rear speakers
- radio supply leads
- radio and speaker connection leads
- radio controls on steering wheel
- coaxial aerial connection lead
- stylus aerial on roof
- connection lead for CD changer, located in boot.

LOCATION OF SYSTEM COMPONENTS


4F019LL01

Component key

- | | |
|------------------------------------|-----------------------|
| 1 Radio | 6 Aerial |
| 2 Radio controls on steering wheel | 7 Coaxial aerial lead |
| 3 Front speaker | 8 Lead for CD changer |
| 4 Front tweeter | 9 CD player/changer |
| 5 Rear speaker | |


55.

CAR RADIO

The radio is customised to fit in with the instrument facia styling. It is fixed because it cannot be adapted to any other car.


It comes in three versions:

RADIO H4 : *with CD player, theft protection, predisposition for handsfree mobile phone use, connection lead for CD changer, possibility of steering wheel controls.*




4F020LL01

RADIO H3 : *with cassette player, theft protection, predisposition for handsfree mobile phone use, connection lead for CD changer, possibility of steering wheel controls.*



4F020LL02

RADIO M2 : *with cassette player, predisposition for handsfree mobile phone use*



4F020LL03

AERIAL

The car is fitted with an aerial on the roof.

Electrically-controlled aerial

The car radio is fitted with the wiring for controlling an automatic electric aerial (that rises when the car radio is switched on and lowers when the radio is switched off).

SPEAKERS

The special sound system comprises:

- 2 elliptical mid-woofer speakers 130 x 180 mm with a power output of 30W max each;
- 2 diffusori fluid iron tweeter dome speakers with a max power output of 40W max;
- 2 full-range Ø 130 mm speakers with a power output of 30W max each (*only for H4 and H3*)

TECHNICAL DATA

Radio power (*H4 and H3 versions*)

- 4 x 15W (with standard sound system made up of mid-woofer + tweeter and full range speakers).


Radio power (*version M2*)

- 2 x 15W (with standard sound system made up of mid-woofer + tweeter speakers).
- 4 x 5W (with optional 4-channel speaker system that can be installed by After Market).

WARNING *The standard system is 2 x 15W. If a 2 x 15W system is fitted, an adaptor is fitted between radio and wiring.*

Fuse

The radio is fitted with a 10A fuse (D). (*5A for the M2 version*)



CONNECTIONS

Connector A

- A1 SCV signal (+) for adjusting volume according to speed
- A2 Phone Mute signal for mobile phone
- A4 +12V ignition-operated voltage supply
- A5 aerial supply output +12V (max. 0.5A)
- A6 +12V display lighting output voltage
- A7 +12V direct supply voltage
- A8 Earth

Connector B

- B1 rear speaker (right +)
- B2 rear speaker (right -)
- B3 front speaker (right +)
- B4 front speaker (right -)
- B5 front speaker (left +)
- B6 front speaker (left -)
- B7 rear speaker (left +)
- B8 rear speaker (left -)

55.

Supplementary connections

Connector C

Line output: possibility of connection for power amplifier (Booster) or active speaker

- C1 Rear speaker (left +)
- C2 Rear speaker (right +)
- C3 Earth (-)
- C4 Front speaker (left +)
- C5 Front speaker (right +)
- C6 Switch signal for power amplifier: on/off (max. 0.3A).

Phone input

Possibility of mobile phone handsfree connection

- C7 NF phone
- C12 NF phone earth

Remote control from steering wheel (*H4 and H3 versions*)

- C8 Earth
- C9 Remote control

Cd changer connection (*H4 and H3 versions*)

- C13 CD bus control line
- C15 CD bus earth
- C16 +12V supply voltage for cd changer
- C17 Switching voltage for cd changer
- C18 NF CD earth
- C19 left NF CD
- C20 right NF CD

**WARNINGS****Anti-theft protection**

The radio comes with a theft protection system comprising of a secret 4 digit code.

The protection system makes the radio inoperable if it is removed from the fascia as a result of a theft. See the following pages to activate the anti-theft device

CODE card

The radio identity document shows the model, serial number and secret code.

The serial number is the same as the number stamped on the set frame

If the set is lost, the CODE card facilitates search investigations and speeds up claim settlement by insurers due to the ownership document.



4F023LL01



If the anti-theft protection is active and the radio is disconnected from the car battery, the radio is still protected electronically

It may only be operated again by entering a special code.

Display

If the set is disconnected from the voltage supply, the display figures flash when it is reconnected.

The flashing figures are a reminder that the clock must be reset as described below.

Extended function field (EXP key)

The EXPERT control level allows the user to use a range of functions beginning with the base control yet without losing an overall view.

Operation with mobile phone (PHONE)

The radio is designed for connection to a mobile phone handsfree system (using the PHONE IN input).

The radio sound is deactivated while the mobile phone is in operation.


PHONE appears on the display.

55.

CONTROL DESCRIPTION

RADIO H4

This comes with a CD player, antitheft protection, predisposition for mobile phone handsfree operation, connection lead for CD changer, possibility of steering wheel controls.



4F024LL01

The tables on the following pages details key functions according to operating mode (RADIO, CD, CD CHANGER, PHONE).


Key	function	Status EXPERT	RADIO mode		CD mode		CD-CHANGER mode		PHONE mode
			short press	> 2 sec. press	short press	> 2 sec. press	short press	> 2 sec. press	
1	Radio on/off VOL/AUD ad- justment	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up		On/off: press VOL/AUD: Turn left: down, Turn right: up		On/off: press VOL/AUD: Turn left: off, Turn right: up		On/off: press VOL/AUD: Turn left: down, Turn right: up
2	TP Traffic Program	-	TP ON/OFF	PTY	TP ON/OFF	-	TP ON/OFF	-	-
3	AF: Alternative frequency	-	AF ON/OFF	RDF ON/OFF	-	-	-	-	
4	Previous (left)	IS=OFF	FM: Search - AM: Search - PTY: Select next programme	FM:MAN - AM:MAN - PTY: automatic search (within pro- gramme)	Track - N	Fast return (continuous)	Track - N	Fast return (continuous)	-
		IS=ON	FM: Store next IS AM: Search - PTY: Select next pro- gramme	FM:MAN - AM:MAN - PTY: automatic search (within pro- gramme)	Track - N	Rapid return (continuous)	Track - N	Rapid return (continuous)	-
5	Previous (right)	IS=OFF	FM: Search + AM: Search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within pro- gramme)	Track + N	Fast forward (continu- ous)	Track + N	Fast forward (con- tinuous)	
		IS=ON	FM: Store next IS AM: Search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within pro- gramme)	Track + N	Fast forward (continu- ous)	Track + N	Fast forward (continu- ous)	
6	Eject	-	Eject (CD)	-	Eject (CD)	-	Eject (CD)	-	Eject (CD)
7	Preset station 1	-	FM/AM/PTY: recall preset station 1	FM/AM: store preset station 1 PTY: store program	-	-	-	-	-
8	Preset station 2	-	FM/AM/PTY: recall preset station 2	FM/AM: store preset station 2 PTY: store programme	-	-	-	-	-

55.

9	Preset station 3	-	FM/AM/PTY: recall preset station 3	FM/AM: store preset station 3 PTY: store programme	-	-	CDC +	-	-
10	Preset station 6	-	FM/AM: recall preset station 6	FM/AM: store preset station 6 PTY: store programme	-	-	CDC -	-	-
11	Preset station 5	-	FM/AM/PTY: recall preset station 5	FM/AM: store preset station 5 PTY: store programme	-	-	-	-	-
12	Preset station 4	-	FM/AM/PTY: recall preset station 4	FM/AM: store preset station 4 PTY: store programme	-	-	-	-	-
13	AUD: Sound settings	-	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)
14	RPT: Repeat	-	-	-	On/off repeat track	-	On/off repeat track	On/off repeat CD	-
15	SCN Automatic scan	IS=OFF	Automatic scan of all stations preset on band in use	Automatic scan of all stations tunable on band in use (Search)	Automatic selection of CD tracks	-	Automatic selection of CD tracks	-	-
		IS=ON	Automatic scan of all stations preset on band in use	Automatic scan of all stations in intelligent search system (IS) (Store)	Automatic scan of CD tracks	-	Automatic scan of CD tracks	-	-
16	BN: Select frequency band	-	FM1, FM2, FM3, MW, LW	Automatic store of preset station groups	-	-	-	-	-
17S	RND: Random repeat	-	-	EXPERT on/off	Random tracks	EXPERT on/off	Random tracks (on selected CD)	EXPERT on/off	-
18	SRC: Select source	IS=OFF	CD, RADIO, CDC (if connected)	-	CD, RADIO, CDC (if connected)	-	CD, RADIO, CDC	-	-
		IS=ON	CD, RADIO, CDC (if connected)	Update intelligent search and store IS	CD, RADIO, CDC (if connected)	-	CD, RADIO, CDC	-	-

RADIO H3

This comes with a cassette player, antitheft protection, predisposition for mobile phone handsfree operation, connection lead for CD changer, possibility of steering wheel controls.



4F027LL01

The tables on the following pages details key functions according to operating mode (RADIO, CASSETTE, CD CHANGER, PHONE).

55.


Key	Function	Status EXPERT	RADIO mode		CASSETTE mode		CD-CHANGER mode		PHONE mode
			short press	> 2 sec. press	short press	> 2 sec. press	short press	> 2 sec. press	short press
1	Radio on/off VOL/AUD adjustment	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up
2	TP Traffic programme	-	TP ON/OFF	PTY	TP ON/OFF	-	TP ON/OFF	-	-
3	AF: Alternate frequency	-	AF ON/OFF	RDF ON/OFF	-	-	-	-	-
4	Previous (left)	IS=OFF	FM: search - AM: search - PTY: Select next programme	FM:MAN - AM:MAN - PTY: automatic search (within programme)	-	-	-	-	-
		IS=ON	FM: (store next IS AM: search - PTY: Select next programme	FM:MAN - AM:MAN - PTY: automatic search (within programme)	-	-	-	-	-
		MSS=OFF	-	-	Fast return (to beginning of tape)	-	Track - N	Fast rewind (continuous)	-
		MSS=ON	-	-	Track -N max. 9)	-	Track - N	Fast rewind (continuous)	-
5	programme (right)	IS=OFF	FM: search + AM: search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within programme)	-	-	-	-	-
		IS=ON	FM: (store next IS AM: search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within programme)	-	-	-	-	-
		MSS=OFF	-	-	fast forward (to end of tape)	-	Track +N	fast forward (continuous)	-
6	Eject	MSS=ON	-	-	Track +N max.9)	-	Track +N	fast forward (continuous)	-
	Reverse	-	Eject Tape	-	Eject Tape	-	Eject Tape	-	Eject Tape
		-	-	-	Reverse/Normal	-	-	-	-

7	Preset station 1	-	FM/AM/PTY: recall preset station 1	FM/AM: store preselected station 1 PTY: store programme	-	-	-	-	-	-
8	Preset station 2	-	FM/AM/PTY: recall preset station 1	FM/AM: store preselected station 2 PTY: store programme	-	-	-	-	-	-
9	Preset station 3	-	FM/AM/PTY: recall preset station 3	FM/AM: store preselected station 3 PTY: store programme	-	-	-	-	CDC+	-
10	Preset station 6	-	FM/AM/PTY: recall preset station 6	FM/AM: store preselected station 6 PTY: store programme	-	-	-	-	CDC+	-
11	Preset station 5	-	FM/AM/PTY: recall preset station 5	FM/AM: store preselected station 5 PTY: store programme	-	-	-	-	-	-
12	Preset station 4	-	FM/AM/PTY: recall preset station 4	FM/AM: store preselected station 4 PTY: store programme	-	-	-	-	-	-
13	AUD: Audio settings	-	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/- AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)
14	RPT: Repeat	-	-	-	On/off repeat track	-	-	On/off repeat track	On/off repeat CD	-
15	SCN: Automatic scan	IS=OFF	Automatic scan of all preset stations on band in use	Automatic scan of all stations tunable on band in use (Search)	-	-	-	Automatic scan of CD tracks	-	-
		IS=ON	Automatic scan of all preset stations on band in use	Automatic scan of all stations on intelligent search system IS (Store)	-	-	-	Automatic scan of CD tracks	-	-
16	BN: Select frequency band	-	FM1, FM2, FM3, MW, LW	Automatically store preset station groups	-	-	-	-	-	-
17S	RND: Random repeat	-	-	EXPERT on/off	EXPERT on/off	-	-	Random tracks (on selected CD)	EXPERT on/off	-
18	SRC: Select source	IS=OFF	CD, RADIO, CDC (if connected)	-	CD, RADIO, CDC (if connected)	-	-	CD, RADIO, CDC	-	-
		IS=ON	CD, RADIO, CDC (if connected)	Update intelligent search and store IS	CD, RADIO, CDC (if connected)	-	-	CD, RADIO, CDC	-	-

55.

RADIO M2

This comes with a cassette player and predisposition for mobile phone handsfree operation



The tables on the following pages details key functions according to operating mode (RADIO, CASSETTE, PHONE).

Key	Function	Status EXPERT	RADIO mode		CASSETTE mode		PHONE mode
			short press	press > 2 secs	short press	press > 2 secs	
1	radio VOL/AUD adjustment on/off	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up	-	On/off: press VOL/AUD adjustment: Turn left: down, Turn right: up
2	TP/Traffic programme	-	TP ON/OFF	PTY ON	TP ON/OFF	-	-
3	AF: Alternate frequency	-	AF ON/OFF	RDF ON/OFF	-	-	-
4	Previous (left)	IS=OFF	FM: Search - AM: Search - PTY: Select next programme	FM:MAN - AM:MAN - PTY: Automatic search (within programme)	-	-	-
		IS=ON	FM: Store next IS AM: Search - PTY: Select next programme	FM:MAN - AM:MAN - PTY: automatic search (within programme)	-	-	-
5	programme (destra)	IS=OFF	FM: Search + AM: Search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within programme)	-	-	-
		IS=ON	FM: Store next IS AM: Search + PTY: Select next programme	FM:MAN + AM:MAN + PTY: automatic search (within programme)	-	-	-
6	Fast rewind	-	-	-	Fast rewind	-	-
	Fast forward	-	-	-	Fast forward	-	-
	Reverse or Eject (IF PRESSED TO- GETHER)	-	-	-	Reverse/Normal (IF PRESSED HALF WAY) Eject Tape (IF FULLY DEPRESSED)	-	-
7	Preset station1	-	FM/AM/PTY: recall preset sta- tion1	FM/AM: store preset station 1 PTY: store programme	-	-	-
8	Preset station2	-	FM/AM/PTY: recall preset sta- tion2	FM/AM: store preset station 2 PTY: store programme	-	-	-
9	Preset station3	-	FM/AM/PTY: recall preset sta- tion3	FM/AM: store preset station 3 PTY: store programme	-	-	-

55.

10	Preset station 6	-	FM/AM/PTY: recall preset station 6	FM/AM: store preset station 6 PTY: store programme	-	-
11	Preset station 5	-	FM/AM/PTY: recall preset station 5	FM/AM: store preset station 6 PTY: store programme	-	-
12	Preset station 4	-	FM/AM/PTY: recall preset station 4	FM/AM: store preset station 4 PTY: store programme	-	-
13	AUD: audio settings	-	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	RESET return to original B/T/B/F/-AUD settings (CENTER)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)	Bass (B), Treble (T), Balance (B), Fader (F), Loudness (LD)
14	AS: Automatic store	-	Automatic store in preset station group	-	-	-
15	SCN: Automatic scan	IS=OFF	Automatic store of all preset stations on band in use	Automatic store of all stations tunable on band in use (Search)	-	-
		IS=ON	Automatic store of all preset stations on band in use	Automatic store of all stations in intelligent search system IS (Store)	-	-
16	BN: Select frequency band	-	FM1, FM2, FM3, MW, LW	-	-	-
17S	EXP: Expert	-	-	EXPERT on/off	EXPERT on/off	-
		IS=OFF	TAPE, RADIO	-	TAPE, RADIO	-
18	SRC: Select source	IS=ON	TAPE, RADIO	Update intelligent search and storage IS	TAPE, RADIO	-

OPERATION**ON/OFF**


The set can be turned on and off in two ways.

1. Press knob A (VOL).
2. Turn on/off by means of car ignition switch. This function may be set in the EXPERT control level. Manual activation and deactivation are possible at all times in this case.

Note: *if the EXPERT "IGN" function is not active, the radio goes off automatically 20 minutes after the engine is turned off.*

ADJUSTING VOLUME AND SOUND**Volume**

Adjust to required volume by means of knob A (VOL).
the display shows: «VOL 00» → «VOL 31».

**Adjusting sound**

For each of the settings BASS, TREBLE, FADER, BALANCE, LOUDNESS:

1. Select functions by pressing the AUD key once or more.
2. Select the required sound setting by means of key A or select the basic setting: press the AUD key for longer than 2 seconds until the display shows «CENTER» Or «- -».
3. Finish adjustment: press the AUD key several times until the display shows «VOL ...».

NOTE: *the radio comes with a sound reproduction condition memory specific to each source type.. This makes it possible to set different sound geometries (FADER, BALANCE) and frequency responses (BASS, TREBLE, LOUDNESS) for radio, cassette and phone sources (Automatic Sound Memory function)..After about 5 seconds, the control level with the current settings is automatically abandoned.*

55.

Example 1: bass setting.

Repeatedly press the **AUD** key until the display shows: «BASS 00».

Use the **A** key to adjust the bass tones.

To restore all sound settings to neutral (all set to zero), keep the **AUD** key depressed for longer than 2 seconds until the display shows "00"

NOTE: *this reset function only applies to the source in current use; the existing settings remain valid for the others. The LOUDNESS FUNCTION IS NOT INCLUDED IN THIS RESET. FUNCTION MUST ALWAYS BE DEACTIVATED MANUALLY.*

Example 2: LOUDNESS setting

Repeatedly press the **AUD** until the display shows «LOUD».

To activate (LOUD ON), turn the volume key anticlockwise; to deactivate (LOUD OFF) turn it clockwise. When the Loudness function is active, the display shows the symbol «LD».

Volume distribution FAD (FADER)

The FADER is used to distribute volume between the front speaker group «F» (Front) and rear group «R» (Rear). Use knob **A**. to adjust the function.

The display shows «FAD F -- -- R».

Only for version M2: the function must be activated (see EXPERT settings) in the case of changes to the speaker system (4 x 5W speakers).

With the standard system (2 x 15W speakers) the function is not usable

Volume ratio BAL (balance)


Balance is the volume ratio between the left and right hand speakers Use knob **A**. to adjust the function

The display shows «BAL L -- -- R».

Manual switching to MONO

See EXPERT settings This function is recommended when the radio is tuned to a station with a lot of interference, to reduce the background noise.

RADIO (Tuner)



Range selection

FM range: press the **BN** key repeatedly until the display shows the required range «FM 1», «FM 2» or «FM 3».

AM Range: press the **BN** key repeatedly until the display shows «MW» (medium wave) or «LW» (long wave).

Last station memory

Once the selection has been made, the last programme tuned on this range can be played (Last Station Memory) While in Last Station Memory mode, the set stores the settings present before it is turned off: selected station, CD or TAPE, and plays them when the set is turned on again.

Stereo reception - FM

When a stereo station is received, the display shows the corresponding symbol.

Traffic information reception (TP)

TP (Traffic Program): RDS station able to transmit traffic broadcasts.

TP function activation

Give the TP key a short press This enables the traffic broadcast reception function: the display shows the message "TP"

When traffic information is received with the TP function active and another sound source is playing (e.g. CD or tape), the source is interrupted to listen to the radio information and the display shows the message "TA INFO" for 10 seconds.

At the end of the traffic information, the source is automatically switched to the source selected originally.

NOTE: *if the station tuned in is not an RDS station able to broadcast traffic information, a search is automatically started for an RDS station when the TP function is selected.*

Interrupting traffic information

Give the TP key a short press. The function still remains active to receive future traffic information.

RDS-EON

Because the radio offers the **EON** service, another station belonging to the same network may tune in while listening to a radio station to provide traffic information (only with TP function enabled); it will return to the original station automatically at the end of the news.

NOTE: *traffic information is provided at minimum volume. This volume may be adjusted by means of the EXPERT control menu.*

If only traffic information is to be played, activate the function by means of the TP key and set the volume to zero using knob A

Alternative frequency (AF)

During reception of an RDS programme that is broadcast by several stations at different frequencies, the radio will automatically switch to the frequency with the best local reception.

NOTE: *in a very poor reception area, the user may become aware of attempts to switch between sound frequencies due to frequent pauses. In this case, it is advisable to deactivate the AF function temporarily.*

55.

Deactivating AF function

NOTE: *this function can be deactivated only when receiving stations with alternative frequencies. To deactivate the AF, simply give the AF key a short press. When a short message »AF OFF« will appear on the display.*

Do the same to reactivate.

NOTE: *the AF OFF reception condition should be considered a local, temporary solution because it involves manual compensation of a broadcasting service.*

For this reason, tuning will automatically be switched to AF ON upon each manual or automatic tuning control or selection of another stored station.

The AF OFF condition can be stored, together with the station, when it is activated before storage.

If an attempt is made to deactivate AF for a station that is not broadcasting using an RDS protocol, the message "NO AF" will appear on the display.

RDS OFF

With some stations (e.g. MF103.3-ISORADIO in Italy), it is advisable to store the station in RDS OFF mode to receive optimum reception.


To activate RDS OFF mode, simply press the AF key for more than 2 seconds.

RDS OFF mode, as with AF OFF mode, is absolutely temporary. The RDS OFF condition can be stored, together with the station, whenever it is activated before storage.

Storing RDS stations/programmes

Press the selection key for stations 1 to 6 for more than 2 seconds until the station can be heard again.

NOTE: *the AF ON/OFF and RDS ON/OFF modes are stored together with the station.*



4F036LL01

TUNING**Tuning RDS stations/programmes with automatic search for stations**

1. Use the **BN** key to select the range: FM1, FM2, FM3, MW or LW.

The automatic search within FM ranges operates with two degrees of sensitivity. During the first search through the reception range, the search is carried out for stations with high field intensity (local stations). The second search seeks stations with low field intensity (distant reception). The message "DX" appears on the display during the search.

The DX function may be deactivated (see chapter on EXPERT control level)

2. An automatic search in the required direction may be started by giving a short press to one of the keys **A** or **B**. The display shows the relevant frequency: when a station with an identification code is found, this is shown on the display. Otherwise the frequency indication remains.
If the **RDS** station/programme tunes within the selected range, it is stored on a selection key for stations 1 to 6. The relevant number appears on the display, e.g. "3" for memory position 3.
3. If the tuned station is to be stored on a selection key, proceed as described in the paragraph on station selection keys.

Recalling stored RDS station/programme

Use the **BN** key to select the range: FM1, FM2, FM3, MW or LW.

Give a short press to the selection key for stations 1 to 6.

Even if the radio power supply is disconnected, the memory contents of the station selection keys are maintained.

Manual frequency tuning

1. Use key **BN** to select the range: FM1, FM2, FM3, MW or LW.
2. Pres one of the keys **A** or **B** for 2 seconds until "MAN" appears on the display and the frequency tuning is not visible. Continual switching takes place during fast forward when one of the keys is held down.
3. Use keys **A** or **B** to tune in the required direction: the frequency will be increased or reduced by 50 Hz while in FM or 1 kHz in AM.
4. If the tuned station is to be stored on one of the station selection keys, proceed as described in the paragraph on "Station selection keys".
5. Conclusion of manual frequency tuning: give a short press to one of the station selection keys from 1 to 6.

NOTE: *If no key is pressed for 60 seconds, manual frequency tuning is automatically concluded.*

Automatic station storage: AUTOSTORE

Automatically store the most powerful stations in the selected local reception range on station keys 1 to 6.

Range selection: FM 1, FM 2, FM 3, MW or LW.

Press the **BN** key for more than 2 seconds until the message "AS" appears on the display and the frequency indication changes.

The station with the best reception can be heard at the end of the search.

55.

Tuning RDS programmes (IS LEARN) function (see EXP)

The IS LEARN function (which can be run only after activating the EXPERT function) can be used to store up to 30 programmes in the IS memory (virtual memory area that does not correspond to storage keys).

Stored programmes can be called up one by one as described in the EXP section.

The IS memory is useful when the station selection keys are restored or when the tuning stops on a new reception field and you do not wish to delete stored stations from preset keys.

Starting the automatic IS LEARN function

Use the **BN** key to select the range «FM 1», «FM 2» or «FM 3».

Press the SRC key for longer than 2 seconds. «IS ...» will appear on the display. the receiver starts the search.

If an attempt is made to start the IS LEARN search without the IS mode being active (see EXPERT), the display will show the message "EXPERT".

NOTE: *Always wait for the end of the automatic intelligent search (IS).*

If no reception is possible, the automatic intelligent research may stay on, e.g. in an underground garage or if the aerial is defective. In this case, the automatic search can be interrupted by pressing one of the station selection keys from 1 to 6.

The automatic intelligent search IS ensures up to 30 stations can be stored with optimum reception.

During automatic intelligent search IS, RDS programmes are stored first ordered by programme code, followed by FM stations.

Calling up the contents of the IS memory

Stations can be called up from the memory in the required direction by giving a short press to one of the keys A or B. «IS-SCAN» appears on the display during station selection.

Programme types (PTY)

Many radio programmes offer the programme type service (PTY) in the FM range (FM1, FM 2, FM3) The message «NEWS» is displayed during a news programme, for example.

The PTY function activates a search filter that allows the radio to tune only to stations that broadcast programmes with a preset PTY code.

Programme types

The types of programme offered by a radio station vary according to the type of programme transmitted.


NEWS	News and topical matters
AFFAIRS	Politics and events
INFO	Special information programmes
SPORT	Sports broadcasts
EDUCATE	Education and training
DRAMA	Radio plays and readings
CULTURE	Culture, church and religion
SCIENCE	Science
VARIED	Various
POP	Pop music (hits and chart music)
ROCK M	Rock music
EASY M	Easy listening
LIGHT M	Light classical music
CLASSICS	Classical music
OTHER M	Unclassified music programmes

WEATHER	Weather forecasts
FINANCE	Financial news
CHILDREN	Children's programmes
SOCIAL A	Social information
RELIGION	Religious and philosophical broadcasts
PHONE IN	Listeners' phone-ins (*)
TRAVEL	Tourist information
LEISURE	Leisure, hobbies and pastimes
JAZZ	Jazz music
COUNTRY	Country music
NATIONAL	National broadcasts
OLDIES	Golden Oldies
FOLK M	Folk music
DOCU	Special documentaries
NO PTY	No identification code

(*) differs from phone-in function, activated only with the handsfree connection for mobile phone

Automatic PTY search

When selecting a programme type, an automatic search may be activated in two ways.



4F039LL01

1. Six programme types are allocated to the 6 programme keys (**station selection keys**). The preset allocation may be altered as required.
2. A programme type may be selected from the stored list and an automatic search may then be started.

The procedure is described below:

1. Reactivate PTY function

Press the TP for longer than 2 seconds until the message «PTY ON» appears on the display. Then the last type of programme selected will appear on the display (e.g. «POP»).

2. setting programme type

Give a short press to a key from 1 to 6. An automatic PTY search is started for the next station offering the selected programme type and the programme type is briefly displayed (e.g. "POP"), followed by the station code and the message "PTY".

Alternatively, press one of the keys A or B repeatedly until the required programme type appears on the display.

Press one of the keys A or B for more than 2 seconds until the automatic PTY search starts. The automatic PTY search stops automatically on the next station offering the preselected programme type, and shows the programme type (e.g. «POP») and the message «PTY».

NOTE: If no station offers the selected programme type, the last station tuned is played and the PTY function is abandoned.

3. deactivating the PTY function

This occurs automatically after about 10 seconds.

Storing PTY programme keys: station selection keys

The standard setting is defined in the table:

1	2	3	4	5	6
NEWS	SPORT	POP	ROCK M	CLASSICS	EDUCATE

Each station selection key may be occupied by any programme type as required:

1. Activating the PTY function:
Press the TP key for longer than 2 seconds until the display shows »PTY ON« and select the set programme type (e.g. «NEWS»).
2. Press one of the keys A or B repeatedly until the required programme type appears on the display.
3. Press one of the station selection keys for longer than 2 seconds.

55.

Scanning stored stations (SCAN)

The SCAN function allows automatic scanning of stored stations.

With IS LEARN OFF (EXP):

- short press: scan of all preset stations (keys 1-6) for all FM bands, or the 6 MW stations, or the 6 LW stations
- press for more than 2 seconds: scan of all stations receivable on the FM band.

With IS LEARN ON (EXP):

- short press: scan of all preset stations (keys 1-6) for all FM bands
- press for longer than 2 seconds: scan IS LEARN

EXPERT CONTROL LEVEL


To make daily radio control as easy as possible, the supplementary control level (EXPERT) contains several settings that may be required once only or only occasionally.

LIST OF POSSIBLE EXPERT SETTINGS

1	Hour setting (TM)
2	Activation/deactivation of time synchronisation with time sent by some RDS stations (SYNC)
3	Setting of maximum volume upon start-up (ON VOL)
4	Setting of minimum volume for traffic information (TA VOL)
5	Activation deactivation by means of car ignition switch (IGN)
6	IS LEARN activation/deactivation (IS)
7	LRN activation/deactivation (LRN)
8	Automatic program change (REG) activation/deactivation
9	Delayed booster activation (BDLY)
10	Suppression of sound in case of incoming/outgoing phone call with handsfree set connected (PHONE)
11	Setting phone input sensitivity (PHONE)
12	Activation of security code (CODE)
13	Control of volume according to speed (SC VOL)
14	Sound confirmation of functions (BEEP)
15	Choice of MONO/STEREO radio broadcasting (MONO)
16	LOC activation/deactivation (LOC)

ALTERING EXPERT SETTINGS**Turning on EXPERT**

Depress the **EXP** key for 2 seconds until «**EXPERT**» appears on the display.



4F041LL01

Choosing options

Select the settings to be checked or altered using keys **A** or **B**.

Example: Setting maximum volume upon start-up. (N.3): use keys **A** or **B** to select the required option (e.g. ONVOL 13), the display shows «ONVOL 13». The selected station is played at the set speed.

Altering the setting

Turn the volume knob to set the required volume, the display shows "ONVOL 20", for example.

Turn the knob clockwise: increase the value; turn the knob anticlockwise: reduce the value.

Concluding the setting

Set the next function using keys **A** or **B**

Alternatively, press the **EXP** for 2 seconds until "EXIT" appears on the display. **EXPERT** mode is closed (except for the code and clock).

POSSIBLE SETTINGS**1 - set time**

«TM 2:13» appears, for example.

Turn the volume knob to set hours and minutes:

- turn fast to adjust hours
- turn slow to adjust minutes

Give a short press to the **EXP** key to start the clock.

2 - activate/deactivate synchronisation of the clock with the time sent by some RDS stations

- turn volume knob clockwise: «**SYNC ON**»: the built-in clock goes forward (synchronisation) toward RDS information.
- turn the knob anticlockwise: »**SYNC OFF**».

Synchronisation may be deactivated in places where no RDS **TIMER** signal is received.

NOTE: The signal sent by the stations may often be incorrect.

55.

3 - setting maximum volume upon start-up

«ONVOL 20» appears for example, where 20 is the setting in a range that extends up to 31

- turn volume knob clockwise: VOL +
- turn volume knob anticlockwise: VOL -

Volume is limited only when volume is higher than the set value when the radio is turned off.

4 - setting minimum volume for traffic information

«TA VOL 16» appears for example (limit values from 4 to 31)

- turn volume knob clockwise = VOL +
- turn volume knob anticlockwise = VOL -

During adjustment, the volume is as selected for traffic news.

5 - automatic deactivation by means of car ignition switch

- turn volume knob clockwise: «IGN ON» appears : in this way, the radio can be turned on/off using the car ignition switch.
- turn volume knob anticlockwise: "IGN OFF": activation/deactivation takes place only via the VOL knob.

6 - IS LEARN activation/deactivation

- turn volume knob clockwise: «IS ON» appears
- turn volume knob anticlockwise: «ISN OFF».

7 - LRN activation/deactivation

With «LRN OFF» (standard mode) the radio remains on the selected station until the incoming signal is practically illegible.

In «LRN ON» mode, the radio turns to another station as soon as the incoming signal quality falls.

When in an area where the reception of RDS programmes with traffic news is uncertain, the station search may be blocked in the radio function.

- turn volume knob clockwise: «LRN ON» appears: automatic search of traffic news broadcasts is activated automatically,
- turn volume knob anticlockwise: «LRN OFF»: automatic search of traffic news broadcasts is not activated.

8 - activation/deactivation of automatic regional programme change

When the same RDS programme is transmitted from various regional stations, the radio may switch between stations due to the reception field.

- turn volume knob clockwise: "REG ON" appears: regional programme may be changed automatically in this mode.
- turn volume knob anticlockwise: «REG OFF»: regional programme cannot be changed automatically.

9 - delayed activation/deactivation for connected booster (BDLY)

NOTE: remember that the Booster switch signal is connected to pin C6 of the radio.

This mode eliminates the abrupt on/off manoeuvre:

- turn volume knob clockwise: »BDLY ON« appears
- turn volume knob anticlockwise: «BDLY OFF»: is disabled.

10 - suppression of sound in case of incoming/outgoing phone call

- turn volume knob clockwise: «PHONE OFF» no use of phone connection
- turn volume knob clockwise: «PHONE ON»: the radio sound is automatically deactivated in the case of a phone call

The «PHONE ON» function required the mobile phone mount base to be connected.

The «PHONE IN» function allows a conversation via the car speakers in the case of a phone call.

The «PHONE IN» function requires the mobile phone to be connected in handsfree mode

If the radio is off, a phone call (IN or OUT) is still possible. In this case the radio

- comes on automatically;
- allows listening under sound conditions identical to the last phone call (BASS, TREBLE, FADER, BALANCE);
- goes off automatically at the end of the phone call

11 - setting mobile phone input sensitivity

Allows adaptation to the signal broadcast level for the type of handsfree system installed.

- turn volume knob anticlockwise: «PHONE 00»: low input sensitivity
- turn volume knob clockwise: «PHONE 03»: high input sensitivity

12 - security code activation

The code is not activated if «CODE» appears on the display.

If «SAFE» appears on the display, the code is activated.

NOTE: See next section for more detailed instructions.

13 - Controlling volume according to vehicle speed (SCV)

Standard value: «SCVOL 19»

Function off: «SCVOL - -»

Function at maximum efficiency: «SCVOL 34»

Setting:

1. Vehicle still, engine on: set required volume using the relevant knob.
2. Depress the EXP key for more than 2 seconds until «EXPERT» appears on the display.
3. Use keys A or B to select the «SCVOL» setting.
4. Set the required value using the volume knob:
 - turn volume knob clockwise: VOL +
 - turn volume knob anticlockwise: VOL -

14 - audible function confirmation (BEEP)

The BEEP function is active in the system

This function gives an audible confirmation (BEEP) of the functions. Function activation requires continuous pressing of the key for a time greater than or equal to 2 seconds.

15 - select MONO/STEREO radio reproduction

- turn volume knob clockwise: «MONO ON».
- turn volume knob anticlockwise: «MONO OFF».

16 - activate/deactivate LOC


The automatic search in the FM range may be used at two sensitivity levels. When in search of stations, the set may be tuned with high field intensity (local stations) or low field intensity (distant reception).

- turn volume knob clockwise: «LOC ON».
- turn volume knob anticlockwise: «LOC OFF».

55.

CODING


When coding is activated, the radio is protected electronically as soon as the radio is disconnected from the car power supply. It can be made to work again only by entering the code. The radio code is on the **CODE CARD**



4F044LL01



ATTENTION: coding is not activated initially by the Manufacturer



4F044LL02

ACTIVATING THE CODE

1. Select the **EXPERT** code level and press keys **A** or **B**, until «**CODE**» appears on the display.
2. Enter the first figure of the code by turning the volume knob and confirm by pressing the **RND/EXP** key.

Example: **1 7 0 3**

- turn the volume knob to display the figure «1---»
press the **RND/EXP** key briefly to confirm
 - turn the volume knob to display the figure «17□»
press the **RND/EXP** key briefly to confirm
 - turn the volume knob to display the figure «170-»
press the **RND/EXP** key briefly to confirm
 - turn the volume knob to display the figure «1703»
press the **RND/EXP** key briefly to confirm
3. To confirm the code: press the **EXP** key, «**SAFE**» appears on the display : the code is activated.
 4. To deactivate **EXPERT** mode: press the **EXP** key until «**EXIT**» appears on the display.

Checking code activation

Select the EXPERT control level and press keys **A** or **B** until «SAFE» or «CODE» appears on the display:

If «SAFE» appears: the code is activated

If «CODE» appears: the code is not activated

DEACTIVATING THE CODE

1. Activate EXPERT mode: «SAFE» appears on the display.
2. Set the code, as described previously.
3. To confirm the code: briefly press the EXP key until «CODE» appears on the display: the coding is no longer active.

NOTE: *If an incorrect code is entered, the message «SAFE» remains on the display and the procedure must be repeated in full. Respect the waiting times between one attempt and the next, as indicated below.*

RESTORING TO OPERATION

If the radio is disconnected from the car power supply (e.g. when servicing), it is protected electronically with the code active.

1. Turn on the radio: the message «SAFE» appears on the display, «1 - - -» appears after more than 3 seconds. The «1» marks the number of input attempts.
2. Set the code, as described in CODE ACTIVATION.
3. Confirm the code by pressing the EXP key briefly. The message "SAFE" appears on the display. The radio switches on after about 3 seconds.

NOTE: *If an incorrect code is entered, the message «SAFE» remains on the display, the radio does not come on and the procedure must be repeated completely. Respect the waiting times between one attempt and the next, as indicated below.*

WARNING: waiting times

To make it impossible to restore the radio to operation and deactivate the code by repeated, successive attempts, specific waiting times must be left between attempts.

The radio must not be switched on during the standby time.

It must still be connected to the power supply

As long as the message "SAFE" is on the display, the waiting time is not over.

The waiting time is up when the number of the next attempt can be seen on the display (e.g. "2- - -").

The following table shows the waiting times between attempts:

Unsuccessful attempts (number shown on display)	Approximate waiting time
1	21 seconds
2	1.5 seconds
3	5.5 seconds
4	22 seconds
5	1.5 seconds
6	6 seconds
7	24 seconds

55.


COMPACT DISC PLAYER – only for H4 version

Activating CD operation

Place a CD in the slot and press slightly, the player will draw in the CD automatically.

If a CD is already present in the slot, press the SRC key until the message «DISC» appears on the display; the CD begins to play automatically.

SRC = Source ; the sources are: RADIO, DISC, CDC (CD Changer)



4F046LL01

Choosing a track

Keep tapping key A to choose a track in increasing order; similarly, keep tapping key B to choose a track in decreasing order.

Fast forward to a track

Hold keys A or B down continuously to fast forward or return to the track being played.

Repeating a track

Press the RPT key to repeat the track being played currently; the wording «RPT ON» appears on the display for a few seconds.

The current track will be repeated until the function is deactivated by pressing the RPT key again; the wording «RPT OFF» appears on the display for a few seconds.

RANDOM track selection

Tracks to be played are selected automatically after pressing the RND key; the message «RND ON» appears on the display for a few seconds.

The function is interrupted by pressing RND again; the message «RND OFF» appears on the display for a few seconds.

Automatic track scan

Press the SCN key to play all tracks on the CD for about 10 seconds each. The message «SCN ON» appears on the display for a few seconds.

The function is suspended by pressing SCN again; the message «SCNOFF» appears on the display for a few seconds.

Concluding operation and removing the CD

Simply press the C EJECT key to remove the CD from the player.

The wording «EJECT» appears for a few seconds on the display.

Alternatively press the SRC key, the source changes from DISC to CDC (if CD Changer present) or RADIO. Source selection is sequential: RADIO, DISC, CDC.

NOTE: Status of RPT, RND, SCN functions are not stored when the radio set is turned off.


TAPE PLAYER) - version H3

Activating tape operation

Place a tape in the slot. «TAPE A» or «TAPE B» appears on the display.

If the slot already contains a tape, press the SRC repeatedly until «TAPE» appears on the display.

SRC = Source; the sources are: RADIO, TAPE, CDC.



4F047LL01

Changing tape side

Press the D REVERSE key briefly.

When the end of the tape is reached the side changes automatically.

The meanings of the symbols on the display are as follows:

«TAPE A» : top side of tape

«TAPE B» : bottom side of tape.

MSS function

MSS = Music-Search-System

This function can be used to forward/rewind to the beginning of the track to obtain the "skip track" or "repeat track" function.

Pauses of at least 3 seconds are left between tracks for the MSS function (without an announcement text). Musical pieces with very low passages (e.g. classical music) are not suitable because these are treated as pauses.

Activating MSS

The MSS function can be turned on or off from the EXPERT menu; the standard condition is MSS ON

In this configuration, press key B to make the radio skip a number of tracks corresponding to the number of presses on the key; «+ --» appears on the display.

Example: 3 short presses on the key: skip three tracks;; «+3» appears on the display.

When keys A or B are pressed for longer than 2 seconds, the CD player is made to forward/rewind fully to the end of the tape.

If the MSS function is deactivated (from EXPERT) a short press on key A or B allows fast forward or fast rewind of the tape.

55.

Finish **MSS** before time

Press key **A** or **B** until «0» appears on the display. The player stops in its current forward/rewind position and starts to play the track from that point.


Concluding tape operation

Press the **C** **EJECT** key: the tape is ejected. «EJECT» appears briefly on the display

Alternatively press the key **SRC**, the source changes from TAPE to **MCD** (if **CD CHANGER** is present) or **RADIO**. source selection is sequential: **RADIO**, **TAPE**, **MCD**.

NOTE: *The source is switched immediately if the fast rewind or fast forward function is active but the tape player completes its current function.*

TAPE PLAYER - version M2



Changing the tape side

Press keys **A** and **B** half way down.

When the end of the tape is reached the side changes automatically.

The meanings of the symbols on the display are as follows:

"TAPE A" : top side of tape

"TAPE B" : bottom side of tape.

Fast forward/rewind

Fully depress keys **A** and **B**

Suspending operation

To suspend operation, briefly press the key opposite to the active key.

The tape begins to play automatically

Concluding tape operation

Fully depress the fast forward and rewind keys simultaneously. The tape will be ejected.

MULTIPLE COMPACT DISC PLAYER (CD changer)


The radio set (*in H4 and H3 versions*) is designed to work with compatible compact disc players available from the Fiat Accessory range.

The Fiat Accessory range player comes with a loader that can hold up to 6 CDs.


Filling the loader

The holder contains 6 holders that can each contain one compact disc.

Take a holder from the loader for each CD to be played and insert the CD



4A50HL01



4A50HL02


Ensure the CD label is facing the correct way, i.e. toward the holder. Otherwise the player will not work

NOTE The CD player is not designed for playing 8 cm CDs, which require adaptors available from Hi-Fi stores.


Inserting the loader into the CD player.

Proceed as follows:

- move sliding flap **A** fully to the right until it locks
- check that switch **B** is in position "1"



4A50HL03



4A51HL01


- insert loader **C** into the CD player with the labelled side (see arrow) facing up.
- close sliding flap **A** after inserting the loader in order to prevent foreign bodies or dust entering the CD player.

55.

Removing the loader from the CD player.

Proceed as follows:

- slide flap **A**- to the right until it is no longer locked
- press the eject button on the CD player, .



4A51HL03

Removing the CDs from the loader

Remove the CDs in order after removing the holders from the loader.

CD PLAYER OPERATION

Selecting CD changer programme source

Press the **SRC** briefly and repeatedly until the message «MCD» appears on the display.

Choosing a CD

Keep tapping station selection key 3 or 6 until the number of the required CD appears on the display.

3: previous CD

6: next CD

Selecting or repeating a track

Keep tapping the «RIGHT» or «LEFT» keys until the required track number appears on the display.

«RIGHT»: next track

«LEFT» : the track currently playing or the previous track is repeated.

Play a track on the selected CD for 10 seconds (**SCAN**)

Press the **SCAN** key briefly.

«SCAN ON» appears briefly on the display.

To stop this function briefly press **SCAN** key.

«SCAN OFF» appears briefly on the display.

Fast forward and return (**TRACK FAST**)

To listen to the track at reduced volume during track fast:

Forward: press "RIGHT" and hold down.

Return: press "LEFT" and hold down.

Repeat track (**TRACK REPEAT**)

To repeat the current track continually: press the **RPT** key, "TRK ON" appears on the display.

A different track may be selected.

Press **RPT** key again to suspend the function: «TRK OFF» appears on the display.

Repetition of a CD (REPEAT)

To repeat the current CD continuously: press the RPT key for longer than 2 seconds: "RPT CD" appears on the display.

A different CD may be selected. To suspend the function, press the RPT key again for longer than 2 seconds: «RPT MAG» appears on the display.

Selecting tracks in a random sequence (TRACK RANDOM)

To start the random track search:

press the RND key: "RND ON" appears on the display. The selected CD tracks are played in a random sequence.

Press the RND key again to end the random track search: "RND OFF" appears on the display.

NOTE: *The TRACK RANDOM function cannot be combined with the TRACK REPEAT and CD REPEAT functions.*

Concluding CD operation

Press the EJECT key

Alternatively, press the SRC to listen to the radio again

ADVICE AND PRECAUTIONS**RECEPTION CONDITIONS**

The reception conditions will vary greatly while driving.

Reception can be affected by mountains, buildings or bridges especially when far away from the transmitter of the station you are listening to.

Note: *when listening to traffic information (TA), the volume may rise considerably compared to normal levels.*

MAINTENANCE

The radio is built for long-term use without any special maintenance requirements.

If necessary, clean the panel with a soft, antistatic cloth. Cleaning and polishing products could damage the surface.

TAPES

For optimal playing conditions:

- do not use poor quality tapes, with deformations or peeling labels;
- do not leave the tape inside the radio when not in use;
- do not introduce any objects into the cassette slot;
- do not expose the tapes to sunlight, excessive temperature or high moisture levels;
- replace the tapes in their cases after use;
- dirt on the playing heads caused by tapes could eventually lead to a reduction in high tones during playing. It is therefore advisable to clean the playing heads at intervals using a special non-abrasive head cleaning tape;
- it is preferable to C60 tapes or in the worst case C90 tapes to ensure optimum playing quality at all times. The very fine tape contained in very long cassettes could also break very easily;
- avoid inserting cassettes with loose tapes, particularly if C90, because the tape could emerge and block the mechanism. If the radio detects a loose tape or similar problems, the cassette is in any case automatically ejected;
- do not lubricate the tape mechanism;
- do not touch the playing heads with magnetic or hard items.

55.

COMPACT DISC

When using the Compact Disc player, remember that dirt or marks on the CD could cause the track to jump or lead to poor sound quality.





The same thing happens if CDs are inadvertently bent.

For optimum playing conditions:





- carefully clean each CD to remove fingerprints and dust using a soft cloth;
- hold the CDs at the edges and clean from the middle outward;
- never use chemical products to clean (e.g. sprays, antistatic products or thinners) because they could damage the CD surfaces;
- replace the CDs in their containers after use to avoid creating marks or scratches that could cause the tracks to jump;
- do not expose the CDs to direct sunlight, high temperatures or moisture for long periods. Avoid bending;
- do not stick labels onto or write on the recorded surfaces of CDs;
- to remove a CD from its case, press in the centre and lift the disc out by holding carefully around the edges;
- always hold CDs by the edges. Never touch the surface;
- new CDs may be rough around the edges. When these discs are used, the radio may not play correctly.
- do not use CDs that are scratched, cracked or deformed etc. The use of such discs could lead to malfunction or damage.

- Electrical symbols	1
- Explanation for reading wiring diagram	4
- Wiring diagrams	5
- Connector block	82
- Key	141





55.

DESCRIPTION	Marea-Marea Weekend			
		 a.t.	 JTD	
Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light - Number plate lights (polyelliptic headlamps)	5	5	5	5
Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light - Number plate lights (parabola headlamps)	7	7	7	7
Fog lights - Rear fog lights	9	9	9	9
Direction indicators and warning light (with alarm) - Hazard warning lights - Brake lights (with check) - Reversing lights	11	11	11	11
Direction indicators and warning light (without alarm) - Hazard warning lights - Brake lights (without check) - Reversing lights	13	13	13	13
Fiat Marea Car interior lighting - symbol lighting	15	15	15	15
Fiat Marea Weekend Car interior lighting - symbol lighting	17	17	17	17
Radio system - Cigar lighter	19	19	19	19
Front electric windows	21	21	21	21
Rear electric windows	23	23	23	23
Fiat CODE device and warning light	25	25	25	25
Alarm/door check	27	27	27	27
Central locking	29	29	29	29
Heated, electrically adjustable door mirrors	31	31	31	31

55.





































DESCRIPTION	Marea-Marea Weekend			
		 a.t.	 JTD	
Predisposition for car phone and TELEPASS	33	33	33	33
Electric sun-roof	35	35	35	35
Headlamp alignment corrector	37	37	37	37
Adjustable, heated front seats	39	39	39	39
Air bag and pretensioners and failure warning light	41	41	41	41
Air bag with side bag and pretensioners and failure warning light	43	43	43	43
Windscreen wash/wipe – Rear wash/wipe – Horns – Heated rear window – Headlamp washer	45	45	45	45
Instrument panel connections	47	49	47	47
Check panel/door check connections	—	—	—	—
Thermostatically-adjustable climate control system/heater	51	51	53	55
Additional heater	—	—	57	—
Versions with climate control Engine cooling	59	59	61	63
Versions without climate control Engine cooling	65	65	61	—

55.

DESCRIPTION	Engine types			
	 1596	 1596 c.a.	 1596 JTD	 1998
Anti-locking braking system (ABS) and failure warning light	67	67	67	67
Starting - Electronic ignition and injection - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter	69	69	—	71
Starting - Electronic injection - Recharging and warning light - Low engine oil pressure warning light - Heater plugs warning light - Injection system failure warning light - Fuel preheating	—	—	73	—
Starting - EGR control - Injection control - Heater plugs and warning light - Recharging and warning light - Low engine oil pressure warning light	—	—	—	—
Automatic transmission – System failure warning light	—	75	—	—
Diagnostic sockect connections	77	77	77	77
Preparation for TAXI	79	79	79	79





































N.B. The numbers in the table correspond to the page number of the electrical system in the manual

Electrical symbols

	Position		Choke		Switch discharge
	Main beams		Water in fuel filter		Dipped beams
	Heated seat		Heater plugs warning light		Central locking direction indicators signal
	Seat belts		Turbocharger pressure		Horns
	Heated rear windscreen		Rear fog lamps		Left direction indicator
	Handbrake applied and low brake fluid level		Fog light		Right direction indicator
	ABS		Brake pad wear		Engine cooling
	Hazard warning lights		Turbocharger pressure		Windscreen wiper
	Direction indicator		Automatic transmission fluid temperature		Electronic sun-roof
	Handbrake applied and low brake fluid level		Speed limits		Catalytic converter temperature
	Recharging		Fuel level		Resistance
	Engine oil pressure		Engine coolant temperature		Diode

55.

Electrical symbols

	Warning light		Trip computer control		Differential lock
	Bulb		Electronic injection		Automatic transmission fluid temperature
	Fuse		Engine oil level		Temperature
	Switch open		Brake fluid level (Japanese Version)		Antitheft device
	Selector switch		Doors ajar		Electrically operated windows
	Coil control switch (relay)		Central locking		Earth
	Engine		Controlled damping suspension Sport Function		Number plate lights
	Rear wiper		Transistor		Pulse generator (timed operation)
	Headlamp washer		Air-bag		Analogue clock
	Windscreen wash/wipe		ABS (Japanese version)		Digital clock
	Rear wash/wipe		Car brake failure		Speedometer
	Engine oil pressure		Windscreen wiper		Rev counter

Electrical symbols



Digital speedometer



Digital rev counter



Digital fuel level



Analogue fuel level



Analogue engine coolant temperature



Economy gauge



Digital engine coolant temperature



Engine oil temperature




Engine oil pressure gauge



Voltmeter

55.

Explanation for reading wiring diagram



4A004N01

Key to references

A Component code

B Connector code


C Colour code

D Connection number of ways

E Connection number of ways

F Ultrasound welding taped in cable loom

Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light - Number plate lights
(polyelliptical headlamps)




* Variant for Marea Weekend

** Variant for C.A.

• Wire not connected





55.



Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light -Number plate lights (Polyelphoptical headlamps)


Component key

- | | |
|---|--|
| 1 Left front light cluster | 17 Right rear light cluster |
| 2 Right front light cluster | 18 Left rear earth |
| 3 Power fusebox | 19 Right rear earth |
| 4 Junction unit: | 2 Left facia earth |
| 5 Dipped headlamps relay | 42 Right facia earth |
| 6 Instrument panel | 236 Connection between rear cables and tail-gate |
| 7 Stalk unit | 310 Connection bridge |
| 8 Left front earth | |
| 9 Right front earth | |
| 10 Engine battery earth | |
| 11 Battery | |
| 12 Ignition switch | |
| 13 Connection between right/left front cables | |
| 14 Left number plate light bulb | |
| 15 Right number plate light bulb | |
| 16 Left rear light cluster | |



(*) The cables involved in the wiring diagram are marked with an asterisk.


Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light - Number plate lights
(Reflector headlamps)



* Variant for Marea Weekend

** Variant for C.A.

4F007ML01




Side lights and warning light - Dipped headlamps - Main beam headlamps and warning light -Number plate lights (Reflector headlamps)

Component key


- | | |
|---|--|
| 1 Left front light cluster | 17 Right rear light cluster |
| 2 Right front light cluster | 18 Left rear earth |
| 3 Power fusebox | 19 Right rear earth |
| 4 Junction unit: | 22 Left facia earth |
| 5 Dipped headlamps relay | 42 Right facia earth |
| 6 Instrument panel | 236 Connection between rear cables and tail-gate |
| 7 Stalk unit | 310 Connection bridge |
| 8 Left front earth | |
| 9 Right front earth | |
| 10 Engine battery earth | |
| 11 Battery | |
| 12 Ignition switch | |
| 13 Connection between right/left front cables | |
| 14 Left number plate light bulb | |
| 15 Right number plate light bulb | |
| 16 Left rear light cluster | |

55.



(*) The cables involved in the wiring diagram are marked with an asterisk.

Fog lights - Rear fog lamps




* Variant for Marea Weekend

** Variant for C.A.

4F009ML01

55.




Fog lights - Rear fog lamps


Component key

- 3 Power fusebox
- 4 Junction unit:
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 16 Left rear light cluster
- 17 Right rear light cluster
- 18 Left rear earth
- 19 Right rear earth
- 22 Left facia earth
- 28 Connection between facia/rear leads
- 29 Connection between front/fog lamp leads
- 30 Left foglamp
- 31 Right foglamp
- 32 Fog lights relay
- 34 Switch control unit
- 70 Connection between dashborad/front cables
- 310 Connection bridge


28A Facia/rear lead connection




30 Left fog light



31 Right fog light




70 Connection between dashborad/front cables



(*) The cables involved in the wiring diagram are marked with an asterisk.

Direction indicators and warning light (with alarm) - Hazard warning lights - Brake lights (with check) - Reversing lights




* Variant for Marea Weekend

** Variant for A.T.

• Automatic transmission: see specific wiring diagram

55.




Direction indicators and warning light (with alarm) - Hazard warning lights - Brake lights (with check) - Reversing lights

Component key


- | | |
|---|---|
| 1 Left front light cluster | 20 Left front side direction indicator |
| 2 Right front light cluster | 21 Right front side direction indicator |
| 3 Power fusebox | 22 Left facia earth |
| 4 Junction unit | 23 Hazard warning light control switch unit |
| 6 Instrument panel | 28 Connection between dashborad/rear cables |
| 7 Stalk unit | 40 Brake lights control switch |
| 8 Left front earth | 41 Additional brake light |
| 9 Right front earth | 55 Connection between front/engine cables |
| 10 Battery earth on engine | 100 Alarm electronic control unit |
| 11 Battery | 107 Door lock remote control receiver |
| 12 Ignition switch | 159 Reversing lights control switch |
| 13 Connection between right/left front cables | 236 Connection between rear cable and tail-gate |
| 16 Left tail light cluster | 310 Connection shunt |
| 17 Right tail light cluster | |
| 18 Left rear earth | |
| 19 Right rear earth | |

1 Left front light cluster




P4F818N02

13 Connection between right/left front cables




23A Hazard warning lights switch unit




4F012ML04

23B Hazard warning lights switch unit



P4F818N05

236 Connection between rear cable and tail-gate




4F012ML06

*The cables concerned are marked in the wiring diagram with an asterisk

55.

Direction indicators and warning light (without alarm) - Hazard warning lights - Brake lights (without check) - Reversing light




* Variant for Marea Weekend

** Variant for A.T.

• Automatic transmission: see specific wiring diagram

55.





Direction indicators and warning light (without alarm) - Hazard warning lights - Brake lights (without check) - Reversing light

Component key


- | | |
|---|---|
| 1 Left front light cluster | 20 Left front side direction indicator |
| 2 Right front light cluster | 21 Right front side direction indicator |
| 3 Power fusebox | 22 Left facia earth |
| 4 Junction unit | 23 Hazard warning lights switch unit |
| 6 Instrument panel | 28 Connection between dashboard/rear cables |
| 7 Stalk unit | 40 Brake light control switch |
| 8 Left front earth | 41 Additional brake light |
| 9 Right front earth | 55 Connection between front/engine cables |
| 10 Engine battery earth | 70 Connection between dashboard/front cables |
| 11 Battery | 107 Door lock remote control receiver |
| 12 Ignition switch | 159 Reversing lights control switch |
| 13 Connection between right/left front cables | 236 Connection between rear cable and tail-gate |
| 16 Left tail light cluster | 328 Hazard warning lights relay |
| 17 Right tail light cluster | |
| 18 Left rear earth | |
| 19 Right rear earth | |

1 Left front light cluster




P4F820N02

13 Connection between right/left front cables




4F014ML03

70 Connection between dashbord/front cables



4F014ML04

236 Connection between rear cable and tail-gate




4F014ML05

*The cables concerned are marked in the wiring diagram with an asterisk

Fiat Marea


Car interior lighting - Symbol lighting



** Variant for C.A.

4F015ML01

55.



4F016ML01


Fiat Marea
Car interior lighting - Symbol lighting

Component key

- 3 Power fusebox
- 4 Junction unit:
- 6 Instrument panel
- 7 Stalk unit
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 19 Right rear earth
- 22 Left facia earth
- 34 Switch control unit
- 35 Connection between dashboard/left front door cables
- 36 Connection between dashboard/right front door cables
- 42 Right facia earth
- 48 Radio receiver with clock
- 58 Control panel light dimmer
- 64 Glove compartment light bulb with built-in switch
- 65 Luggage compartment light
- 69 Cigar lighter
- 86 Connection between rear/left rear door cables


- 87 Connection between rear/right rear door cables
- 107 Door remote control receiver
- 108 Left rear door lock
- 109 Right rear door lock
- 110 Left front door lock
- 111 Right front door lock
- 243 Luggage compartment light button
- 244 Integrated services control system
- 245 Rear courtesy light
- 310 Connection bridge

35 Connection between dashboard/left front door cables



P4F822N02

36 Connection between dashboard/right front door cables




P4F822N03

(*) The cables involved in the wiring diagram are marked with an asterisk.


Fiat Marea Weekend

Car interior lighting - Symbol lighting



** Variant for C.A.

55.




Fiat Marea Weekend
Car interior lighting - Symbol lighting


Component key

- | | |
|---|---|
| 3 Power fusebox | 69 Cigar lighter |
| 4 Junction unit: | 86 Connection between rear/left rear door cables |
| 6 Instrument panel | 87 Connection between rear/right rear door cables |
| 7 Stalk unit | 107 Door remote control receiver |
| 10 Engine battery earth | 108 Left rear door lock |
| 11 Battery | 109 Right rear door lock |
| 12 Ignition switch | 110 Left front door lock |
| 18 Left rear earth | 111 Right front door lock |
| 19 Right rear earth | 236 Connection between rear cables and tailgate |
| 22 Left fascia earth | 243 Luggage compartment light button |
| 34 Switch control unit | 244 Integrated services control system |
| 35 Connection between dashboard/left front door cables | 264 Left rear car interior courtesy light |
| 36 Connection between dashboard/right front door cables | 265 Right rear car interior courtesy light |
| 42 Right fascia earth | 310 Connection bridge |
| 48 Radio receiver with clock | |
| 58 Control panel light dimmer | |
| 64 Glove compartment light bulb with built-in switch | |
| 65 Luggage compartment light | |

35 Connection between dashboard/left front door cables




36 Connection between dashboard/right front door cables



(*) The cables involved in the wiring diagram are marked with an asterisk.


Radio system - Cigar lighter



* Preparation for CD

** Variant for C.A.

55.




Radio system – Cigar lighter

Component key


- | | |
|---|--------------------------------------|
| 3 Power fusebox | 51 Speaker in left front door |
| 4 Junction unit: | 52 Speaker in right front door |
| 6 Instrument panel | 53 Left rear speaker |
| 10 Engine battery earth | 54 Right rear speaker |
| 11 Battery | 69 Cigar lighter |
| 12 Ignition switch | 248 Radio controls on steering wheel |
| 22 Left facia earth | 310 Connection bridge |
| 28 Connection between facia/rear cables | 320 Aerial power supply |
| 35 Connection between dashboard/left front door cables | 321 Connection for TELEPASS |
| 36 Connection between dashboard/right front door cables | |
| 42 Right facia earth | |
| 48 Radio receiver with clock | |
| 49 Left front tweeter speaker | |
| 50 Right front tweeter speaker | |

28B Facia/rear lead connection




P4F826N02

36 Connection between dashboard/right front door cables




P4F826N04

48A Radio receiver with clock



4F020ML04


48B Radio receiver with clock




4F020ML05

(*) The cables involved in the wiring diagram are marked with an asterisk.

Electric front windows



55.




P4F830N01

Electric front windows

Component key


- 3 Power fusebox
- 4 Junction unit:
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 19 Right rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 35 Connection between dashboard/left front door cables
- 36 Connection between dashboard/right front door cables
- 42 Right facia earth
- 73 Pushbutton unit for front electric windows on left arm-rest
- 74 Pushbutton unit for right front electric windows on right arm-rest
- 76 Left front electric window motor
- 77 Left front electric window motor
- 244 Integrated services control system
- 310 Connection bridge

35 Connection between dashboard/left front door cables



P4F830N02


36 Connection between dashboard/right front door cables




P4F830N03

(*) The cables involved in the wiring diagram are marked with an asterisk.

Rear electric windows



55.



P4F830N01


Rear electric windows

Component key

- 3 Power fusebox
- 4 Junction unit:
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 19 Right rear earth
- 28 Connection between facia/rear cables
- 35 Connection between dashboard/left front door cables
- 78 Pushbutton unit for rear electric windows on left front door
- 80 Rear electric window inhibition switch
- 82 Pushbutton unit for left rear electric windows on left front door
- 83 Pushbutton unit for right rear electric windows on right rear door
- 84 Left rear electric window motor
- 85 Right rear electric window motor
- 86 Connection between rear/left rear door cables
- 87 Connection between rear/right rear door cables


- 238 Rear electric windows control unit
- 244 Integrated services control system
- 310 Connection bridge

35 Connection between dashboard/left front door cables




P4F832N03

86 Connection between rear/left rear door cables



P4F832N03


87 Connection between rear/right rear door leads



P4F832N04


(*) The cables involved in the wiring diagram are marked with an asterisk.

FIAT CODE and warning light



4F025ML01

** Variant for C.A.




Fiat Code and warning light

Component key


- 3 Power fusebox
- 4 Junction unit:
- 6 Instrument panel
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 55 Front/engine lead connection
- 131 FIAT CODE electronic control unit
- 148 Earth for electronic injection
- 190 Injection/ignition electronic control unit (1998)
- 193 Earth for electronic injection
- 195 Ignition/injection control unit (1596)
- 199 FIAT CODE aerial
- 333 Injection control unit (JTD)

55.

3A Power fusebox




55 Connection between front/engine cables (1998)




131 Fiat-CODE electronic control unit

- 2 MN 6A *
- 3 RV n.d. *
- 4 N 55 *
1998
- 6 GV 190A *
1998
- 8 CB n.d. *
- N 193 *
1596
JTD
- G 333A *
JTD
- GV 195A *
1596




(*) The cables involved in the wiring diagram are marked with an asterisk.

Alarm device and door check



55.




4F028ML01

Alarm device and door check

Component key


- | | |
|---|---|
| 3 Power fusebox | 86 Connection between rear/left rear door cables |
| 4 Junction box | 87 Connection between rear/right rear door cables |
| 6 Instrument panel | 100 Alarm electronic control unit |
| 8 Left front earth | 105 Alarm deactivation switch |
| 10 Battery earth on engine | 106 Alarm switch on bonnet |
| 11 Battery | 107 Door lock remote control receiver |
| 12 Ignition switch | 108 Left rear door lock |
| 18 Left rear earth | 109 Right rear door lock |
| 19 Right rear earth | 110 Left front door lock |
| 22 Left facia earth | 111 Right front door lock |
| 28 Connection between facia/rear leads | 236 Connection between rear cable and tail-gate |
| 34 Switch control unit | 243 Luggage compartment light control button |
| 35 Connection between dashboard/left front door cables | 310 Connection shunt |
| 36 Connection between dashboard/right front door cables | 375 Standard tester input |
| 42 Right dashboard earth | |
| 70 Connection between dashboard/front cables | |

35 Connection between dashboard/left front door cables




P4F383N03

87 Connection between rear/right rear door cables




P4F838N03

100A Alarm electronic control unit




4F028ML04


100B Alarm electronic control unit



Central locking



55.




Central locking

Component key


- 3 Power fusebox
- 4 Junction unit:
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 35 Connection between dashboard/left front door cables
- 36 Connection between dashboard/right front door cables
- 42 Right facia earth
- 70 Connection between dashborad/front cables
- 86 Connection between rear/left rear door cables

- 87 Connection between rear/right rear door cables
- 100 Alarm electronic control unit
- 107 Door remote control receiver
- 108 Left rear door lock
- 109 Right rear door lock
- 110 Left front door lock
- 111 Right front door lock
- 236 Connection between rear cables and tail-gate
- 244 Integrated services control system
- 261 Tailgate locking/unlocking actuator
- 310 Connection bridge

35 Connection between dashboard/left front door cables




36 Connection between dashboard/right front door cables




(*) The cables involved in the wiring diagram are marked with an asterisk.

Electrically adjustable, heated rear view mirrors



55.




P4F842N01

Electrically-adjustable, heated door mirror

Component key


- 3 Direction indicator
- 4 Junction unit:
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 19 Right rear earth
- 28 Connection between facia/rear cables
- 35 Connection between dashboard/left front door cables
- 36 Connection between dashboard/right front door cables
- 42 Right facia earth
- 66 Control panel for electrically adjustable external rear view mirrors
- 67 Left door mirror
- 68 Right door mirror
- 310 Connection bridge

35 Connection between dashboard/left front door cables



P4F842N02


36 Connection between dashboard/right front door cables




P4F842N03

* The cables involved in the wiring diagram are marked with an asterisk.

Preparation for car phone and TELEPASS



55.




4F034ML01

Preparation for car phone and TELEPASS

Component key


- 3 Power fusebox
- 4 Junction unit:
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 19 Right rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 42 Right facia earth
- 48 Radio receiver with clock
- 69 Cigar lighter
- 310 Connection bridge
- 319 Connection for car phone
- 321 Connection for TELEPASS
- 332 Ignition activated power relay

3D Power fusebox




4F034ML02

28A Facia/rear lead connection




4F034ML03

319 Connection for car phone



P4F844N09


321 Connection for TELEPASS



P4F844N05

* The cables involved in the wiring diagram are marked with an asterisk.

55.




P4F846N01

Electric sun-roof

Component key


- 3 Direction indicator
- 4 Junction unit
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 70 Connection between dashbord/front cables
- 92 Sun roof cables connection
- 93 Sun roof control unit
- 244 Integrated services control system
- 332 Ignition activated power relay

3D Power fusebox




4F036ML02

28C Facia/rear lead connection




P4F846N03

92A Electric sun-roof lead connection



P4F846N04


244C Integrated services control system




P4F846N05

* The cables involved in the wiring diagram are marked with an asterisk.

Headlamp alignment corrector





Headlamp alignment corrector

Component key

- 3 Direction indicator
- 4 Junction unit
- 5 Dipped headlamps relay
- 7 Stalk unit
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 13 Connection between right/left front cables
- 42 Right facia earth
- 43 Electric actuator for left headlamp alignment corrector
- 44 Electric actuator for right headlamp alignment corrector
- 45 Headlamp alignment control unit
- 310 Connection bridge

55.

5 Dipped headlamps relay feed

4F038ML02

7B Steering column switch unit

4F038ML03

13 Connection between right/left front cables

4F038ML04

44 Electric actuator for right headlamp alignment corrector


P4F848N05


45 Headlamp alignment control unit

P4F848N06

* The cables involved in the wiring diagram are marked with an asterisk.

Adjustable, heated front seats





P4F850N01


Adjustable, heated front seats

Component key

- 3 Direction indicator
- 4 Junction unit
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 19 Right rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 134 Connection between rear/driver's heated seat cables
- 135 Connection between rear/passenger heated seat cables
- 322 Seat height adjustment connection
- 323 Seat lumbar adjustment connection
- 332 Ignition activated power relay


55.

3D Power fusebox




4F040ML02

28C Facia/rear lead connection



P4F850N03


332 Ignition activated power relay.



P4F850N04

* The cables involved in the wiring diagram are marked with an asterisk.

Air Bag, pretensioners and failure warning light




** Variant for C.A.

(●) Where passenger Air Bag is fitted

4F041ML01

55.




4F042ML01

Air Bag, pretensioners and failure warning light

Component key


- 3 Power fusebox
- 4 Junction unit
- 6 Instrument panel
- 10 Engine battery earth
- 11 Battery
- 70 Connection between dashborad/front cables
- 114 Air bag electronic contol unit
- 115 Passenger's Air Bag
- 116 Driver's Air Bag
- 117 Airbag/facia lead connections
- 231 Clock spring connector
- 239 Air Bag/left pretensioner cables connection
- 240 Air Bag/right pretensioner cables connection
- 241 Left pretensioner
- 242 Right pretensioner
- 354 Air Bag earth
- 375 Standardized diagnostic socket

3D Power fusebox




4F042ML02

117 Air Bag/facia cables connection




4F042ML03

115 Passenger Air Bag



P4F852N04


116 Driver's Air Bag



P4F852N05

* The cables involved in the wiring diagram are marked with an asterisk.

55.




4F044ML01

Air Bag with Side Bag and pretensioners and failure warning light

Component key


- 3 Power fusebox
- 4 Junction unit
- 6 Instrument panel
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 70 Connection between dashboard/front cables
- 114 Air bag electronic control unit
- 115 Passenger's Air Bag
- 116 Driver's Air Bag
- 117 Airbag/facia lead connections
- 231 Clock spring connector
- 239 Air Bag/left pretensioner cables connection
- 240 Air Bag/right pretensioner cables connection
- 241 Left pretensioner
- 242 Right pretensioner
- 352 Left side bag connection
- 353 Right side bag connection
- 354 Air Bag earth
- 355 Pretensioners connection
- 356 Left side bag sensor
- 357 Right side bag sensor
- 358 Left side bag
- 359 Right side bag
- 375 Standardized diagnostic socket

3D Power fusebox




4F044ML02

117 Connection between Air Bag/dashboard cables




4F044ML03

356 Left side bag sensor



P4F854N04


358 Left side bag



P4F854N05

* The cables involved in the wiring diagram are marked with an asterisk.


Windscreen wash/wipe - Rear wash/wipe - Horns - Heated rear window - Headlamp washers



4F045ML01

• Variants for Marea Weekend

55.




Windscreen wash/wipe - Rear wash/wipe - Horn - Heated rear window - Headlamp washers

Component key


- | | |
|---|---|
| 3 Power fusebox | 34 Switch control unit |
| 4 Junction unit | 39 Heated rear window |
| 7 Stalk unit | 46 Left low tone horn |
| 8 Left front earth | 47 Right high tone horn |
| 9 Right front earth | 97 Headlamp washer pump |
| 10 Engine battery earth | 98 Headlamp washer intermittence |
| 11 Battery | 120 Connection for air conditioning unit cables |
| 12 Ignition switch | 127 Connection between front left cable/cable on relay holder bracket |
| 13 Connection between right/left front cables | 236 Connection between rear cables and tail-gate |
| 18 Left rear earth | 244 Integrated services control system |
| 19 Right rear earth | 253 Air conditioner control unit |
| 22 Left facia earth | |
| 24 Windscreen wiper motor | |
| 25 Front/rear washer pump | |
| 26 Rear wiper motor | |
| 28 Connection between facia/rear cables | |

13 Connection between right/left front cables



28A Facia/rear lead connection

Instrument panel connections




A.T. version: see specific wiring diagram

--- Variant from January 2001

4F047M102

55.




Instrument panel connections

Component key

- 3 Power fusebox
- 4 Junction unit
- 6 Instrument panel
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 55 Connection between front/engine cables
- 56 Fuel level gauge control unit
- 70 Connection between facia/front leads
- 88 Insufficient brake fluid level sensor
- 89 Left brake pad wear sensor
- 90 Switch indicating handbrake applied
- 137 Vehicle speed sensor
- 142 Switch indicating insufficient engine oil pressure
- 262 Seat belt warning light switch
- 334 Engine temperature twin sender unit
- 335 Sensor for detecting water in diesel filter

6A Instrument panel


1	BV 95	12	VB 333A	JTD
2	BN 88 *	12	VB 190A	1998
3	BR 89A *	12	VB 195A	1596
4	CL 333A	13	AG n.d. *	
5	MN 131B	14	CN 55 *	1596
6	LN 333A	14	CN 55C *	1998 JTD
7	HN 55	15	HB 55	
8	HG 55 *	16	HL 70	
9	LN 190A	17	HM 55 *	1596
9	LN 195A	17	HM 55C *	1998 JTD
10	RV 95	18	L 190A	1998
11	GN 195A	18	L n.d.	JTD
11	GN 190A	18	L 195A	1581




6B Instrument panel

1	RG 4J	15	H 70
2	RV n.d.	16	CN n.d.
3	RV n.d.	18	GR 58
4	C 117	19	N 22 *
5			

instrument panel connections (C.A. version)



55.




4F050ML01

Instrument panel connections (C.A. version)

Component key


- 3 Direction indicator
- 4 Junction unit
- 6 Instrument panel
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 18 Left rear earth
- 22 Left facia earth
- 28 Connection between facia/rear cables
- 55 Connection between front/engine cables
- 56 Fuel level gauge control unit
- 70 Connection between dashborad/front cables
- 88 Insufficient brake fluid level sensor
- 89 Left brake pad wear sensor
- 90 Switch signalling handbrake applied
- 137 Vehicle speed sensor
- 142 Switch signalling insufficient engine oil pressure
- 262 Seat belt warning light switch
- 334 Dual engine temperature sending unit

6A Instrument panel




4F050ML02

6B Instrument panel




4F050ML03


28A Facia/rear lead connection



Climate control system/heater with thermostatic adjustment (1596)



55.




Climate control system/heater with thermostatic adjustment (1910 JTD)

Component key

- | | |
|---|--|
| 3 Power fusebox | 209 Air intake flap control actuator |
| 4 Junction unit | 211 Frost sensor |
| 6 Instrument panel | 233 Thermal relay on engine coolant pump |
| 9 Right front earth | 244 Integrated services control system |
| 10 Engine battery earth | 253 Air conditioner control unit |
| 11 Battery | 254 Climate control system controls with interior temperature sensor |
| 12 Ignition switch | 255 Electronic speed variator for climate control fan |
| 13 Connection between right/left front cables | 256 Air mixing control actuator |
| 28 Connection between facia/rear cables | 258 Treated air temperature sensor |
| 34 Switch control unit | 259 Required temperature adjustment solenoid |
| 36 Connection between dashboard/right front door cables | 260 MAX-DEF microswitch |
| 68 Right door mirror | 333 Injection control unit (JTD) |
| 70 Connection between dashborad/front cables | 334B I.E. protective fuse (JTD) |
| 120 Connection for air conditioning unit cables | 365 4-stage pressure switch |
| 124 Air condiitoning compressor control relay | 375 Standardized diagnostic socket |
| 127 Connection between front left cable/cable on relay holder bracket | |
| 147 Air conditioner compressor | |
| 150 I.E. system relay feed | |
| 202 Heater/air conditioner unit control symbol lighting bulbs | |
| 206 Climate control system fan | |
| 207 Fan speed adjustment switch | |


36

Connection between dashboard/right front door cables




120

Connection for air conditioning unit cables



127

55.




4F056ML01

Climate control unit/heater with thermostatic control (1998)


Component key

- | | |
|---|--|
| 3 Power fusebox | 209 Air intake flap control actuator |
| 4 Junction unit | 211 Frost sensor |
| 6 Instrument panel | 222 Earth for air conditioning system |
| 10 Engine battery earth | 244 Integrated services control system |
| 11 Battery | 253 Air conditioner control unit |
| 12 Ignition switch | 254 Climate control system controls with interior temperature sensor |
| 28 Connection between facia/rear cables | 255 Electronic speed variator for climate control fan |
| 34 Switch control unit | 256 Air mixing control actuator |
| 36 Connection between dashboard/right front door cables | 258 Treated air temperature sensor |
| 55 Connection between front/engine cables | 259 Required temperature adjustment solenoid |
| 68 Right door mirror | 260 MAX-DEF microswitch |
| 70 Connection between dashbord/front cables | 365 4-stage pressure switch |
| 120 Connection for air conditioning unit cables | 375 Standardized diagnostic socket |
| 124 Air conditioning compressor control relay | |
| 127 Connection between front left cable/cable on relay holder bracket | |
| 147 Air conditioner compressor | |
| 190 Injection/ignition electronic control unit (1998) | |
| 202 Heater/air conditioner unit control symbol lighting bulbs | |
| 206 Climate control system fan | |
| 207 Fan speed adjustment selector | |


36 Connection between dashboard/right front door cables



Additional heater (JTD)



55.



Additional heater (JTD)


Component key

- 3 Power fusebox
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 326 Additional heater control unit
- 333 Injection control unit (JTD)
- 346 Additional heater relay
- 347 Additional heater relay
- 348 Additional heater remote control switch
- 349 Additional heater protective fuse
- 350 Additional heater sensor
- 351 Additional heater spark plug


55 Front/engine lead connection

JTD	1	N n.d.	16	BV 55	48	BR 375	76	ZB 291
	2	N n.d.	17	CR 377	49	VB 6A	77	GN 291
	3	N n.d.	18	MG 127	51	BN 127	78	ZN 291
	4	R n.d.	19	AB 127	52	B 127	79	A 291
	5	RN n.d.	20	AG 127	58	CB n.d.	80	MB 291

Version with climate control
Engine cooling (1596)




55.




- Version with climate control
Engine cooling (1596)
- Component key
- 3 Power fusebox
 - 8 Left front earth
 - 10 Engine battery earth
 - 11 Battery
 - 12 Ignition switch
 - 122 Engine cooling fan low speed relay feed
 - 123 Engine cooling fan high speed relay feed
 - 127 Connection between left front cable/cable on relay holder bracket
 - 129 Engine cooling fan protection power fuse
 - 154 Engine cooling fan
 - 170 Resistance for engine cooling fan
 - 195 Injection/ignition electronic control unit (1596)
 - 365 4-stage pressure switch


3A Power fusebox




122 Engine cooling fan low speed relay




123 Engine cooling fan high speed relay



127 Connection between front left cable/cable on relay holder bracket




Engine cooling (1910 JTD)



--- Version without air conditioning

55.




4F062ML01

Engine cooling (1910 JTD)


Component key

- 3 Power fusebox
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 22 Left facia earth
- 122 Engine cooling fan low speed relay feed
- 123 Engine cooling fan high speed relay feed
- 127 Connection between front left cable/cable on relay holder bracket
- 128 Connection between front/radiator cables
- 129 Engine cooling fan protective power fuse
- 154 Engine cooling fan
- 170 Resistance for engine cooling fan
- 333 Injection control unit (JTD)
- 365 Pressostato a 4 livelli
- 369 Engine cooling fan remote control switch

3A Power fusebox



55.




Version with climate control
Engine cooling (1998 engine)


Component key

- 3 Power fusebox
- 8 Left front earth
- 10 Engine battery earth
- 11 Battery
- 12 Ignition switch
- 22 Left facia earth
- 122 Engine cooling fan low speed relay feed
- 123 Engine cooling fan high speed relay feed
- 127 Connection between front left cable/cable on relay holder bracket
- 129 Engine cooling fan protection power fuse
- 154 Engine cooling fan
- 170 Resistance for engine cooling fan
- 190 Injection/ignition electronic control unit (1998)
- 365 4-stage pressure switch


3A Power fusebox




122 Engine cooling fan low speed relay




123 Engine cooling fan high speed relay



Version without climate control
Engine cooling (petrol engine)




55.




- Version without climate control
Engine cooling (petrol engine)
- Component key
- 3 Power fusebox
 - 8 Left front earth
 - 10 Engine battery earth
 - 11 Battery
 - 12 Ignition switch
 - 122 Engine cooling fan low speed relay
 - 127 Connection between front left cable/cable on relay holder bracket
 - 129 Engine cooling fan protection power fuse
 - 154 Engine cooling fan
 - 190 Injection/ignition electronic control unit (1998)
 - 195 Ignition/ injection control unit (1596)

127 Connection between front left cable/cable on relay holder bracket

1998






Anti-locking braking system (ABS) and failure warning light


- Component key
- 3 Power fusebox
 - 4 Junction unit:
 - 6 Instrument panel
 - 8 Left front earth
 - 10 Engine battery earth
 - 11 Battery
 - 12 Ignition switch
 - 40 Brake lights control switch
 - 88 Insufficient brake fluid level sensor
 - 95 Connection between front cables/anti-lock brakes A.B.S.
 - 96 60A fuse protecting anti-lock brakes (A.B.S.)
 - 174 Power earth for A.B.S.
 - 176 Diagnostic socket for A.B.S.
 - 177 Sensor on left front wheel (A.B.S.)
 - 178 Sensor on left rear wheel (A.B.S.)
 - 179 Sensor on right front wheel (A.B.S.)
 - 180 Sensor on right rear wheel (A.B.S.)
 - 181 Electro-hydraulic control unit
 - 375 Standardized diagnostic socket

55.

3A Power fusebox



95 Connection between front cables/anti-lock brakes A.B.S. leads



181 A.B.S. hydraulic control unit

9	M 180 *	18
---	---------	----

