LANCIA



LANCIA k

3rd Volume

Workshop Manual


COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A.
D.M.C. - M.P.S.
Servizi Post Vendita - Assistenza Tecnica
10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5
Publication no. 506.475/12 - Aprile 1996 - 400
Printed in Italy - Tip. Stampart - TORINO
order no. 60444236



Update for "LANCIA K 1st - 2nd - 3rd volume" Manuals - sec. 00-10-44-55-70 (Print no. 506.475/19) (VIII-97) order n°. *604.45.103*

This booklet is composed, in order, of the following pages:

- Summary for the 1st volume replaces the one for the appropriate manual
- 13 sheets which replace those in section 00 of the manual
- 1 sheet which replaces the one in section 00 of the manual for the 1998 20v version with automatic transmission.
- 1 sheet which replaces the one in section 10 dealing with the removing-refitting of the 1998
 20v 2446 20v version
- 2 sheets which replace those in section 44 of the manual
- 1 sheet which replaces the one in section 44 dealing with the 96 range versions
- Summary for the 2nd volume which replaces the one for the appropriate manual
- 2 sheets which replace those in section 55 of the manual
- 1 sheet to be inserted in section 55 of the manual
- An index for section 55 for the LANCIA k 96 range wiring diagrams which replaces the one in the manual
- 4 sheets to be inserted in section 55 for the LANCIA k 96 range wiring diagrams
- An index for section 70 which replaces the one in the manual
- 1 sheet to be inserted in section 70 of the manual
- A Summary for the 3rd volume which replaces the one in the manual
- 7 sheets which replace those in section 00 of the LANCIA k SW
- 1 sheet which replaces the one in section 44 of the LANCIA k SW
- 5 sheets which replace those in section 00 of the LANCIA k Coupé
- An index and pages for section 55 of the LANCIA k Coupé dealing with the version with exhaust gas lights
- An index for section 70 for the LANCIA k Coupé which replaces the one in the manual
- 5 sheets which replace those in section 70 dealing with the LANCIA k Coupé

3U07SV

SERVICE MANUAL COMPOSITION

At present, June 1997, the LANCIA k 3rd volume manual is composed of the following booklets:

Print N°	Sections	Page Nos.	Versions	Comments					
	00	1÷36		Introduction - Technical data					
506.475/12 With binder (IV/96)	44	1÷10	LANCIA k SW	Nivomat self-levelling suspension					
	55	1÷7	LANCIA K 3VV	Electrical equip. wiring diagrams					
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and the environment - Bodyshell alignment - Replacing structural body panels - Adjustment of moveable parts					
	00	3÷14 21÷26		Technical Data Update					
506.475/15 (VI/96)	44	11÷16	Removing-refitting rear suspension spring - shock absorber assembly						
		1÷14	LANCIA k SW	Electrical equipment					
	55	1÷19		Completion of wiring diagrams					
	70	1÷55		Removing-refitting Replacing body panels					
	00	21÷24	LANCIA L CIAI	Technical Data Update					
	55	Index 14/1÷14/4 17÷18	LANCIA k SW	Wiring diagrams Update: Radiotelephone					
	00	÷ 1÷31		Introduction - Technical data					
		1÷14	Electrical equipment Lig Control units-Relays-Fuses						
	55	1÷39	LANCIA k Coupé	Electrical equip. wiring diagram					
	70	1÷27		Introduction-Safety-Bodyshell-Ecology and the environment-Bodysh alignment- Replacing structural bo panels- Adjustment of moveable par					
		1÷68		Removing-refitting Replacing body panels					

Print N°	Sections	Page Nos.	Versions	Comments				
	00	1÷2 3÷4 5÷6 7÷8 17÷18 23÷24 35÷36	LANCIA k SW	Update: Technical data				
	44	15÷16		Update: Nivomat self-levelling suspension				
506.475/19 (VI/97)	00	1÷2 3÷4 7÷8 21÷22 29÷30		Update: Technical data				
	55	1÷14	LANCIA k Coupé	Exhaust gas headlamps Automatic headlamp alignment device				
	70	19÷28		Update: front seats				

3110653

SERVICE MANUAL COMPOSITION

At present, June 1996, the LANCIA k 3rd volume manual is composed of the following booklets:

Print No.	Sections	Page Nos.	Versions	Comments						
	00	1÷36		Introduction - Technical data						
506.475/12	44	1÷10	LANCIA k SW	Nivomat self-levelling suspension						
With binder (IV/96)	55	1÷7	LANCIA K 3W	Electrical equip. wiring diagrams						
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and the environment - Bodyshell straightening - Replacing structural body panels - Adjusting moveable parts						
	00	3÷14 21÷26		Update - Technical data						
	44	11÷16		Removing-refitting rear suspension shock absorber-spring assembly						
506.475/15 (VI/96)	FF	1÷14	LANCIA k SW	Electrical equipment						
	55	1÷19		Wiring diagrams completion						
	70	1÷55		Removing-refitting Replacing body panels						



3U06SV

SERVICE MANUAL COMPOSITION

At present, June 1996, the LANCIA k 3rd volume manual is composed of the following booklets:

Print No.	Sections	Page Nos.	Versions	Comments							
	00	1÷36		Introduction - Technical data							
506.475/12	44	1÷10	LANCIA k SW	Nivomat self-levelling suspension							
With binder (IV/96)	55	1÷7	LANCIA R SVV	Electrical equip. wiring diagrams							
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and the environment - Bodyshell straightening - Replacing structural body panels - Adjusting moveable parts							
	00	3÷14 21÷26		Update - Technical data							
	44	11÷16		Removing-refitting rear suspension shock absorber-spring assembly							
506.475/15 (VI/96)	55	1÷14	LANCIA k SW	Electrical equipment							
	55	1÷19		Wiring diagrams completion							
	70	1÷55		Removing-refitting Replacing body panels							

Markey.

, () . ed Distance

......

SERVICE MANUAL COMPOSITION

At present, April 1996, the LANCIA k 3rd volume manual is composed of the following booklets:

Print No.	Sections	Page Nos.	Versions	Comments
	00	1÷36		Introduction - Technical data
FOC 475/42	44	1÷10	LANCIA I. CW	Nivomat self-levelling suspension
506.475/12 With binder (IV/96)	55	1÷6	LANCIA k SW	Diagrams: electrical equipment
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and environment - Bodyshell alignment - Replacing structural body panels - Adjustment of moveable parts

. 3 7 And the second s

3U07SV

SERVICE MANUAL COMPOSITION

At present, November 1997, the **LANCIA k 3rd volume** manual is composed of the following booklets:

Print N°	Sections	Page Nos.	Versions	Comments						
	00	1÷36		Introduction - Technical data						
506.475/12	44	1÷10	LANCIA k SW	Nivomat self-levelling suspension						
With binder (IV/96)	55	1÷7	LANCIA K SVV	Electrical equip. wiring diagrams						
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and the environment - Bodyshell alignment - Replacing structural body panels - Adjusting moveable parts						
	00	3÷14 21÷26		Update: Technical data						
	44	11÷16		Removing-refitting rear suspension spring - shock absorber assembly						
506.475/15 (VI/96)		1÷14	LANCIA k SW	Electrical equipment						
	55	1÷19		Completion of wiring diagrams						
	70	1÷55		Removing-refitting Replacing body panels						
	00	21÷24	LANCIA k SW	Update: Technical data						
	55	Index 14/1÷14/4 17÷18	E WORK OV	Wiring diagrams update: Ra- diotelephone						
	00	÷ 1÷31		Generalità - Dati tecnici						
506.475/13		1÷14		Impianto elettrico: Illuminazione- Centraline-Teleruttori-Fusibili						
(XII/96)	55	1÷39	LANCIA k Coupé	Schemi impianto elettrico						
	70	1÷27		Generalità-Sicurezza-Scocca-Ecologia e ambiente-Riquadratura scocca- Sos- tituzione lamierati strutturali- Registra- zione parti mobili						
		1÷68		Stacchi riattacchi Sostituzione lamierati						

Print N°	Sections	Page Nos.	Versions	Comments			
	00	1÷2 3÷4 5÷6 7÷8 17÷18 23÷24 35÷36	LANCIA k SW	Update: Technical data			
	44	15÷16		Update: Nivomat self-levelling suspension			
506.475/19 (VI/97)	00	1÷2 3÷4 7÷8 21÷22 29÷30		Update: Technical data			
	55	1÷14	LANCIA k Coupé	Gas headlamps Automatic headlamp alignment			
	70	19÷28		Update: front seats			
	00	1÷7	LANCIA k (all versions) '97 update	Technical data - Special tools - Tightening torques - Vehicle with C.530 gearbox			
506.475/20 (XI/97)			LANCIA k - k SW	Introduction - Technical data			
	21-27	1÷28	LANCIA k (all versions) '97 update	Removing-refitting C.530 gear- box - External gearbox controls (the procedure illustrated deals with the 2959 V6 24v version)			

311075

SERVICE MANUAL COMPOSITION

At present, February 1998, the **LANCIA k 3rd volume** manual is composed of the following booklets:

Print N°	Sections	Page Nos.	Versions	Comments						
	00	1÷36		Introduction - Technical data						
506.475/12	44	1÷10	LANCIA k SW	Nivomat self-levelling suspension						
With binder (IV/96)	55	1÷7	EAIVOIA K OVV	Electrical equip. wiring diagrams						
	70	1÷23		Introduction - Safety - Bodyshell - Ecology and the environment - Bodyshell alignment - Replacing structural body panels - Adjusting moveable parts						
	00	3÷14 21÷26		Update: Technical data						
F00 47F (4 F	44	11÷16		Removing-refitting rear suspension shock absorber - spring assembly						
506.475/15 (VI/96)		1÷14	LANCIA k SW	Electrical equipment						
	55	1÷19		Completion of wiring diagrams						
	70	1÷55	,	Removing-refitting Replacing body panels						
	00	21÷24	LANCIA k SW	Update: Technical data						
	55	Index 14/1÷14/4 17÷18	ZANCIA K SW	Wiring diagrams update: Radio phone						
	00	÷ 1÷31		Introduction - Technical data						
506.475/13		1÷14		Electrical equipment: Lighting- Control units-Relays-Fuses						
(XII/96)	55	1÷39	LANCIA k Coupé	Electrical equip. wiring diagrams						
	70	1÷27		Introduction-Safety-Bodyshell-Ecology and the environment-Bodyshell alignment- Replacing structural body panels- Adjusting moveable parts						
		1÷68		Removing-refitting Replacing body panels						

Cont'

Print N°	Sections	Page Nos	. Versions	Comments				
	00	1÷2 3÷4 5÷6 7÷8 17÷18 23÷24 35÷36	LANCIA k SW	Update: Technical data				
	44	15÷16		Update: Nivomat self-levelling suspension				
506.475/19 (VI/97)	00	1÷2 3÷4 7÷8 21÷22 29÷30		Update: Technical data				
	55	1÷14	LANCIA k Coupé	Exhaust gas headlamps Automatic headlamp alignmen device				
	70	19÷28		Update: front seats				
	00 1÷7		LANCIA k (all types) '97 update	Technical data - Special tools - Tightening torques - Vehicles with C.530 gearbox				
506.475/20 (XI/97)			LANCIA k - k SW	Introduction - Technical data				
	21-27	1÷28	LANCIA k (all types) '97 update	Removing-refitting C.530 gear- box - External gearbox controls (the procedure illustrated is for the 2959 V6 24v version)				
506.475/21		1÷72	LANCIA k					
(1/98)	55	1÷115	Integrated Bodywork System	Electrical equip. wiring diagrams				
	00	1÷2	LANCIA k '97 update	Update: Technical data				
506.475/22 (II/98)	55	27÷28 39	LANCIA k Coupé	Update: Key Wiring diagrams				
	70	21÷22	Entitoia k coupe	Update: Front seats				

3U04P\


This manual contains the main instructions for repairing and maintaining the LANCIA k SW.

The section **INTRODUCTION AND TECHNICAL DATA (00.)** has a dual function of introducing the model and supporting the remaining part of the manual. This section includes the tables of technical data and specific information relating to the sections in the remaining part of the manual.

The remaining sections (10. - 18. etc.) include descriptions of the repair operations.

This manual contains graphic representations and symbols in place of descriptions for mechanical components, operations and servicing.









For anything not dealt with in this manual, refer to the LANCIA k 1st and 2nd volume manuals (print nos. 506.475 and 506.475/01) and the updates.

THIS PUBLICATION HAS BEEN PRODUCED IN A LOOSE LEAF FORMAT TO FACILITATE THE OPERATION OF UPDATING THE MODEL.



When using chemical products stick closely to the instructions in the safety chart which the supplier must give to the consumer (for Italy in accordance with D.M. no. 46/1992)

Foreword

The LANCIA k SW is a two box 5 door vehicle with a load carrying structure, transversely mounted engine and front wheel drive.

The LANCIA k SW comes in 5 different versions.

The LANCIA k SW 2.0 is driven by a 1998 cc, 5 cylinder in line engine with 4 valves per cylinder, a BOSCH Motronic integrated electronic injection/ignition system and it develops a power output and 114 kW (1,55 CV).

The LANCIA k SW 2.0 t is driven by a 1998 cc, 4 cylinder in line engine, with 4 valves per cylinder, a BOSCH Motronic integrated electronic injection/ignition system, is supercharged by a Garrett turbocharger and develops a power output of 151 kW (205 CV)

The LANCIA k SW 2.4 is driven by a 2446 cc 5 cylinder in line engine with 4 valves per cylinder, a BOSCH Motronic integrated electronic injection/ignition system and develops a power output of 129 kW (175 CV)

The LANCIA k SW 3.0 is driven by a 2959 cc 6 cylinder in a 60° V formation engine with 4 valves per cylinder, a BOSCH Motronic integrated electronic injection/ignition system and develops a power output of 150 kW (204 CV)

The LANCIA k SW 2.4 td is driven by a 2387 cc 5 cylinderin line Diesel engine with electronically controlled indirect injection, supercharged by an IHI turbocharger and develops a power output of 91 kW (124 CV)

Graphic representations and symbols

	•
.	Removing Disconnect
<u>.</u>	Refitting Connect
_ R	Dismantling Disassembly
	Refitting Composition
•)	Tighten to torque
€) _α	Tighten to torque plus angle
	Fully tighten
•	Stake nut
	Adjustment Regulation
•	Visual inspection Check
\triangle	Warning
7	Lubricate Grease
LANCIA LANCIA	Replace Genuine spares
1	Bleed braking system
<u> </u>	Work surface Machined surface
→	Interference Force fit
	Distance to be measured Measurement – Check Thickness - Clearance
\longleftrightarrow	Rolling torque

→]		Inlet
()		Exhaust
=		Operation
	_	Tolerance Difference in weight
Û		Pre-loading
		Rotation
Q		Compression ratio
A		Selection Classes
>	Oversize Greater than Maximum	Undersize Smaller than . Idling
		No. of revs
= I = = I =		Ratio
har		Pressure
_ 		Temperature
<u>♣</u>		Temperature < 0°C Cold Winter
-		Temperature >0°C Hot Summer
©		Windscreen wiper with electric washer pump
		Rearscreen wiper
		with electric washer pump

•

e e	200	Second Second		- 25		and the same	September 1		19402							100					0.55			
22	111	-	. #	1 1	髓谱	1 編 1	2	1				1000	Sec.	SHIPS.	AU PA		en en	44	and the same	periors	1	**		
COM	1		AL.	a.l.		5. J.		4			s	1000	B .	額り	# :	4 4	1 1	118	12	報 瀬	13	H.	1 200	
							BRIE	100		garan.		飘跳	فالله		38.1	b		-	and the			44		22
逐。	× 3		الأست	3 0	4 - 1	11.	- 福田	16	78	1 13	. 4					3.50		\$245						200
- 1	Δľ	ä١	-2		1.2.	LL.	A.I		2			200												凞
						132	100						100	100	-3	H H	.18	7	F. W	2000		7. B	: 10	. 10
7	7	38	.11	1	4	1 200	S	988		28.		200	醤	100	97	3 4	₹. ቜ	7 .	/ Y	-			ŧ₩	
200	ary.	a 3	7,1	7.4	Æ B	불째	(P)			300	455	122				20								

ALLGEMEINES TECHNISCHE DATEN

GENERALITÀ DATI TECNICI

			
MOTEUR	ENGINE	MOTOR	MOTORE
EMBRAYAGE	СLUТСН	KUPPLUNG	FRIZIONE
BOITE DE VITESSES DIFFERENTIEL	GEARBOX DIFFERENTIAL	SCHALTGETRIEBE AUS- GLEICHGETRIEBE	CAMBIO DI VELOCITÀ DIFFERENZIALE
ARBRE DE TRANSMISSION	PROPELLER SHAFT	GELENKWELLE	ALBERO DI TRASMISSIONE
DIFFERENTIEL ARRIERE	REAR DIFFERENTIAL	HINTERES AUS- GLEICHGETRIEBE	DIFFERENZIALE POSTERIORE
FREINS	BRAKING SYSTEM	BREMSEN	FRENI
DIRECTION	STEERING	LENKUNG	STERZO
SUSPENSIONS ET ROUES	SUSPENSION AND WHEELS	AUFHÄNGUNGEN UND RÄDER	SOSPENSIONI E RUOTE
ORGANES SUBSIDIAIRES	AUXILIARY UNITS	ZUSATZ- EINRICHTUNGEN	ORGANI SUSSIDIARI
EQUIPEMENT ELECTRIQUE	ELECTRICAL EQUIPMENT	ELEKTRISCHE ANLAGE	IMPIANTO ELETTRICO
CARROSSERIE	BODYWORK	CAROSSERIE	CARROZZERIA

LANCIA k SW

Introduction and technical data

Index 00.

page

A CONTRACTOR OF THE				
	\mathbf{n}	P		
8 L 26 S	KU	1919	ION	

- Car exterior - Identification data - Performance-Fuel consumption - Weights - Dimensions - Capacities - Characteristics of Fiat Lubricant products	1 2 4 6 7 8
TECHNICAL DATA	
ENGINES (1998) 20v (1995) 16v turbo	
- Characteristics - Typical curves	10 11
ENGINE (2008) 24v	
- Characteristics - Typical curves	12 13
ENGINE TD	·
- Characteristics - Typical curves	14 15
CLUTCH	16
GEARBOX AND DIFFERENTIAL	17
AUTOMATIC GEARBOX - DIFFEREN-	
TIAL (Z.F.)	19
BRAKING SYSTEM	20
STEERING WHEELS	22
FRONT SUSPENSION	23 25
REAR SUSPENSION	25 26
ELECTRICAL EQUIPMENT	27
Starting	29
RechargingElectronic injection/ignition	32 34

COPYRIGHT FIAT AUTO


The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Tecnica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/12 - Aprile 1996 - 400 Printed in Italy - Tip. Stampart - TORINO order no. 60444236

0.00



3/4 front view



3/4 rear view

Copyright by Fiat Auto

Introduction **Identification data**


0.00

	CHACCIC	ENGINE	VERSION	GEAI	RBOX
	CHASSIS	ENGINE	VERSION	5 speed	automatic
1998 20v		838 A6.000	838 BG 1AA 07B 838 BG 1AA 07C(▲)	•	
2446 ₎ 20v		838 A2.000	838 BC 1AA 09 838 BC 1AA 09B(▲)	•	
1995 16v turbo	ZLA 838.000	838 A4.000	838 BB 1AA 08	•	
2387 TD		838 A7.000	838 BH 1AA 11(■) 838 BH 1AA 11B	•	
12959 24v		838 B.000	838 BD 11A 10		•

- (▲) Voluntary for Germany(■) Version for specific markets (France)


Vehicle type identification code and chassis manufacture number

Stamped on the floor panel of the passenger compartment, near the right front seat. Access is gained by lifting the appropriate flap.




P3U02AD01

0.00



P3U03AD02


Engine type and number



P3U03AD03

V.I.N. Plate (EEC regulations)

- A. Name of manufacturer
- Homologation number В.
- Vehicle type identification code C.
- Chassis manufacture number Maximum authorized weight of vehicle fully D. E.
- Maximum authorized weight of vehicle fully F. laden plus tow
- Maximum authorized weight on first axle G. (front)
- Maximum authorized weight on second axle Η. (rear)
- Engine type 1.
- Bodywork version code
- Spares number M.
- Correct value of smoke absorption coefficient (Diesel engines only)



Performance - Fuel consumption

00.0

	ENGINE TYPE	1998 20v	2446 20v	1995 16v turbo
	GEARBOX	999	999	0 0 0 2 0 0
	1 00	54	56	52
Speed kph		92	94	87
(average load)		136	139	143
		178	183	201
	006	205	212	230
	000	58	60	55
%	Maximum climable gradient fully laden		36	
	Urban	15,0	15,3	14,6
	Extra-urban	8,4	8,4	8,1
Fuel consumption directive 93/116/CE (litres/100 km)	Combined	10,8	11,0	105
CO2 exhaust emissions	(g/km)	258	263	252

The 93/116/CE directive fuel consumption figures have been defined in the course of homologation tests involving:

- an urban cycle which includes a cold start followed by a varied urban cycle simulation.
- an extra urban cycle which includes frequent acceleration in all gears simulating normal out of town usage. The speed varies between 0 and 120 kph.
- The average combined consumption includes 37% of the urban cycle and 63% of the extra urban cycle.

The type of journey, traffic conditions, driving styles, atmospheric conditions, trim level/equipment/accessories, whether a roof rack is fitted, the presence of special equipment and the general state of the vehicle can lead to fuel consumption figures which differ from those obtained through the above mentioned procedures. The CO₂ exhaust emissions (in g/km) are measured during the average combined cycle

Performance - Fuel consumption

00.0

	ENGINE TYPE	2959 V6	2387 TD
	GEARBOX	基	900
			32 - 37 (■)
Speed kph	200	_	55 - 62 (■)
(average load)		_	91 - 103 (■)
	000	max 218	129 - 144 (■)
	000		190 - 190 (■)
	000	_	34 - 40 (■)
%	Maximum climable gradient fully laden	36	37
	Urban	17,6	12,0 - 11,6 (■)
	Extra-urban	9,8	6,7 - 6,6 (■)
Fuel consumption direct 93/116/CE (litres/100 km)	Combined	12,7	8,6 - 8,4 (■)
CO2 exhaust emissions (g	/km)	304	230 - 224 (■)

(■) Version for specific markets (France)

The 93/116/CE directive fuel consumption figures have been defined in the course of homologation tests involving:

- an urban cycle which includes a cold start followed by a varied urban cycle simulation.
- an extra-urban cycle which includes frequent acceleration in all gears simulating normal out of town usage. The speed varies between 0 and 120 kph.
- The average combined consumption includes 37% of the urban cycle and 63% of the extra-urban cycle.

The type of journey, traffic conditions, driving styles, atmospheric conditions, trim level/equipment/accessories, whether a roof rack is fitted, the presence of special equipment and the general state of the vehicle can lead to fuel consumption figures which differ from those obtained through the above mentioned procedures.

The CO₂ exhaust emissions (in g/km) are measured during the average combined cycle

Weights


0.00

	ENGINE TYPE	1998 20v	20v	16v turbo	24v	(2087) TD
WEIGHTS (in kg)	GEARBOX	999	999	999	五	
WEIGHTS (III kg)		1510	1520	1550	1610	1555
+500		2090	2085	2105	2175	2120
		1180	1180	1180	1180	1180
Maximum permissible loads o les ■	n the ax-	1180	1180	1180	1180	1180
Maximum permissible load or	n the roof	100	100	100	100	100
Load on the tow hook (trabraking system)	iler with	90	90	90	90	90
	Trailer without braking system	500	500	500	500	500
	Trailer with braking system	1500	1500	1500	1500	1500

■ Loads which must never be exceeded

NOTE FOR VERSIONS WITH ACCESSORIES: in the presence of special equipment (non standard air conditioner, sun roof, trailer towing device), the empty weight increases and therefore the carrying capacity may decrease, in relation to the maximum permissible loads.

00.0



DIMENSIONS

Α	Front projection	947
В	Wheelbase	2700
С	Rear projection	1040
D	Maximum length	4687
E	Maximum height	1464
F	Front track	1530
G	Rear track	1527
Н	Maximum width	1826

The height E refers to an unladen car

Capacities

00.0

Consision	Capacities Unit		
Capacities		dm³(l)	(kg)
Petrol O.R. 95 (●)	1998 20v - 2446 20v 1995 16 v turbo - 2959 V6 24v	70	
Diesel	2387 td	70	-
50% + Division	1998 20v 2446 20v 1995 16v turbo 2387 td	8,3	_
H₂0 (▲) 11 🔆	Total capacity of 2959 6V 24v cooling system	9	-
Petrol engines:	1998 20v - 2446 20v	6,5	5,8
SELENIA 20 K	Total capacity 1995 16v turbo	7	6,25
(SAE 10 W/40)	2959 V6 24v	7,5	6,7
1 1 7 7	2387 td	7	6,25
Diesel engines:	1998 20v - 2446 20v	5,4 5*	4,85 4,45*
SELENIA Turbo Diesel	1995 16v turbo	5,5 5*	4,9 4,45*
(SAE 15 W/40)	Partial capacity 2959 V6 24v	6,9 6,5*	6,2 5,85*
	(periodic replacement) 2387 td	5,4 5*	4,85 4,45*
a = TUTELA 736 ZC 75 SYNTH 246	а	2	1,80
b = TUTELA I	2959 V6 24v	9,1	8,2 4,5**
a = TUTELA GI/A	1998 20v-2446 20v 1995 16v turbo-2387 TD	_	0,80
0	2959 V6 24v		1,80
b = TUTELA MRM2	b		0,080
TUTELA TOP 4 270 °C	Total capacity of braking system and hydraulically op. cle	- utch	0,5
AREXONS	3%	8	7
+ DP1	- 20°C 50% < - 20°C 100%	3	-

- (▲) distilled water
 (*) Engine sump only
 (**) Periodic replacement
- (•) Unleaded petrol only must be used

Characteristics of Fiat Lubricant products

00.0

Name of product	Description International designation	Application
SELENIA 20 K SAE 10 W/40	Semi-synthetic multigrade engine oil. Exceeds specifications ACEA A3-96/CCMC G5 and API SH	Temperature - 25°C ÷ 40°C
VS MAX SAE 15 W/40	Mineral based multigrade engine oil. Exceeds specifications API SG, CCMC-G4 and UNI 20153	Temperature - 15°C ÷ 40°C
SELENIA Turbo SAE 15 W/40 Diesel	Semisynthetic, multigrade engine oil. Exceeds specifications ACEA B3-96/CCMC PD2, API CD	Temperature - 15°C ÷ 40°C
VS MAX Diesel SAE 15 W/40	Multigrade, mineral based engine oil. Exceeds specifications API CD, CCMC and UNI 20153	Temperature - 15°C ÷ 40°C
TUTELA ZC 80S	SAE 80W EP oil. Satisfies standards MIL-L-2105 and API GL4	Manual gearboxes and differentials
TUTELA ZC 90	Non EP SAE 80 W/90 oil, for manual gearboxes, containing anti-wear additives.	Gearboxes and non hypoid differentials
TUTELA ZC 75 SYNTH	SAE 75 W EP synthetic oil. Satisfies standards API GL.4 and MIL-L-2105	Manual gearboxes and differentials
TUTELA W 90/M DA	Special SAE 80 W/90 EP oil for normal and self-locking differentials. Satisfies standards MIL–L–2105 D and API GL5	Hypoid differentials Self-locking differentials Steering boxes
TUTELA GI/A	"DEXRON II" type oil for automatic transmissions.	Automatic gearboxes Power assisted steering
TUTELA CVT Universal	Oil for continuous variation automatic transmissions.	Continuous variation automatic transmissions
TUTELA JOTA 1	Lithium soap based grease, consistency NLGI = 1	Greasing the vehicle except for components particularly exposed to water requiring special greases
TUTELA MRM2	Water-repellant, lithium soap based grease containing molybdenum disulphide, consistency $NLGI = 2$	Constant velocity joints
TUTELA MR3	Lithium soap based grease, consistency NLGI= 3	Wheel hub bearings, st. rod, various comps.
TUTELA PLUS 3 (240 °C)	Synthetic fluid, F.M.V.S.S. n° 116 DOT 3 ISO 4925, CUNA NC 956-01	Hydraulic brakes and hyd. op. clutches
TUTELA TOP 4 (270 °C)	Synthetic fluid, F.M.V.S.S. n° 116 DOT 4 ISO 4925, CUNA NC 956-01	Hydraulic brakes and hy- draulically op. clutches
К 854	Lithium soap based grease, consistency NLGI = 000, containing molybdenum disulphide	Rack and pinion steering boxes
SP 349	Special grease compatible with brake fluid	Load proportioning valve Load proportioning valve rod bush
Arexons DP1	Mix. of alcohol, H20 & surf. act. agents CUNA NC 956-11	To be used neat or diluted in windscreen washer systems
Paraflu ¹¹	Mono-ethylene glycol based anti-freeze for cooling system, CUNA NC 596 - 16	Cooling circuits Percentage to be used 50% up to - 35°C
Diesel Mix Arexons	Additive for diesel fuel with protective action for diesel engines	To be mixed with diesel fuel (25 cc per 10 litres)

00.10

HARACTERISTICS








CHARACTERISTICS			<u> </u>				
	Cycle		OTTO 4 stroke				
•	Timing	twir	shaft				
	Engine balancing	through 1 coun	ter-balance shaft	through 2 counter- balance shafts			
	Type of fuel system	Bosch Motronic M2.10 Bosch Motronic M2.10 integrated electronic injection/ignition		Bosch Motronic M2.7 electronic integrated injection/ignition			
	Number of cylinders	5 in	line	4 in line			
	Cylinder liner mm (bore)	82	83	84			
	Stroke mm	75,65	90,4	90			
	Capacity cc	1998	2446	1995			
- F - 9	Compression ratio	10,4±0,15	10±0,15	8±0,15			
Max pow	kW (CEE) (CV) (CEE)	114 (155)	129 (175)	151 (205)			
	rpm	6500	6100	5600			
Max torqu	daNm (CEE) (kgm) (CEE)	18,6 (19)	23 (23,5)	29,8 (30,4)			
, wax torq	rpm	4000	3750	2750			


Engine: typical curves

00.10










2446 20v



Typical engine curves


The power and torque curves illustrated can be obtained with the engine overhauled and run in (50 hours of operation) without a fan, with a silencer and air filter fitted at sea level.

00.10

CHARACTERISTICS



CHARACTERISTICS	.	
Cycle		OTTO 4 stroke
	Timing	2 camshafts for each cylinder head
	Type of fuel system	Bosch Motronic M3.7 injection/ignition
	Number of cylinders	6 in a 60° V
-Ø	Cylinder liner mm (bore)	93
	Stroke mm	72,6
	Capacity cc	2959
- F	Compression ratio	10 ± 0,15
Max power	kW (CEE) (CV) (CEE)	150 (204)
	rpm	6300
Max tore	daNm (CEE) (kgm) (CEE)	27 (27,5)
	rpm	4500



Typical power curves

The power curve illustrated can be obtained with the engine overhauled and run in (50 hours of operation), without a fan, with a silencer and air filter fitted, at sea level.


CHARACTERISTICS



f	T			
	Cycle	Diesel 4 stroke		
هند ا	Timing	single overhead camshaft		
	Engine balancing	through 1 counter-balance shaft		
	Type of fuel system	Indirect mechanical injection		
	Number of cylinders	5 in line		
Ø	Cylinder liner mm (bore)	82		
	Stroke mm	90,4		
	Capacity cc	2387		
= 9	Compression ratio	20,7 ± 0,5		
Max po	kW (CEE) (CV) (CEE) wer	91 (124)		
<u>/</u>	rpm	4000		
Max tor	daNm (CEE) (kgm) (CEE)	26,5 (27)		
	rpm	2000		

Engine: typical curves

00.10



Typical engine curves

The power curve illustrated can be obtained with the engine overhauled and run in (50 hours of operation), without a fan, with a silencer and air filter fitted, at sea level.

2446) 20v	1998 20v	1995 16v turbo	2387) TD
	Value	in mm	

<u></u>			Values	in mm		
Type	·	(dry, sing	gle plate		
6 8						
Operating mechanism			diaphrag	m spring		
Spring loading	daN	525	485	650	620	
Ø1 PO		228	228,6		235	
Lining	Ø2	155 155		55		
Distance between pedal i end of travel position an rest position	n d		132,7 ÷	138,7		
Clutch release			hydra	nulic	:	
Clutch pump operation	Ø		18,75 ((3/4")		
Operating cylinder	Ø		25,4	(1")		

Technical data


Gearbox and differential

00.21-27

			1998 20v	2446 20v	1995 16v turbo	2387 TD
				0.6	3 6	
					H	
GEARBOX		Type	C.503.5.23	C.503.5.23	C.503.5.29	C.503.5.29
, = - - - - - - - - - - - -	spring r (Porsch type)	ing le O		-	_	
Synchronizers	baulk ri type	ng O		96)	
00	helical toothed				6	
Gears	straight toothed			0 6 2 6		
			3,800	3,800	3,800	3,800
		<u> </u>	2,235	2,235	2,235	2,235
= -	0	့ စု ့ ၀၀၀	1,360	1,520	1,360	1,360
		000	0,971	1,156	0,971	0,971
Gear ratio		00 0	0,811	0,917	0,811	0,707
		000	3,545	3,545	3,545	3,545

DIFFERENTIAL

=		16/57	16/57	16/57	16/63 (3,937)
Crown	wheel & pinion reduction	(3,563)	(3,563)	(3,563)	(3,937)



00.21-27

GEARBOX DIFFERENTIAL		1998 20v	2446) 20v	1995 1 16v turbo	2387) TD
	H	13,539	13,539	11,910	14,961
- 1		7,963	7,963	6,911	8,799
, = <u>I</u> =	♀ ♀ 	4,860	5,430	4,840	5,354
		3,460	4,119	3,671	3,823
Ratio at the wheels	000 000	2,889	3,267	2,912	2,783
	999 60 6	12,631	12,631	11,259	13,957
Differential internal casing bearing		conical roller bearings			
Adjustment of bearing pre-loading ** LANCIA () mm	by shims 1,25 ÷ 1,60			
Bearing rolling torque		0,10 ÷	- 0,14		
Clearance between planet/sat. gears	0,10 ÷ 0,20				
Adjustment of clrnce btwn plan./sat. gears		by shims			
* LANCIA (0,10)	\		1,8 ÷		

00.21-27


Z.F. AUTOMATIC GEARBOX

ENGINE	2959 V69 24v
--------	-----------------

EARBOX		
Gears	<u>T</u>	0000
i i	(00000	2,579:1
, = =	00000	1,407:1
- T- 00 4	00800	1:1
Coornetics	00000	0,742:1
Gear ratios		2,882:1
= 8	Idler ratio	55/56 (0,982)
	rque nverter Ø mm	260
= <u> </u> = X	Ratio (multiplication) of engine torque	2,296
Quantity of oil	total, with gearbox converter, radiator and pipes empty	8,2 kg
of oil GI/A	replacement only	4,5 Kg

DIFFERENTIAL

	Crown wheel and pinion reduction	75/22 (3,409)
	Final ratio	55/56 × 75/22 (3,348)
T 0 0	(00000	8,634
	0000	4,711
	(00300	3,348
Ratio at the wheels	00000	2,484
		9,649





FRONT BRAKES	S		Values	in mm
		Ø	280,800 ÷ 281,200	280,800 ÷ 281,200
 	Disc (21,900 ÷ 22,100	25,900 ÷ 26,100
Ø	s {		20,55	24,55
	(<	allowed	20,2	24,2
s S	Brake s<	allowed	1,	5
↓ ø	Caliper	Ø	54	57
	Master cylinder (pump)	Ø		_
	Servo brake		LUCAS 10" hydro-pneumatic vacuum servo acting on all four wheels	LUCAS 9"+8" (10" ●) hydro-pneumatic vacuum servo acting on all four wheels

For 2446 20v and 2387 TD versions

REAR BRAKES

-#4-			Ø	275,800 ÷ 276,200
	Disc	(9,80 ÷ 10,10
		s{		9,35
		(<	allowed	9
s S	Brake pads	s<	allowed	1,5
□ ‡ø	Caliper		Ø	38
	Load pr	oportioning	valve	acting on the rear wheels
Ratio (reduction)				0,36





WHEEL GEOMETRY

WHEEL GEOMETH		
Front suspension	camber (**)	0° 40′ ± 1° 20′
	caster (**)	3° ± 3° 40′
	toe in	0 ÷ 2 mm
	front wheel offset ▲	0°
	camber (**)	-
	caster (**)	1° 45′ ± 2° 25′
Rear suspension	toe in	1,5 ÷ 3,5 mm
	rear wheel thrust angle A	0°

- (*) With tyres inflated to the correct pressure and vehicle in running order
- (**) Angles cannot be adjusted
- (A) Angular values which cannot be adjusted, used for the correct alignment of the vehicle

TYRES

ENGINE TYPE	Radial, tubeless type, tyre	Inflation pressure			
		Fre	ont	Re	ear
	fitted as standard	average load	heavy Ioad	average load	heavy Ioad
1995 16v turbo	205/55 R16 89W	2,2 bar	2,3 bar	2,2 bar	2,3 bar

NOTE The homologated snow tyres bear the code 205/55 R16 89H

WHEEL RIMS


ENGINE TYPE	Wheel rim
	fitted as standard and snow
1995 16v turbo 2446 20v 2959 24v	6½ J×16 H2-31

NOTE All versions have a spare wheel with a 4.00×15 H rim and a T 125/90 R15 96M tyre. Speed limit: 80 Kph. Inflation pressure: 4.2 bar


Electrical equipment: recharging

00.55


ALTERNATORS - WIRING DIAGRAMS AND TYPICAL OUTPUT CURVES (at operating temperature at a constant voltage of 13.5 V with bedded in brushe)



Bosch NC - 14 V - 60/120 A



Bosch NC - 14 V - 60/120 A



Typical voltage regulator curve for Bosch NC - 14V - 60/I20A alternator

Technical data

Electrical equipment: electronic injection/ignition

00.55

INTEGRATED ELECTRONIC INJECTION/IGNI- TION CONTROL MODULE	1995 16v turbo	2446 20v
Make and type	Bosch Motronic M2.7 0.261.203.792	Bosch Motronic M2.10 0.261.203.669
Firing order	1 - 3 - 4 - 2	1 - 2 - 4 - 5 - 3

IGNITION COIL (1 PER SPARK PLUG)

Make		Bosch (with 4 high tension sockets)	Bosch (1 per spark plug)
Туре		0.221.503.407	0.221.504.006
Ohmic resistance of primary winding at 20 °C	Ω	0,45 ÷ 0,55	-
Ohmic resistance of secondary winding at 20 °C	Ω	12000 ÷ 14600	-

DETONATION SENSOR


Make	Bosch		
Tuno	0.261.231.095 0.261.231.09	0.261.231.095	
Type	0.201.231.030	0.261.231.007	

TDC AND RPM SENSOR


Make and type		Bosch 0.261.210.093	Bosch 0.261.210.119
Sensor winding resistance at 20 °C	Ω	-	774 ÷ 946
Distance (gap) between sensor and cran- kshaft pulley tooth	mm	-	0,8 ÷ 1,5

SPARK PLUGS

Make and type		Bosch WR6 DTC	Champion RC7BMC
Thread		M 14 x 1,25	
Electrode gap	mm	0,8 ÷ 1	0,4 ÷ 0,6



3/4 front view



3/4 rear view

Copyright by Fiat Auto

Introduction **Identification data**


0.00

	CHASSIS	ENGINE	VERSION	GEARBOX	
	CHASSIS	ENGINE	VERSION	5 speed	automatic
1995 16v turbo		838 A4.000	838 CB 1AA 12		
2446 20v	ZLA 838.000	838 A2.000	838 CC 1AA 13 838 CC 1AA 13B (▲)	•	
[2959] 24v		838 B.000	838 CD 11A 14		•


(**A**) Voluntary for Germany


Vehicle type identification code and chassis manufacture number

Stamped on the floor panel of the passenger compartment, near the right front seat. Access is gained by lifting the appropriate flap.



P3U02AD01






P3U03AD02

Engine type and number

V.I.N. Plate (EEC regulations)

- Α. Name of manufacturer
- Homologation number В.
- Vehicle type identification code C.
- Chassis manufacture number
- Maximum authorized weight of vehicle fully laden
- F. Maximum authorized weight of vehicle fully laden plus tow
- Maximum authorized weight on first axle G.
- Maximum authorized weight on second axle Н. (rear)
- ١. Engine type
- Bodywork version code
- M. Spares number
- Correct value of smoke absorption coefficient N. (Diesel engines only)



Introduction

Performance - Fuel consumption

00.0

	ENGINE TYPE	1995 16v turbo	2446 20v	2959 V6 24v
	GEARBOX	000	999	I
	900	52	56	-
Speed kph	200	87	94	-
(average load)		143	139	-
		201	183	max 225
	006	235	218	· -
	000	57÷58	60	-
%	Maximum climable gradient fully laden		37	
	Urban	14,1	15,0	17,4
	Extra-urban	7,8	8,2	9,4
Fuel consumption directive 93/116/CE (litres/100 km)	Combined	10,1	10,7	12,3
CO2 exhaust emissions	(g/km)	240	255	294

The 93/116/CE directive fuel consumption figures have been defined in the course of homologation tests involving:

- an urban cycle which includes a cold start followed by a varied urban cycle simulation.
- an extra-urban cycle which includes frequent acceleration in all gears simulating normal out of town usage. The speed varies between 0 and 120 kph.
- The average combined consumption includes 37% of the urban cycle and 63% of the extra-urban cycle.

The type of journey, traffic conditions, driving styles, atmospheric conditions, trim level/equipment/accessories, whether a roof rack is fitted, the presence of special equipment and the general state of the vehicle can lead to fuel consumption figures which differ from those obtained through the above mentioned procedures.

The CO2 exhaust emissions (in g/km) are measured during the average combined cycle

Introduction Identification data - Weights

0.00

IDENTIFICATION		ENGINE	VERS	SION .	GEARBOX
DATA		LNOINE	SALOON	SW	automatic
2446) 20v	ZLA 838.000	838 A2.000	838 AC 11 A 15	838 BC 11 A 16	•

	ENGINE TYPE	2446 20v	
	GEARBOX	ī.	
WEIGHTS (in kg)		SALOON	sw
		1480	1550
+500		2060	2130
Max. permissible loads on the a	axles •	1180	
		118	30
Maximum permissible load on	the roof	100	0
Load on the tow hook (train braking system)	ler with	90	
	Trailer without braking system	500)
	Trailer with braking system	150	0

Loads which must never be exceeded

NOTE FOR VERSIONS WITH ACCESSORIES: in the presence of special equipment (non standard air conditioner, sun roof, trailer towing device), the empty weight increases and therefore the carrying capacity may decrease, in relation to the maximum permissible loads.

Introduction

Performance - Fuel consumption



00.0

	ENGINE TYPE	2446	20v
	GEARBOX	1	F
		SALOON	sw
	000	-	-
Speed kph (average load)	200	-	-
(average 10au)	9	-	-
	000	215	210
		_	-
	006	-	-
%	Maximum climable gradient fully laden	37	36
	Urban	15,4	15,6
Fuel consumption	Extra-urban	9,0	9,2
Fuel consumption directive 93/116/CE (litres/100 km)	Combined	11,3	11,6
CO2 exhaust emissions (g/km)	270	275

The fuel consumption figures in accordance with directive 93/116/CE have been defined in the course of homologation tests involving:

- an urban cycle which includes a cold start followed by a varied urban cycle simulation.

- The combined average consumption includes 37% of the urban cycle and 63% of the extra-urban cycle.

The type of journey, traffic conditions, driving styles, atmospheric conditions, trim level/equipment/accessories, whether a roof rack is fitted, the presence of special equipment and the general state of the vehicle can lead to fuel consumption figures which differ from those obtained through the above mentioned procedures. The CO₂ exhaust emissions (in g/km) are measured during the average combined cycle


⁻ an extra-urban cycle which includes frequent acceleration in all gears simulating normal out of town usage. The speed varies between 0 and 120 kph.

<u> </u>				_	Quar	ntity
	Capacities		Un	it	dm³(l)	(kg)
	Petrol O.R. 95 (●	. \		1995 16v turbo 2446 20v - 2959 V6 24v	70	
	retion O.N. 95 (,		including a reserve of	9	
3	+ Language +	\		1995 16v turbo 2446 20v		
H ₂ 0	(A) 11	*	Total capacity of cooling system	2959 V6 24v	9	-
			<u>ھ</u>	1995 16v turbo	7	6,25
			Total capacity	2446 20v	6,5	5,8
HO HAIZ	SELENIA 20 K			2959 V6 24v	7,5	6,7
OITTO	(SAE 10 W/40)		1995 16v turba	5,5 5*	4,9 4,45*
				2446 20v	5,4 5*	4,85 4,45*
			Partial capacity (periodic replacement)	2959 V6 24v	6,9 6,5*	6,2 5,85*
70 Ar(a = TUTELA ZC 75 SYNTH	9 9		1995 16v turbo 2446 20v	2	1,80
0/1/0	b = TUTELA GI/A			2959 V6 24v	9,1 5**	8,2 4,5**
100 100 100 100 100 100 100 100 100 100	a = TUTELA		a D	1995 16v turbo 2446 20v	a -	0,80
150	GI/A			2959 V6 24v		1,80
0	b = TUTELA MRM 2		b	ł	-	0,080
SECTION	TUTELA TOP 4 270°C		Total capacity of braking sy.	stem and hydraulically op. cl	- utch	0,5
I	AREXONS		- -		8	-
H ₂ 0	+ DP1		- 20°C 50% - 20°C 100%		-	_

^(▲) Distilled water (**) Periodic replacement

^() Unleaded petrol only must be used

^(*) Engine sump only



LANCIA k '97 update

Introduction and technical data

Index

0.00

page

		1000
LANCIA k (all ve	rsion	\odot

TECHNICAL DATA

1	ea	1401	DΧ				ere	нап	ıaı		0 76	7 233		27.0	
			8082												
				00	1_					5250					
3	36	Cic		.OO	15									8	
	100									4					600
		-+-				qu									
1	u	ILC	111	HU.	w	uu	じン								

LANCIA k - kSW 2445 20V L

INTRODUCTION

				410 No.	300		1/4		0.07-5/20						100000000				÷
			2.14		1110	n -	330 V 1	100	100									100	ь
100	36 8 65				1818	\$ 50 Ballion							1300000					40	٠.
	1000	Jassalia Jassalia	200		and awa	44.5500537	0.77	1000000		States.									7
	200	1,041,000,000					NAMES	T. 187											4
				10000	U-32-Y2-Y	e -		0.750	200							X2754.00		6.00	•
		211	arr	บาวเ		2000		P	Sec. 25-6	គារតា	553.83	8 6 8 8	海飞车	(A) 1.5			1100	11.12	,
	1	2000			1000	400	200		650,000			222	100					0.00	٠.

TECHNICAL DATA

gearbox and c	

COPYRIGHT FIAT AUTO.


The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A.
D.M.C. - M.P.S.
Servizi Post Vendita - Tecnologie Assistenziali
Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia)
Publication no. 506.475/20- Gennaio 1998 - 400
Printed in Italy - Tip. Giraudo - Torino
order no. 60445590

00.21-27





GEARBOX		Туре	C.530.5.24	C.530.5.24	C.530.5.31	C.530.5.31	C.530.5.31		
	spring ring (Porsch	e type)			_				
Synchronizers	baulk rii type	ng 🔘	9 9 6						
00	straight toothed								
Gears	helical toothed				0 8 6 2 0)			
		•	3.800	3.800	3.800	3.500	3 800		



3,800	3,800	3,800	3,500	3,800
2,235	2,235	2,235	2,235	2,235
1,360 (1,520) ●	1,520	1,360	1,520	1,360
0,971 (1,156) ●	1,156	0,971	1,156	0,971
0,811 (0,914) ●	0,914	0,811	0,914	0,707 (0,763) ■
3,545	3,545	3,545	3,545	3,545

DIFFERENTIAL

= I = = I =		16/57 (3,562)	16/57 (3,562)	16/57 (3,562)	17/57 (3,353)	16/63 (3,937)
Ratio	crown wheel and pinion reduction	(16/63) ● (3,937) ●	(3,302)	(3,302)	(3,333)	(16/57) ■ (3,562) ■

For Power Drive Version (Saloon) Version for specific markets (France) Saloon and SW

NOTE The LANCIA k saloon is available in all versions whilst the LANCIA k SW is only available in the 1998 20v - 2446 20v - 1995 16v turbo - 2387 TD versions and the LANCIA k Coupè is only available in the 1995 16v turbo and 2446 20v versions.

'97 update

00.21-27

GEARBOX DIFFERENTIAL		1998 20v	2446 20v	1995 16v turbo	²⁹⁵⁹ 24v	2387 TD
	9 00	13,535 (14,960) •	13,535	13,535	11,735	14,960 (13,535) ■
=	200	7,961 (8,799) ●	7,961	7,961	7,494	8,799 (7,961) ■
		4,844 (5,984) ●	5,414	4,844	5,096	5,354 (4,844) ■
	60	3,458 (4,551) ●	4,117	3,458	3,876	3,823 (3,458) ■
Ratio at the wheels	000	2,889 (3,598) ●	3,255	2,889	3,065	2,783 (2,718) ■
	000	12,627 (13,957) ●	12,627	12,627	11,886	13,957 (12,627) ■
Differential internal casing bearing			conica	al roller bea	arinas	
					90	
Adjustment of bearing pre-loading				by shims		
Thickness of shims	0,05) mm		1,	,25 ÷ 1,60)	
Bearing rolling torque	daNm		0,	.10 ÷ 0,14		
	mm		0,	10 ÷ 0,20)	
Clearance between planet & sat. gears						
Adjust. of clrnce btwn planet & sat. ge	ears			by shims		
Thickness of shims	0,10) mm		1	,8 ÷ 2,2		
For Power Drive Version (Saloon)	(=) \/ou	.:			١ ٠ ١	



⁽**■**) Version for specific markets (France) Saloon and SW



TUTELA ZC 75 Semi Synth type oil should be used in the C530 gearbox; it has the following characteristics: SAE 75 W 90 oil, satisfies standards API GL5 and MIL-L-2105 D $\,$

Technical data

Special tools

00.21-27

			00.21-27
1840005001	Universal extractor	1870657000	Tool for fitting gear engagement rod housing bushes in gearbox
1840005301	Tool for universal extractor 1840005001	407000000	casing
1840005400	Clamp	1870658000	Tool for removing-refitting shafts (in three pieces)
1847017004	Flange for removing inner section of left drive shaft (to be used with 1840206001)	1870659000	Tool for fitting main shaft bear- ings and lay shaft rear bearing
1840206001	Mass	1870660000	Reaction base for removing lay shaft front bearing
1840207814 1846001001	Tool for extracting bush pin (to be used with 1840206001) Pair of half rings for extracting	1870675000	Half rings for removing-refitting gearbox shafts
1040001001	main shaft front bearing	1870676000	Half rings for removing main shaft
1846017001 1860974000	Base for puller half rings Tool for adjusting gearbox flexible	1870681000	Tool for supporting gearbox whilst removing
1870007000	cables Tool for fitting bush pin	1871000000	Rotating column for overhauling gearboxes and differentials
1870595000	Cross member for supporting power unit	1871001014	Support for gearbox-differential unit whilst overhauling (to be fitted to 1871000000)
1870647000	Plate for gauges 1870648000	1874290000	Plate for removing-refitting gearbox shafts
1870648000	Gauges for determining size of shims	1874365000	Grip for tool 1870656000
1870649000	Reference cross member (to be used with 1870648000)	1895655000	Tool for determining differential
1870651000	Set of bracket for supporting engine whilst removing/refitting gearbox-differential unit	, , , , , , , , , , , , , , , , , , , ,	bearing adjustment shim (to be used with 1895884000)
1870652000	Bush for rotating main shaft	1895881000	Dial gauge to be used with specific tools (measuring capacity 25 mm, shank length 17 mm)
1870654000	Tool for extracting-introducing gear engagement rod housing bushes in bell housing	1895884000	Dial gauge to be used with specific tools (measuring capacity 5
1870655000	Tool for extracting bearing outer races (to be used with 1840206001)		mm, shank length 16,5 mm)
1870656000	Tool for introducing bearing outer races (to be used with 1874365000)		

LANCIA K

Technical dataSpecial tools

'97 update

00.21-27

DESCRIPTION	Thread size	Tightening torques
		daNm
Clutch release sleeve mounting cover fixing, bolt	M6	0,75
Left side cover fixing, bolt	M8	2,5
Right side cover to casing fixing, bolt	M8	2,5
Gearbox casing to support fixing, bolt	M9×1,25	3,4
Gearbox casing to support fixing, bolt with double thread	M9×1,25	3,4
Gearbox oil threaded drain plug	M18×1,5 (tapered)	2,5
Differential cover to engine-gearbox mounting fixing, bolt	M8	2,5
Differential cover to engine-gearbox mounting fixing, bolt	M10×1,25	5,0
Magnetic plug	M22×1,5 (tapered)	4,6
5th speed and reverse selector fixing, self-locking bolt	M8	2,5
Reverse gear shaft fixing, bolt	M10×1,25	5,0
5th speed selector fork fixing, self-locking bolt	M8	2,5
Gearbox damper mass fixing, bolt	M8	2,0
Selector lever fixing, nut	M10×1,25	3,0
Gearbox cover fixing, bolt	M8	2,5
Speedometer mounting fixing, bolt	M6	1,0
Crown wheel fixing, bolt	M10×1,25	9,0
Reversing lights switch, bolt	M12×1	3,0
Drive shaft to support on engine fixing, bolt	M8	2,9

Technical data

Automatic gearbox - Differential

00.21-27

AISIN AUTOMATIC GEARBOX

ENGIN	E TYP	E
		1



GEARBOX		
Gears	<u> </u>	0000
	(00000	3,606:1
= <u>I</u> =	02000	2,060:1
	⟨ ⟨ ○○❸○○ │	1,366:1
Gear ratios	00000	0,982:1
Geal latios	(0000 B	3,949:1
* I * 8	Idler ratio	55/56 (0,982)
Ø To	rque nverter Ø mm	241
	Ratio (multiplication) engine torque	1,96
Quantity of oil	1st filling	7,5 I (6,8 Kg)
TUTELA GI/2●	periodic replacement	3,5 l (3,2 kg)

(●) "DEXRON II" type oil for automatic transmissions

DIFFERENTIAL

	Crown wheel and pinion reduction	2,654:1 (69/26)
_ T _ O	(00000	9,570:1
	02000	5,467:1
	⟨○○❸○○	3,625:1
Ratio at the wheels	00000	2,606:1
C		10,481:1




As far as the composition, operation and overhauling and adjustment operations for the gearbox are concerned, refer to print no. 506.475/03 dealing with the LANCIA k 1998 20V version with automatic transmission.

•

Braking system

00.33





Adjustment

- Let the rear suspension bed in;
- position the vehicle on a horizontal plane with the wheels on the ground;
- load the luggage compartment, if possible against the rear seat backrest with a different weight depending on the amount of fuel in the tank as described in the table below:

Fuel tank full	35 Kg
Fuel tank 3/4	50 Kg
Fuel tank 1/2	65 Kg
Fuel tank 1/4	80 Kg
Fuel tank - reserve	95 Kg



- apply a load of 2 daN to the bracket eyelet (2);
- keeping the bracket (3) in this position, lock the bracket fixing bolt (1).


NOTE In the case of irregular operation the complete load proportioning valve must be replaced.


Operation

The load proportioning valve for the rear wheels, fixed to the rear cross member, alters the braking pressure in the rear braking circuit in relation to that for the front wheel circuit depending on the vehicle load and deceleration conditions.

The variation in pressure is determined by the position of the spring connected to the suspension transverse rods which, via the fork (4), act on the load proportioning valve piston.


- 1. Housing for brake pipe connector
- 2. Housing for brake pipe connector
- 3. Dust cover
- 4. Piston fork





P3U21AD03

Туре		rack and pinion	electronically controlled
		power assisted	rack (servotronic)
- I - - I -	no. of turns lock to	2,83 o lock	3
- I - Ratio	rack travel	153	mm
Ø	Turning circle	10,9) m
α_1	outer α_1	32°	40′
Steering angle	inner $lpha_2$ wheel	37°	30′
	Steering col- umn	with 2 unive	ersal joints
Management of the second secon	*Miller.		





WHEEL GEOMETRY

WHEEL GEOMETH			Marine W. Communication of the
	camber (**)		− 0° 35′ ÷ − 1° 15′
	caster (**)		2° 50′ ÷ 3° 30′
Front suspension	toe in	•	0 ÷ 2 mm
	front wheel offset A		O°
	camber (**)		– 0° 25′ ÷ - 1° 5′
	caster (**)		-
Rear suspension	toe in	•	1,5 ÷ 3,5 mm
	rear wheel thrust angle	A	O°

- (*) With tyres inflated to the correct pressure and vehicle in running order
- (**) Angles cannot be adjusted
- (A) Angular values which cannot be adjusted, used for the correct alignment of the vehicle

Technical data

Wheels

00.44

TYRES

ENGINE TYPE	Radial, tubeless type tyre		Inflation			
			Fro	ont	Rear	
	fitted as standard	available on request	average load	heavy load	average load	heavy Ioad
1998 20v	195/65 R15 91V	205/60 R15 91V	2,2 bar	2,3 bar	2,2 bar	2,3 bar
2446 20v	205/60	2,2 bar	2,3 bar	2,2 bar	2,3 bar	
1995 16v turbo	205/55 R16 91W	215/55 R16 91W (*)	2,2 bar	2,3 bar	2,2 bar	2,3 bar
(2959) 24v	205/60 R15 91W		2,2 bar	2,3 bar	2,2 bar	2,3 bar
12387) TD	195/65 R15 91V 205/60 R15 9		2,2 bar	2,3 bar	2,2 bar	2,3 bar

^(*) Snow chains cannot be fitted on this type of tyre

WHEEL RIMS

ENGINE TYPE	Wheel rim			
	fitted as standard	available on request		
1998 20v 2446 20v	steel 6½ J×15 H2	alloy 6½ J×15 H2		
1995 16v turbo	alloy 7J × 16 H2			

NOTE All versions have a spare wheel with a $4B \times 15$ H rim and T 125/90 R15 96M tyre. Speed limit: 80 Kph. Inflation pressure: 4.5 bar

Technical data

Front suspension

00.44

Front suspension independent. Lower track control arms; dampers incorporated with the double acting, hydraulic shock absorbers, coil springs and stabilizer bar.

Coil springs	Eſ	ENGINE TYPE		1998 20v (●)	16v turbo 2357 TD	(2959)24v
Diameter of wire		mm		14,25-	÷14,35	
Number of turns				3	,6	
Direction of coil				clock	wise	
Height of spring released mm			374	385	395	406
	(412 daN mm	185	40	-	-
Height of spring)	436 daN mm	-	185	_	-
under a load of:)	458 daN mm	-		185	-
483 da		483 daN mm	<u></u>	-	-	185
The springs are subdi gories, identifiable by	vided into tv y a mark	vo cate-				
(412 daN I	neight of mm	>185	-	-	-
yellow (1) for	436 daN I	neight of mm	-	>185	-	-
those under a load of:	458 daN l	neight of mm	-	-	>185	· •
	483 daN height of r		-	~	-	>185
(412 daN I	neight of mm	≤185	-	-	-
green (1) for	436 daN I	neight of mm	-	≤185	-	-
those under a load of:	458 daN l	neight of mm	-	-	≤185	-
	483 daN height of mm		-	•	-	≤185

⁽¹⁾ Springs of the same category must be fitted.

Shock absorbers

Type:		hydraulic telescopic, double acting
Open (start of damping action)		505 ÷ 511
Closed (metal against metal)	mm	351 ÷ 35 7
Travel	mm	154

() Vehicles with air conditioning

Copyright by Fiat Auto 25

Rear suspension

00.44

Rear suspension independent. Longitudinal and transverse rods, telescopic dampers incorporated with the double acting, hydraulic shock absorbers (high pressure gas) with a self-levelling function, coil springs and stabilizer bar.

Coil s

springs		1998 20v	2446 20v	16v turbo	²⁹⁵⁹ 24v	2397 TD	
neter of wire	mm		1	2,25÷12,3	 35		

Diameter of wire)	mm	12,25÷12,35
Number of turns			3,20
Direction of coil			clockwise
Height of spring	released	mm	228
Height of spring under a load of:		mm	195
The springs are si gories, identifiab	ubdivided into tw le by a mark	o cate-	
yellow (1) for those under a load of:	279,5 daN	height of mm	> 195
green (1) for those under a load of:	279,5 daN	height of mm	≤195

⁽¹⁾ Springs of the same category must be fitted.

Shock absorbers

BOGE Nivomat self-levelling type	•	hydraulic telescopic, double acting (high pressure gas)
Open (start of damping action)	mm	724
Closed (metal against metal)	mm	529,3
Travel	mm	194,7









STARTER MOTOR	M.Marelli E 70R-12V-1,4 kW (with reduc. gear)			Bosch Ø74,5-12V-1,4kW (with reduc. gear)
ALTERNATOR	A 127IR-14 Bo	larelli IV-55/100A sch 0/120A (*)	Bosch N1-14V-40/115A	Bosch NC-14V-60/120A
VOLTAGE REGULATOR	BUILT IN ELECTRONIC			
BATTERY	12V - 60Ah - 320A		12V - 60Ah - 380A	
IGNITION SYSTEM	Bosch Motronic M2.10 integrated electronic injection/ignition	Bosch Motronic M2.10 integrated electronic injection/ignition	Bosch Motronic M2.7 integrated electronic injection/ignition	Bosch Motronic M3.7 integrated electronic injection/ignition
IGNITION COIL	Bosh 0.221.504.006 (1 per spark plug)		Bosch 0.221.503.407	Bosch 0.221.504.456 (1 per spark plug)
POWER MODULE		_	Bosch 0.221.100.201	-
SPARK PLUGS	Champion RC7BMC	Champion RC7BMC	Bosch WR6 DTC	NGK PFR6B

^(*) For vehicles equipped with air conditioning

Technical data Electrical equipment

00.55



STARTER MOTOR	M.Marelli E 95RL - 12V - 2,2kW (with reduction gear)	
ALTERNATOR	M.Marelli A 127IR - 14V - 55/100A	
VOLTAGE REGULATOR	BUILT IN ELECTRONIC	
BATTERY	12V - 70Ah - 450A	
PRE-HEATING ELECTRONIC CONTROL UNIT	Bosch 0.281.003.010	
HEATER PLUGS	BERU 0.100.226.249	

Technical data

Electrical equipment: recharging

00.55

1998 20v 2446 20v	1995	(•) (•) 1998 20v 2446 20v
2387 TD	1995 turbo	2959) 24v

ALTERNATOR

ALILIMATON				
, Type		M. Marelli A127I-14V-55/100A	Bosch N1 - 14V 40/115A	Bosch NC - 14V - 60/120A
Nominal voltage	V		14	1
Nominal current at 1800 rpm	Α	55	50	60
Cut in speed when warm	rpm	-	≤1100	≤1100
Current delivery on the battery at 7000 rpm at op. temp.	А	100	≤115	> 120
Field winding resistance between the slip rings (*)	Ω	2,47 ÷ 2,73 (*)	2,6 ÷ 2,85 (**)	_
Direction of rotation (seen from control side)			clockwise	
Diode rectifiers		bridge		

^(*) Data obtained at an ambient temperature of 20°C.

VOLTAGE REGULATOR	ULATOR Built in electro			
Туре		RTM 151 A	Bosch EL - 14V - 4C	Bosch
Alternator speed for test	rpm	7000	6000	6000
Thermal stabilization current	А	50 ÷ 55	40 ÷ 45	55 ÷ 60
Test current	А	50 ÷ 55	40 ÷ 45	55 ÷ 60
Regulation voltage (*)	V	14,35 ÷ 14,55 (*)	14 ÷ 14,3 (*)	14,35 ÷ 14,65 (**)


^(*) Data obtained at an ambient temperature of 20°C. (**) Data obtained at an ambient temperature of 25°C.

^(**) Data obtained at an ambient temperature of 25°C

^() For vehicles with air conditioning

00.55


ALTERNATORS - WIRING DIAGRAMS AND TYPICAL OUTPUT CURVES (at operating temperature, at a constant voltage of 13.5 V and with bedded in brushes)




P3U31AD02

Bosch NC - 14 V - 60/120 A


M. Marelli A 1271R - 14V - 55/100A






Bosch NC - 14 V - 60/120 A

M. Marelli A 1271R - 14V - 55/100A







Typical regulation voltage output curve for Bosch NC - 14V - 60/I20A alternator

Typical regulation voltage output curve for M. Marelli A 127IR - 14V -55/100A alternator

Electrical equipment: recharging


00.55





Bosch N1 - 14V - 40/115 A

Bosch N1 - 14V - 40/115 A



Typical voltage regulator curve for Bosch N1 - 14V - 40/115 A alternator

00.55

	1998 2446 1995	2959	2387
TARTER MOTOR	20v 20v turbo	24v	TD
Туре	M.MARELLI E70R - 12V - 1,4kW (with reduction gear)	BOSCH Ø74,5 - 12 V - 1,4 kW (with reduction gear)	M. Marelli E 95RL - 12 V - 2,2 k (with reduction gea
Voltage, V		12	
Nominal power kW	•	1,4	2,2
Rotation, pinion side		clockwise	
No. of poles	4	6	4
Winding	series	permanent magnets	series - parallel
Engagement		free wheel	
Operation		solenoid	
End float of armature shaft mm		0,15 ÷ 0,45	
Data for bench test			
Operating test (*): current A speed rpm voltage V torque developed daNm Engagement test (*): current A voltage V torque developed daNm	360 ÷ 380 1150 8,15 1,30 680 ÷ 700 4,9 3,11	360 1800 8,5 0,98 690 ÷ 730 4,8 ÷ 5,2 2,15	600 1400 7,9 1,6 1110 ÷ 1150 4,4 ÷ 4,6 ≥3,9
Free running test (*): current A voltage V speed rpm	60 ÷ 80 11,1 4040	25 ÷ 40 11,8 ÷ 12 3000 ÷ 4000	120 ÷ 140 11 4500 ÷ 4750
Relay			
Winding resistance (*) \int pull in Ω	0,33 ÷ 0,37	0,32 ÷ 0,36	0,23 ÷ 0,27
$\left\{\begin{array}{c} \\ \\ \\ \end{array}\right.$ hold in Ω	1,13 ÷ 1,27	1,65 ÷ 1,95	0,93 ÷ 1,07
Lubrication Internal splines and shaft bushes		VS ⁺ SAE 10 W	
Engagement sleeve and intermediate disc		TUTELA MR3	


^(*) Data obtained at an ambient temperature of 20°C.

NOTE When overhauling it is not necessary to under the insulator between the commutator bars


Electrical equipment: starting

00.10


STARTER MOTOR - TYPICAL CURVES



M. Marelli E 70R - 12 V - 1,4 kW



Bosch Ø 74,5 - 12 V - 1,4 kW



M. Marelli E 95R - 12 V - 2,2 kW

Electrical equipment: electronic injection/ignition

00.55

BOSCH MOTRONIC M2.10 INTEGRATED ELECTRONIC INJECTION/IGNITION





Makė - Bosch	0.261.623.053	0.261.203.669
Firing order	1 - 2 - 4	1 - 5 - 3

IGNITION COIL (1 PER SPARK PLUG)

Make		Bosch
Туре		0.221.504.006
Ohmic resistance of primary winding at 20 °C	Ω	0,4
Ohmic resistance of secondary winding at 20 °C	Ω	8500

TDC AND RPM SENSOR

Make and type		Bosch 0.261.210.119
Sensor winding resistance at 20 °C	Ω	774 ÷ 946
Distance (gap) between sensor and crankshaft pulley tooth	mm	0,8 ÷ 1,5

DETONATION SENSOR

Make	Bosch
	0.261.231.095
Type	0.261.231.007

SPARK PLUGS

Make and type		Champion RC7BNC
Thread		M 14 x 1,25
Electrode gap	mm	0,4 ÷ 0,6

LANCIA K '97 Update

Gearbox and differential

Contents

21-27.

	3.5%	10		
22	E	11		
٠.	100	4.3	- 1	

27

			2000	The state of the s
C.53		E . 188.00 . 18		- L - A
200 Sept. 100 Se	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E - 20 - 1	K IS	30 30 . 93
	A	N		

linkage

REMOVING-REFITTING	
- Removing	1
- Refitting	15
GEAR SELECTOR LINKAGE	
- Removing gear selector linkage	17
- Dismantling-reassembly at the bench	26

- Refitting and adjusting gear selector

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A. D.M.C. - M.P.S.
Servizi Post Vendita - Tecnologie Assistenziali
Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia)
Publication no. 506.475/20- Gennaio 1998 - 400
Printed in Italy - Tip. Giraudo - Torino
order no. 60445590

Removing-refitting

21-27.




REMOVING




Place the vehicle on ramps, remove both front wheels and proceed as described below:


1. Working from the engine compartment, disconnect both battery connectors, then undo the nut securing the battery to the cage and remove the battery.



P3U01FB02

- 2. Undo the two clips (1), disconnect the air temperature sensor connector (2) and remove the resonator (3), releasing it from the bottom centring bracket.
- 3. Remove the rubber mat from the battery cage, then undo the bolts (arrowed) and remove the cage.
- 4. Undo the bolt (arrowed) and remove the EGR valve complete with bracket and pipes.







P3U01FB04

Removing-refitting

LANCIA K '97 update













- 1. Disconnect the air flow meter connector (1), undo the bracket mounting bolt (2) and remove the air cleaner case (3), releasing it at the bottom from the intake duct and withdrawing it from the rubber supports.
- 2. Undo the bolts (arrowed) securing the clutch cylinder mounting.
- 3. Undo the reverse inhibiting cable ring nut (1) and disconnect the connector from the reversing light switch (2).
- 4. Disconnect the earth cable (arrowed) from the gearbox mounting.
- 5. Undo the three bolts (arrowed) on the engine electrical connector mounting bracket, and disconnect the connector.







Removing-refitting













- and secure it temporarily outside the working area, making sure not to damage or bend the pipes.
- 4. Disconnect the connectors from the coolant temperature sensors (1) and (2) and move aside the wiring and clutch cylinder.
- 5. Remove the spherical heads from the gear engagement lever (3) and gear selector lever (4).



P3U03FB03

5





P3U03FB05


Removing-refitting

'97 update

LANCIA K














- 1. Undo the nuts (arrowed) securing the flexible cable mounting bracket.
- 2. Disconnect the steering wheel connector (1) and the connector (2) on the fan motor.
- 3. Undo the bolts (arrowed) securing the air conditioning dehydrating filter, and move it aside to allow the fan to be removed.
- 4. Undo the bolts (arrowed) and remove the
- fan from the engine compartment.
 5. Undo the bolts (arrowed) and remove the reaction link.






21-27.




P3U05FB01




RAise the vehicle, then proceed as described below.

1. Remove the left wheelarch (two parts) by undoing the attachments.



P3U05FB02

- 2. Undo the bolts (arrowed) and remove the engine compartment bottom guard.
- 3. Undo the bolts on the manifolds (1) and catalytic converter (2) and the bracket bolt (3), and remove the sections (A) and (B) of the exhaust pipe.





P3U05FB03

Removing-refitting

LANCIA K '97 update

21-27.





P3U06FB02









1. Prepare a suitable container and drain the oil from the gearbox-differential unit by undoing the plug (arrowed).


NOTE The collection and disposal of used oils are governed by legal regulations.

- 2. Undo the nut (arrowed) securing the tie rod end to the vertical link.
- 3. Using tool 1847035000, remove the tie rod end from the vertical link.
- 4. Remove the wheel speed sensor from the vertical link.
- 5. Undo the nut securing the anti-roll bar link to the wishbone.






P3U06FB04





P3U06F805

Removing-refitting











P3U07FB03



- 1. Disconnect the brake pad wear sensor connector (arrowed) and move aside the electrical wiring.
- 2. Undo the bolts (arrowed) and remove the brake caliper, securing it temporarily to the steering subframe, taking care not to place the pipe under tension.
- 3. Undo the bolts securing the left drive shaft coupling.
- 4. Undo the bolts (arrowed) securing the lower wishbone arm to the vertical link.
- 5. Undo the bolts (arrowed) securing the shock absorber to the vertical link, then withdraw the left drive shaft complete with vertical link and brake disc.




P3U07FB04




P3U07FB05


Removing-refitting

LANCIA k '97 update














- 1. Remove the right wheelarch (two parts) by undoing the attachments.
- 2. Using a ring spanner, turn the tensioner anti-clockwise and remove the alternator drivebelt.
- 3. Place a jack under the front left auxiliary chassis, undo the bolts and lower the chassis by about 2 centimetres, supporting it with the jack.
- 4. Undo the alternator bolts (arrowed), then do up the bolts without tightening them to the correct torque.
- 5. Rotate the alternator to gain access to the electrical wiring, then disconnect the cables and remove the alternator.






P3U08FB05


Removing-refitting








P3U09FB02






- 1. Undo the nut securing the anti-roll bar link to the wishbone.
- 2. Undo the bolts securing the right drive shaft coupling and move it to the rear of the compartment.
- 3. Undo the bolts (arrowed) on the intermediate shaft.
- 4. Withdraw the intermediate shaft from the differential.
- 5. Undo bolts (arrowed) and remove the heat shield.









P3U09FB05

Removing-refitting

LANCIA K (2959)


'97 update














- 2. Undo the bolts and remove the rear exhaust manifold by rotating it as appropriate and withdrawing it from the right wheelarch.
- 3. Undo the bolts and remove the flywheel shield.
- 4. Disconnect the supply cables (arrowed) on the starter motor (1); also undo the nut (2) securing the gearbox to the engine block.
- 5. Undo the three bolts (arrowed) and remove the starter motor.




P3U10FB03







Removing-refitting

21-27.










P3U11FB03

- Undo the nut securing the rear right mounting to facilitate the movements of the power unit during withdrawal of the gearbox.
- 2. Disconnect the vehicle speed sensor connector.

Lower the vehicle, then proceed as follows.

3. Working on the left side, disconnect the connector (1) and remove the cover (2) which is a press fit, releasing the wiring.





4. Undo the bolts (arrowed) and remove the left spring-shock absorber assembly.


Removing-refitting

LANCIA K 1999 '97 update

21-27.













- 1. Undo the screws (arrowed) and remove the cylinder head top cover.
- 2. Undo the two bolts (1), undo the clip (2), remove the inlet stub pipe and block the inlet manifold.
- 3. Using the bolts arrowed in the figure, fit two L-brackets suitably shimmed so that their eyelets are at the same height.
- 4. Fit tool 1870595000 and hook the previously mounted brackets by means of two eyebolts, so as to support the power unit.




P3U12FB04


Removing-refitting

21-27.






P3U13FB02





Raise the vehicle, then proceed as follows:


- 1. Undo the bolts which attach the bottom left mounting (gearbox side) to the auxiliary chassis.
- 2. Gently lift the power unit by operating the adjustable support of tool 1870595000, undo the nut (arrowed) and remove the mounting.
- 3. Fit the tool 1870681000, slackening the adjustment bolts (arrowed).



P3U13FB04


4. Fit the tool 1870681000 on the gearbox unit and tighten the two bolts on the left side (arrowed).

21-27.






1. Fit the block, tightening the locking bolt (1), then tighten the tool's adjustment bolts (2).



P3U14FB02




2. Place a jack under tool 1870681000.

3. Undo the bolts (arrowed) securing the gearbox to the engine block, then manoeuvre the gearbox-differential unit as appropriate to release it from the centring pins on the engine block, and so that the main shaft can be withdrawn from the clutch plate.

Removing-refitting

21-27.






REFITTING


Before refitting the gearbox-differential unit, withdraw the clutch release bearing from the clutch diaphragm spring and refit it in the clutch release fork, as follows.

1. Remove the clutch assembly by undoing the bolts (arrowed).





- 2. Remove the clutch release bearing from the clutch spring using tool 1875084000.
- **NOTE** The bearing must not stick or be noisy, otherwise it will have to be replaced.






3. Line up the driven plate using the centring pin 1870081000 and fit the clutch assembly.

Removing-refitting


LANCIA K 1999 '97 update


21-27.






P3U16FB01








P3U16FB02








3. Refit the gearbox-differential unit, securing it to the engine block, then push the clutch release lever (arrowed) with force so as to hook the clutch release bearing onto the clutch diaphragm spring.

Refit the gearbox-differential unit in reverse order to removal.

NOTE When refitting the gearbox cables, follow the procedure described in the "Gear selector linkage" sub-section.

Remote control assembly

21-27.






REMOVING GEAR SELECTOR LINKAGE ASSEMBLY


Place the vehicle on ramps and proceed as described below:


1. Working from the engine compartment, disconnect both connectors from the battery, then undo the nut securing the battery to the cage and remove the battery.



P3U01FB02

- 2. Undo the two clips (1), disconnect the air temperature sensor connector (2) and remove the resonator (3), releasing it from the bottom centring bracket.
- 3. Remove the rubber mat from the battery cage, then undo the bolts (arrowed) and remove the battery.
- 4. Remove the bolt (arrowed) and move aside the EGR solenoid complete with bracket and pipes.







P3U01FB04


Remote control assembly

'97 update


LANCIA K










- 1. Disconnect the air flow meter connector (1), undo the bolt (2) securing the bracket and remove the air cleaner case (3), releasing it at the bottom from the intake hose, and withdrawing it from the rubber mountings.
- 2. Undo the bolts (arrowed) securing the clutch cylinder.
- 3. Undo the reverse inhibition cable ringnut (1) and disconnect the reversing light connector (2).
- 4. Disconnect the earth cable (arrowed) from the gearbox mounting.
- 5. Undo the three bolts (arrowed) securing the engine electrical system connector mounting bracket and disconnect the connector.













P3U03FB02




P3U03FB03



- 1. Undo the nut (arrowed) on the EGR valve pipe connection.
- 2. Undo the bolts (arrowed) securing the mounting bracket for the brake pipes and ABS electrohydraulic unit.
- 3. Move aside the ABS electrohydraulic unit and secure it temporarily outside the work area, taking care not to damage or bend the pipes.
- 4. Disconnect the coolant temperature sensor connectors (1) and (2) and move aside the wiring and clutch cylinder.
- 5. Remove the spherical heads from the gear engagement lever (3) and gear selector lever (4).



P3U03FB04





P3U03FB05

Gear selector linkage


LANCIA K '97 update

21-27.






P3U05FB02











- 1. Undo the nuts (arrowed) securing the flexible cable mounting bracket and disconnect it from the gearbox casing.
- 2. Raise the car and, working under the vehicle, undo the bolts (arrowed) and remove the engine compartment bottom guard.
- 3. Undo the attachment bolts to the manifold (1) and catalytic converter (2), and the bracket bolt (3), and remove the first section of the front (A) and rear exhaust pipe (B).
- 4. Undo the bolts (arrowed) of the steering box heat shield (1) and remove the shield.

21-27.







1. Undo the points arrowed and remove the front trim from the tunnel.



- 2. Remove the rear air vents.
- 3. Undo the rear bolts ssecuring the tunnel trim.
- 4. Fold down the seat, then remove the tunnel trim by undoing the screws shown.







P3U21FB04

Gear selector linkage

LANCIA K 1999 197 update









P3U22FB02




- 1. Undo the front bolt (arrowed) on the left bulkhead.
- 2. Undo the rear side screw (arrow A) and the front side screw (arrow B) on the left bulkhead and remove the latter.
- 3. Undo the rear screws (arrowed) on the right bulkhead.
- 4. Undo the front screw (arrowed) on the right bulkhead.
- 5. Remove the front cover of the right bulkhead (1), undo the screw (arrowed) and remove the bulkhead.





P3U22FB03







Gear selector linkage








- 1. Undo the screws on the left of the relay mounting bracket (1).
- 2. Undo the nut (arrowed) on the right and remove the relay mounting bracket.
- 3. Undo the nuts (arrowed) securing the Air. Bag control unit mounting to the bodywork and remove the mounting. Remove the front left seat (driver's) as described in Section 70.
- 4. Undo the nuts (arrowed) of the front shield (1) and remove the latter with the seal.
- 5. Undo the screws (arrowed) on the left foot tread and remove the latter.







P3U23FB05


Gear selector linkage

LANCIA K '97 update

21-27.











- 1. Undo the two bolts (arrowed) of the left floor trim, undo the limit switch (1) of the accelerator and fold the trim towards the rear of the car.
- 2. Undo the bolts (arrowed) securing the left dashboard bottom mounting bracket and remove the bracket.
- 3. Remove the rear left air diffuser.



4. Remove the right foot tread (arrowed).


Gear selector linkage

21-27.






1. Remove the rear right air diffuser.






- 2. Undo the bolts (arrowed) securing the
- gear lever mounting.

 3. Working from inside the car, remove the gear lever complete with mounting and control cables.



P3U25FB03

21-27.






DISMANTLING-REASSEMBLY AT THE BENCH



Flexible cables

After separating the gear lever assembly complete with mounting and control cables, proceed as described below:

1. Remove the retaining clips (arrowed) from the flexible cable mounting brackets.








Remove the retaining clips (arrowed), disconnect the two flexible cables (arrowed) from the gear lever and remove the cables by withdrawing them from the rubber stops.

NOTE To refit the flexible cables, reverse the procedure for removal.








After disconnecting the flexible cables from the gear lever, undo the bolts (arrowed) and detach the gear lever from its mounting.

NOTE To refit the gear lever, reverse the procedure for removal.

P3U26FB03

Gear selector linkage

21-27.






REFITTING AND ADJUSTING GEAR SELECTOR LINKAGE


After refitting the gear lever and flexible control cables, proceed as described below:

 Working from inside the car, insert the gear lever assembly complete with mounting and flexible cables into its seating, and tighten the bolts (arrowed) on the gear lever mounting.





 Operate the gear selector levers to set the gearbox to the reverse position, then insert the fitting gauge (arrowed) 1860974000 as shown in the figure, and reposition the gearbox in NEUTRAL.







 Fit the flexible cable mounting bracket in its seating in the gearbox and tighten the nuts (arrowed).


Gear selector linkage

LANCIA K 1999 1997 update

21-27.










- Set the gear lever (arrowed) to the NEU-TRAL position, fully home at the limit of its travel, and hold it in this position with a locking wrench. Undo the selection cable adjustment nut (1) on the gear lever.
- 2. Connect the end of the flexible cable (arrowed) to the spherical head of the selector lever. Tighten the selection cable adjustment nut on the gear lever and remove the locking wrench illustrated in point 1.
- 3. Set the gear lever to the reverse position, in order to raise the inhibition tube, and remove the positioning gauge 1860974000 (arrowed).



Set the gear lever to the NEUTRAL position and connect the end of the cable (arrowed) to the spherical head of the engagement flexible cable.

NOTE Finish refitting the gear selector linkage by reversing the procedure for removal.

LANCIA k SW

Suspension and wheels Contents

ЛΛ

page

BOGE NIVOMAT SELF-LEVELLING SUSPENSION	
- Introduction	1
- Description	- 3
- Operation	4
 Procedure for checking the efficiency of the self-levelling units 	8
- Instructions for scrapping the self-	
levelling units	10
- Removing-refitting	11
TIGHTENING TORQUES	
- Rear suspension	16

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Tecnica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/15 - Giugno 1996 - 400 Printed in Italy - Tip. Bogliani - TORINO order no. 60444456

BOGE NIVOMAT SELF-LEVELLING SUSPENSION


INTRODUCTION

Springs and shock absorbers play an extremely important role in vehicle safety and comfort. When transporting a heavy load or towing a trailer or caravan, both these important features can affect the load on the rear axle of the vehicle.

A vehicle with a great load on the rear axle has lesser contact of the front wheels with the road surface with the result that the road holding and stability are drastically reduced.

This problem is particularly acute on vehicles with a high carrying capacity in relation to their empty weight, on vehicles used for towing trailers and on multi-purpose, single volume vehicles, estate cars and minibuses.

One solution to this problem is the adoption of a self-levelling suspension system which keeps the distance between the rear axle and the bodywork constant, irrespective of the load applied to the rear part of the vehicle.



A. Vehicles with conventional suspension

B. Vehicles with self-levelling suspension

Copyright by Fiat Auto

Suspension and wheels

Nivomat self-levelling suspension

44.

The BOGE Nivomat self-levelling suspension system is fitted on the LANCIA k Station Wagon: it is made up of two compact, independent units which are fitted in place of the conventional shock absorbers.

These units maintain the correct distance between the rear axle and the bodywork and their damping depends on the load.

Nivomat suspension systems thereby eliminate the well known problem of conventional suspension systems which tend to be too rigid when the vehicle is empty and too "spongy" when travelling with a heavy load.

The LANÇIA k Station Wagon equipped with Nivomat units gives a comfortable ride even with a light load, but remains dynamically stable and safe when fully laden.

The BOGE Nivomat self-levelling suspension system works without any need for an external energy source.

The Nivomat suspension system is a unit which has its own internal pumping action. The energy required for this purpose comes entirely from the vertical movements of the vehicle bodywork.

As soon as the vehicle moves and causes the suspension to work, the pump inside the Nivomat units starts to work. It takes the hydraulic fluid from an internal tank and sends it to a hig pressure chamber where a gas compressor is working. In this way the Nivomat units ensure that the vehicle bodywork reaches the pre-set optimum height when the vehicle starts to move from stationary, compensating for the downwards movement of the bodywork due to a heavy load or trailer.

There is no separate device for controlling the height which needs adjustment: the height sensors are integrated in the shock absorber stems.

The initial adjustment procedure for the height of the bodywork is completed after the vehicle has covered a distance of around 2000 metres, depending on the road surface.

When the load is removed or the passengers leave the vehicle, the optimum height is restored whilst the vehicle is stationery.

Nivomat units simultaneously carry out the functions of a hydro-pneumatic spring depending on the load and a hydro-pneumatic shock absorber and replace conventional shock absorbers, offering the advantages of hydro-pneumatic self-levelling suspension for each type and class of vehicle, with damping depending on the load.

This system can be fitted on new vehicles or on vehicles already in circulation with relative ease, without too many adjustments or a great outlay.

COMPOSITION

The BOGE Nivomat self-levelling units used on the LANCIA k Station Wagon are made up of an outer casing which contains two chambers:

- 'the low pressure chamber (1), located at the bottom, works as an oil tank and is partly filled with pressurized gas;
- the high pressure chamber (2), located in the upper part of the unit, is divided in two by a diaphragm (3); there is pressurized gas in the outer part whilst the inner section is filled with oil.

When empty the pressure inside the two chambers is identical at around 25 bar; fully laden the low pressure chamber is at around 8 bar, whilst the high pressure chamber reaches about 80 bar.

Inside the outer casing is the actual shock absorber cylinder (4), with the piston (6) and damper valves connected to the stem (5).

A perforated pumping stem (7), connected to the base of the unit, slides inside the piston groove, forming the oil pump (8).

On the outer surface of the stem (7) there is a port (9) which acts as a height sensor.





Diagram showing Nivomat unit



Diagrammatic section of a Nivomat unit

P3U03CG02

Copyright by Fiat Auto


3

Suspension and wheels Nivomat self-levelling suspension

44

OPERATION

After having loaded the vehicle (passengers, baggage), the Nivomat units will yield a certain amount (condition A) in proportion to the rigidity of the spring.



Section of BOGE Nivomat self-levelling units

A. Not levelled condition

B. Levelled condition

Suspension and wheels

Nivomat self-levelling suspension

44.


Following vertical movements of the wheels, produced by irregularities of the road surface which are more or less accentuated, the oil in the low pressure chamber (2) is drawn in by the oil pump (8), through the perforated stem (7) and the inlet valve (11).

From the pump the oil is sent, via the outlet valve (12) and the duct (13), to the lower chamber of the shock absorber (4): from here, the oil reaches the high pressure chamber (2), via a duct (14) and compresses the gas enclosed by the diaphragm (3).

The greater pressure which is produced also acts in the lower chamger of the shock absorber (4), causing the extension of the stem (5) and the raising of the vehicle.

When the splining (10) starts to project from the piston (6) this means that the optimum driving height has been reached (condition B) and the oil under pressure can flow through the port (9) and the perforated stem (7) into the low pressure chamber (2).

The distance at which this levelling condition is reached is around 2000 m according to the road surface. A very irregular surface causes a very energetic pumping action which can lead to a levelling of 15-20 mm higher than the nominal value (greater distance from the surface of the uneven ground).



P3U05CG01

Raising of the vehicle on uneven surface

The height of a laden vehicle is usually kept levelled from one day to another, unlike the breaks which occur during a journey (stops for fuel, meals, overnight stays, etc.).

When the vehicle is unloaded, the bodywork rises as in a system with conventional springs and then lowers immediately because the oil is transferred from the high pressure chamber to the low pressure chamber until it reaches a nominal level at which it remains.

Copyright by Fiat Auto


Suspension and wheels Nivomat self-levelling suspension

44.

Typical curve for Nivomat suspension

The graph below compares the typical curves for a conventional shock absorber with a BOGE Nivomat self-levelling unit.

The horizontal axis shows the downward movements (s) of the bodywork, whilst the vertical axis shows the loads (N) applied to the vehicle.



Typical curves for a conventional shock absorber and a Nivomat self-levelling unit

The conventional shock absorber is fitted with a spring whose rigidity is constant and for whom a downwards movement of the bodywork (s) is directly proportional to the load applied (N) with its characteristics being linear (dotted line).

With the empty weight defined as Pv and the weight fully laden Pc, it is possible to obtain the respective operating points A* and B* on the linear characteristic and the relative downwards movement S*.

Suspension and wheels

Nivomat self-levelling suspension

44.

Nivomat units are equipped with lesser rigidity springs which also have the flexible effect of the compressed gas which varies according to the load applied and the effect of the end of travel flexible buffer (dotted line). Three typical curves can be defined:

1. typical curve (linear) for the single mechanical spring, less steep than the curve for a conventional shock absorber as it is less rigid;

2. typical curve for the Nivomat unit, with no load, which is added to the flexible effects of the mechnical spring, the compressed gas (around 25 bar) and the end of travel damper;

3. typical curve for the Nivomat unit, fully laden, which differs from the previous one through a greater component due to the compressed gas (pressure increased to around 80 bar).

It should be noted that in Nivomat units the rigidity increases as the load applied increases.

The curve (2) shows the operating points A and B in the empty and full load conditions and the relative downwards movement S with the vehicle stationary.

When the vehicle starts driving, in Nivomat units the oil is transferredfrom the low pressure chamber to the high pressure chamber as a result of the uneveness of the road surface.

As the pressure of the gas increases, the operating point gradually moves towards the left on an increasing rigidity curve, causing the raising of the vehicle.

After having travelled a distance of around 2000 metres operating point C is reached, corresponding to the levelling condition: the height of the vehicle fully laden is equal to the nomial one (points A and C are on the same vertical).

Main advantages of BOGE Nivomat self-levelling suspension

The main advantages of this system are:

- quick and realistic check of the driving height (maintains the ideal distance betwen the axle and the bodywork);
- improved driving safety and comfort as a result of the more consistent manoeuvre conditions for all load conditions;
- optimum vehicle stability;
- damping dependent on the load corresponding to flexible rigidity variations eliminating the compromise between low load and heavy load conditions required in conventional systems;
- better vehicle geometry fully laden, maintaining an optimum aerodynamic profile, resulting in a fuel saving;
- decreased tendency for the tyres to rest on the shoulder in heavy load conditions, thereby reducing wear;
- the driving height on the right and the left is equal evenif the load is not positioned in the centre;
- precise headlamp alignment for all load conditions;
- damage due to collisions minimized because the bumpers always remain at the same height;
- the energy requirements are entirely satisfied by the movement of the suspension (without an increase in consumption, without electrical wiring or hydraulic pipes);
- no power units or electric motors are required;
- no height sensor needs setting
- compact, modular design (pump, regulator, tank and shock absorber in a single unit);
- location near the wheels which avoids height adjustment tolerances;
- lighter than other systems;
- limited costs if compared with other self-levelling systems;
- environmentally friendly;
- easy to fit or retrofit.

Copyright by Fiat Auto

44

PROCEDURE FOR CHECKING EFFICIENCY OF SELF-LEVELLING UNITS


The efficiency of BOGE Nivomat self-levelling units is checked by measuring the height of the vehicle empty-and fully laden in static conditions after a journey which allows bedding in.

NOTE The measuring conditions must be as follows:

- fuel tank half full.
- → vehicle on a horizontal plane,
- service and parking brakes released,
- y gearbox in first gear or position P.

Prepare the vehicle by carrying out the following checks:

- check the inflation pressure of the tyres and, if necessary, adjust it,
- inspect the underbody and remove any dirt, dust, mud or sand,
- remove anything from the luggage compartment which is not part of the original equipment of the vehicle.



Measuring height H of the vehicle between the lower edgeof the wheel arch and the ground

Proceed with measuring height H by carrying out the following operations:

- 1. place the vehicle on a horizontal plane; do not use the brakes to stop the vehicle, but let it run until it stops by itself; engage 1st gear or place the selector lever in position P (on vehicles with automatic transmission);
- 2. measure distance H levelled with the vehicle unladen without a driver and make a note of it in a table; the maximum permissible difference between the right side and the left side is 6 8 mm;
- 3. place a load of 160 kg in the luggage compartment, let two people sit in the rear seats or two people in the front seats (or place a weight of 70 kg for each person);
- 4. measure distance H not levelled and make a note of it in a table; the maximum permissible difference between the right side and the left side is 6 8 mm;

Nivomat self-levelling suspension

44.

- 5. drive the vehicle, with this load condition, for 2000 m on a road which preferably has an uneven surface;
- place the vehicle on a horizontal plane; do not use the brakes to stop the vehicle, but let it run until it stops by itself; engage 1st gear or place the selector lever in position P (on vehicles with automatic transmission);
- 7. measure distance H levelled and make a note of it in a table; the maximum permissible difference between the right side and the left side is 6-8 mm;
- 8. after the last measurement fully laden, let the people get out (or remove the weights) and remove the load from the luggage compartment and drive the vehicle for 2000 m;
- 9. measure distance H levelled with the vehicle unladen without the driver and make a not of it in a table; the maximum permissible difference between the right side and the left side is 6 8 mm.

Compare the height values measured for the vehicle with the ones in the table below: if there are not within the recommended tolerances, replace the Nivomat self-levelling units.

Table of levelled and non levelled height values for the vehicle

LOAD	HEIGHT H(*)			
CONDITIONS	Not levelled	Levelled		
Empty	<u>-</u>	640±5		
Fully laden (**)	590±5	620±5		

(*) Values in mm

(**) Four persons + 160 kg luggage approximately equivalent to the maximum permissible load.



All the values for the measurements carried out on the vehicle are aceptable with a tolerance of ± 5 mm.


With the vehicle levelled, the difference for distances H, between the vehicle empty and fully laden, should not exceed 20 mm.

INSTRUCTIONS FOR SCRAPPING SELF-LEVELLING UNITS

Before sending Nivomat self-levelling units to be scrapped they must be de-pressurized.



In normal conditions, the pressure inside Nivomat units is 25 bar. If they are scrapped without being de-pressurized the units could explode and cause serious damage to surrounding people and objects.



In order to de-pressurize Nivomat self-levelling units two small openings must be made with a drill in the areas shown at the side, corresponding to the high pressure chamber (1) and the low pressure chamber (2). The openings should be 1 mm in diameter and at least 8 mm deep.

Position of openings for de-pressurizing Nivomat units



As a result of the high internal pressure, a mixture of oil and gas will be sprayed so it is advisable to carry out the drilling operation shielded behind a protective screen.


NOTE The self-levelling unit is de-pressurized when the stem can be thrust manually.

Suspension and wheels

Nivomat self-levelling suspension

REMOVING-REFITTING

44.



į.

NOTE This Section describes the procedure for removing-refitting the BOGE Nivomat self-levelling units used on the LANCIA k SW.

With regard to the removal and refitting of the other components of the rear suspension, not covered in this publication, reference should be made to Section 44 of Volume 1, concerning the LANCIA k '96 range (Publication no. 506.475/14).

P3U11CG01







Place the car on ramps and remove the rear wheels.


Open the tailgate, then carry out the following operations:

- remove the rear seat which is a press fit, undo the bottom bolt securing the seat belt and side squab to the body shell and withdraw the side squab upwards to release it from the catch;
- 2. fold down the rear squabs and remove the boot cover screen by pressing the release buttons;
- 3. remove the bolts securing the boot screen seating;
- 4. undo the internal nut securing the boot side moulding;






P3U11CG03



P3U11CG04


Suspension and wheels Nivomat self-levelling suspension


44.







- undo the bolt and remove the boot side moulding;
- **NOTE** Disconnect the boot courtesy light connector.






- 2. undo the front bolt on the boot side trim and the bolts securing the side squab catch;
- 3. remove the cam-locks (1) and remove the folding shelf, then undo the side bolt (2) of the boot side trim;
- 4. undo the rear bolt of the boot side trim and remove the trim;






Suspension and wheels

Nivomat self-levelling suspension




P3U13CG01

1. undo the three bolts and remove the seat belt winder;




P3U13CG02


- 2. using tools 1857168000 1860973000, undo the nut securing the flexible mounting to the strut of the selflevelling unit;
- 3. undo the three nuts securing the self-levelling unit to the body shell;
- 4. undo the two bolts securing the Nivomat self-levelling unit to the stub axle and remove the unit.







P3U13CG04






Dismantling


Carry out the following operations:

1. place the Nivomat self-levelling unit on the pneumatic tool 1874555000 and operate the lever (1) so as to lock the unit;





2. adjust the position of the hooks (2), bringing them up to the spring, then place the tool under pressure so that the spring begins to compress;







3. undo the nut securing the mounting to the strut;

Suspension and wheels

Nivomat self-levelling suspension



- remove the top mounting, then release the spring and remove it.




Self-levelling unit and coil spring

NOTE If the self-levelling unit is found to be faulty, the entire unit should always be replaced.

> Also check that the spring is not cracked or deformed such that its efficiency is impaired.

The coil springs are divided into two categories, identified by a paint stripe on the central coil. Matching springs of the same category must be fitted.





Fitting

7 daNm (nominal torque) 6.3 daNm (wrench calibration value)

Refit the components of the self-levelling unit by following the reverse procedure, and tighten the nut securing the mounting to the strut to the specified torque.



Using tool 1860973000 causes a change in tightening torque from 7 daNm to 6.3 daNm.

NOTE Refit the self-levelling unit by reversing the procedure for removal.

Suspension and wheels Tightening torques

PART	Thread	Tightening torques
		daNm

REAR SUSPENSION

REAR SUSPENSION		
Nut securing rear wheel hubs to knuckle	M 24 × 1.5	32
King pins securing rear wheels to hub	M 12 × 1.25	9.8
Nut securing self-levelling unit to vertical link (knuckle)	M 12 × 1.25	9
Self-locking nut securing self-levelling unit to rubber mounting	M 14 × 1.5	7
Self-locking nut secruing self-levelling unit mounting to bodywork	M 8	2.5
Bolt securing longitudinal rod to vertical link (knuckle)	M 12 × 1.25	10
Bolt with tapered and plain shake-proof washer for securing longitudinal rod to bodywork	M 10 × 1.25	6
Nut securing longitudinal rod to mounting	M 10 × 1.25	6
Bolt securing stabilizer bar U-bolt to cross member	M 8	2.8
Bolt securing stabilizer bar to link rod	M 10 × 1.25	5
Bolt securing link rod to mounting bracket	M 10 × 1.25	5
Bolt with shake-proof tapered plain washer securing cross member to bodywork	M 10 × 1.25	6
Self-locking nut securing transversal rods to cross member and shock absorber	M 12 × 1.25	9
Bolt for locking sleeve for adjusting rear transversal rods	M 8	1.5
	L	l

LANCIA K SW

Electrical equipment

Index

55.

	page
LIGHTING	
Rear light clustersAdditional brake light	1
light cluster	4
- Rear no. plate courtesy light	5
- Luggage compartment courtesy light	5
Centre rear courtesy lightCourtesy light on rear pillar	6 7
VARIOUS DEVICES	
Steering column switch unitRearscreen wiper	8 9
JUNCTION UNIT	
- List of fuses and main circuits protected	11
RADIO EQUIPMENT	
 Location of radio system compnents (normal range) 	12
- Location of radio system	
components (top range)	13
 Removing-refitting tweeter from rear pillar 	14
- Removing-refitting speaker	
from tailgate	14



For anything not dealt with in this section, refer to section 55 of the LANCIA k Manual 2 volume, print n 506.475/01

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Tecnica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/15 - Giugno 1996 - 400 Printed in Italy - Tip. Bogliani - TORINO order no. 60444456

LANCIA k SW

Electrical equipment Wiring diagrams

		•	pag
			•
 Wiring diagrams 			•
- Kev			•



Consult section 55 Wiring diagrams of the LANCIA k manual volume 2, publication no. 506.475/01 for information not given in this section.


COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A.
D.M.C. - M.P.S.
Servizi Post Vendita - Assistenza Tecnica
10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5
Publication no. 506.475/12 - Aprile 1996 - 400
Printed in Italy - Tip. Stampart - TORINO
order no. 60444236







REAR LIGHT CLUSTERS

Removing-refitting light cluster located in the rear wing


- 1. Working from inside the vehicle, open the access flap for the electrical equipment devices.
- 2. Undo the bolts shown in the diagram and partly extract the light cluster from its housing, acting carefully.
- 3. Disconnect the electrical connector shown in the diagram and remove the light cluster from the vehicle.4. Press gently on the retaining tabs shown
- Press gently on the retaining tabs shown in the diagram and extract the bulb support.












P3U01EL03

Electrical equipment

Lighting

55.









Replacing bulbs for light cluster located in rear wing

NOTE When replacing the bulbs it is not necessary to remove the light cluster.







- A. Brake light and side light
- B. Direction indicator
- C. Side light

Removing-refitting light cluster located in rear tailgate


- 3. Undo the fixing bolts and remove the tailgate handle.
- 4. Undo the bolts fixing the tailgate lining.



P3U02EL02









P3U02EL04


Electrical equipment Lighting

55.





P3U03EL02









- 1. Remove the tailgate lining, taking care not to damage it.
- 2. Disconnect the electrical connector
- shown in the diagram.
 3. Undo the bolts shown in the diagram and remove the complete light cluster.

Replacing bulbs (light cluster located in rear tailgate)


- 4. Proceed as described up until point 2, then act on the tabs shown in the diagram to extract the bulb support and replace the faulty bulbs.
- 5. The functions of the bulbs illustrated in the diagram are as follows:
 - A. Rear fog lamp
 - B. Reversing light







P3U03EL05






CENTRE REAR COURTESY LIGHT

Removing-refitting


1. Working carefully, remove the rear courtesy light from its housing.








2. Use a screwdriver as illustrated in the diagram to separate the electrical connector from the courtesy light.





3. To replace the bulb, act at the point shown in the diagram.







REAR PILLAR COURTESY LIGHT




- 1. Using a screwdriver, remove the lens cover for the courtesy light, taking care not to damage it.
- 2. Undo the bolt shown in the diagram and separate the courtesy light from the pillar.
- 3. Disconnect the electrical connector shown in the diagram and remove the courtesy light.
- 4. Raise the upper part of the map reading light and extract the bulb.











Various devices

55.

STEERING COLUMN SWITCH UNIT




P3U08EL01




1	Windscreen washer pump
2	Rearscreen washer pump
3	Windscreen wiper
4	Rearscreen wash/wipe
5	Windscreen wiper intermittent device

P3U08EL02

Rearscreen wash/wipe switch wiring diagram



	P3U08EL03				
Co	onnector E (4 way)	Cable colour			
1	Rearscreen wash/wipe	CN			
2	Free				
3	Free				
4	Rearscreen wash/wipe	N			



P3U08EL04




For anything not dealt with, refer to Section 55 - Electrical Equipment of the "LANCIA k" Service Manual (print no. 506.475/14).


Electrical equipment

Various devices


55.








P3U09EL02




REARSCREEN WASH/WIPE

Removing-refitting rearscreen wiper motor

- 1. Lift up the protection for the nut fixing the rearscreen wiper arm, then remove it complete with seal.
- 2. Remove the shield for the jet from the rearscreen wiper motor threaded pin.
- 3. Remove the luggage compartment lining, working as described on pages 2 and 3, then disconnect the electrical connector shown in the diagram.
- 4. Separate the pipe from the jet.
- 5. Undo the bolts shown and remove the rearscreen wiper motor.








P3U09EL05

Various devices

55.








P3U10EL02






Removing-refitting rearscreen washer fluid pump and reservoir

- 2. Lift up the luggage compartment shelves and gain access to the rearscreen washer fluid reservoir, undo the bolts shown and remove the reservoir.
- 3. Drain the fluid from the reservoir and disconnect the electrical connector shown in the diagram.
- 4. Acting carefully, lift the rearscreen washer pump towards the outside of the reservoir, then extract it and disconnect the pipe from the pump.







P3U10EL04

LIST OF FUSES AND MAIN CIRCUITS PROTECTED


Fuse No.	Amp.	Ideo- gram	Circuit protected	Fuse No.	Amp.	ldeo- gram	Circuit protected
1	15	Services 1	Switch signalling I.G.E. control unit for checking fuse for braking lights; braking lights; signal for ABS-auto-	5	10	Services 5	Electric, heated mirrors; electric, heated, folding mirrors control unit; electronic automatic transmission.
			matic transmission of brake lights pressed; i.e.	6	30	□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Climate control system.
			system for diesel- turbo.	7	15	Services 7	Radio; electric aeriel; front cigar lighter.
2	5	Services 2	Switch signal for I.G.E. control unit for dipped	8	10		Direction indicators/- hazard warning lights system
			headlamps; main beam headlamps relay; instru- ment panel; fog light- s/rear fog lamps warn-	9	5	Services 9	Relay for electric heated seats compressor-relay feed
			ing light; Infocenter. In- strument panel light dimmer; exterior lights	10	5	Services 10	Electro-mechanical boot release relay
			switch; heater pads switch light; electric mirrors switch light; front cigar lighter light; ashtray light; headlamp	11 12 13	25 20 25	Services 11 Services 13	Spare Headlamp washer Sun roof-reversing light- s-reversing lights signal for electro-mechanical
			alignment light; Radio; Electric windows. Elec- tro-chromic internal rear view mirror; signalling	14 15	25 25		mirror Windscreen wash/wipe Motors for left and right electric front windows
			instrument for timer; electric windows inhibitor device; infra red receiver signal; passenger visor light.	16	15	Services 16	Rearscreen wash-/wipe-Infocenter; Air-Bag system; I.G.E. control unit signal - signal to front electric windows control unit - signal to electric rear windows control unit - Servotronic control unit.
				17	5	Services 17	Infocenter; instrument panel; radio (security code); signal for auto-
3	15	Fuel Pump	Fuel pump; key + battery position.				matic transmission; audible signal for automatic transmission.
4	10	Services 4	4 puddle lights; 2 floor lights; left and right rear courtesy lights; luggage	18	5	Services 18	Siren for alarm; receiver for alarm; LED for alarm.
			compartent light; glove compartment light; front courtesy light;	19	25		Motors for locking doors; motor for unlocking fuel filler.
			timer for front courtesy light.	20	5	Services 20	Electronic key system, (Lancia CODE).

Electrical equipment

Radio equipment

55.

LOCATION OF RADIO SYSTEM COMPONENTS (NORMAL RANGE)




P3U12EL01

Components key

- 1. Battery
- 2. 60A protective fuse for IGE control unit/junction unit
- protective 3. 30A fuse for ignition switch/alarm system
- 4. Right front speaker
- 5. Speaker in right front door
- 6. Earth on carrier device
- 7. Left front speaker
- 8. Ignition switch

- 9. Amplifier for aerial in rearscreen
- 10. Right rear speaker
- 11. Left rear speaker
- 12. Speaker in tailgate (woofer)
- 13. Speaker in left front door
- 14. Junction unit
- 15. Radio
- 16. Main connector block
- 17. Earth on bodyshell

LOCATION OF RADIO SYSTEM COMPONENTS (TOP RANGE)



P3U13EL01

Components key

- 1. Battery
- 2. 60A protective fuse for IGE control unit/junction unit
- 3. 30A protective fuse for ignition switch/alarm system
- 4. Right front speaker
- 5. Speaker in right front door
- 6. Earth on carrier device
- 7. Left front speaker
- 8. Ignition switch
- 9. Amplifier for aerial in rearscreen

- 10. Right rear speaker
- 11. Left rear speaker
- 12. Speaker in tailgate (woofer)
- 13. Left rear earth
- 14. Compact Disc (CD) (optional)
- 15. Amplifier for radio
- 16. Speaker in left front door
- 17. Junction unit
- 18. Radio
- 19. Main connector block
- 20. Earth on bodyshell


P3U14EL02


Electrical equipment

Radio equipment

55.

3









REMOVING-REFITTING TWEETER FROM REAR PILLAR


- 1. Using tool 1878077000, remove the rear pillar cover.
- 2. Undo the bolts shown and separate the tweeter from its housing.
- 3. Disconnect the electrical connector and remove the tweeter.

REMOVING-REFITTING SPEAKER FROM TAILGATE


- 4. Remove the tailgate lining (see pages 2 and 3), then disconnect the electrical connectors shown in the diagram;.
- 5. Undo the bolts shown and extract the speaker from its housing.



When refitting, make sure that the anti-vibration sponge behind the speaker is fitted correctly.







P3U14EL05

LANCIA k SW

Electrical equipment Contents

55.

	page
Electrical symbols	1
How to read the wiring diagr	am 4
Wiring diagrams	5
Connector blocks	17
Key to components	19



For information not given in this section, consult sect. 55 Wiring diagrams of the LANCIA k manual volume 2, publication no. 506.475/01.

3U00FL

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Tecnica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/15 - Giugno 1996 - 400 Printed in Italy - Tip. Bogliani - TORINO order no. 60444456

Electrical equipment Wiring diagrams

55.

NAME	ENGINE					
IVAIVIE	1998	1998 T	2446	2959	2387 Td	
Provision for car radio, mid range	5	5	5	5	5	
Provision for car radio, high range	7	7	7	7	7	
Turn signals and warning light - Hazard warning lights and warning lamp - Braking lights - Reversing lights	9	9	9	9	9	
Windscreen wash/wipe - Rear wash/wipe - Headlamp washer - Electric horns	11	11	11	11	11	
Courtesy light	13	13	13	13	13	



55.

Electrical symbols

				··-	And the second s
<u> </u>	Positions		Cold starting (starter)	30 15	Ignition discharge
	Main beam head- lamps		Water in fuel filter	[10]	Dipped headlamps
	Heated seat		Glow plug preheating	\$\psi\$	Turn signal with central locking warning light
	Seat belt	C ® _	Turbo charger pressure	[a	Electric horns
[444]	Heated rear wind- screen		Rear fog lamp		Left turn signal
	Handbrake on and low brake fluid level	(D)	Fog lamps		Right turn signal
(ABS)	A.B.S.	(O)	Brake lining wear	35	Engine cooling system
	Hazard warning lights		Turbocharger pressure		Windscreen wiper
	Turn signals		Automatic transmission fluid temperature		Electrically operated sun roof
	Handbrake and low brake fluid level	120 Km/h	Speed limit	### 	Catalytic converter temperature
[F-]	Recharging		Fuel level		Resistance
6	Engine oil pressure	J.	Coolant temperature		Diode
					P3U01FL01

Electrical equipment

Wiring diagrams

LANCIA k SW

55.

Electrical symbols

positive and the second		
Warning light	☐ ☐ Trip computer control	Differential lock
Bulb	Electronic injection	Automatic transmission fluid temperature
다 Fuse with reference 나 number	Engine oil level	()()° Temperature
Switch open	BRAKE Brake fluid level (Japanese version)	Antitheft device
Selector switch	Doors open	Electrically-operat- ed windows
Button open	Central locking	Ē Earth
Coil-controlled switch (Relay)	SPORT Electronic suspension system sport setting	Number plate lights
Engine	K Transistor	Pulse generator (Timer)
Rearscreen wash/wipe	Air-Bag	Analogue clock
Headlamp washer	ANTI A.B.S. (Japanese version)	88:88 Digital clock
Windscreen wash/wipe	المجابعة STOP Vehicle brake failure	Speedometer
Rear wash/wipe	Windscreen wiper	Rev counter

P3U02FL01

[886]	Digital speedometer
<u>таманчайнены</u>	Digital rev counter
	Digital fuel gauge
B	Analogue fuel gauge
	Analogue coolant tem- perature gauge
	Econometer
<u> </u>	Digital coolant tempera- ture gauge
	Engine oil temperature
	Engine oil pressure gauge
	Voltmeter


P3U03FL01

Electrical equipment

Wiring diagrams

55.

How to read the wiring diagram



Reference key

P3U04FL01

- A Component number
- B Connection number
- C Identification of connector on component
- D Connection pin number
- E Taped ultrasound welding in wiring bundle


3704FL


Provision for car radio, mid range -

Electrical equipment

55.

Provision for car radio, mid range -





Provision for car radio, mid range


Key to components

- 7 8 9 73 73 73
- Battery
 Main junction unit
 Earth on body
 Secondary juntion unit
 OAA fuse protecting I.G.E. control unit/junction
- 73C 30A fuse protecting ignition switch/antitheft de
- 75 Junction unit (facia)
 90 Connection between facia cable and left front door cable
- 91 Speaker on left hand front door 96 Earth on carrier 100 Connection between facia lead and left longitu-
- dinal lead
- 105 119B Ignition switch
 Connection between facia cable and right longitudinal cable

- 122 Speaker on right hand from 164 Left hand rear speaker 166 Amplifier for aerial on bacl 166A Rear cable connection on 169 Right hand rear speaker 227 Right front speaker 288 Left front loudspeaker 295 Radio cable connection 296 Radio cable connection Amplifier for aerial on back window Rear cable connection on rear window Speaker on right hand front door Connection between facia cable and right front door cable
- 426 Speaker on tail-gate (woofer)
 428 Connection between left longitudinal cables/left
 tail-gate for speaker
 N.D. Taped ultrasound welding in wiring bundle

P3U07FL01

Z D



Wires involved in the wiring diagram are marked with an asterisk


3U08FL


6

V-96 - Annulla e sostituisce

P3U08FL01

Provision for car radio, high range -






P3U09FL01

V-96 - Supersedes previous version

Copyright Fiat Auto



Key to components Provision for car radio, high range


- 7 Battery
 8 Main junction unit
 9 Earth on body
 73 Secondary juntion unit
 73B 60A fuse protecting I.G.E. control unit/junction
- unit 73C 30A fuse protecting ignition switch/antitheft de-
- 75 Junction unit (facia) 90 Connection between facia cable and left front
- 91 Speaker on left hand front door96 Earth on carrier100 Connection between facia lead Connection between facia lead and left longitu-
- dinal lead
- 105 1198 Ignition switch
 Connection between facia cable and right longitudinal cable
- 120 Connection between facia cable and right front door cable
- Speaker on right hand front door Amplifier for car radio
- Left hand rear speaker
- Amplifier for aerial on back window 166A Rear cable connection on rear window
- Connection between left longitudinal cable and right longitudinal cable Right front speaker
- 122 151 164 166
- 169 Right hand rear speaker178 Left rear earth181 Connection between lef
- 227


228 295 296 422 426 428 Left front loudspeaker Radio cable connection Radio cable connection


Pautifloi

- Connection between facia/left longitudinal cables speaker on tail-gate (woofer)
 Connection between left longitudinal cables/left
- Taped ultrasound welding in wiring bundle tail-gate for speaker

Z O







Wires involved in the wiring diagram are marked with an asterisk


RV 119B ★ BN 181*

 ∞

Wiring diagrams Electrical equipment

55.

Turn signals and warning light - Hazard warning lights and warning lamp - Braking lights - Reversing lights - R



55.

33A

₩ AB 75 F

V 68

VN 85B

Connection between facia cable and right engine bay cable H 85B BR 85 B AN n.d. HR 347 (Turbo D) BR 340 RN 342 N 26 B 26

> VN 346 AB 341 *

73C 73B/c

175

178

BG 78C

L 26

V 26

N n.d.

€ 84

75E

Junction unit (facia)

₩AG 104B

LB nd

* AN n.d.

₩ AV 85B ₩ LG 78A -75

AR 104B * **★** LG 75E AG 119C MB n.d. AV 119C 78A NZ 101 CN 76B Z 85D. Instrument panel BN 768 -- CB 76B _ G n.d. _ LR 32B Nn.d. And. * . RV 85B AN n.d.

Connection between facia lead and left longitudinal lead N 107B

8


M 105


Rnd


CN 296

AN 296

A 296_ C 296







Wires involved in the wiring diagram are marked with an asterisk

GV 175S

₩N.n.d.

G 175D

Left front light cluster Left front earth

Key to components

Turn signals and warning light - Hazard warning lights and warning lamp - Brake lights - Re-

Battery Left side turn signal

105 Ignition switch
131 Earth on steering column mount
171 Supplementary stop light indicator
172 Right tail-light cluster on fixed part
174 Right tail-light cluster on mobile part
175 Connection between left longitudinal cable and

104 Stalk unit
D Turn signal/parking light stalk
E Main beam flasher button
F Main beam control switch

AB n.d. 06 ZN

Gn.d.

M 75F

8 Main junction unit
9 Earth on body
13 Reversing lights switch
27 Right front earth
30 Right front light cluster
33A Connection between facia cable and right engine bay cable
73 Secondary juntion unit
73B 30A fuse protecting I.C.E. control unit/junction

73C 30A fuse protecting ignition switch/anti-theft de-VICE

177 Left tail-light cluster on mobile part 178 Left rear earth 179 Left ail-light cluster on fixed part 271 Braking light switch 341 Right side turn signal 343 40A starter relay 345 Right front earth N.D. Taped ultrasound welding in wiring

tail-gate cable Left tail-light cluster on mobile part

175

Rn.d.

N 107A N 107A

₩Sn.d.

H 174

laped ultrasound welding in wiring bundle

75 Junction unit (facia) E2 Turn signal/hazard warning light flasher IGE control unit.

A Trailer turn signal warning light
L Left turn signal warning light
L Right turn signal warning light
N Handbrake warning light
N Handbrake warning light
S Infocenter ECU
Fearth on floor pan
Connection between facia lead and left longitudi-76 IGE control unit.
78 Instrument panel

nal lead


10

V-96 - Supersedes previous version

Publication no. 506,475/15


P3U15FL01

Windscreen wash/wipe - Rear wash/wipe - Headlamp washer - Electric horns -



Component location Electrical equipment

55.



Windscreen wash/wipe - Headlamp washer - Electric horns

P3U16FL01

Key to components

- Electric horns Left front earth
- Battery

104

- bay cable 33A. Connection between facia cable and right engine bay cable
- 73 Secondary juntion unit 73B 60A fuse protecting I.G.E. control unit/junction
- 73C 30A fuse protecting ignition switch/anti-theft de-
- 74 60A fuse protecting peripheral control unit (en

- IGE control unit.

- Power earth on facia
 Windscreen wiper control unit
 Exterior lighting unit
 B Side light/number plate light switch
- gine bay))
 Junction unit (facia)
 E1 Switch discharge connector
 E3 Turn signal/hazard warning light flasher

- 8 Main function unit
 9 Earth on body
 27 Right front earth
 28 Headlamp washer pump
 31 Peripheral ECU (engine bay)
 E1 Dipped beam relay
 E2 Horn relay
 C32B Connection between facia cable and left engine 178 342 345 421 421 422 423 423 424 427 433 105 131 175 C Dipped beam/main beam switch
 D Parking light switch
 E Symbol light control switch
 1 Stalk unit
 A Windscreen washer / headlamp washer control Left rear earth Horn button
 Turn signal/parking light stalk
 Main beam flasher button Windscreen wiper control stall
 - - G Rear window wiper switch Main beam control switch


 - Ignition switch
 Earth on steering column mount
 Connection between left longitudinal cable and tail-gate cable
 - Electric windscreen washer pump Right front earth

 - Connection between facia/left longitudinal cables Connection between facia/left longitudinal cables Rear screen control relay.

 Rear wiper control intermittence

Electric pump for rearscreen washer Rear window wiper motor

laped ultrasound welding in wiring bundle



32B * BN 104D ₩HV n.d. **AV 104A** VB 858 HN n.d. AN 78D NZ n.d. **GR 103** V 78D C 103 Connection between facia cable and left engine bay cable _ Z 105 _BL 78C _ L 78D _ LR 78A AR 78C M 78D **BV 78D** GN 78D GR n.d. C n.d. BV 22 Z 343 AR 31A BR 31A M 14 GN 14 L 14 L LR 31_

> HN 69 AN 12


V 22


VB 5

AV 31

HV 31A*

BN 31A米






Wires involved in the wiring diagram are marked with an asterisk


V-96 - Supersedes previous version

Pauraelor

13

Courtesy light -






Key to components Courtesy light


- 73C 30A fuse protecting ignition switch/anti-theft de-8 Main junction unit 9 Earth on body 73 Secondary juntion unit 73B 60A fuse protecting I.G.E. control unit/junction
- 75 Junction unit (facia)
 79 Connection between facia cable and courtesy light
- 90 90
- Glove compartment / boot release control lighting Connection between facia cable and left front door
- 93 Puddle light on left front door 95 Left front door lock motor and
- Left front door lock motor and left front door open warning light
- 96 97 100 Earth on floor pan
- 105 Ignition switch 120 Connection between facia cable and right front nal lead Connection between facia lead and left longitudi
- door cable
- open warning light
 128 Timer controlling front/boot courtesy light
 131 Earth on steering column mount
 137 Luggage compartment ""
 141 Connection" Right front door lock motor and right front door

 - Earth on steering column mount Luggage compartment tail-gate lock assembly
- Connection between right longitudinal cable and


P3U19FL01

- alarm activated w/light 150 Connection between left longitudinal cable and 144 Puddle light on right rear door 146 Right rear door lock motor and right door open/car
- left rear door cable Puddle light on left rear door
- 153 155 car alarm activated w/light Left rear door lock motor and left rear door open/
- 162 163
- Luggage compartment lighting Left rear courtesy light for car interior
- 170 Right rear courtesy light for vehicle interior
- 173 175
- 176 178 181 Right rear earth Connection between left longitudinal cable and Luggage compartment tail-gate cable connection tail-gate cable
- Connection between left longitudinal cable and right longitudinal cable Left rear earth
- Left floor light
- Right floor light Connection between facia cable and receiver cable Infra-red ray receiver for anti-theft device
- 225 226 266 269 281 283 425 N.D. Front courtesy light for car interior Lighted panel on passenger side
- Right hand luggage compartment courtesy light Taped ultrasound welding in wiring bundle









. Wires involved in the wiring diagram are marked with an asterisk

JUZIFL

V-96 - Supersedes previous version

Publication no. 506.475/15

LANCIA k SW

Electrical equipment Connector blocks

55

CONNECTOR BLOCK CONTENTS

Explanation	of	codes	on	connector	
olocks					16
Wiring colou	r co	de			16
Connector bl	ocks	S			17


Electrical equipment

Connector blocks

55.

INTRODUCTION

Explanation of codes on connector blocks




- A Connection block identification number shown in wiring diagram
- **B** Wire colour identification code (see table at the foot of the page)
- **c** Identification number of wire target block with code
- **D** The code n.d. (connector block) identifies a taped ultrasound welding in wiring bundle

Cable colour codes


LR Blue-Red LV Blue-Green MB Brown-White MN Brown-Black te NZ Black-Violet RB Red-White RG Red-Yellow RN Red-Black RV Red-Green SN Pink-Black VB Green-White VN Green-Black VR Green-Red ZB Violet-White
nt k te k k

55.







421 Connection between facia/left longitudinal cables




423 Rear screen control relay




424 Rear wash/wipe control switch




Right hand luggage compartment courtesy light



426 Speaker on tail-gate (woofer)






P3U23FL01

Electrical equipment

Connector blocks

LANCIA k SW

55.



P3U24FL01

KEY TO COMPONENTS

- 1 Left front light cluster
 - Left front earth Electric horns

- 6 Left side turn signal
 7 Battery
 8 Main junction unit
 9 Earth on body
 13 Reversing lights switch
 27 Right front earth
 28 Headlamp washer pump
 30 Right front light cluster
 31 Peripheral ECU (engine b Headlamp washer pump
- 30 Right front light cluster 31 Peripheral ECU (engine bay) E1 Dipped beam relay E2 Horn relay 33A Connection between facia cable and right
 - 32B Connection between facia cable and left engine bay cable
- control 1GE fuse protecting engine bay cable Secondary juntion unit 60A
- 73C 30A fuse protecting ignition switch/car unit/junction unit
 - alarm
- 60A fuse protecting peripheral control unit (engine bay)) 74
- E1 Switch discharge connector E2 Turn signal/hazard warning light Junction unit (facia)
 - flasher
 - E3 Headlamp washer timer
 - IGE control unit.
- Instrument panel
- A Trailer turn signal warning light
- L. Left turn signäl warning light L1. Right turn signal warning light N. Handbrake warning light
- O Insufficient brake fluid level warning
 - Connection between facia cable and courtesy light cable
 - Power earth on facia
- Windscreen wiper control unit
- Glove compartment / boot release control Infocenter ECU 833
- Connection between facia cable and left 90
- Speaker on left hand front door front door cable
 - Puddle light on left front door
 - Earth on carrier 93 96 97
- Earth on floor pan

- 104 Stalk unit
- A Windscreen washer / headlamp washer control stalk

Right rear courtesy light for vehicle interior

Right hand rear speaker

Right tail-light cluster on mobile part Connection between left longitudinal ca-

170 Right rear courtesy light for vehicle in 171 Supplementary stop light indicator 172 Right tail-light cluster on fixed part 178 Right rear earth 174 Right tail-light cluster on mobile part 175 Connection between left longitudin:

Luggage compartment tail-gate cable

ble and tail-gate cable

Left tail-light cluster on mobile part

Left rear earth

connection

Left tail-light cluster on fixed part

- B Windscreen wiper control stalk C Horn button D Turn signal/parking light stalk E Main beam flasher button F Main beam control switch G Rear window wiper switch Ignition switch
- Hand brake warning light switch Connection between facia cable and right longitudinal cable
 - Connection between facia cable and Speaker on right hand front door right front door cable
- Puddle light on right front door Right front door lock motor and right 122 124 126
 - front door open and alarm on warning

Connection between left longitudinal cable and right longitudinal cable

81

- Front courtesy light control timer Earth on steering column mount 28 31 37
- sembly

Luggage compartment tail-gate lock as-

A Luggage compartment courtesy light B Tail-gate lock/release motor and alarm switch

Connection between facia cable and re-

ceiver cable

Infra-red ray receiver for alarm device

Left front loudspeaker

Right front speaker

225 226 227 227 228 266 269

Right floor light

Left floor light

- Electronic control unit for driver's side Connection between right longitudinal electric seat with memory 141
 - Right rear door lock motor and right door cable and right rear door cable Puddle light on right rear door 144 146
- open/car alarm activated w/light Connection between left longitudinal 150
 - cable and left rear door cable Amplifier for car radio
- Left rear door lock motor and left rear door open/car alarm activated w/light Luggage compartment lighting 151 153 155

Puddle light on left rear door

- Left rear courtesy light for car interior
- Left hand rear speaker
- Rear cable connection on rear window Amplifier for aerial on back window 162 163 164 166

MB Brown-White MN Brown-Black HV Grey-Green
LB Blue-White
LG Blue-Yellow
LN Blue-Black
LR Blue-Red
LV Blue-Green AR Light blue-Red AV Light blue-Violet BG White-Yellow AN Light blue-Black

Cable colour codes

Light blue C Orange White

G Yellow 271 Braking light switch
295 Radio cable connection
296 Radio cable connection
341 Right side turn signal
342 Electric windscreen washer pump
343 40A starter relay
344 Facia cable connection with anti-lock

GV Yellow-Green

HG Grey-Yellow

HN Grey-Black HR Grev-Red

GN Yellow-Black

GL Yellow-Blue GR Yellow-Red

H Grey L Blue

brake cable (A.B.S.)

Right front earth

345

nal cables nal cables

422 421

M Brown Black Connection between facia/left longitudi-

R Red **S** Pink Connection between facia/left longitudi-

V Green Z Violet Right hand luggage compartment courtesy

Rear wiper control intermittence

Rear screen control relay

AG Light blue-Yellow AB Light blue-White

Electric pump for rearscreen washer

Speaker on tail-gate (woofer) 426 Speaker on tail-gate (woo' 427 Electric pump for rearscree 433 Rear window wiper motor


NZ Black-Violet RB Red-White RG Red-Yellow RN Red-Black RV Red-Green SN Pink-Black VN Green-Black VR Green-Red ZB Violet-White **VB** Green-White BL White-Blue
BN White-Blue
BR White-Red
BZ White-Green
CA Orange-Light blue
CB Orange-White
CN Orange-Black

SUZZEL



55.

Provision for car radio, mid range - (See key following diagrams)




Electrical equipment


Wiring diagrams

55.

Provision for car radio, top range - (See key following diagrams)




Turn signals and warning light - Hazard warning lights and warning lamp - Braking lights - Reversing lights - (See key fallowing diagrams)



Copyright Fiat Auto




Windscreen wash/wipe - Rear wash/wipe - Headlamp washer - Electric horns - (See key following diagrams)



Publication no. 506.475/12

Courtesy light - (See key following diagrams)



Copyright Fiat Auto



KEY TO COMPONENTS:

- 1 Left front light cluster 3 Left front earth Electric horns

- 6 Left side turn signal
 7 Battery
 8 Main junction unit
 9 Earth on body
 13 Reversing light switch
 27 Right front earth
 28 Headlamp washer pump
 30 Right front light cluster
 31 Peripheral ECU (engine ba)
- Right front light cluster
 Peripheral ECU (engine bay)
 E1 Dipped beam relay
 C2 Horn relay
 C2 Horn relay and right
 - engine bay cable 33A
- Connection between facia cable and left engine bay cable 32B
 - 73 Secondary juntion unit 73B 60A fuse protecting IGE control unit/junction unit
- 73C 30A fuse protecting ignition/alarm 74 60A fuse protecting peripheral control unit
 - Junction unit (facia)
 E1 Switch discharge connector
 E2 Turn signal/hazard (engine bay) 75
- Turn signal/hazard warning

light

- E3 Headlamp washer timer IGE control unit.
- A Trailer turn signal warning light Instrument panel
- Insufficient brake fluid level warning L Left turn signal warning light
 L1 Right turn signal warning light
 N Handbrake warning light
 O Insufficient brake fluid level w
- Connection between facia cable and courtesy light cable
 - Windscreen wiper control unit Power earth on facia Infocenter ECU 83 83 85 87
- Glove compartment / boot release control
- Connection between facia cable and left front door cable 90
- Speaker on left hand front door Puddle light on left front door
 - Earth on carrier
- Earth on floor pan

- 104 Stalk unit
- A Windscreen washer / headlamp washer control stalk
- B Windscreen wiper control stalk C Horn button D Turn signal control / parking light
 - control stalk
- E Main beam flasher button F Main beam control switch G Rear window wiper switch
- 105 Ignition switch 117 Hand brake warning light switch 119B Connection between facia cable and right longitudinal cable
 - 120 Connection between facia cable and right front door cable
- Puddle light on right front door Right front door lock motor and right 122 Speaker on right hand front door 124 Puddle light on right front door 126 Right front door lock motor and
 - front door open indicator and alarm activation
- Luggage compartment tail-gate lock as-Front courtesy light control timer Earth on steering column mount 128 131
- A Luggage compartment light switch and alarm activation sembly
- Electronic control unit for driver's side Tail-gate lock/release motor 138
- Connection between right longitudinal electric seat with memory 141
 - Right rear door lock motor and right rear door open indicator and alarm activation cable and right rear door cable Puddle light on right rear door 144 146
- Connection between left longitudinal cable and left rear door cable Amplifier for car radio 150
- Puddle light on left rear door Left rear door lock motor and left rear door open indicator and alarm activation 151 153 155
 - Left rear courtesy light for vehicle interior 162 Lugage compartment lighting 163 Left rear courtesy light for vehicle i 164 Left hand rear speaker 166 Amplifier for aerial on rear window 166A Rear cable connection on rear wir 169 Right hand rear speaker
 - Amplifier for aerial on rear window
- Rear cable connection on rear window Right hand rear speaker

- 170 Right rear courtesy light for vehicle inte-
- Supplementary stop light indicator Right tail-light cluster on fixed part
 - Right rear earth
- Right tail-light cluster on mobile part Connection between left longitudinal cable and tail-gate cable
 - Luggage compartment tail-gate cable connection
 - Left tail-light cluster on mobile part Left rear earth
- Left tail-light cluster on fixed part Connection between left longitudinal
 - cable and right longitudinal cable
 - Right floor light Left floor light
- Right front speaker
- Receiver for alarm and door lock remote Left front loudspeaker 225 226 227 227 228 266
 - Connection between facia cable and receiver cable control unit 269
 - Radio cable connection Radio cable connection Braking light switch 271 295 296 341
 - Right side turn signal
- Electric windscreen washer pump 40A starter relay 342 343 344
- Facia cable connection with anti-lock brake cable (A.B.S.) Right front earth 345

Cable colour codes

A Light blue B White C Orange

G Yellow

H Grey L Blue

- Connection between facia/left longitudinal cables
- Right hand luggage compartment cour-Rear wiper control intermittence Rear wiper control relay 423 424 425
- Speaker on tail-gate (woofer) tesy light
- Electric pump for rearscreen washer Rear window wiper motor

HV Grey-Green
LB Blue-White
LG Blue-Yellow
LN Blue-Black
LR Blue-Red
LV Blue-Green
MB Brown-White MN Brown-Black **GV** Yellow-Green GN Yellow-Black HG Grey-Yellow GL Yellow-Blue GR Yellow-Red HN Grey-Black HR Grey-Red

M Brown

N Black R Red S Pink V Green

NZ Black-Violet

AB Light blue-White


Z Violet

- RB Red-White RG Red-Yellow RN Red-Black AG Light blue-Yellow
 AN Light blue-Black
 AR Light blue-Red
 AV Light blue-Violet
 BG White-Yellow
 - RV Red-Green BL White-Blue
 BN White-Blue
 BR White-Red
 BV White-Green
 CA Orange-Light blue
 CB Orange-White
 CN Orange-White
- SN Pink-Black VB Green-White VN Green-Black VR Green-Red


ZB Violet-White



Electric, heated front seats with memory and warning lights - (See key at end of wiring diagrams)



Copyright by Fiat Auto



Electric, heated front seats with memory and warning lights

8 Main connector block

9 Earth on bodyshell

73 Secondary connector block 73A 80A fuse protecting rear services

75 Junction unit (dashboard)

£1 Ignition discharge relay

78 Instrument panel B Driver's side h Driver's side heated seat warning light

B1 Passenger's side heated seat warning light 90 Connection between dashboard and left front

95 Left front central locking geared motor and sig-nalling of left front door open and anti-theft de-

96 Earth on carrier

119A Connection between dashboard and right longitudi nal cables

119B Connection between dashboard and right longitudi nal cables

119C Connection between dashboard and right longitudi nal cables

120 Connection between dashboard and right front door

128 Timer for front courtesy light
131 Earth on steering column support
138A Control panel for electrically adjustable driver's seat
138B Driver's seat backrest adjustment motor
138C Driver's seat height adjustment motor
138D Driver's seat height adjustment motor
138B Driver's seat sliding adjustment motor
138B Driver's seat lumbar adjustment motor
139 Driver's side seat heated pad
140 Switch for driver's side seat heated pad

149 Connection between left longitudinal and left seat

156 Connection between right longitudinal and right

seat cables 158 Control panel for electrically adjustable passenger

158A Passenger seat sliding adjustment motor 158B Passenger seat height adjustment motor 158C Passenger seat sliding adjustment motor 158C Passenger seat sliding

P3U50DL01

158E Passenger seat lumbar adjustment motor 159 Switch for passenger saet heater pad 58D Passenger seat backrest adjustment motor

160 Passenger seat heater pad 182 Rear connector block

Rear connector block

Relay for driver's heater pad
7.5A fuse protecting driver's heated pad relay
Relay for passenger heater pad
Relay for passenger heater pad

7.5A fuse protecting passenger heated pad relay 30A fuse protecting passenger electric seat 30A fuse protecting driver's electric seat Earth on centre tunnel

439 Driver's electric seat control unit

440 Line for initializing driver's seat control unit
441 Sensor detecting driver's seat in retracted position
442 Sensor detecting driver's seat in forwards position
443 Connection between right longitudinal and driver's
easy-enter electric seat cables

444 Connection between right longitudinal and passen ger easy-enter electric seat cables

443

Connection between right longitudinal and right side easy-enter electric seat

444

Connection between right longitudinal

B 159 *

and right seat cables

cables

₩ AR 184

Nn.d. *

* AR 160 **★** G 159

₩ N n.d

₩G n.d. ***** B 184


445 Passenger electric seat control unit
446 Line for initializing passenger seat control unit

447 Sensor detecting passenger seat in retracted position 448 Sensor detecting passenger seat in forwards position 453 Connection for sensors detecting driver's seat posi-

454 Connection for sensors detecting passenger seat po UOUS

N.D. Ultrasound welding taped in cable foom

55.



The cables in the wiring diagram, are marked with an asterisk

R 186 A

439 *

445

P3U510101

28

1 Left front light cluster 3 Left front earth 5 Left front bake pad wear sensor 6 Left side direction indicator 7 Batter 8 Main connector block 9 Earth on bodyshell 10 Button on bounet lid for engaging anti-theft device 11 Insufficient brake fluid level sensor 12 Reversing lights switch 14 Impulse generator for speedometer signal 12 Minimum engine oil level sensor 13 Reversing lights switch 14 Impulse generator for speedometer signal 15 Right front leath 16 Right front leath 17 Beripheral control unit (engine compartment) 18 Right front light cluster 19 Right front light cluster 10 Peripheral control unit (engine compartment 10 Right front light cluster 11 Dipped headlamps relay feed 12 Connection between dashboard and left 13 Romection between dashboard and left 14 Rower earth 15 Connection between dashboard and right 16 Connection between dashboard and right 17 Rower earth 18 Rower earth 18 Rower earth 19 Rower earth 20 Romection control unit (ashopard) 21 Rower light connector block 22 Rower light connector block 23 Rob protective fuse for I.E. control unit (dashboard) 24 Rower protective fuse for I.E. control unit (angine compartment) 26 Luction unit (dashboard) 27 Luction unit (dashboard) 28 Litherfit device compartment) 29 Rower earth and seated seat warning light 28 Lither's side heated seat warning	H Main beam headlamps warning light L Left direction indicator warning light L Left direction indicator warning light J Seat belts not fastened warning light J Seat belts not fastened warning light M Insufficient engine oil pressure warning light N Handbrake warning light / I.G.E. con- trol unit O Insufficient brake fluid level warning light T Voltmeter U Electronic rev counter V Fuel level gauge V Fuel level gauge V Electronic tachometer Z Electronic automatic transmission gear selector display Y Electronic tachometer Z Electronic tachometer Z Electronic tachometer Z Irip computer zeroing button Connection between dashboard and courtesy light cables Infocenter control unit Light for glove compartment / boot release controls Diagnostic socket for Fiat / Lancia tester Left rear view mirror A Motor for vertical positioning of left rear view mirror C Motor for vertical positioning of left rear view mirror E Outside temperature sensor Connection between dashboard and left front door cables Speaker in left front door Left front centrel Connection between dashboard and left front door cables Speaker in left front door open and alarm on Earth on carrier Earth on carrier Earth on floor Cigar lighter Connection between dashboard and left	C Switch for dipped beam headlamps / brake lights D Switch for parking lights E Switch for ideogram lights E Switch control unit A Fog lights switch B Rear fog lamps control switch C Headlamp alignment control unit OS Switch for windscreen/headlamp washer D washer Of control unit for anti-theft device Ing lights E Button for flashing main beam head- lamps F Switch for main beam headlamps 105 Ignition switch 107 Control unit for anti-theft device 108 Immobilizer control unit 115 Controls for electrically adjustable rear view mirrors 108 Connection between dashboard and right longitudinal cables 119C Connection between dashboard and right longitudinal cables 119C Connection between dashboard and right longitudinal cables 120 Connection between dashboard and right front door cables 121 Right rear view mirror A Motor for folding right rear view mirror B Motor for vertical positioning of right rear view mirror C Motor for vertical positioning of right rear view mirror D Right rear view mirror C Motor for horizontal positioning of right front door cables 122 Speaker in right front door 123 Control panel for right electric window on right door 125 Right front electric window motor 126 Right front electric window motor 127 Right front electric window on right door 128 Right front electric window on right door 129 Right front electric window on right door 126 Right front electric window on right door 127 Right front electric window on right door 128 Right front electric window on right door 129 Right front electric window on right door 129 Right front electric window on right door 120 Right front electric window on right door 120 Right foot electric window on right door 121 Right foot electric window on right door 122 Right front electric window on right door 123 Control panel for right feot door open 126 Right foot electric window on right door 127 Right foot electric window on right door 128 Right foot electric	A Luggage compartment is switch and anti-theft de B Tailgate locking/unlocki 168A Control panel for driver's ed justable seat control panel for driver's ed justable seat backrest adjust 138E Driver's seat height adjustr 138E Driver's seat height adjustr 138E Driver's seat lumbar adjustr 139E Driver's seat lumbar adjustr 139E Driver's seat lumbar adjustr 139E Driver's seat lumbar adjustr 140 Connection between left and right seat cables and left seat cables and left seat cables and left seat cables and right seat cables 157 Connection between righ and right seat cables Connection parsenger seat sliding adjur 158A Passenger seat breckrest ad tor 158E Passenger seat height adjur 158B Passenger seat heater pad 160 Passenger seat heater pad 161 Left rear speaker 165 Heated rear windser 165 Amplifier for aerial in rears 166 Amplifier for aerial in rears 167 Fuel level gauge 169 Right rear speaker 167 Fuel level gauge 169 Right rear speaker 171 Additional brake lights wai 172 Right rear light cluster on tion
light C Heated rear windscreen warning light D Fog lights warning light E Rear fog lamps warning light F Side lights warning light G Dipped headlamps warning light	Light dimmer Exterior lights control unit B Switch for side lights / number plate lights	127 Switch signalling seat belts not fastened 128 Timer for operation of front courtesy light 131 Earth on steering column support 137 Tailgate lock assembly	

450 N H H H H H H H H H H H H H H H H H H
297 Warning light for alarm / immobilizer 298 Electric front windows control unit (298 Connector for electric windows control unit (1) 300 Central locking electronic control unit (3) 300 Central locking electronic control unit (340 Right front brake pad wear sensor 341 Right side direction indicator 343 Starter relay 40A 345 Right front earth 422 Connection between dashboard and left longitudinal cables 1.5. A fuse protecting heated rear view mirrors 1.5. A fuse protecting heated rear view mirrors 20A protective fuse for ignition relay feed 1.5. A protective fuse for ignition relay feed 2.5. A protective fuse for ignition relay feed 3.5. A protective fuse for ignition relay feed 3.5. A protective fuse for ignition relay feed 3.5. A protective fuse for ignition relay feed 4.3. Device for operating direction indicators with doors closed 3.2. OA protective fuse for ignition relay feed 4.3. Preparation for radio phone 4.3. Device for operating direction indicators with doors closed 3.5. Dual function speaker for radio and radiophone in right front door 4.3. Dual function speaker for radio and radiophone in right front door 4.3. Dual function between right longitudinal and driver's electric seat control unit 4.4. Sensor detecting driver's seat in forwards position and passenger electric seat control unit 4.4. Sensor detecting passenger seat in forwards position 5. Sensor detecting passenger seat in forwards position 5. Sensor detecting passenger seat in forwards position 5. Sensor detecting passenger sea
and tailgate cables and tailgate cables 1755 Left no plate light 175 Seared motor for locking/ unlocking tail- gate 177 Left rear light cluster on movable section 178 Left rear light cluster on fixed section 179 Left rear light cluster on movable section 170 Left rear light cluster on fixed section 170 Left rear light cluster on fixed section 171 Left rear light cluster on fixed section 172 Left rear light cluster on fixed section 173 Left rear light cluster on fixed section 174 Left rear light cluster on fixed section 175 Left rear light cluster on fixed section 176 Left rear light cluster on fixed section 187 Rear connector block 188 Rear connector block 187 A 7.5A fuse protecting driver's heated pad 184 Relay for passenger heated pad 184 Relay for passenger electric seat 185 30A fuse protecting boot release electro-magnet 186 SoA fuse protecting boot release electro-magnet 187 A 30A fuse protecting boot release electro-magnet 188 25A fuse protecting boot release electro-magnet 189 30A fuse protecting heated rear wind-screen 190 Tailgate locking/unlocking relay feed 190 Alarm siran 200 Controlled damping suspension electronic control unit (S.C.S.) 219 Earth on centre tunnel 227 Right front speaker 228 Left front speaker 226 Left front speaker 227 Right front speaker 227 Right front speaker 228 Left front air vent controls light 239 Light for left centre air vent controls 290 Left front air vent controls light 291 Light for left centre air vent controls light 292 Right centre air vent controls light 293 Right centre air vent controls light 295 Radio cables connection 296 Radio cables connection
A Luggage compartment courtesy light switch and anti-theft device on B Tailgate locking/unlocking motor 168A Control panel for driver's electrically adjustable seat 28C Driver's seat backrest adjustment motor 138C Driver's seat height adjustment motor 138D Driver's seat length adjustment motor 138D Driver's seat lumbar adjustment motor 140 Switch for driver's side seat heated pad 141 Connection between left longitudinal and left seat cables 151 Amplifier for radio 156 Connection between right longitudinal and right seat cables 151 Amplifier for radio 156 Connection between right longitudinal and right seat cables 158 Passenger seat sliding adjustment motor 158 Passenger seat leight adjustment motor 158 Passenger seat height adjustment motor 158 Passenger seat lumbar adjustment motor 158 Passenger seat height adjustment motor 158 Passenger seat height adjustment motor 158 Passenger seat height adjustment motor 158 Passenger seat lumbar adjustment motor 158 Passenger seat leight claster on fixed section 171 Additional brake lights warning light 172 Right rear light cluster on movable section 174 Additional brake lights warning light 175 Right rear light cluster on movable section 175 Right re
dipped beam headlamps s parking lights ideogram lights old unit switch unit or windscreen/headlamp or windscreen/headlamp direction indicators / parkflashing main beam headlamps which unit or windscreen/headlamp direction indicators / parkflashing main beam headlamps who inti-theft device or old unit electrically adjustable rear ling handbrake applied between dashboard and inal cables between dashboard and inal cables between dashboard and or cables wirror or cables between dashboard and inal cables between dashboard and inal cables between dashboard and or cables between dashboard and inal cables between dashboard and or cables between dashboard and or cables wirror liding right rear view mirror heating resistor wirdow mirror for right front door open device on ling seat belts not fastened atton of front courtesy light ing column support

USZDL

Yellow-Green Grey-Yellow Grey-Black Blue-Green Brown-White Brown-Black Black-Violet Red-White Red-White Red-Black Red-Black of driver's seat Connector for sensors detecting position of passenger seat Radiophone aerial Connector for radiophone aerial Grey-Green Blue-White Blue-Yellow Blue-Black Green-Black Green-Red Violet-White Connector for sensors detecting position Control panel for right electric window on Micro-switch for electric windows in right Green-White Yellow-Red Pink-Black Blue-Red Grey-Red Pink Green Violet Light blue-White Light blue-Pellow Light blue-Black Light blue-Black White-Blue White-Bed White-Green White-Green White-Caren White-White-Black White-Black White-Wiolet Orange-Light blue Orange-White ole colour code Light blue left door Orange Blue Brown Yellow White Black Grey glass

Red

Micro-switch for electric widnows in left

LANCIA k Coupé

Electrical equipment

55.

page

LIGHTING

•	das discharge neadramps	
_	Complete light cluster	1
-	Location of gas discharge headlamp and automatic headlamp alignment correcomponents	cto
-	Xenon bulb	:
-	Reflective surfaces	:
-	Electronic control system	4
-	Automatic headlamp alignment corrector	Ę
-	Fault diagnosis	7
_	Checks and adjustments	8
	Headlamp alignment	Ę
-	Removing-refitting headlamp	10
_	Removing-refitting system components	11

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A.
D.M.C. - M.P.S.
Servizi Post Vendita - Tecnologie Assistenziali
Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia)
Publication no. 506.475/19 - Gennaio 1998 - 400
Printed in Italy - Tip. Stampart - Torino
order no. 60445103

GAS DISCHARGE HEADLAMPS

Introduction

Lighting devices are one of the most important active safety systems on a vehicle.

A need to improve the performance of current iodine bulb-based systems, in terms of emitted light energy, spectral range and bulb duration led to the development of gas discharge headlamp technology, and associated devices to allow operation on the vehicle.

Since July 1996, Italy has been subject to EC regulations governing homologation of these headlamps on vehicles. It has therefore been possible to adopt such devices on newly-homologated vehicles since that date.

This technology essentially offers three advantages:

- more efficient lighting allows lower electrical energy uptake under steady-state conditions;
- because the light emits more light, its size may be reduced (particularly the height) to allow the car's front end to be designed with greater freedom;
- the bulb lasts roughly twice as long as an iodine bulb.


Gas discharge headlamp technology has involved the development of a set of devices, which briefly include:

- a xenon bulb;
- optics (reflective surfaces of the headlamp);
- electronic control system, consisting of a reactor (ignitor) and control unit (ballast).

Due to its high light intensity, this type of bulb requires the adoption of an automatic alignment corrector (sensor and actutors).

COMPLETE LIGHT CLUSTER

Each light cluster contains all the components required to operate the discharge lamp (bulb, reactor, control unit and alignment control actuator). Conventional components are also present (side lights, turn signals, dipped beams).



1. Gas discharge bulb


bulb in a headlamp

- 2. Shade
- 3. Control unit (ballast)

Cross-section through the gas discharge

- 4. Boot
- 5. Reflective surface


LOCATION OF GAS DISCHARGE HEADLAMP AND AUTOMATIC HEADLAMP ALIGNMENT COR-**RECTOR COMPONENTS**



- 1. headlamp assembly
- housing for xenon dipped beam
 housing for iodine main beam
 bulb control unit (ballast)

- 5. bulb electrical connectors
- 6. alignment correction actuator (step motor)
- 7. static charge sensor
- 8. alignment correction control unit
- 9. ignition switch
- 10. stalk unit
- 11. battery
- 12. relay and fuse

NOTE: Parts 2 to 6 are built into headlamp 1.



XENON BULB

The xenon bulb consists of two electrodes spaced a few millimetres apart. The ampoule is filled with low-pressure xenon gas.

The ignition process is similar to that occurring in neon tubes for civil applications.

For light emission to take place, an electric arc must be triggered between the electrodes and then maintained.

The following table summarises the main features of a xenon bulb compared to those of the iodine bulb in current use (approximate values).

P3U03LL01

	xenon bulb	iodine bulb
flow emitted [Lm] efficiency [Lm/W] average luminescence [cd/cm2] average life [h] ignition voltage [V] steady state voltage [V]	3000 85 6000 3000 18.000 AC 100 AC	1500 25 2000 1500 12 DC 12 DC

Very high voltage is required to ignite the bulb and keep in running. Its luminescent power is about twice that of an iodine bulb and its efficiency is higher.


A xenon bulb involves certain critical points during the ignition stage which may cause the following to occur during the first moments of operation:

-colour tone slightly different to that when the lamp is under steady state conditions;

-non-instantaneous light flow;

-reignition when the lamp is warm, which affects bulb duration.

For these reasons, the bulb is not currently used for main beams with a flasher function (even with lights off).



P3U03LL02

REFLECTIVE SURFACES

The xenon bulb requires the adoption of a new reflective surface, because the shape and position of the light emission point is different to that for an iodine bulb.

The reflector used is complex surface type, i.e. it lacks a spherical lens.

This surface receives light rays from the bulb and orients them in order to distribute the light beam correctly.

Electrical equipment

Lighting

55.

ELECTRONIC CONTROL SYSTEM

Each bulb is controlled by an electronic control system consisting of two devices: a control unit (ballast) and a reactor (ignitor).

The ballast converts low voltage direct current from the vehicle battery into medium-voltage alternating current and controls subsystem function in a closed loop.

The ballast is able to control voltage-current specifications in optimal manner during ignition and also able to deliver the power required for bulb operation under steady state conditions.

The ignitor is controlled by the ballast and is able to generate the high voltage (max 25 volts) required to trigger an arc between the electrodes.

Operation

Xenon bulb operation is divided into four stages.

Ignition

During this stage, the ballast generates voltage able to bring about ignition of a special device located in the ignitor. A voltage elevator circuit transfers appropriately amplified overvoltage to the the bulb to bring about discharge between the electrodes.

Arc maintenance (take-over)


During this stage (a few seconds) the bulb is supplied with the additional power required to bring about rapid evaporation of metallic halogens contained in the bulb in order to ensure peak brightness is quickly achieved. Under these conditions, the bulb emits a light flash of double the normal intensity for a period of about 100 microseconds.

Warm up

For a period of about two minutes, the ballast regulates light intensity by measuring physical bulb conditions from its impedence (closed loop control).


Steady state

Continual closed loop control of the light beam even under steady state conditions.




- 1. Power source (12 V)
- Negative high tension generator
- 3. Square wave generator (500 Hz)
- 4. CPU
- 5. Voltage elevator circuit
- A. Ballast
- B. Ignitor
- C. Bulb

P3U04LL01



P3U05LL01



AUTOMATIC HEADLAMP ALIGNMENT CORRECTOR

Because the bulb is so bright, the vehicle must be fitted with an automatic headlamp alignment corrector to avoid dazzling oncoming vehicles due to the following types of aignment change:

- static, due to load distribution (A);

dynamic, due to acceleration (A) and deceleration (B).

The automatic corrector also ensures better driving comfort because the lit area stays stable and the eyes do not need to adapt continually to lighting changes.

The device consists of:

- a step actuator for each headlamp;

- a control unit, located in the cabin beneath the passenger seat;
- an accelerometer sensor, built into the control unit;
- a load sensor, connected to the right hand arm of the rear suspension.

Static correction

This is carried out via a signal from the load sensor, which is connected to the rear suspension arm and provides an indication of vehicle load status.

The control unit activates whenever the ignition switch is turned to "MAR." and resets the headlamps to the correct height (saved as a function of vehicle load). This involves fully lowering the headlamps and then repositioning.

The load sensor signal is also periodically downloaded and mediated so that headlamp position may be readjusted if necessary. This adjustment is not immediate, but carried out gradually in order to avoid unwanted corrections (holes, unsurfaced roads etc.).

This correction is carried out regardless of whether the lights are lit or not. Daytime flashing is thus carried out with the headlamps properly positioned.

Dynamic correction

This is carried out via an accelerometer signal built into the control unit.

Correction is carried out on the basis of the ratio between longitudinal acceleration and the vehicle's dynamic pitch angle. The values are mediated and the headlamps are repositioned only once a given memorised threshold has been exceeded.

This correction is active only when the dipped beams are on. The system is reset to zero when they are turned off.

Electrical equipment

Lighting


55.

Headlamp alignement control unit

The control unit is located on the floor beneath the passenger seat in upright position.

A microprocessor controls system operation on the basis of a load sensor signal (static correction) and a signal from the accelerometer sensor (dynamic correction).

Static correction is a function of the weight acting on the rear axle and the suspension type. Dynamic correction takes into account overall mass, dampers and acceleration/deceleration values.




Alignment control unit pin-out

- 1. load sensor earth
- 2. load sensor signal
- 3. dipped beam positive
- 4. key positive (+15)
- 5. step actuator (pin 1)
- 6. step actuator (pin 2)
- 7. step actuator (pin 3)
- 8. step actuator (pin 4)
- 9. earth
- 10. load sensor power source
- 11. unused
- 12. unused
- 13. unused
- 14. unused
- 15. unused
- 16. unused

Static load sensor

The sensor is fastened to the vehicle body, while a specially profiled spring-loaded lever integral with the potentiometer cursor follows rear suspension movements.

The sensor is supplied by control unit (5V) and supplies a linear output signal proportional to suspension position.




P3U06LL02

Step actuator

The step actuator is fitted to the light cluster. It consists of an electric step motor and a worm screw reduction unit, which converts rotary motion into linear motion of a hinged rod via a parabolic ball joint.

- 1. step actuator
- 2. headlamp position adjustment



FAULT DIAGNOSIS

Headlamp alignment corrector fault diagnosis

The system is equipped with a self-diagnostic strategy to check function.

Proceed as follows to activate self-diagnosis:

- position the unladen vehicle on a flat surface 10 m from a vertical wall, which should be light and reflective if possible;
- adjust beam to -1% in normal manner;
- turn the light switch to "position"
- turn the ignition switch to "MAR";
- within 3 seconds of the last operation, turn the light switch from "position" to "off" and viceversa for at least three times, then leave the switch on "dipped beam". The headlamps now come on and the cycle begins.

A: zero line (headlamp centre)

B: normal beam (-1%)

C: beam during recovery (-2,3%)

D: low beam (-3,6%)

E: floor level

F: beam fully lowered (on floor)

Cycle stages are as follows:

1. Beam fully lowered (check maximum mechanical lowering on floor);

2. normal beam (-1%)

3. pause of 1.3 seconds;

4. low beam (check reduction, -3.6%)

5. pause of 1.3 seconds;

6. beam half way through travel (recovery position: -2.3%)

7. pause of 10 seconds: during this pause, the control unit tests the load sensor (circuit open, short-circuit). If an anomaly is found, the beam oscillates rapidly 5 times about the recovery position. This cycle repeats itself continually: simply move the ignition switch to "off" to break the cycle

Headlamp alignment corrector operating strategy (reflector movement)

	on	off
ignition switch	zero (*)	stopped
side lights	stopped	zero
dipped beam	stopped	stopped

(*) 1 second after activation

NOTE Due to the static correction strategy adopted, it is not possible to move the headlamp immediately be simply operating the load senosr manually.

Electrical equipment

Lighting

55.

Load sensor recovery

If the load sensor is found to be anomalous, the control unit positions the headlamps midway through their travel (corresponding to point 6 of the self-diagnostic cycle).

This position is slightly lower than the position during normal motion in order to prevent oncoming vehicles from being dazzled if the vehicle is loaded and not to impair night vision excessively if the vehicle is unladen.


This situation persists until the igntion switch is turned off.

When correct operating conditions are restored, the alignment corrector returns to normal operation only once the ignition switch has been turned off and back on.

Finding faults in a gas discharge bulb

If one or both headlamps fail to come on, proceed as follows:

- check whether the headlamp is properly aligned. If not, check fuse and/or relay conditions;
- check for obvious signs of damage to the headlamp, i.e the lens (outer glass) and the case (plastic part). If signs are found, replace the entire assembly (after recovering the control unit);
- check the bulb is properly positioned by opening the rear cover. Reposition the bulb if necessary;
- check the bulb for signs of deformations or cracks. Replace the bulb if found;
- replace the headlamp but reuse the same control unit (ballast);
- replace the control unit.




CHECKS AND ADJUSTMENTS

Measuring internal load sensor resistance


The connector is in the right load compartment well.

Check that the resistance is within the specified range as shown in the figure.

Specified value: 1.2 kohm ± 20%



P3U09LL01



P3U09LL02

HEADLAMP ALIGNMENT

- 1. Horizontal light beam adjustment screw
- 2. Vertical light beam adjustment screw

The car must be complete with spare wheel, tools, fluids and fuel reserve. Tyre pressure must be as for normal driving conditions, with the driver on board.

Place the vehicle on a flat surface with the headlamp unit lens 10 m from a screen or opaque surface on which the following lines have been drawn:

V-V: vertical corresponding to vehicle plane of symmetry.

C-C: corresponding to vertical planes passing through the headlamp unit reference centres.

HC-HC: horizontal corresponding to height of headlamp unit reference centres from the ground.

ground. AC-AC: horizontal 10 cm above the HC-HC line (value for new vehicles and allocated corresponding to a reduction of 1%).

Set the headlamps to dipped beam. Adjust the headlamp positioning device as follows.

Vertical positioning

Align the horizontal section of the demarcation line between the shaded area and the area lit by the light beam with the AC-AC line drawn on the screen.


Horizontal positioning

Align the crossover point of the two horizontal and inclined demarcation lines with the point at which the C-C and AC-AC lines cross on the screen. This value must be reduced proportionally if the screen is set at a shorter distance.

Electrical equipment

Lighting

55.







REMOVING-REFITTING HEADLAMP




The headlamp must not be removed unless the battery positive terminal is disconnected, or the ignition key re-






Proceed as follows:


- 1. open the bonnet and disconnect the battery positive terminal, then disconnect:
 - A. both bulb connectors;
 - B. connector of headlamp alignment step motor;
 - C. turn signal connector;
- 2. remove the lower section;
- 3. unscrew lower and upper screws retaining the light unit and remove from its housing.





P3U10LL05

Publication no. 506.475/19






REMOVING-REFITTING SYSTEM COM-**PONENTS**


Dipped headlamp bulb (xenon)



The bulb may not be removed unless the battery positive terminal has been disconnected or the ignition key removed, because the voltage rises to about 20,000 V when the bulb is turned on and several hundred volts is present at the bulb terminals during normal operation








Proceed as follows:

- 1. turn the protective cover and remove;
- 2. turn the bayonet connector and remove;
- 3. open the retaining clips and remove the bulb.




Do not touch the glass part of the bulb with the fingers when remov-

P3U11LL02








P3U11LL04

Electrical equipment

Lighting

55.



P3U12LL01






Main beam headlamp bulb (iodine)

NOTE For greater clarity, the headlamp unit is shown removed from its housing. The bulb may nevertheless be replaced even without removing the headlamp.

Proceed as follows:

1. turn the protective cover and remove;



P3U12LL02

- 2. remove the bayonet connector;
- 3. open the retaining clips and remove the bulb.




Do not touch the glass part of the new bulb with the fingers when fitting.


Step actuator

Proceed as follows:


4. remove the headlamp unit, then turn the actuator and remove from its seat.



P3U12LL03



P3U12LL04






Xenon bulb control unit (ballast)


Proceed as follows:

1. remove the headlamp unit, then unscrew the four screws retaining the control unit;



P3U13LL02

2. turn the control unit over carefully, being careful not to pull the wiring, and remove the gasket retaining plate;




P3U13LL03


3. remove protective gasket (1) and disconnect connector (2).

Electrical equipment

Lighting

55.






P3U14LL02

P3U14LL01

Headlamp alignment control unit

Proceed as follows:

- 1. remove the passenger seat, then remove the cover in the floor trim and unscrew the control unit retaining bolts;
- 2. disconnect the control unit connector.





P3U14LL03

Vehicle alignment sensor

Proceed as follows:

3. working in the well on the right hand side of the luggge compartment, disconnect the connector:





- 4. lift the vehicle and unscrew both screws retaining the sensor;
- 5. open the clips and prise up the cable duct sheath from the floor, then remove the connector by withdrawing from the luggage compartment together with the cable duct sheath.,

NOTE Replace the cable duct sheath to ensure perfect water-tightness.

Bodywork Contents 70.

	page
INTRODUCTION	
- Introduction - Aerodynamics	1 1
SAFETY	
Safety systemFlectional and torsional strengthSeats	2 3 5
BODY SHELL	
Vehicle sound-proofingProtective treatmentsPaintwork	7 8 9
ECOLOGY AND ENVIRONMENT	
- Recyclability of materials	12
BODY SHELL ALIGNMENT	
 Introduction Diagram for checking underbody 	15 16
- Typical dimensions	18
REPLACING STRUCTURAL BODY PANELS	
- Introduction	22
ADJUSTING MOVEABLE PARTS	
- Dimensions for adjusting moveable parts	23
WINDOW GLASSES	
- Fixed side window	24
DOOR HINGES	
- Replacing fixed hinges	29

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Teenica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/12 - Aprile 1996 - 400 Printed in Italy - Tip. Stampart - TORINO order no. 60444236

INTRODUCTION

This set of technical information supports the training plan LANCIA has arranged for the new Station Wagon models of the LANCIA k. In accordance with the Company's expectations, the new car consolidates the aims of habitability, comfort, functionality and strength already achieved by the saloon version.


The subjects discussed mainly cover the technical innovations, with emphasis on the descriptive and teaching aspects.

AERODYNAMICS


The styling of the new Station Wagon in the Lancia family has the rounded shapes of the new generation of cars. In addition the truncated tail end, typical of Station Wagons, permits an excellent CX factor which, multiplied by the area (A) gives the value indicated in the table.

AERODYNAMIC COEFFICIENT (CX)	0.32
AERODYNAMIC COEFFICIENT FOR AREA (CX × A)	0.71

NOTE The value indicated in the table is the result of measurements made in the Fiat "wind tunnel".



Front view



Rear view

P3U01DM02

SAFETY SYSTEM

The main aim of car manufacturers is without doubt the total safety of passengers and driver. Market regulations in both Europe and the rest of the world have become very strict in this respect. To meet this requirement, the new car from the LANCIA house has been designed in order to ensure an optimum response in every situation.

Preventive safety

This concerns all factors which ensure comfort:

- high, body strength

- optimized engine mountings

- balanced climate control throughout the interior compartment, with highly adjustable, large diffuser vents with anti-pollen filter

- all controls and warning lights illuminated, so easier to read

- addition of third stop light in anticipation of regulation (1st September '98).

Active safety

- ABS braking system with independent cross circuits

McPherson front suspension with wishbones angled in the direction of travel, so as to generate an anti-skid effect (the car remains parallel to the road during braking)

- rear suspension with new geometry which allows the vehicle to be stabilized under the effect of steering of the rear wheels on bends. In addition the adoption of a new device permits a virtually constant attitude as the load varies

- variable-ratio and power-assisted steering designed to permit precise and immediate response in all situations.

Passive safety

The style of the S.W. is characterized by rounded shapes and continuous curves which, in addition to giving the car a new line, give strength and compactness to the structure. The structure has been designed to deform in a controlled manner in the event of front-end, side and rear-end crashes, and to absorb the energy created by the crash, without impairing the vital spaces in the interior compartment.

Main performance of the passive safety system

To pass the variouis tests imposed by legislation (EEVC '96), the model presents specific passive safety performance which limits the spread of damage and so reduces repair times.

The regulations concern crash resistance which is provided in various ways:

 Resistance to offset front-end crashes, at high speed, with the basic model and with Air Bag (AMUS/ADAC test and to USA 208 standard), due to the controlled-deformation front structure and the rigid interior compartment cell reinforced at key points.

Resistance to dynamic side crashes (ECE/EEVC '96), due to the structure of the reinforced side and

door panels.

- Resistance to Roll-Over (USA 216), due to the high-strength roof structure.
- Anti-intrusion resistance of rear load (ECE 34) due to the reinforced rear seat squab and its body shell attachments.
- Resistance to rear-end crashes, due to the reinforced structure and bumper which exceed the ECE 42 test.
- Safety against fire achieved with the FIAT FPS (FIRE PROTECTION SYSTEM) comprising:
- internal fireproofing which limits the rate of flame propagation (USA 302 standard);

- inertial switch for cutting off the petrol pump;

- anti-backflow valve and anti-misfiring guards (excessive heating of the catalyser under fault conditions);
- system for protecting cables which carry high currents.


FLECTIONAL AND TORSIONAL STRENGTH


In addition to giving the vehicle considerable passive strength, the flectional and torsional strength of the body shell of the LANCIA k SW generates a sensation of solidity and comfort in general, maintaining correct suspension angles and offering absolute precision of driving. If the body shell is subjected to a torsional force (A) of 1464 kgm, the body inclines by only one degree. Similarly, it flexes 1 mm if a flectional force (B) of 870 kg is applied.

These high strength values give the following advantages:

- less vibration
- ۱ less noise
- better driveability
- higher resistance to damage resulting from driving on particularly rough road surfaces
- feeling of compactness of the vehicle
- longer lasting overall qualities of the vehicle.

TORSIONAL STRENGTH	Body shell with windows, no moving parts	1464
(kgm/degree)	Complete motorized vehicles	1842
FLECTIONAL STRENGTH	Body shell with windows, no moving parts	870
(kg/mm)	Complete motorized vehicle	1094






Copyright Fiat Auto 3

Resistance to side and rear-end crashes

On the side, the central pillar (1) is reinforced on its entire length and at the seat belt anchor points (2). In addition, if the car overturns, safety is ensured by the very strong roof, reinforced by the presence of a fin (3) which joins the rear door pillars, the box-section cross member (4) on the tailgate frame and finally the side members (5).

The rear pillars (7) on the tailgate frame are welded at the bottom to the floor members and, together with the cross member (8) of the rear shock absorber top mountings, contribute to the protection of the interior compartment and safety of the rear passengers in the event of a side or rear-end crash, as stated in the ECE 32 regulation in force since 1/10/1995.



- 1. Central pillar reinforcement
- 2. Seat belt anchorage reinforcements
- 3. Rear fin
- 4. Rear cross member

- 5. Top side members
- 6. Rear door tubular reinforcements
- 7. Rear pillar box section reinforcement
- 8. Separating wall cross member

NOTE In the case of bodywork repairs, the structural reinforcements indicated in the drawing, if deformed, should always be replaced.

SEATS

To protect the interior compartment and the passengers, safety devices have also been adopted in the front and rear seats.

The structure of the front and rear seats of the LANCIA k SW adds to the protection offered by the safety belts, especially due to the "antisubmarining" element.

Under strong deceleration, passengers risk sinking into their seats and sliding under the waist section of the seat belt.

This cannot happen on the LANCIA k SW as the front seats include specific rigid cross members under the cushion, which ensure that the occupants are held perfectly in the event of a crash.

The rear seat consists of a fixed cushion and a 40/60 folding squab. The squab is designed to withstand intrusion from the rear load as required by the strict regulations planned in the near future in Germany: ADAC dynamic test which requires a structural strength with deformation not exceeding 30 cm in a crash at 50 km/hour, with a load of two suitcases weighing 18 kg.


The requirement is obtained separately for each part of the squab by the adoption of a tubular structure (2), strengthened by box-section diagonal cross members (1) (see figure on next page).


The squabs have lock/release devices (3, Figure A) with red indicator to show that they are locked onto the body shell.

The back of the rear seat squab is covered with carpet, so that when the seat is folded, a continuous platform with the top load platform is formed. The top of the rear seat squabs is shaped so as to form a stop preventing movement of the luggage towards the front seats. There are two plastic suitcase stops (4) on the top edge.


The rear seat is ergonomically optimzed to provide excellent lateral containment and a firm seating position ("antisubmarining" effect).

The squab anchorages (5, figura B) are locked onto the body shell in such a position as to present any possible accidental interference with the seat belts.






P3U05DM02



P3U06DM01



P3U06DM02

An important safety feature is the load anchorage systems; the load can be secured by appropriate braces or netting to the attachments (6) located in the 4 corners of the load compartment.

- 6. Trim cover
- 7. Luggage retaining net attachment
- 8. Trim cover reinforcing plate
- 9. Bolt

VEHICLE SOUND-PROOFING


The sound-proofing on the LANCIA k SW has been developed from the experience acquired on the saloon version. Noise measurements inside the interior compartment have given excellent results conforming to Italian laws (corresponding Fiat table: LE 115/25 e 116/25).

The vehicle's comfort is all the more noticeable when it is easy to hear a conversation at normal voice level under average driving conditions.

Particular care has been given to the effects of noiselessness at the rear part of the vehicle. In the absence of the dividing wall to the load compartment, present on the saloon, the LANCIA k SW comprises a sound-proofing kit and total covering of the wheelarches and floor platform with sound-proofing materials.

Acoustic cavities (pillar box sections) have been neutralized by filling them with foam. To avoid direct contact between trim and sheet metal, widespread foam has been inserted (soft URL).

The load compartment is lined at the sides with a polythene covering 4 - 5 mm thick with carpet on the outside. While the bottom load platform is covered with plastic offering high abrasion resistance, the top load platform has been strengthened to ensure a capacity of 200 kg.



P3U07DM01

PROTECTIVE TREATMENTS

Introduction

In accordance with the Italian law corresponding to the Fiat LE 107/94 table, the bodywork of the LAN-CIA k-SW withstands, both internally and externally, all corrosion processes thanks to several protective treatments to which the body panels are subjected.

The treatments may involve not only the surfaces of panels exposed to the environment, but also internal surfaces which, although physically isolated, can nevertheless be attacked by rust because of leaks or the formation of condensation.

Internal agents

- Formation of condensation
- Water leaks
- Action of parasitic currents
- Electro-erosion

External agents

- Salty sea air and the salt used to de-ice the roads
- Rain (especially if acidic)
- Frost and temperature fluctuations
- Smog and pollutants in the air
- Hydrocarbons in general (solvents, tar and petrols)
- Some components in sunlight (ultraviolet rays)
- Projection of stones and gravel
- Bird excrement.

The vehicle's panels are also protected by the application of paint products which, in addition to aesthetic purposes, also act as a barrier between the sheet metal and the external environment.

Preventing the corrosion of the bodywork starts with the vehicle's design, by selecting the most suitable materials, with the various components designed so that the structures can be accessed by the protective processes, avoiding weak points which are particularly susceptible to corrosive agents, and continues throughout the production process with the various anti-corrosion treatments applied at the different stages of assembly.




Diagram showing overlapping of the various protective layers of a panel

The side closest to the letter A is the outside, and the side closest to the letter B is the inside.

- 1. Finishing paint
- 2. Primer
- 3. Cataphoresis
- 4. Galvanization (on both sides of the sheet metal)
- 5. Sheet metal
- 6. Wax-based oil or anti-roar paint (depending on the location of the panel)

PAINTWORK

As already mentioned, the paintwork on the body shell has two main aims: to protect the sheet metal from environmental attack, and to achieve, from an aesthetic point of view, high levels of lustre and colour intensity.

The type of colour and its characteristics are indicated on the identification plate which also gives the following details:

Paint supplier

Colour and type of finishing paint

- Code

- Type of product to be used for touching up or painting over repairs.

The colour range for the LANCIA k SW comprises 1 pastel colour and 4 metallic colours.

The development of paint products has led to the use of two-component acrylic finishing paints and primers with medium and high solid content (i.e. high percentage of dry residue). A distinction is therefore made between:

- "Medium solid" paint products;

"High Solid" paint products.


The final appearance of these products is characterized by very high shine, spread and intensity. These products save time both during application as they require fewer coats, and during subsequent drying as they require a low baking temperature.

So in addition to saving solvent, a significant benefit is gained for the operator's health and for the protection of the environment.

The table below gives the combinations of external colours and internal colours and trim available for the new LANCIA k SW.

EXTERNAL COLOURS	TERNAL COLOURS CODES	LOURS CODES		LE velvet		LS velvet		LX alcantara			LEATHER (opt) leather			
·		Blue	Grey	Blue	Dove	Blue	Light grey	Anthracite grey	Blue	Dove	Anthracite grey	Bordeaux		
LANCIA BLUE	435/A	•			•	•	•			•	•	•		
BLACK	632		•		•		•			•	•	•		
MERCURY GREY	609/A		•	•		•		•	•		•			
WILD VIOLET	142/A	•			•		•			•	•			
GOLDEN WHITE	506	•		•		•		•	•		•			
URANIUM GREY	616/A	•		•		•			•		•			
APOLLO BLUE	425/B	•		•		•	•			•	•			
PLUTO GREEN	384		•		•		•	•		•	•			
YORK GREEN (*)	345		•		•		•	•		•	•			
MARS RED (**)	120/A							•		•	•			

(*) pastel



P3U09DM01

^(**) specific for performance version of S.W.

Panel preparation treatment (bonderization)


After assembly, the body shell undergoes a series of treatments to clean off grease and oxidation and to preserve it from corrosion.

The cycle comprises the following stages:

- Pre-degreasing: washing with an acid solution (deoxidant) to remove the oily substances present on the metal.
- Degreasing: washing with a solution of water-surfactants; this solution is sprayed at a temperature of about 60°C.
- Rinsing this is done using industrial water to remove alkaline residues.
- Activation: washing at ambient temperature with a solution of titanium salts (for brightening the windows, "pickling").
- Phosphating: washing with zinc phosphates at a temperature of about 55°C; the electrolytic deposition of these metals constitutes and multiplies the crystalline centres creating an even and protective microcrystalline layer on the body shell (tempering).
- Passivation: washing with a chromium-based solution which provides a further layer of protection and smoothing of the windows.
- Rinsing: the residues of the previous solutions are removed using deionized water.
- Drying: in an oven at a temperature of about 110°C.

Application of protective paint (cataphoresis)

The cataphoresis treatment is carried out by immersing the body shell in a bath of electroconductive solution, in which particles of paint have been introduced in suspension to an average thickness of 30 micron.



P3U10DM01

Line of application of the cataphoresis treatment in production

- 1. Application of cataphoresis by immersion
- 2. Washing body shell
- 3. Baking paintwork

All the join lines are sealed to prevent the entry of corrosive agents.

During after-sales servicing, it is advisable to use polyurethane sealants to restore the seal lines. These products dry right through even if applied thickly, and paint can be applied on top of them after a short time (about 20 minutes).

Galvanization

Galvanization consists of applying a thin layer of zinc on one or both sides of the sheet metal.


In the presence of water, the layer of zinc, together with the iron which constitutes the sheet metal, generates an electrocouple with an electric potential which prevents the oxidation of the iron until the layer of zinc is fully eroded.

The galvanization of one or both sides of the sheet metal leads to the distinction between galvanized or bi-galvanized sheets.

As the galvanization forms an integral part of the structure of the panel, is not damaged by crashes and subsequent repairs, so there are no problems regarding the restoration of treatment during after-sales work.

As in the saloon version, on the Station Wagon the anti-corrosion protection has been extended to most of the panels on both sides, with a treatment thickness of 7.5 micron.

Greater care has been given to some areas with an application of 20 micron; the chosen areas are generally critical points in terms of safety, such as seat belt attachments, attachments of mechanical components, etc.




NOTE The parts shown in the figure are subjected to protective treatment by electrogalvanization.

Copyright Fiat Auto

Ecology and environment

70.



RECYCLABILITY OF MATERIALS


The problem of recycling plastic materials is solved at the design stage, when it is necessary to assess whether the material can be reused on future components.

At present, when a vehicle reaches the end of its life, only the metal part is recovered and reused, to produce new steel and new aluminium alloys.

All the rest of the vehicle, which corresponds to about 25% in weight, is instead abandoned or dumped.

Thus a vast amount of materials and energy is wasted, and also contributes to increasing the extent of the problem of disposing of solid waste.

This model has been designed so that all the plastic and elastomer components (rubbers) weighing over 50 grammes are marked with coded symbols so that the material can be recognized at the recycling stage, and all the components can be recycled.



Recycling does not allow a component the same as the original component to be obtained, as the material may not guarantee the necessary reliability characteristics or may not be suitable.


From the plastics used to stuff the seats, insulation material for the building industry is obtained.

For the other plastics, recycling is effected in cascade form: for example, the bumper plastic provides material for the wheelarch trim, which is in turn made into elements for making sound-proofing linings, which finally end up as fuel for blast furnaces.

P3U12EM02

The recycling thus involves three subsequent generations of cars, contributing to the saving of raw materials.

Body shell with recyclable materials



The figure shows the flows of main components of the LANCIA k SW which are recycled with the F.A.R.E. system, now well established throughout Italy, with the participation of A.D.A. (Italian Car Breakers' Association) which works in the sector of scrap recycling.

MATERIAL	APPICATIONS	LANCIA k SW OBJECTIVE
Cadmium	- Coatings for nuts and bolts - Plastics and paints	Absent
CFC (chlorofluorocarbons)	Seat stuffingsPlastic componentsAir conditioners	Absent
Asbestos	- Brake and clutch linings - Engine flat gaskets	Absent
Formaldehyde	- Porous sound-proofing, carpets, ceiling trim	70 ppm
Beryllium oxide	- Electronic control units	Absent
Brominated fireproofing	- Additives for plastics/fabrics	Absent

Copyright Fiat Auto

Bodywork Ecology and environment

70.

The table below gives symbols and the corresponding name for identifying the materials. This is because during after-sales work, suitable products from among the many available on the market are used for washing the interior, painting plastics, repairs, glueing, etc. The aim is to avoid damage by using incompatible products.

THERMOPLASTIC AND THERMOHARDENING MATERIALS

	ISO SYMBOL	FAMILY NAME				
3°	AOS	ACRYLONITRILE - BUTADENE - STYRENE				
3	CA	CELLULOSES				
	PA 6		6 C atoms in monomeric structure			
	PA 66	POLYAMIDES WITH:	two monomeric structures each with 6 C atoms			
	PA 11	FULTAMIDES WITH:	11 C atoms in monomeric structure			
	PA 12	·	12 C atoms in monomeric structure			
	POTP	POLYESTERS	poly(butylene terephthalate)			
	PETP	routestens	poly(butylene terephthalate)			
	PC	POLYCARBONATES				
	PC+ABS	POLYCARBONATE/ABS ALLOYS				
TERMOPLASTIC	PE	POLYETHYLENES				
	PMMA	METHACRYLICS				
	РОМ	ACETALS				
	PP	POLYPROPYLENES				
	PPOX	POLY(PHENYLENES) - MODIFIED				
	PPOX+PA	THERMOPLASTIC ALLOYS				
	FFUATEA	(POLY(PHENYLENE OXIDES)/POLYAMIDES)				
	PSE	POLYSTYRENES (FOAMS)				
	PVC-P	FLEXIBLE VINYLS				
	PVC	RIGID VINYLS				
	SAN	STYRENES	copolymer styrene - acrylanitrile			
	SMA	STITLENES	copolymer styrene - maleic anhydride			
	MF	MELAMINES				
	PF	PHENOLS				
	PUR	POLYURETHANES				
TERMOHARDENING	UF	UREAS				
		UNSATURATED	() () () ()			
	UP	POLYESTERS	for moulding and compression (SMC)			
		THERMOHARDENING SUBSTANCES	for injection moulding (BMC)			

CHARGES AND REINFORCEMENTS

ISO SYMBOL	NAME
GB	Glass balls
GF	Glass fibre
GH	Glass mattress
M	Mineral charges
Т	Talc
WD	Ground wood
SF	Textile fibres

CHARGES AND REINFORCEMENTS

ISO SYMBOL	NAME
ACM	CHLOROETHYL-VINYL-ETHER-ACRYLATE
AU	POLYURETHANE
CSH	CHLOROSULPHONATE POLYETHYLENE
CR	CHLOROPRENE
EPDM	ETHYLENE PROPYLENE DIENE MONOMER
ECO	EPYCHLORHYDRIN
FPM	FLUOROCARBON
MVQ	SILICONE
NBR	ACRYLONITRILE-BUTADIENE
NR	NATURAL ISOPRENE
IR	SYNTHETIC ISOPRENE
SBR	STYRENE-BUTADIENE
IIR	ISOBUTYLENE/ISOPRENE
IIR	ISOBUTYLENE/ISOPRENE

INTRODUCTION

Crash diagnosis

This sub-section describes the most rational and correct method of proceeding, so that the coach builder may obtain the best results.


A series of checks must be carried out before starting to repair a vehicle, even if only slightly damaged.

Checking with template (check rod)

These checks are also for checking that the infrastructural components are not significantly deformed in relation to the original geometry; if they are, the mechanical parts will have to be removed and the vehicle will have to be repaired on a repair bench.

The comparative dimensions may be subject to slight differences (approx. \pm 3 mm), which the repairer will be able to establish by experience whether they are due to possible crashes or to constructional tolerances.

Start the check on a part of the vehicle not affected by the crash. For example, for a car which has suffered a front-end collision, to check whether the structure is deformed, check points C-E = B-F; if no differences in length are observed at these points, proceed with checking points B-D = A-E. In this way you can establish in advance a more precise diagnosis for the repair.



P3U15DM01

Check points




In extreme cases, do not forget to check the mechanical components that may have been deformed.

Copyright Fiat Auto 15








16


Publication no. 506.475/12




TYPICAL DIMENSIONS

Measuring dimensions of windscreen and bonnet frames

The dimensions of the frames given below are taken from technical design drawings and may be subject to tolerances of about $\pm~2~\text{mm}$




P3U18DM01




P3U18DM02


 $\label{lem:decomposition} \mbox{Dimensions for checking windscreen frame, bonnet frame and distance of front shock absorber top mountings$


Measuring dimensions of space between central pillare and rear pillars



P3U19DM01









Dimensions for checking distance between central door pillars measured on the seat belt attachment nuts and between the door lock strikers


Copyright Fiat Auto


70.


Measuring door frame dimensions













P3U20DM01



P3U20DM06

Dimensions for checking door frames

Measuring dimensions of tailgate frame




N.B.: The points where the measurements should be taken are the panel joins.

INTRODUCTION


General instructions for repair

For safety reasons and for a better quality of repair, the following is not permitted:

- To replace a longitudinal member, semi-block or block, without using a repair bench. By using a bench, you can guarantee restructuring the vehicle with the original factory dimensions, ensuring the correct positioning of the front and rear axle components.
- To cut and butt weld, on the same line, any component of the body shell and its reinforcement (see Figure 1).
- To use heat to straighten the longitudinal members.



INCORRECT SOLUTION




CORRECT SOLUTION


When carried out correctly, the operation includes a difference of a few centimetres between the two cutting lines in order to distribute the melted points created by the welds (see Figure 2).

Dimensions for adjusting moveable parts

To facilitate the checks and operations for dismantling the moveable parts, the values of the existing gaps are given for appropriate adjustment (measurements are in millimetres).



P3U23DM01






FIXED SIDE WINDOW

Preliminary operations

Before removing the fixed side window, disconnect the battery's negative pole, and remove the components that could obstruct the removal operations, in particular the side ceiling moulding.


- Remove the sliding curtain covering the luggage compartment by operating the side buttons, then remove the side support blocks underneath by undoing the screws; remove the tailgage frame central and side mouldings by undoing the screws.
- 2. Remove the courtesy light on the rear pillar trim by dismantling the lens, screw and connector.
- Remove the side courtesy light in the luggage compartment by releasing the lugs and disconnecting the connector; then open the access flap to the electrical devices and undo the screw securing the moulding to the bodywork.
- 4. Remove the rear seat cushion and undo the bottom seat belt bolt.




P3U24DM02

P3U24DM03


P3U24DM01









P3U24DM04








P3U25DM02









- 1. Fold down the rear seat squab and remove the side arm rest by lifting it from its seat-
- 2. Undo the nut indicated and remove the luggage compartment side moulding.
- 3. Using tool 1878077000, remove the side window's rear pillar trim.
- 4. Using tool 1878077000, remove the side window's front pillar trim.
- 5. Remove the rear courtesy light lens, disconnect the connector and remove the courtesy light from the car, then remove the rear sunshade hooks.







Copyright Fiat Auto








 Disconnect the aerial and separate the ceiling trim from the roof, inserting spacers.



Use a cloth to protect the luggage compartment and the parts that could be damaged during the curreing and installation of the window glass, and use adhesive tape to protect the edge of the window seating to prevent damage to the paintwork.







Removing




- Working from outside the car, cut the sealant on the top edge of the window, using a vibrating knife with the blade shown in the insert.
- 3. Fit the blade on the vibrating knife shown in the insert, then cut the window sealant from inside the car.
- 4. Mark the reciprocal positions of the window and its seating with strips of adhesive tape, then using appropriate suction handles remove the window glass, after cutting the strips of adhesive tape applied previously.








P3U26DM04








P3U27DM02

Refitting


- Smooth down the window glass sealant with a scraper, respecting the dimensions of the window end stops at the top and bottom of the window frame, as shown in the figure.
- 2. Remove the bottom and side seals of the window.
- 3. Remove the bead of old sealant from the window, using an appropriate scraper.
- 4. Fit the window side and bottom seals.


NOTE If the window is being replaced, position it in its seating and mark the position with adhesive tape, as described on the preceding page.

5. Thoroughly degrease the window using heptane and paper towel.











P3U27DM04

P3U27DM05

27







Apply the adhesion promotor using an appropriate swab, making sure not to go beyond the printed area.


NOTE Allow the adhesion promotor to dry at ambient temperature for at least 15 minutes, but not longer than 24 hours.

- 2. Apply sealant on the bottom of the window using a gun, observing the dimensions given in the figure.
- 3. Apply sealant to the top and side of the window using a gun, observing the dimensions indicated.
- 4. Fit the window into its seating using the appropriate suction pads, then exert appropriate pressure with a belt in order to obtain correct alignment; leave the window glass under pressure for at least 6 hours.




The car must not be delivered until at least 20 hours have elapsed since the time of glueing the window glass.


NOTE Complete the assembly of the removed parts by reversing the procedure for removal.





P3U28DM02














REPLACING FIXED HINGES

To replace the fixed hinges, proceed as follows:


- remove the front wheelarch protective trim and the wing as described in the relevant pages of the "LANCIA k" Workshop Manu-
- al (specific operation for the front doors); offer up to the body shell the door fitted with the hinges (1) and (2) to be welded to
- temporarily tack the hinges (1) and (2) to the pillar, respecting the dimensions given in Figures A and B; check that they are lined up correctly with the body shell:
- remove the door and finish welding the hinges (1) and (2);
- refit the door.





Reference dimensions for positioning half-hinges on body shell front pillar

- 1. Top hinge
- 2. Bottom hinge
- 3. Top hole for cable pass





Reference dimensions for positioning half-hinges on body shell central pillar

- 4. Top hinge
- 5. Bottom hinge
- 6. Cable pass hole

The second of the second 3 · -- / /

Bodywork Contents

70.

	page
BUMPER	
- Rear bumper and supporting bracket	1
TAILGATE	
 Removing-refitting tailgate Tailgate hinge Adjustments Tailgate lock Replacing lock barrel 	3 6 7 8 9
SEATS	
Rear seatRear seat cushionFolding rear seat squab	10 12 13
INTERIOR FITTINGS	
 Ceiling trim Wing panel interior trim Rear seat belts 	15 20 23
EXTERNAL MOULDINGS	
- Roof trim side moulding	25
WINDOWS	
Fixed side windowRear window	26 31
REPLACING BODY PANELS	
Graphic indexSymbolsReplacing roof panelReplacing rear wing panel	38 39 40 44
 Replacing rear cross panel trim and right pillar reinforcement 	49


COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.


The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Assistenza Tecnica 10040 Volvera - TO - (Italia) - Largo Senatore G.Agnelli, 5 Publication no. 506.475/15 - Giugno 1996 - 400 Printed in Italy - Tip. Bogliani - TORINO order no. 60444456







P3U01EM02









REAR BUMPER AND SUPPORTING **BRACKET** Removing-refitting

- 1. Open the door to the compact disk (CD) compartment in the boot.
- 2. Undo the screws shown in the rigure.3. Disconnect the supply connections and remove the CD from the car. 4. Working from the CD compartment, re-
- move the nuts securing the bumper to the rear cross member trim.
- 5. Working from the compartment opposite the CD, remove the nuts securing the bumper to the rear cross member trim.

NOTE The insert shows a cross-section of the rear bumper (1) near the rear cross member (2), with the relevant attachments (3).



P3U01EM03



@ **@** 3


P3U01EM06


P3U01EM04

P3U01EM05

Bumper

70.






P3U02EM02




P3U02EM03




- 1. Undo the bolts securing the wheelarch guard to the bumper and body shell, indicated in the figure.
- 2. Undo the bottom bolt securing the wheelarch guard to the bumper and the nut securing the bumper to the body shell.
- curing the bumper to the body shell.

 3. Move aside the wheelarch trim to gain access to the bolt securing the bumper to the wing panel.
- 4. Remove the rear bumper from the body shell.
- 5. Undo the bolts shown in the figure and remove the bumper supporting bracket from the rear cross member trim.


NOTE To refit, reverse the procedure for removal.









P3U02EM05





P3U03EM02






REMOVING-REFITTING TAILGATE




Before starting this procedure, disconnect the battery's negative pole.

- 1. Remove the attachment covers, undo the bolts indicated and remove the tailgate handle.
- 2. Undo the bolts and remove the tailgate interior trim.
- 3. Remove the additional stop light trim.
- 4. Undo the bolts shown in the figure and remove the rear window frame right pillar
- trim.
 5. Undo the bolts indicated and remove the rear window frame left pillar trim.









P3U03EM05

Tailgate












- 1. Disconnect the additional stop light connector, shown in the figure.
- 2. Release the cable bundles from the clips indicated by the arrows, then disconnect the following connectors:
 - Heated rear window earth
 - 2. Left tail light
 - Loudspeaker 3.
 - 4. Rear window wiper
 - Rear window wash pipe
 - Left number plate light
 - Right number plate light
 - 8. Lock switch
 - Lock solenoid 9.
 - 10. Right tail light
 - 11. Heated rear window
- 3. Disconnect the connector blocks from the following cables:
 - Left tail light.
 - Rear window wiper
 - Lock switch
 - 10. Right tail light




Mark the electric cables as appropriate with the positions of the connector blocks as shown in the insert.


4. Wrap the cable bundle with adhesive tape to facilitate its withdrawal through the slots in the tailgate.








P3U04EM04










- Tie the cable bundle in an appropriate manner to facilitate subsequent reassembly.
 With draw the cable bundles through the
- 2. Withdraw the cable bundles through the slots in the tailgate.
- 3. Disconnect the tailgate hydraulic rams from the top mounting by releasing the attachment clips, one of which is shown in the figure.
- 4. Undo the bolts securing the tailgate to the hinge, then remove the tailgate from the car, with the help of a second operator.












P3U05EM04

Tailgate

70.





TAILGATE HINGE

Removing

Remove the tailgate as described on page 3 and following.

- 1. Using tool 1878077000, remove the boot rear pillar trim and remove the rear sunshade catch by undoing the screw.
- 2. Remove the lens, disconnect the electrical connector and remove the courtesy light from the ceiling trim.
- 3. Carefully lower the ceiling trim, then undo the nut and separate the hinge from the



To refit, proceed as follows:







4. In the area surrounding the hinge seat, remove the traces of heat-expanding sealant, then insert between the hinge and body shell a suitable air-drying acrylic sealant such as IVI 854.210 or equivalent product, then fit the hinge and tighten the nut.




Water leaks may arise if the heat-expanding sealant is not applied.

NOTE Complete the assembly of the removed parts by reversing the procedure for removal.










P3U06EM04





ADJUSTMENTS

Adjusting position of tailgate stops

1. Rotate the rubber stops on the ends of the tailgate as appropriate.



If the stops are not adjusted correctly, the tailgate will be forced or there will be excessive play on the closing mechanism, thus causing damage to the tailgate.

Adjusting horizontal position of tailgate

2. Slacken the bolts securing the hinges to the tailgate and adjust the position of the tailgate.

NOTE The arrows show the permitted movements for adjustment.




Adjusting tailgate side position


3. Slacken the bolts and adjust the position of the anti-vibration device.

NOTE The arrows show the permitted movements for adjustment; it is also possible to insert shims between the anti-vibration device and the bodywork to ensure correct adjustment.


Adjusting and removing-refitting tailgate lock striker


4. Remove the central moulding on the tailgate by undoing the bolts; slacken the striker bolts and adjust its position; to remove the striker, undo the bolts indicated by the arrows.







P3U07FM02







P3U07EM04



P3U08EM01




TAILGATE LOCK

Removing-refitting

Remove the tailgate interior trim as described on page 3.

- 1. Disengage the tailgate open/close tie rod from its seating.
- 2. Disconnect the supply wiring connectors from the central door locking motor.
- 3. Undo the bolts indicated and remove the tailgate lock.

NOTE To refit, reverse the procedure for removal.



P3U08EM02







Removing-refitting tailgate lock tie rod and central locking motor

Before removing the tailgate lock tie rod, remove the lock as described above.


 Remove the tie rod from the lock catch system, then undo the bolts securing the central door locking motor, disconnect the wiring clip and remove the central door locking motor.



P3U08EM03



P3U08EM04



P3U08EM01




REPLACING LOCK BARREL

Sequence of operations


Remove the tailgate interior trim as described on page 3.

- 1. Release the tie rod from the lock barrel catch device.
- 2. Undo the bolts securing the lock barrel to the tailgate.
- 3. Insert the key in the barrel, then withdraw the retaining clip indicated.
- 4. Withdraw the barrel and replace it.


NOTE To refit, reverse the procedure for removal.




P3U09EM02




P3U09EM03



P3U09EM04








REAR SEAT

P3U10EM02





P3U10EM01

P3U10EM03

P3U10EM04




Removing-refitting cushion

- 1. Remove the rear cushion by releasing the locking system as shown in the figure.
- 2. Place the cushion in its seating, fitting the slots on the cushion on the retaining brackets on the body shell.


Removing-refitting folding squab

- 3. Fold the squab by operating the lock/release device.
- 4. Lift the cover pieces covering the squab anchorage systems.
- 5. Undo the squab bolts from the anchor brackets, then remove the squab from the car.


NOTE To refit, reverse the procedure for removal.







P3U10EM05






Removing-refitting fixed squab

Remove the cushion as shown on page 10, then fold down the squab.

- 1. Lift the cover covering the seat belt bottom attachment.
- 2. Undo the bolt securing the seat belt bottom attachment.
- 3. Lift the fixed squab, releasing it from its locking system.

NOTE To refit, reverse the procedure for removal.






Removing-refitting squab anchor brackets

Remove the squab and cushion as described on page 10.


4. Undo the bolts securing the anchor brackets to the body shell, arrowed, then remove the seat anchor brackets.

NOTE To refit, reverse the procedure for removal.







P3U25DM01



P3U11EM04







P3U12EM01

REAR SEAT CUSHION

Dismantling


Remove the cushion from the car as described on page 10.

- 1. Cut the clips on the perimeter of the trim, securing the trim to the vulcanized tie rods in the stuffing.
- 2. Continue cutting the clips in the central area of the trim with the stuffing.


 3. Detach the trim from the cushion stuffing.

Refitting


- 4. Starting from the centre of the cushion, secure the trip using the appropriate clips to the vulcanized tie rods in the stuffing using pliers (USAG 156/215).
- 5. Continue fitting the trim around the edge of the stuffing.




P3U12EM03




P3U12EM04




P3U12EM05





P3U13EM02







Dismantling-reassembly

Remove the squab from the car as described on page 10.


- 1. Remove the suitcase stop from its seating, releasing the pins from their clips.
- 2. Undo the screws indicated and remove the squab lock/release device.
- 3. Undo the top screws securing the squab trim.
- 4. Undo the bottom screws and remove the squab trim from its seating.
- 5. Undo the screws indicated and remove the seat belt attachment embellishment.









13










- 1. Remove the heat rest by releasing the pins from the squab as shown in the insert.
- 2. Withdraw the seating of the head rest pins from the squab frame.
- 3. Cut the clips securing the perimeter of the squab trim to the frame.
- 4. Cut the clips securing the squab trim to the vulcanized tie rods in the stuffing.
- 5. Dismantling:
 - 1. Squab trim
 - 2. Stuffing
 - 3. Squab frame


NOTE To refit, reverse the procedure for removal.












P3U15EM02

P3U15EM01


CEILING TRIM









- screws. 2. Remove the courtesy light after removing
- the lens, undoing the screws securing the courtesy light to the trim and disconnecting the relevant connectors.
- 3. Remove the courtesy light for lighting the right sunshade mirror by releasing the tabs and disconnecting the wiring connector.
- 4. Using tool 1878077000 remove the front pillar trim pieces, after partially removing the door frame seals.
- 5. Partially remove the central pillar trim pieces using tool 1878077000.











P3U15EM05


15

P3U16EM02


70.










- 1. Undo the screws indicated and remove the passenger grab handles.
- 2. Remove the courtesy lights on the rear pillar trim by removing the lenses, screws and connectors.
- 3. Remove the boot screen by operating the side buttons.
- 4. Remove the boot screen side blocks by undoing the attachment screws.
- 5. Remove the tailgate frame central moulding by undoing the screws indicated.




















- 1. Undo the screws indicated and remove
- the tailgate frame side mouldings.

 2. Using tool 1878077000, remove the luggage compartment rear pillar trim.


 3. Remove the luggage compartment side
 - courtesy light by releasing the lugs and disconnecting the wiring connector indicated.
- 4. Open access door to the connectors and undo the screw securing the moulding to the body shell.
- 5. Remove the rear seat cushion and undo the seat belt bottom bolt.









P3U24DM04














- Lower the rear seat squab and remove the fixed squab by releasing it from its catches.
- 2. Undo the nut indicated and remove the luggage compartment side moulding.
- 3. Undo the screw indicated, and using tool 1878077000 remove the rear pillar trim pieces.
- 4. Undo the screws and remove the rear sunshade catches.
- 5. Remove the rear courtesy light lens by releasing the retaining lugs.












ed and remove the courtesy light from the ceiling trim.

2. Partially remove the tailgate seal, and us-

1. Disconnect the wiring connector indicat-


- 2. Partially remove the tailgate seal, and using tool 1878077000 release the ceiling trim from the press clips located at the rear of the ceiling trim and from the Velcro on the edges and near the ceiling fins.
- 3. Remove the ceiling trim, withdrawing it from the luggage compartment.






NOTE To refit, reverse the procedure for removal.

- 4. The figure shows the location of the press clips.
- **NOTE** The shaded areas represent the positions of the Velcro on the ceiling trim.









P3U19EM04

19






P3U24DM01

WING PANEL INTERIOR TRIM

P3U25DM03



P3U24DM04





Removing-refitting

- 1. Remove the luggage compartment screen and remove the side blocks underneath by unscrewing the bolts, then remove the luggage compartment frame central and side mouldings by undoing the bolts.
- 2. Remove the luggage compartment rear pillar trim using tool 1878077000.
- pillar trim using tool 1878077000.


 3. Remove the rear seat cushion and undo the seat belt bottom mounting bolt.


 4. Lower the rear seat squab and remove the
- Lower the rear seat squab and remove the fixed squab, releasing it from the stop catch.
- Disconnect the wiring connector and remove the courtesy light, undo the nut and bolt and then remove the side moulding.






P3U20EM01













- 1. Undo the screws indicated in the figure and remove the luggage compartment folding trim.
- 2. Undo the screw indicated and remove the catch on the side trim.
- 3. Lower the rear seat squab, undo the screws shown in the figure and remove the top side trim from the body shell.4. Using the tool 1878077000, remove the
- Using the tool 1878077000, remove the buttons securing the rear cross panel interior trim and remove the trim from the car.
- 5. Remove the bottom trim from the rear seat base.







P3U21EM05







P3U22EM02








- 1. Remove the load compartment floor trim.
- 2. Undo the bolts shown in the figure and remove the wing interior bottom trim.
- 3. Remove the preformed sound-proofing panel from the body shell.
- 4. Open the fuel filler flap and undo the bolts shown in the figure.
- 5. Undo the bolts shown in the figure and detach the electrical devices mounting from its seating.




When removing this mounting, be careful that the fuel filler flap pushrod does not fall out.


NOTE To refit, reverse the procedure for removal.







P3U22EM05






REAR SEAT BELTS


Removing-refitting

- Remove the luggage compartment screen by operating the side buttons, then remove the side blocks underneath by undoing the bolts; remove the tailgate frame central and side mouldings by undoing the bolts.
- Remove the luggage compartment side courtesy light by releasing the retaining lugs and disconnecting the electrical connector; then open the access flap to the electrical devices and undo the screw securing the moulding to the body shell.
- 3. Remove the rear seat cushion, remove the attachment cover and undo the seat belt bottom bolt.
- 4. Lower the rear seat squab and remove the fixed side squab, lifting it from its seating.




P3U20EM01


P3U23EM01








23






- 1. Remove the luggage compartment folding trim by undoing the screws indicated.
- 2. Undo the screw indicated and remove the luggage retaining hook on the side trim.
- 3. Undo the bolts shown in the figure and remove the top side trim from the body shell.
- 4. Undo the bolts shown in the figure and remove the seat belt complete with bracket from the car.







NOTE To refit, reverse the procedure for removal, fully tightening (indicative torque: 5 daNm) the bolts securing the seat belt winder to the body shell.









P3U24EM04













ROOF TRIM SIDE MOULDING


Removing-refitting

- 1. Remove the embellishments shown by pressing them and moving them inwards as shown in the figure.
- 2. Open the rear tailgate and undo the screw shown in the figure.
- 3. Move the end of the side moulding in the direction of the arrow and undo the screw underneath.
- 4. Undo the screws located under the embellishments removed previously.
- 5. Remove the side moulding of the roof trim.














FIXED SIDE WINDOW


Preliminary operations


Before commencing the removal of the fixed side window, disconnect the battery's negative pole and remove the components that could hinder the removal operations, in particular the roof trim side moulding as described on page 25.

- Remove the luggage compartment screen by operating the side buttons, then remove the side blocks underneath by undoing the bolts; remove the tailgate frame central and side mouldings by undoing the bolts.
- 2. Remove the courtesy light on the rear pillar trim by removing the lens, screw and connector.
- Remove the luggage compartment side courtesy light by releasing the side lugs and disconnecting the connector; then open the access flap to the electrical devices and undo the screw securing the moulding to the body shell.
- 4. Remove the rear seat cushion and undo the seat belt bottom bolt.




P3U24DM02







P3U24DM04
















- 1. Lower the rear seat squab and remove the fixed side squab by lifting it from its seating.
- 2. Undo the nut indicated and remove the luggage compartment side moulding.
- 3. Using tool 1878077000, remove the side window rear pillar trim.
 4. Using tool 1878077000, remove the side
- window front trim.
- 5. Remove the rear courtesy light lens, disconnect the electrical connector and remove the courtesy light from the car, then remove the rear sunshade catches.







P3U25DM05







 Remove the aerial electrical connector and attach it to the window by means of adhesive tape, then separate the trim from the ceiling by interposing appropriate spacers.





Protect with a cloth the luggage compartment and parts that could be damaged during the cutting and window installation operations. Use adhesive tape to protect the edge of the window seating to prevent damage to the paintwork.

Removing




- 2. Working from outside the car on the top edge of the window, use a vibrating knife to cut the sealant, using the blade shown in the insert.
- 3. Continue cutting the sealant at the bottom and side, using the blade shown in the insert, working from inside the car.
- 4. Mark the reciprocal positions of the window and seating with strips of adhesive tape, then using appropriate handles with suction pads remove the window from its seating, after cutting the strips of adhesive tape applied previously.






P3U26DM03




P3U26DM04


3







P3U27DM02






- 1. Smooth the sealant on the window frame using a suitable scraper, making sure that the window stops at the top and bottom are of the dimensions shown in the figure; thoroughly degrease the entire window frame using heptane and paper towel.

 2. Remove the side and bottom window
- seals.
- 3. Remove the bead of old sealant from the window using a scraper.
- 4. Fit the window side and bottom seals.

NOTE If the window is replaced, position the window in its seating and mark the position with adhesive tape, working as stated on the preceding page.


5. Degrease the window thoroughly using heptane and paper towel.






P3U27DM03






P3U27DM05





P3U28DM02





 Using a swab, apply the adhesion promoter, taking care not to go beyond the printed area.


NOTE Leave the adhesion promoter to dry at ambient temperature for at least 15 minutes, and not longer than 24 hours.

- 2. Using a gun, apply the sealant on the bottom of the window, observing the dimensions shown in the figure.
- 3. Apply the sealant with a gun on the window at the top and side, observing the dimensions indicated.
- 4. Fit the window in its seating using the special handles with suction pads, observing the adjustment references, then using a belt exert appropriate pressure in order to obtain correct alignment; leave the window under pressure for at least 6 hours.




The car must not be delivered until at least 15 hours have elapsed since glueing the window.


NOTE Complete the assembly of the removed parts by reversing the procedure for removal.















REAR WINDOW


Preliminary operations


Before starting the removal of the rear window, disconnect the battery's negative pole and remove the parts that could hinder the operation, as described below.

- 1. Remove the attachment covers, undo the screws indicated, remove the tailgate handle, then undo the screws and remove the tailgate trim.
- 2. Remove the perimetral trim on the rear window frame, in the following sequence:
 - A. Central trim
 - B. Side trim
- 3. Disconnect the additional stop lights wiring connection.
- 4. Undo the screws indicated and remove the additional stop lights cluster.











P3U31EM04









- 1. Undo the nut and remove the rear window wiper arm.
- 2. Disconnect the rear window wiper motor wiring connector.
- 3. Undo the screws (arrowed) and detach the wiper motor from its seating.
- 4. Disconnect the rear window washer fluid pipe and remove the rear window motor from the car, then disconnect the heated rear window connections.




Protect with a cloth the luggage compartment and parts that could be damaged during the cutting and window installation operations; protect the edge of the window seating with adhesive tape to prevent damage to the paintwork.




P3U32EM02






P3U32EM04



P3U33EM01



Removing


1. Lift the tailgate, and working from inside the car, cut the sealant at the bottom of the window using the vibrating knife blade shown in the insert.

NOTE This blade can be used for all sides of the window.


- 2. Continue cutting the window sealant on the side edges.
- 3. Cut the window sealant at the top.
- 4. Mark the reciprocal positions of the window and seating with strips of adhesive tape, then using the appropriate handles with suction pads, remove the window from its seating, after cutting the strips of adhesive tape applied previously.




If the paint is scratched during removal of the window, apply anti-corrosion products.








33











Refitting

1. Using an appropriate blade, cut and smooth the sealant in the window frame, so as to leave a thickness between 0.25 and 1 mm without reaching the paintwork, thus avoiding scratching it.


NOTE The film of sealant remaining on the window frame acts as a base for the subsequent glueing.


2. Using an appropriate blade, cut and smooth the bead of sealant, trying to reduce the thickness to a minimum. It is not necessary to remove the sealant completely.

NOTE If the window is replaced, position the window in the seating and mark the position using adhesive tape, as described on the preceding page.

- 3. Thoroughly degrease the window and its seating using heptane and paper towel.
- 4. Using an appropriate swab, apply the adhesion promoter, taking care not to go beyond the printed area.


NOTE Allow the adhesion promoter to dry at ambient temperature for at least 15 minutes, and not over 24 hours.














P3U34EM04








- 1. Apply a two-sided adhesive seal for containing sealant, of the dimensions given in the figure, on the top and bottom edges.
- 2. Dimensions for applying two-sided adhesive seal on the window.
- 3. Apply the sealant on the window using a gun, in accordance with the dimensions given in the figure.
- 4. Fit the window in its seating using the special handles with suction pads, bearing in mind the adjustment references, then using a belt exert appropriate pressure in order to obtain correct alignment; leave the window under pressure for at least 6 hours.







The car must not be delivered until at least 15 hours have elapsed after glueing the window.

NOTE Complete the assembly of the removed parts by reversing the procedure for removal.





P3U35EM04



P3U36EM01

Introduction'

The windows fitted to this model conform to the industrial standard concerning the removal/refitting of fixed windows.


This system has many advantages, both in terms of quality as it ensures perfect permeability and resistance to air, and in terms of safety as it renders the structure more solid and less noisy.

TOOLS

To remove and refit glued windows, use the products and tools described below.

Composition of the glueing kit

- 1. Cartridge of GURIT BETASEAL sealant
- 2. 1/2 Cartridge of GURIT BETASEAL sealant
- 3. Adhesion promoter (primer) for glass
- 4. Bottle of degreasing product
- 5. Degreasing cloth
- 6. Swab for applying adhesion promoter (primer)
- 7. Harmonic wire
- 8. 2 diffusers




P3U36EM02


The previous adhesive marketed by the Volvera Marketing and Commercial Directorate has been replaced by an improved product, which is BETASEAL 1703 Sprint, a single-component polyurethane product which polymerizes rapidly.

This is certainly an advantage, as the adhesive hardens more quickly and the length of time the window has to be held by the appropriate tools is shorter. In addition, the delivery time (to the customer) of the repaired vehicle is reduced.


Its mechanical characteristics conform to the Fiat Auto S.P.A. specification.



P3U37EM01



P3U37EM02



P3U37EM03

Vibrating knife

The vibrating knife consists of special shears and a suitable set of vibrating blades with electrically-adjustable number of oscillations.

It can be used to cut polyurethane sealants.

It is important that during cutting, the blade always proceeds parallel to the window and the bodywork, to avoid breaking the blade.

To avoid overheating of the shears, it is advisable to adjust the advance and number of oscillations in accordance with the conditions of use.


Detail A shows the scraper to be fitted to the vibrating shears to level the sealant residues.



Do not use lubricants during cutting.

The blades must always be sharp.

The figures opposite and below illustrate some common window cutting situations, showing the necessary type of blade.




P3U37EM04

70.

GRAPHIC INDEX	
Replacement intervention	Manual reference
Replacing Roof panel P3U3BEM01	page 40
Replacing Rear Wing P3U38EMO2	page 44
Replacing Rear Cross Panel Trim and Pillar Reinforcement P3U38EM04	page 49


SYMBOLS

CUTTING WITH RECIPROCATING SAW	
CUTTING WITH CIRCULAR SAW	
CLEANING WITH ROTARY BRUSH	
REMOVAL OF SPOT WELDS WITH CHAMFERING MACHINE	
REMOVAL OF SPOT WELDS WITH DRILL	
DRILLING FOR MIG WELDING	
DISCHARGE OF PANEL WITH CHISEL	THE REST
DRILLING FOR MIG WELDING	
APPLICATION OF ELECTRO- WELDABLE PROTECTION	
APPLICATION OF THICK ELECTROWELDABLE PROTECTION	
CENTRING OF COMPONENTS	++++
MEASUREMENT	
ATTACHMENT OF COMPONENTS	
ATTACHMENT OF THREADED RIVETS	



SYMBOLS ON ILLUSTRATIONS

CUTTING LINE SPOT WELD FILL MIG WELD UUUUUUU CONTINUOUS MIG WELD XXXXXXXXX **BRAZING**



REPLACING ROOF PANEL (7090A 58)*

(*) This number indicates the operation code stated on the Service Time Schedule.

The part for which the replacement procedure is described is shown in the figure opposite.

P3U40EM01

PRELIMINARY PROCEDURES

Ascertain the extent of the damage and check whether connected components are deformed by checking the bodywork alignment dimensions, using appropriate measuring equipment (measuring benches, jigs or gauges).

Carry out any operations to straighten the body shell before cutting the part.

Check after this operation that components not to be replaced are not damaged.


PRELIMINARY DISMANTLING

Dismantle moveable parts of the bodywork and interior trim which could hinder the repair operations or sustain damage during these operations.

REMOVAL

Cut the roof panel using a pneumatic saw, following the dotted lines shown in the figure below; use a hammer and chisel in the areas of the fins.

The sections of the panel are shown in the most significant points, in order to allow the operator to adjust the position and depth of cutting in order not to damage the panels underneath.






When carrying out the operations described, follow accident-prevention regulations closely. Wear protective shoes, ear defenders and gloves during cutting operations, welding mask and gloves during welding, and protective mask and gloves during painting.

Removing burrs and preparing the edges of the bodywork

1. Grind down the weld spots along the entire perimeter of the edge of the bodywork, using a suitable grinder. Remove the panel burrs using clippers.

- 3. Straighten the edges with a shaped stake and hammer.
- 4. Apply IVI Epox epoxy primer or an electro-weldable galvanizing paint or equivalent product, on the areas previously affected by the grinding.




Preparing the new part

1. Apply a coat of primer by spray gun.


2. Along the entire perimeter of the inside and outside of the new part, remove the anti-corrosion treatment using a grinding disc.

3. Use the electro-weldable paint on the edges in contact with the body shell.




Fitting the new part

- 1. Restore the sealant on the body shell fins, using IVI 854210 transparent acrylic sealant or an equivalent product, then apply the heat-expanding product on the rear fin.
- 2. Carefully fit the new part in its seating.
- 3. Check that the roof panel is positioned perfectly on the body shell.
- 4. Secure the spare part to the body shell using the appropriate self-locking grippers.



Welding the new part


- 1. Carry out the brass welding using an oxyacetylene torch on the corners of the front, side and rear roof pillars.
- 2. Using a spot welder, continue the operation along the whole contact edge between roof panel and body shell.



P3U42EM02

Finishing operations

- 1. Correct any deformations in the panel using a shaped stake and hammer.
- 2. Remove any welding slag using a grinding disc.







P3U43EM01

Protection

- 1. Apply the anti-corrosion protection on the areas affected by the welding.
- 2. Seal the joins between roof panel and body shell using IVI 854210 transparent acrylic sealant or an equivalent product.
- 3. Proceed with painting and waxing.





REPLACING REAR WING (7090A 54)*

(*) This number indicates the operation code stated in the Service Time Schedule.

The part for which the replacement procedure is described is shown in the figure opposite.

PRELIMINARY PROCEDURES

P3U44EM01

Ascertain the extent of the damage and check whether connected components are deformed by checking the bodywork alignment dimensions, using appropriate measuring equipment (measuring benches, jigs or gauges).

Carry out any operations to straighten the body shell before cutting the part. Check after this operation that components not to be replaced are not damaged.


PRELIMINARY DISMANTLING

Dismantle moveable parts of the bodywork and interior trim which could hinder the repair operations or sustain damage during these operations.

REMOVAL

Cut the vehicle's rear wing using a pneumatic saw, following the dotted lines shown in the figure below.

The sections of the panel are shown in the most significant points, in order to allow the operator to adjust the position and depth of cutting in order not to damage the panels underneath.






When carrying out the operations described, follow accident-prevention regulations closely. Wear protective shoes, ear defenders and gloves during cutting operations, welding mask and gloves during welding, and protective mask and gloves during painting.

Removing burrs and preparing the edges of the bodywork


- 1. Grind down the weld spots along the entire perimeter of the bodywork edge, using a suitable grinder.
- 2. Remove the panel burrs using clippers.
- 3. Straighten the edges with a shaped stake and hammer.
- 4. Remove the weld spots using a disc grinder.
- 5. Apply IVI Epox primer or an electro-weldable galvanizing paint or equivalent product, on the areas previously affected by the grinding.



P3U45EM01

Preparing the new part


- Cut the top of the new part, then place it in its seating so that it adheres perfectly with the body shell.
 Check that the wing panel overlaps the body shell by about 50-60 mm.
- 3. Secure the part using self-locking grippers.
- 4. Cut the two panel edges so as to obtain a perfect join line.



P3U45EM02

Preparing the new part


- 1. Make equidistant holes on the edges of the new part as shown in the figure.
- 2. Remove the anti-corrosion treatment along the entire perimeter of the inside and outside of the new part, using an appropriate grinder.
- 3. Use electro-galvanizing paint on the contact edges with the body shell.
- 4. Carry out spot welding on the contact edges between wing panel, fuel filler compartment and lock striker mounting bracket, after interposing sealant.



P3U46EM01

Checking that the new part is positioned correctly on the body shell


- 1. Tack the new part on the body shell by making a few spot welds.
- 2. Close the tailgate and rear door.
- 3. Check that the surrounding gap is aligned and even.



P3U46EM02


Welding the new part

- 1. Carry out spot welding on the door frame and wheelarch.
- 2. Use the MIG welder between wing panel and body shell.
- 3. Carry out fill welding in the holes made previously on the new part, namely between wing panel, door sill and body shell.
- 4. Restore the guide for securing the door seal.



Continuation of welding the new part


- 1. Carry out fill welding in the holes made previously on the new part, and namely in the rear lights cluster frame and rear pillar.
- 2. Carry out spot welding on the contact edges between wing panel and rear cross panel.



Copyright Fiat Auto 47

Finishing operations

- 1. Correct any deformation in the panel using a shaped stake and hammer.
- 2. Remove any welding slag using a grinding disc.




Protections

1. Apply the anti-corrosion protecton on the areas previously affected by the welding.


 Seal the join lines between wing panel and body shell using IVI 854210 transparent acrylic sealant or an equivalent product.

3. Fit damping panels inside the wing panel.

4. Proceed with painting and waxing.



P3U48EM02



REPLACING REAR CROSS PANEL TRIM AND RIGHT PILLAR REIN-FORCEMENT (7090G 76)*

(*) This number indictes the operation code stated in the Service Time Schedule.

The part for whic the replacement procedure is described is shown in the figure opposite.

PRELIMINARY OPERATIONS

Ascertain the extent of the damage and check whether connected components are deformed by checking the bodywork alignment, using appropriate measuring equipment (measuring benches, jigs or gauges).

Carry out any operations to straighten the body shell before cutting the part. Check after this operation that components not to be replaced are not damaged.


PRELIMINARY DISMANTLING

Dismantle moveable parts of the bodywork and interior trim which could hinder the repair operations or sustain damage during these operations.

REMOVING REAR CROSS PANEL TRIM

Cut the rear cross panel trim of the car using a pneumatic saw, following the dotted lines shown in the figure below.

The sections of the panel are shown in the most significant points, in order to allow the operator to adjust the position and depth of cutting in order not to damage the panels underneath.






When carrying out the operations described, follow accident-prevention regulations closely. Wear protective shoes, ear defenders and gloves during cutting operations, welding mask and gloves during welding, and protective mask and gloves during painting.


Removing right pillar reinforcement

- 1. Cut the contact edges between the pillar reinforcement and floor longitudinal member, using a chisel and hammer.
- 2. Cut the pillar reinforcement using a pneumatic saw, following the dotted lines shown in the figure.
- 3. Reduce the weld spots along the entire perimeter of the body shell as shown in the figure.



Removing burrs and preparing the edges of the bodywork


- 1. Reduce the weld spots along the entire perimeter of the bodywork edge as shown in the picture, using an appropriate grinder.
- 2. Remove the panel burrs using clippers.
- 3. Straighten the edges with shaped chisel and hammer.
- 4. Remove the welding spot residues using a grinding disc.
- 5. Apply IVI Epox epoxy primer or an electro-weldable galvanizing paint or equivalent product on the areas previously affected by the grinding.



P3U50EM02

Preparing the rear cross panel trim


- 1. Make equidistant holes along the edges of the new part as shown in the figure.
- 2. Remove the anti-corrosion treatment along the entire perimeter of the inside and outside of the part, using a grinding disc.
- 3. Use electro-galvanizing paint on the previously treated edges.



P3U51EM01

Fitting the rear cross panel trim

- 1. Fit the new part carefully in its seating.
- 2. Check that the cross panel trim is perfectly in position.
- 3. Secure the new part to the body shell using appropriate self-locking grippers.
- 4. Tack the new part by making a few spot welds.
- 5. Close the tailgate and check that the surrounding gap is aligned and even.




P3U51EM02

Replacing body panels

Welding the rear cross panel trim


- 1. Carry out spot welding on the contact edges between the rear cross panel trim and wing panel.
- Continue spot welding on the contact edges near the spare wheel compartment and side edges.
 Use a MIG welder to fill the holes made previously on the spare part.
- 4. Make a continuous bead weld on the edges of the rear pillar reinforcement.
- 5. Carry out brass fill welding using an oxyacetylene torch on the contact edges between cross panel trim, light housing and wing panel.




P3U52EM01

Preparing the rear pillar reinforcement

- Measure the distance between the longitudinal member and pillar reinforcement 490 mm.
- Make up the dimension measured previously, increased by at
 Remove the surplus on the new part using a pneumatic saw. Make up the dimension measured previously, increased by about 10 mm on the spare part.






P3U52EM02


Fitting the new part on the body shell

- 1. Position the new part on the body shell using self-locking grippers.
- 2. Check that the new part is positioned perfectly by checking the position of the centring holes for the rear bumper bolts.
- 3. Draw the profile of the new part on the body shell using a marker pen or scribe, leaving a gap of 1 mm between the profile of the new part and the body shell.



Removing burrs and preparing the edge of the body shell


- 1. Reduce the weld spots along the entire perimeter of the bodywork edge as shown in the insert, using a appropriate grinding tool.
- 2. Remove the panel burrs using clippers.
- 3. Straighten the edges with a shaped stake and hammer.
- 4. Remove the welding spot residues using a grinding disc.
- 5. Apply IVI Epox epoxy primer or electro-weldable galvanizing paint or equivalent product on the areas previously affected by the grinding.



P3U53EM02

Preparing the pillar reinforcement

- 1. Remove the anti-corrosion treatment along the entire perimeter of the inside and outside of the new part using a grinding disc.
- 2. Use electro-galvanizing paint along the previously treated edges.







P3U54EM01

Welding the pillar reinforcement

- 1. Carry out spot welding on the contact edges between pillar reinforcement and body shell.
- 2. Using a MIG welder, make a continuous bead weld along the edges of the new part and floor longitudinal member and on the top edge between the new part and body shell.






P3U54EM02

Finishing operations


- 1. Correct any deformations in the panel using a shaped stake and hammer.
- 2. Remove any welding slag using a grinding disc.



P3U55EM01

Protection

- 1. Apply anti-corrosion protection on the areas previously affected by the welding.
- 2. Seal the join lines between cross panel trim and rear pillar reinforcement and the body shell.
- 3. Proceed with painting and waxing.
- 4. Apply wax-based oil protection inside the rear pillar reinforcement.



P3U55EM02

LANCIA k Coupé

Bodywork Contents

70. -

	page	page
BOOT LID		REPLACING STRUCTURAL PANELS
Removing-refitting boot lidAdjustmentsRemoving-refitting boot lid catch striker	1 2 2	- Graphic index 57 - Symbols 58 - Replacing rear wheel arch 59 - Replacing central pillar together with part of door sill frame 63
FRONT DOOR		
 Removing-refitting front door Removing-refitting door panel and protective trim Dismantling-fitting door panel Removing-refitting door lock Removing-refitting descending window Removing-refitting window mechanism Adjusting descending window glass 	3 4 6 8 9 11 13	For further information, consult section 70 Bodywork of the Lancia k manual (publication no. 506.475/01)
INTERIOR TRIM		
 Removing-refitting roof panel trim Removing-refitting rear seat belts Removing-refitting rear wing inner lining 	14 16 18	
SEATS		
 Sedile anteriore Removing-refitting front seat Removing-refitting seat belt catch device Dismantling-fitting front seat 	19 21 23 24	
WINDOW GLASSES		
Replacing rear side window glassReplacing rear glass (rear window)	28 33	
REPLACING BODY PANELS		
 Graphic index Symbols Replacing roof panel Replacing rear wing Replacing door sill trim Replacing tail-light cluster housing 	39 40 41 45 49 53	

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A.
D.M.C. - M.P.S.
Servizi Post Vendita - Tecnologie Assistenziali
Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia)
Publication no. 506.475/19 - Gennaio 1998 - 400
Printed in Italy - Tip. Stampart - Torino
order no. 60445103

FRONT SEAT


Components

The front seat is fitted with a control unit which governs the various adjustment motors (squab rake, lumbar adjustment, front/rear cushion height, seat reach).

A button on the left side of the seat controls seat heating. Two knobs control the seat position adjustment motors.




P3U18CM05




9 8

- 1. Cushion rear height adjustment motor
- 2. Cushion front height adjustment control motor
- 3. Control unit
- 4. Seat reach control motor
- 5. Squab rake adjustment control motor
- 6. Squab lumbar adjustment control motor
- 7. Seat heater operation button
- 8. Button operating cushion height adjustment control motors and seat slide
 9. Button operating lumbar adjustment and
- squab rake control motors


Seats



P3U20CM06



3U18CM09



Operation



Seat position may be adjusted only with the ignition key turned to

Two control knobs A and B are located on the side of the seat.

Knob A can be used to carry out the following adjustments:

- Seat reach adjustment Seat tilt adjustment (cushion front height)
- 3. Seat tilt adjustment (cushion rear height)

Knob B can be used to carry out the following adjustments:

- 4. Squab rake adjustment
- 5. Lumbar support adjustment

Access to rear seats

To gain access to rear seats, lift lever C and move the squab forward.

When the squab is moved, the seat slides forward automatically to improve access to the rear seats.

When the squab is restored to its normal position, the seat automatically resumes its original memorised position.

If it should encounter an obstacle while moving backward (e.g. the legs of a passenger), it will stop and then move forward a few centimetres before locking.


Electrical seat heating

Turn on switch D on the seats to activate/deactivate. Warning lights light up on the control panel when activated.


Adjusting front seat head restraints

Front seat head restraints may be adjusted in two ways:

- 1. vertically, by clicking the restraints upward or downward.
- 2. angular adjustment.







P3U21CM06


REMOVING - REFITTING SEAT FRONT

Removing

- 1. Move the front seat fully forward to the end of its travel, then unscrew the bolts securing the guide rails to the floor.
- 2. Move the seat fully back by undoing the bolts shown in the figure, disconnect the connections shown in the box and then remove the front seat from the vehicle.


Refitting

3. Position the seat in the vehicle, then connect the connections arrowed in the fig-





P3U19CM05


- 4. Position the seat retaining bolts as shown in the diagram above, in the following or-
- A. Right rear retaining bolt.
- B. Left rear retaining bolt.
- C. Right front retaining bolt.
- D. Left front retaining bolt.
- Move the seat fully foward and fully back.
- Tighten the seat retaining bolts to a torque of 2.4 daNm.
















Initialising the seat control unit



Whenever the front seats are removed, the control unit must be initialised as described below:

- Connect an electrical lead (1) to the tester lead located beneath the seat.
- Move the seat squab upright by adjusting control (B).
- Position the seat fully back and lower fully by means of control (A).
- Connect electrical lead (1) fitted previously to earth.
- Wait 5 to 20 seconds.
- Disconnect electrical lead (1).
- Tilt the squab within 30 seconds: the seat will activate and move fully forward, fully back and then fully forward again in sequence.
- Once the cycle has finished, move the squab upright and the seat will return to its starting position, i.e fully back.




If the procedure has never been carried out or is interrupted, the control unit will move the seat foward and the procedure must be repeated.

Emergency manual operation of front seat




If the horizontal seat movement motor fails, the seat may be moved manually.

 Insert a tool with the dimensions shown in the box into the seat on the seat operating pin (arrowed). Then turn the tool to move the seat to the required position.








P3U19CM08

P3U23CM06







REMOVING-REFITTING SEAT BELT CATCH DEVICE

- 1. Remove the front seat as described on page 21.
- 2. Disconnect the seat belt attachment connector block.
- 3. Prise off the seat belt attachment retaining bolt protection.
- 4. Unscrew retaining screw indicated.
- 5. Disconnect the seat belt attachment from its seat.

NOTE Reverse removal instructions to refit.








P3U20CM05

(3U83CM)


Bodywork

Seats

70.







P3U24CM07


DISMANTLING-FITTING FRONT SEAT

Removing cushion moulding


- Remove the front seat as described on page 21, until it is fully raised. Then unscrew the retaining bolts and remove the side moulding.
- 2. Unscrew the retaining bolt indicated in the figure, remove the moulding and remove the seat operation controls from the seat.
- 3. Unscrew the underlying bolts, disconnect the heated seat button connector and remove the cushion moulding.
- 4. Undo the retaining tabs to remove the heated seat control button.

Removing squab adjustment motors


5. Unscrew the retaining bolts indicated and lift the squab trim in the arrowed direction to release the tabs.




P3U24CM08




P3U21CM03




P31124CM09








P3U22CM03






P3U22CM05

- 1. Remove the squab control lever and its seat.
- 2. Lift the head restraint from the seat, press on the points indicated to release the pin from the retaining clip.
- 3. Remove the squab trim with padding by raising the tabs shown in the figure and releasing the link.
- 4. Squab adjustment motor (1), lumbar adjustment motor (2).
- 5. Unscrew the connector and the retaining bolts shown in the figure and remove the lumbar adjustment motor from the seat squab.






P3U25CM06

25


Bodywork

Seats

70.







P3U26CM07

P3U26CM06


1. Disconnect connector and the retaining bolts shown in the figure and remove the squab adjustment motor.

Removing seat adjustment motors


- 2. Component Icoation:
 - 1. Seat reach motor; 2. Control unit; 3. Seat operation control; 4. Front ride adjustment motor; 5. Rear ride adjustment motor
- Unscrew the retaining bolts and the electrical connections, then disconnect the guide together with seat activation motors.
- 4. Seat adjustment motors.

Removing seat operating control

5. Unscrew the bolts retaining the seat operation device and remove together with electrical wiring.










P3U26CM10

(3U86CM)












Removing seat control unit


1. Disconnect the connector indicated and the retaining bolts, then remove the control unit from the seat.

Removing cushion trim


- 2. Lift the cushion trim link retaining tabs and prise up the cushion trim from the top.
- 3. Cut the padding fasteners indicated in the figure.
- 4. Detach the cushion trim complete with padding from the frame.








(3U87CM)



P3U18CM04



P3U28CM02

REPLACING REAR SIDE WINDOW GLASS



Protect any parts which could become damaged during glass cutting and installation using a cloth. Then protect the edge of the glass housing with adhesive tape to prevent damage to the paintwork.

Before beginning the glass replacement procedure, disconnect the battery negative terminal.

Operation sequence

- 1. Remove the rear wing inner lining as described on page 18.
- 2. Lift the protection and unscrew the nut shown in the figure. Then remove the front seat belt (only the upper part) by undoing the retaining tab. Remove the height adjustment knob of the seat belt.
- 3. Remove the rear pillar trim from its seat by undoing the retaining clips using tool 1878077000.
- 4. Remove the rear pillar trim by releasing from its retaining clips using tool 1878077000.

