LANCIA



LANCIA k

Volume 5







COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Tecnologie Assistenziali Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia) Publication no. 506.475/26 - Marzo 1999 - 400 Printed by Satiz S.p.A. - Turin (Italy) order no. 60446664

TECHNICAL SERVICE MANUAL COMPOSITION

At present, May 2000, the LANCIA k 5th volume manual is composed as follows:

| Print N° | Sections | Page Nos. | Versions | Notes | |
|------------------------|----------|--------------|--|---|--|
| | | 1-46 | 1998) 20 <i>v</i> 2446) 20 <i>v</i> 98 Update | Engine: Fuel system | |
| 506.475/26 (1/99) | 10 | 1-52 | 98 Update | Engine: Fuel system | |
| | | 1-24 | 2387) πο 98 Range | Engine: Operations on vehicle | |
| 506.475/25 (III/99) | 55 | 1-45 | 1998) 200 (2446) 200 (2959) 200 98 Update | Electrical equipment: Wiring diagrams | |
| 506.475/27 | 10 | 17-18 | 1998) 20V (2446) 20V 98 Update | Update: Fuel system | |
| (IV/99) | 00 | 1-7 | 2446) 20 <i>V</i> 99 Update | Technical Data | |
| 506.475/29 (IX/99) | 55 | 44/1-44/4 | automatic transmission 2446) 20V automatic transmission 99 Update | Wiring diagrams update Electrical equipment | |
| 506.475/30 | 55 | 1-4 | 99 Update | Electrical equipment: Removing-refitting alternator | |
| (V/2000) | | 44/4-44/10 | 2387) Л D 99 Update | Wiring diagrams update | |



TECHNICAL SERVICE MANUAL COMPOSITION

To date, September 1999, the LANCIA k 5th volume manual comprises the following:

| Publication no. | Sections | Number of pages | Versions | Notes |
|------------------------|----------|--------------------|--|--|
| 506.475/26 (1/99) | | 1-46 | 1998) 20V 2446) 20V 98 update | Engine: Fuel system |
| | 10 | 1-52 | (2959) 24V (98 update | Engine: Fuel system |
| | | 1-24 | 2387) ЛО '98 range | Engine: interventions on the car |
| 506.475/25 (III/99) | 55 | 1-45 | (1998) 20V (2446) 20V (2959) 20V (98 update | Electrical system: Wiring dia- grams |
| 506.475/27 | 10 | 17-18 | 1998) 20V (2446) 20V '98 update | Update: Fuel system |
| (IV/99) | 00 | 1-7 | 2446) 20V '99 update | Technical data |
| 506.475/29 (IX/99) | 55 | 44/1-44/4 | automatic transmission 2446) 20V automatic transmission '99 update | Wiring diagrams update Electrical equipment |



| Print N° | Sections | Page Nos. | Versions | Comments |
|------------|----------|--|-------------------------------------|---|
| | 10 | Index 1-2 7-8 13-18 33-34 55-56 | 1998) 20V turbo 98 range | Fuel system: Update |
| 506.475/25 | 21 - 27 | 29-40 | <mark>2959</mark>) 24V 98 range | ZF4HP20 automatic gearbox and differential: Overhauls and adjustments |
| (11/99) | 50 | 1-19 | 98 range versions | Auxiliary units: Automatically operated climate control system |
| | 69-120 | 69-120 | 98 range versions | Update: Electrical equipment |
| i | 55 | 132/1-132/24 | 98 range versions | Electrical equipment wiring diagrams: Update |

П



SERVICE MANUAL COMPOSITION

At present, April 1999, the Lancia k 5th volume manual is composed as follows:

| Print N° | Sections | Page Nos. | Versions | Comments |
|------------------------|----------|-----------|---|-------------------------------------|
| | | | 1998) 20V 2446) 20V | Engine: Fuel system |
| 506.475/26 (1/99) | 10 | 1-52 | 2959) 24V 1998 update | Engine: Fuel system |
| | | 1-24 | 2387) ЛD 1998 range | Engine:Operations on vehicle |
| 506.475/25 (III/99) | 55 | 1-45 | 1998) 20V (2446) 20V (2959) 24V 1998 update | Electric equipment: Wiring diagrams |
| 506.475/27 | 10 | 17-18 | 1998) 20V 2446) 20V 99 Update | Fuel system update |
| (IV/99) | 00 | 1-7 | 99 Update | Technical data |



SERVICE MANUAL COMPOSITION

At present, March 1999, the LANCIA k 5th volume manual is composed as follows:

| Print N° | Sections | Page Nos. | Versions | Comments |
|------------------------|----------|-----------|---|---------------------------------------|
| | | 1-46 | 1998) 20V 2446) 20V 98 Update | Engine: Fuel system |
| 506.475/26 | 10 | 1-52 | (<mark>2959</mark>) 24V 98 Update | Engine: Fuel system |
| | | 1-24 | 98 range | Engine: Operations on vehicle |
| 506.475/25 (III/99) | 55 | 1-45 | 1998) 20V (2446) 20V (2959) 24V 98 Update | Electrical equipment: Wiring diagrams |

SERVICE MANUAL COMPOSITION

At present, January 1999, the LANCIA k 5th volume manual is composed as follows:

| Print N° | Sections | Page Nos. | Versions | Comments |
|--------------------------|----------|--------------|--------------------------------------|-------------------------------|
| | | 1÷46 | 1998 20v 2446 20v 98 update | Engine: Fuel system |
| 506.475/26 (1/99) | 10 | 1÷52 | ²⁹⁵⁹ 24V 98 update | Engine: Fuel system |
| | | 1÷24 | 2387) ль 98 range | Engine: Operations on vehicle |



| GENERALITES | INTRODUCTION | ALLGEMEINES | GENERALITÀ |
|--------------------------------|-----------------|---|---------------|
| CARACTERISTIQUES TECHNIQUES | TECHNICAL DATA | TECHNISCHE DATEN | DATI TECNICI |
| Thours | | DATEN | |
| | | | T |
| MORRID | ENGINE | MOTOR | MOTORE |
| MOTEUR | ENGINE | MOTOR | MOTORE |
| | | | |
| | <u> </u> | 1 | T |
| | a | *************************************** | DDIGIONE |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| | | | |
| - | · | | 1 |
| BOITE DE | GEARBOX | SCHALTGETRIEBE | CAMBIO DI |
| VITESSES | DIFFERENTIAL | AUS- GLEICHGETRIEBE | VELOCITÀ |
| DIFFERENTIEL | | GLEICHGETRIEBE | DIFFERENZIALE |
| | | | 7 |
| ARBRE DE | PROPELLER | | ALBERO DI |
| TRANSMISSION | SHAFT | GELENKWELLE | TRASMISSIONE |
| TRANSMISSION | SHAF I | <u> </u> | |
| | | | |
| DIFFERENTIEL | REAR | HINTERES | DIFFERENZIALE |
| | DIFFERENTIAL | AUS- | POSTERIORE |
| ARRIERE | DIFFERENTIAL | GLEICHGETRIEBE | TOSTERIORE |
| | | | |
| | | | |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| | | | |
| | | | |
| | | | |
| DIRECTION | STEERING | LENKUNG | STERZO |
| | | <u></u> | |
| <u></u> | | + | |
| SUSPENSIONS ET | SUSPENSION AND | AUFHÄNGUNGEN | SOSPENSIONI E |
| ROUES | WHEELS | UND RÄDER | RUOTE |
| | <u> </u> | <u></u> | |
| | T | T | |
| ORGANES | | ZUSATZ- | ORGANI |
| SUBSIDIAIRES | AUXILIARY UNITS | EINRICHTUNGEN | SUSSIDIARI |
| | | | |
| | | | <u></u> |
| EQUIPEMENT | ELECTRICAL | ELEKTRISCHE | IMPIANTO |
| ELECTRIQUE | EQUIPMENT | ANLAGE | ELETTRICO |
| | | | |
| <u> </u> | | | |
| CAPPOGGEDIE | DODAMORE | CADOCCEDIE | CARROZZERIA |
| CARROSSERIE | BODYWORK | CAROSSERIE | UARRULLERIA |
| | | | 1 |

ALLGEMEINES

GENERALITES



Introduction and technical Contents

00.

nage

| | 17-31 |
|---|-------------|
| INTRODUCTION | |
| - Identification data | 1 |
| TECHNICAL DATA | |
| Engine 2000 - Cylinder head and valve gear components - Cooling system - fuel system - Fuel system | 2 3 4 |
| Automatic transmission - differential | 5 |
| Electrical equipment - Electronic injection ignition | 6 7 |

NOTE This section shows 2446 20v engine variants with Bosch Motronic ME 3.1 returnless fuel system. Consult the LANCIA k 1998 range manual, publication no. 506.475/25 for further information.

Copyright Fiat Auto 0

COPYRIGHT by Fiat Auto S.p.A.

Any reproduction of the text or illustrations is prohibited.

The information contained in this publication is supplied as a guide and may no longer be up to date as a result of modifications made by the Manufacturer, at any time, for reasons of a technical or commercial nature in addition to meet legal requirements in different countries.

Fiat Auto S.p.A.

D.M.C. – M.D.S. Servizi al Cliente – Post Vendita Largo Senatore G. Agnelli, 5 – 10040 Volvera – To – (Italia) Print n° 506.475/27 – Maggio 1999 – 400 Printed by Satiz S.p.A. – Turin (Italy) order n° *604.46.763*



| | 01140010 | | VERSION | GEAR | вох |
|----------------------------|-------------|------------|---------------|------|-----|
| | CHASSIS | ENGINE | SALOON | 986 | |
| 2446) _{20V} ZLA 8 | ZLA 838.000 | 838 A2.000 | 838 AC 1AA 03 | • | |
| | ZLA 030.000 | | 838 AC 11A 15 | | • |


| | CHASSIS | , , , , , , , , , , , , , , , , , , , | VERSION | | | GEARBOX | |
|-------------|------------|---------------------------------------|---------|---------------|---------------|---------|---|
| | | ENGINE | sw | COUPÉ | CODE | 999 | 1 |
| ZLA 838.000 | | | • | | 838 BC 1AA09 | • | |
| | 838 A2.000 | | • | 838 CC 1AA 13 | • | | |
| | | | • | | 838 BC 11A 16 | | • |

Engine: cylinder head and valve gear components




00.10

TIMING DIAGRAMS









P3U32LA01

| TIMING ANGLES | | | 2446) ₂₀₀ |
|---------------|----------------|-------------------|------------------------------|
| A Inlet | | starts before TDC | 12° after TDC (*) 6° (**) |
| В | 7 2 | ends after BDC | 52° (*) 34° (**) |
| C Exhaust | & 7 | begins before BDC | 40° |
| D | | ends after TDC | 0° |

^(*) With low engine load (**) With high engine load and consequent variable valve timing cut-in



Engine: cooling system - fuel system

00.10



COOLING SYSTEM

| COOLING SYSTEM | | | | | |
|---|----------------|--------------|---|-------------|--|
| Cooling circuit | | | Coolant circulationvia centrifugal pump, radiator and fan controlled by electronic control unit | | |
| Coolant pump drive | | | | by belt | |
| | | 7 | 1 st speed | 96.4 | |
| Fan activation-deactivation | (- |) | 2 nd speed | 101.9 | |
| controlled by control unit | | | 1 st speed | 93.6 | |
| control and | sto | り | 2 nd speed | 98.7 | |
| | opening begins | | g begins | 81° - 85°C | |
| Engine coolant thermostat | • | max opening | | 99° - 103°C | |
| | | valve travel | | 9.5 mm | |
| Fitting clearance betwen impelle vanes and pump casing | r | | 70 | - | |
| Pressure for checking system water tightness | | | 0.98 bar | | |
| Checking exhaust valve on supplementary expansion tank pl | lug | | | 0.98 bar | |

CONTROL

| Make | Bosch Motronic ME 3.1 Electronic integrated injection-ignition |
|---------------------------------|--|
| Electric | pump |
| Flow rate | ≥ 120 l/h |
| Fuel pressure regulator setting | 3.5 bar |

| Checking idle concentration of pollutant emissions | CO (%) | HC (p.p.m.) | CO ₂ (%) |
|--|--------|-------------|---------------------|
| Upstream of the catalytic converter | 04 - 1 | ≤ 600 | ≥12 |
| Downstream of the catalytic converter | ≤ 0.35 | ≤ 90 | ≥ 13 |

Engine: fuel system



00.10

COMPONENTS OF BOSCH MOTRONIC ME 3.1 INTEGRATED INJECTION - IGNITION SYSTEM

| , | 2446) _{20V} |
|---|--------------------------------|
| Injection/ignition system electronic control unit | 0.261.206.069 |
| Throttle body | 0.205.003.052 |
| Injector | 0.280.155.770 |
| Electric fuel pump | 0.580.313.020 |
| Air flow meter | 0.280.217.108 |
| Engine coolant temperature sensor | 269 0350 402 183.01 |
| Lambda sensor | 0.258.006.072 0.258.006.193 |
| Fuel vapour solenoid valve | 0.280.142.340 |
| Knock sensor | 0.261.231.131 |
| Injection timing sensor | 0.232.101.036 |
| Top Dead Centre and rpm sensor | 0.260.210.160 |
| Potentiometer on accelerator pedal | 0.281.002.202 |

Automatic transmission - Differential

00.21-27

| GEARBOX AUTOMATIC AISIN | ENGINE VERSION | 2446) _{20V} | | |
|---|---|----------------------|--|--|
| Speeds | 4 | 0000 | | |
| | (00000 | 3.606:1 | | |
| -I- Ŧ | \bigcirc 2 \bigcirc \bigcirc | 2.060:1 | | |
| | < ○○ ❸ ○ ○ | 1.366:1 | | |
| Gear ratios | 00000 | 0.982:1 | | |
| | | 3.949:1 | | |
| -1- 8 | Idler ratio | 56/57 (0.982) | | |
| Torque converter | Ø mm | 241 | | |
| ± X rat | ve torque io olitter) | 1.99 | | |
| for | initial filling | 7.5 I (6.8 kg) | | |
| GI/2 ● | iodic change | 3 I (2.7 kg) | | |
| (●) DEXTRON II automatic transmission fluid | | | | |

| DIFFERENTIAL | | |
|----------------------|--------------------------------------|------------------|
| | Spur gear and pinion set ratio | 2.864 (63/22) |
| | (00000 | 10.328 |
| = | 0000 | 5.899 |
| | <00000 | 3.912 |
| Ratio at the wheels | 00000 | 2.813 |
| riatio at the wheels | (000 B | 11.309 |

Electrical equipment

LANCIA K 246 20V 1999 update

00.55

| | 2446) _{20V} |
|----------------------|---|
| STARTER MOTOR | Magneti Marelli E 70R-12V 1.4 kW (with reduction gear) |
| ALTERNATOR | Magneti Marelli A 127I-14V – 55/100A |
| | Bosch NC-14V-60/120A (*) |
| VOLTAGE REGULATOR | BUILT IN ELECTRONIC |
| BATTERY | 12V - 60Ah |
| IGNITION COIL | Integrated electronic injection-ignition Bosch Motronic ME 3.1 |
| IGNITION COIL | 0.221.504.014 (1 per spark plug) |
| POWER MODULE | - |
| SPARK PLUGS | LANCIA 7G BMSR Champion RC8 BYC |

^(*) For vehicles with air conditioning



Electrical equipment: electronic injection-ignition

00.55

| CONTROL MODULE BOSCH MOTRONIC INTEGRATED ELECTRONIC INJECTION-IGNITION | 2446 20V | |
|--|--|---------------------|
| Make | | 0.261.206.069 |
| Firing order | | 1 - 2 - 4 - 5 - 3 |
| IGNITION COIL (1 PER SPARK PLUG) | | |
| Make | | Bosch |
| Туре | | 0.221.504.014 |
| Ohmic resistance of primary winding at 20°C | Ω | 0.73 |
| Ohmic resistance of secondary winding at 20°C | Ω | 9600 |
| TOP DEAD CENTRE AND RPM SENSOR | | : |
| Make and type | | Bosch 0.261.210.119 |
| Sensor winding resistance at 20°C | Ω | 774 ÷ 946 |
| Distance (gap) between sensor and crankshaft pulley tooth | mm | 0.8 ÷ 1.5 |
| KNOCK SENSOR | | |
| Make | | Bosch |
| Type | | 0.261.231.007 |
| SPARK PLUGS | L | |
| Make and type | THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TRANSPORT NAMED IN CO | Champion RC8BYC |
| Thread | | M 14 x 1.25 |
| Electrode gap | T THE TAXABLE AND ADDRESS OF THE TAXABLE AND ADD | 0.8 ÷ 1 |



| ATI TECNICI | |
|-------------|--|
| | |

GENERALITÀ DA

| MOTEUR | ENGINE | MOTOR | MOTORE |
|--------------------------------------|-------------------------|--|--|
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |

10

| pa | ge | | page |
|--|-----|--|------|
| BOSCH MOTRONIC ME 3.1 M.P.I. IN- TEGRATED INJECTION/IGNITION | | INJECTION/IGNITION SYSTEM COMPONENTS | 17 |
| SYSTEM | 1 | - Injection/ignition system wiring | 17 |
| Introduction General description of the injection | 1 | - Injection/ignition electronic control unit | 17 |
| system | 1 | - Identification of connections at the | |
| - General description of the ignition sys- | • | control unit | 18 |
| tem | 1 | - Injection/ignition electronic unit | 18 |
| - Functional diagram showing the injec- | | - Ignition coils | 20 |
| tion/ignition system | 2 | - Timing sensor | 21 |
| - Functions of the injection/ignition | | - Rpm and TDC sensor | 22 |
| system | 3 | - Detonation sensors | 23 |
| | | - Electric fuel pump | 24 |
| SYSTEM MANAGEMENT | | Fuel supply manifold | 24 |
| STRATEGIES | 4 | - Injectors | 25 |
| - Adjustment of the injection times | 4 | - Accelerator pedal potentiometer | 26 |
| - Ignition advance adjustments | 4 | - Brake pedal switch | 26 |
| - Check on the cold starting | 4 | - Clutch pedal switch | 26 |
| - Checkontheenrichmentofthemixturedur- | | - Air flow meter | 27 |
| ing acceleration | 4 | - Butterfly casing actuator | 28 |
| - Fuel cut-off during overrun | 4 | - Lambda sensor | 29 |
| - Check on engine idle speed | 5 | - Phase transformer | 30 |
| - Restriction of the maximum engine | | - Coolant temperature sensor | 33 |
| speed (protection outside of revs) | 5 | - Inertia switch | 34 |
| - Check on combustion using Lambda | | - Multi-purpose valve | 35 |
| sensor | 5 | - Safety and ventilation valve | _ 36 |
| - Fuel vapour recovery | 6 | - Fuel vapour separator (expansion | 26 |
| - Check on detonation | 6 | tank) | 36 |
| - Check on phase transformer | 6 | - Charcoal filter and fuel vapour cut out | 27 |
| Check on inlet manifold | 6 | solenoid valve | 37 |
| - Self-adjustment of the system | 7 | CHECKS-ADJUSTMENTS AND REPAIR | |
| - Autodiagnosis | 7 · | OPERATIONS ON THE BOSCH | |
| - Connection with engine immobilizer | | MOTRONIC ME 3.1 INJECTION/IGNI- | |
| device (Lancia CODE) | 7 | TION SYSTEM IN ADDITION TO THE | |
| Management of the climate control system | า 8 | FAULT DIAGNOSIS | 38 |
| - Management of the radiator fan | 8 | FAULI DIAGNOSIS | - 50 |
| - Air intake circuit | 8 | Check on engine idle speed | 39 |
| Diagram showing information enter- | | Checking concentration of pollutant | |
| ing/leaving the control unit and | | emissions | 39 |
| sensors/actuators | 9 | Checking exhaust concentration of CO | |
| | 10 | and HC | 39 |
| | 11 | - Removing-refitting accelerator pedal | |
| | 1 1 | potentiometer | 40 |
| System for recirculating gases coming | 4.0 | - Adjusting the accelerator pedal end of | |
| from the engine crankcase | 12 | travel | 43 |
| Engine exhaust assembly diagram | 13 | | |
| Injection/ignition system wiring | | DIAGNOSTICS | 44 |
| diagram | 14 | | |
| Connection between control unit/igni- | | | |
| tion coils and injectors | 15 | | |
| Location of injection/ignition system | . • | | |
| components | 16 | • | |
| | | | |

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Tecnologie Assistenziali Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia) Publication no. 506.475/26 - Marzo 1999 - 400 Printed by Satiz S.p.A. - Turin (Italy) order no. 60446664

1

BOSCH MOTRONIC ME 3.1 M.P.I. INTEGRATED INJECTION/IGNITION SYSTEM

Introduction

Starting from November 1998 the 1998 20V version will be equipped with a new Bosch Motronic ME 3.1 type injection/ignition system.

This system belongs to the category of static advance, inductive discharge digital electronic ignition systems integrated with sequentil, phased electronic injection systems. The system has only one electronic control unit, a single set of wiring and one joint set of sensors.

Its function is to inject the exact quantity of petrol, into the engine inlet manifold, upstream of the inlet valves, designed to mix with the air introduced in the cylinder to obtain the correct mixture strength.

The Motronic ME 3.1 system gurantees efficient operation providing optimum performance and fuel economy and allowing a reduction in harmful emissions by means of a prompt response to the different engine operating conditions.

General description of the injection system

There are essentially two conditions which must always be satisfied in the preparation of the air/fuel mixture for the smooth running of the engine:

- 1. the metering (air/fuel ratio) should be kept as steady as possible and close to the stoichiometric value, to ensure rapid combustion avoiding unnecessary fuel consumption;
- 2. the mixture should be composed of petrol vapours diffused as finely and evenly as possible in the air.

As far as the optimum metering, on the other hand, is concerned, it is calculated by the control unit after the following measurements:

- exact quantity of intake air via the flow meter (air flow meter);
- engine rotation speed via the rpm sensor;
- power requested via the accelerator pedal potentiometer;
- Engine coolant temperature via the sensor on the thermostat mounting;
- measurement of the exhaust gas oxygen content via the Lambda sensor.nda lambda.

This information is processed by a micro-calculator contained in the injection/ignition electronic control unit which determines the basic injection time by means of experimentally obtained values which are stored in a special memory in the above mentioned control unit.

General description of the ignition system

The ignition system is the static advance inductive discharge type (i.e. there is no high tension distributor) with power modules located inside the electronic control unit.


The system has a single coil for each spark plug: the advantages of this solution are:

- less electrical overloading
- gurantee of constant discharge at each spark plug

The electronic control unit contains a map where the entire series of optimum advance values which the engine can use in its operating range on the basis of the engine speed and load conditions are memorized.

In the case of detonation it is possible to selectively delay the ignition in the individual cylinder, recognized by the combination of values transmitted by the detonation sensors and the timing sensor.

INJECTION/IGNITION SYSTEM FUNCTIONAL DIAGRAM



P3U02GX01

- 1. Fuel tank filler cap
- 2. Fuel tank
- 3. Electric fuel pump with filter and pressure regulator
- 4. Accelerator pedal potentiometer
- 5. Variable geometry manifold solenoid valve
- 6. Battery
- 7. Ignition switch
- 8. System relay feed
- 9. Climate control compressor
- 10. Inertia switch
- 11. ABS control unit (vehicle speed signal)
- 12. Diagnostic socket
- 13. Rev counter
- 14. Injection system failure Infocenter
- 15. Air flow meter
- 16. Butterfly casing actuator
- 17. Clutch pedal switch
- 18. Fuel manifold
- 19. Injectors
- 20. Phase transformer solenoid valve
- 21. Brake pedal switch

- 22. Ignition coils
- 23. Engine timing sensor
- 24. Air filter
- 25. Engine rpm sensor
- 26. Detonation sensors
- 27. Coolant temperature sensor
- 28. Fuel vapour solenoid valve
- 29. Charcoal filter
- 30. Engine coolant overheating warning light
- 31. Lambda sensor
- 32. Catalytic silencer
- 33. Injection/ignition control unit
- 34. Speedometer
- 35. Fuel vapour separator
- 36. Multi-purpose valve
- 37. Lancia CODE control unit
- 38. Engine coolant temperature gauge
- 39. Cruise control system
- 40. Automatic transmission

These values have been obtained experimentally, by means of a long series of practical tests carried out on prototypes at the engine test bench, to identify the advances where it is possible to achieve the best compromise between the conflicting demans of maximum power and a reduction in consumption and harmful exhaust emissions.

The optimum advances have then been stored in the system control unit memory. During the operation of the engine, the control unit is constantly informed of the (engine) speed and load conditions and on this basis it "selects" the necessary advance value from its memory for the spark to strike at the spark plug in the cylinder during the explosion stroke with the optimum advance.

In addition the control unit corrects this value on the basis of further factors such as the engine coolant temperature, intake air temperature, detonation and butterfly valve position, so that the ignition point is always optimum.

The information required by the control unit to operate the single coils is transmitted by means of electrical signals from the following sensors:

- a. **An rpm sensor** which produces an alternating single phase signal whose frequency indicates the engine rpm.
- b. **An air flow meter** with a temperature sensor which, on the basis of the quantity/temperature of the air drawn in by the engine transforms these values into electrical signals, sending them to the electronic control unit.
- c. **Two detonation sensors** which, located in the upper part of the cylinder block/crankcase one between cylinders 1 and 2 and the other between cylinders 4 and 5, allow the control unit to recognize the cylinder where detonation (or the onset of detonation) is taking place and correct the ignition advance at the spark plug for the cylinder concerned only.
- d. **An accelerator pedal potentiometer** which transforms the angular value assumed by the actual pedal into an electrical signal allowing the control unit to recognize the minimum, partial and full load conditions.

Injection/ignition system functions

In addition to electronically controlling the moment of ignition and the air flow rate at the idle rotation speed, in order to allow the smooth operation of the engineas the environmental parameters and loads applied vary, the control unit must also control and manage the injection so that the stoichiometric (air/fuel) ratio is always within the optimum value.

The electronic control unit establishes the «time» for operating the injectors using a relatively simply rule which can be summarized as follows.

Taking the physical properties of the fuel (viscosity and density) and the difference in pressure between the fuel pressure and the pressure in the inlet manifolds as constant, the quantity of fuel injected only depends on the «opening time» of the injector.

The injection/ignition system basically carries out the following functions:

- injection timing adjustment;
- ignition advance adjustment;
- check on cold starting;
- check on the enrichment during acceleration:
- fuel cut-off during overrun;
- check on engine idle speed;
- restriction of the maximum engine speed;
- check on combustion via the Lambda sensor;

- fuel vapour recovery;
- check on detonation;
- check on the phase transformer;
- check on the inlet manifold
- self-adjustment of the system;
- autodiagnosis;
- connection with engine immobilizer device (Lancia CODE);
- management of the climate control system;
- management of the radiator fans.
- check on the cruise control system (where fitted)
 - connection with the automatic transmission (where fitted)



SYSTEM MANAGEMENT STRATEGIES

Adjustment of the injection times

Digital technology has made it possible to guarantee optimum consumption and performance by means of maps, stored in the electronic control unit memory, according to the engine speed and load conditions.

The control unit oprates the injectors with great speed and precision, calculating the opening time on the basis of the engine load (rpm and air flow rate), also taking into account the battery voltage and the temperature of the engine coolant.

The injection is sequential and phased for each cylinder (the moment of injection is not simultaneous for all cylinders) and takes place at the optimum injection point.

Adjustment of the ignition advance

Thanks to a map stored in its memory, the control unit is capable of calculating the advance in accordance with the engine load (minimum, partial, full load, on the basis of the rpm and air flow rate), the intake air temperature and the engine coolant temperature.

It is possible to selectively delay the ignition at the cylinder required, recognized from the combination of values recorded by the detonation and cam angle sensors.

Check on cold starting

Under these circumstances there is a natural weakening of the mixture as a result of the poor turbulence of the particles of fuel at low temperatures and reduced evaporation and condensation on the internal walls of the inlet manifold, all of which is exacerbated by the increased viscosity of the lubricant oil.

The electronic control unit recognizes this condition and corrects the injection time according to the signal for the coolant temperature, the intake air temperature, the battery voltage and the engine speed.

The ignition advance is only subject to the engine speed and the temperature of the engine coolant. During starting the control unit implements an initial simultaneous injection for all the injectors (full-group injection) and after the recognition of the reference on the flywheel, it switches to normal se-

quential phased operation.

Check on the enrichment of the mixture during acceleration

The control unit detects the acceleration request from the signal supplied by the accelerator pedal potentiometer and, as a result, increases the injection times and alters the opening of the butterfly valve in order to reach the required number of revs rapidly.

If, following an acceleration request, the variation in the signal supplied by the air flow meter exceeds a pre-set increase, the control unit not only adjusts the injection to meet the new requirements it also increases it further for several seconds to improve the responsiveness.

Fuel cut-off

When the accelerator pedal is released and beyond a certain pre-set engine speed threshold, the injection control unit cuts off the supply to the injectors.

With no supply, the number of revs starts to decrease at a speed which depends on the vehicle driving conditions.

Before the idle speed is reached, the dynamics of the engine speed decrease are verified.

If they exceed a certain value, the fuel supply is partly reactivated on the basis of a logic which involves "the soft accompaniment of the engine idle speed".

5

Having reached this condition the normal idle functions are reactivated and the cut-off is only reactivated when the fuel cut-off threshold is exceeded to ensure that the engine runs smoothly. The levels for restoring the fuel supply and cut-off vary according to the engine temperature.

There is another fuel cut-off logic in the control unit which intervenes during partial deceleration, i.e. when the engine load conditions are lower.

The function is only activated if the new condition persists for a pre-set time and after having adapted the ignition advance angle to the new situation.

Check on engine idle speed

The control unit recognizes the "idle" condition (accelerator pedal released) from the signal supplied by the accelerator pedal potentiometer and according to the signals of the brake and clutch pedal switches and the electrical consumers being switched on (climate control and radiator fan) and operates the butterfly valve motor so that the idle speed is 700±50 rpm.

The correction of the idle also takes place through the variation of the ignition angle which has a more immediate effect.

The correct self-learning of the butterfly minimum and maximum opening positions is therefore vital for the effective control of the idle speed; it should be carried out at least once in production and each time the engine control unit or the motorized butterfly casing is replaced.

A self-adjustment function allows the adjustment of the idle to possible variations, over a period of time, in the condition of the idle management components.

Restriction of the maximum engine speed (protection outside of revs)

When the engine speed exceeds 6,800 rpm, the electronic control unit reduces the injector operating time to prevent the engine from being overloaded also protecting it outside of the revs.

If the engine speed exceeds 7,000 rpm, then the control unit activates the fuel cut-off strategy operating the injectors when the speed goes below a certain level.

Check on combustion using Lambda sensor

The Lambda sensor informs the control unit of the quantity of oxygen present in the exhaust and therefore the correct air/fuel metering by means of a two-level voltage signal corresponding to a lean mixture and a rich mixture, respectively

To obtain the ideal mixture for the operation of the three-way catalytic converter and minimize emissions, the petrol must be injected according to a pre-set (stoichiometric) ratio with the intake air, measured from the unitary value of the Lambda parameter (=1); in the case of a lean mixture it is >1, in the case of a rich mixture, on the other hand, it is <1.

The Lambda sensor, in contact with the exhaust gases, produces an electrical signal whose voltage value depends on the concentration of oxygen in the actual gases:

if the mixture is lean (>1), the sensor provides a low voltage level (<200 mV) and the control unit slightly increases the quantity of petrol injected;

if the mixture is rich (<1), the sensor provides a high voltage level (>800 mV) and the control unit reduces the quantity of petrol injected.

The closed-loop management of the Lambda sensor allows the control unit to keep the Lambda value very close to the theoretical unitary value, also assisted by appropriate self-adjustment functions.

The control unit also manages the supply of the Lambda sensor heater. In effect, on the basis of the engine load and speed, the control unit processes a forecast for the temperature of the exhaust gases and consequently controls the heater current supply, limiting it to the actual needs which depend on the engine conditions.

Copyright by Fiat Auto

Fuel vapour recovery

The (pollutant) fuel vapours are sent to an active charcoal filter and from there to the engine where they are burnt; this takes place by means of a solenoid valve which is only operated by the control unit when the engine is in a certain load condition to allow the correct combustion without the operation of the engine being "disturbed": in effect, the control unit compensates for this quantity of petrol entering with a reduction in the supply to the injectors.


Check on detonation

This function is designed to detect the presence of detonation (engine knock) by processing the signal coming from the appropriate sensors. The control unit continuously compares the signals coming from the sensors with a set value which, in turn, is constantly updated to take into account background noise and the ageing of the engine.

The control unit is thereby capable of detecting the presence of detonation, (or the onset of detonation) and reduces the ignition advance (from 3° up to a maximum of about 9°), until the phenomenon disappears. Later, the advance is gradually restored to the basic value.

In acceleration conditions, a higher level is used to take into account the increased engine noise under these circumstances. The detonation control strategy is also equipped with a self-adjustment function which memorizes the reductions in the advance which are continuously repeated in order to adjust the map to the different conditions the engine finds itself in.

Check on phase transformer



The control unit controls the phase transformer hydraulic actuator solenoid valve (fitted on the inlet side camshaft) by means of a relay.

There are two operating positions for the transformer:

- A. OFF position (power, reduced engine load and idle), corresponding to the normal camshaft fitting value;
- B. ON position (torque), corresponding to an 18° crankshaft advance of the camshaft.

The transformer, normally in the OFF position, is switched to the ON position according to the engine load and speed conditions, as illustrated in the diagram.

In any case, the ON position is only enabled if the coolant temperature is above 40°C.

- 1. Transformer in ON position
- 2. Accelerator pedal fully depressed
- 3. Maximum speed restriction

Obviously the control of the phase transformer operates with a hysteresis field, i.e. the solenoid valve activation level is always higher than the deactivation level; this is in order to avoid balance conditions and too rapid a succession of movements from one timing diagram to another with obvious operational irregularities.

Check on inlet manifold

The control unit controls the geometry of the inlet ducts to improve the quantity of air drawn in by the engine.

The control unit selects the short ducts for speeds above 4500 rpm and high loads In other engine operating conditions, the control unit selects the long duct configuration.

Engine Fuel system

10.

Self-adjustment of the system

The control unit is equipped with a self-adjustment function which has the task of recognizing the changes which take place in the engine due to the process of bedding in and the ageing of both the components and the actual engine.

These changes are memorized in the form of modifications to the basic map and are designed to adapt the operation of the system to the gradual alterations in the engine and the components compared with when they are new.

This adjustment function also makes it possible to compensate for the inevitable differences (due to production tolerances) in components which may be replaced. This makes it possible to gain maximum results from all vehicles without special adjustment and checking operations.

Autodiagnosis

The ME 3.1 injection/ignition system is also equipped with an "**autodiagnostic**" function which memorizes any faults in the sensors and actuators making their identification and correction easier. Any faults are signalled at the Infocenter.

Check on cruise control (where fitted)

According to the cruise control lever setting, the injection/ignition control unit directly operates the butterfly casing actuator to control and maintain the memorized vehicle speed.

A warning light activated by the control unit indicates whether or not the system is operating.

The injection control unit momentarily deactivates the cruise control system when the brake pedal or the

The injection control unit momentarily deactivates the cruise control system when the brake pedal or the clutch pedal is operated; by pressing the recall button the operation of the cruise control system at the last speed memorized is restored.

Connection with automatic transmission

The control unit adjusts the engine speed according to the load when the selector lever is moved to change gear.

Connection with engine immobilizer device (Lancia CODE)

To improve protection against theft attempts, the vehicle is equipped with an immobilizer system (Lancia CODE) which only allows the activation of the injection/ignition control unit through an electronic code.

Each time the key is turned to the OFF position, the Lancia CODE system completely deactivates the injection/ignition control unit.

If the ignition key is turned from OFF to ON, the following operations take place, in order:

- 1. The injection/ignition control unit sends the Lancia CODE control unit a request for the secret code in order to deactivate the immobilizer function.
- 2. The Lancia CODE control unit responds by only sending the secret code after having, in turn, received the recognition code transmitted by the ignition key which contains a special transponder.
- 3. The recognition of the secret code allows the de-activation of the immobilizer function and the injection/ignition control unit can activate the normal system management programme.

A special two-way serial line allows the exchange of data between the injection/ignition control unit and the Lancia CODE control unit.

If the Lancia CODE system is faulty the engine can still be started up via the emergency procedure.



Given the presence of the Lancia CODE system **DO NOT**, during the fault diagnosis and/or functional checks, carry out tests using another injection/ignition control unit. In such a case the Lancia CODE control unit would transfer the (unrecognized) recognition code to the test control unit which could then no longer be used on other vehicles.

Copyright by Fiat Auto 7

EngineFuel system

LANCIA K (1998) 20v (2446) 20v

10.

Management of the climate control system

The injection/ignition control unit is functionally connected to the climate control system, in that:

- 1. it receives the request to switch on the compressor from the climate control unit via pin F6 and carries out the appropriate interventions (additional air);
- 2. it gives the go ahead to switch on the compressor via pin F13, when the strategy conditions are verified;
- 3. it receives information concerning the state of the four stage pressure switch from pins F9 and F41 and carries out the appropriate interventions (operation of the radiator fan).

As far as point 1 is concerned,, if the engine is idling, the control unit increases the air flow rate passing through the motorized butterfly casing in advance of the compressor being switched on and viceversa returns the actuator to the normal delay position after the compressor is switched off.

On the other hand, as far as point 2 is concerned, the control unit automatically controls the disengagement of the compressor:

- for several seconds (timed disengagement):
 - in high engine power request conditions (strong acceleration);
 - during engine take-off;
- as long as the following critical conditions persist:
 - for engine coolant temperatures above a certain value;
 - for engine speeds above or below a certain level.

Management of the radiator fans

The control unit directly controls the operation of the radiator fans according to the temperature of the engine coolant and the engagement of the climate control system.

The fans are engaged when the temperature exceeds 98°C (1st speed) and 101°C (2nd speed). They are switched off with a hysteresis of 2°C below the temperature threshold.

AIR INTAKE CIRCUIT

The 1998 5 cylinder 20 valve version is equipped with a special system of air intake ducts. The manifold is composed of two half shells and an internal rocker element (module) which, operated by a special pneumatic actuator, can assume two positions and alter the length of the inlet ducts (variable geometry).

In this way there are five possible long (torque) ducts or five short (power) ducts.

The two different length ducts operate alternately allowing maximum volumetric efficiency at different speeds.

By selecting the length of the inlet duct appropriately the oscillations of the column of gas entering can be timed with the movement of the valve to increase the inertia effect of the gaseous mass in the cylinder.


This means that the degree of filling can be increased.

Obviously the device operates with a hystersis field, i.e. the changes from "power" duct and viceversa do not always take place at the same engine speed.

This is to avoid the possible creation of balance conditions and too rapid shifts from one length to another with obvious operational irregularities.

8

DIAGRMA SHOWING INFORMATION ENTERING/LEAVING THE INJECTION/IGNITIN SYSTEM CONTROL UNIT AND SENSORS/ACTUATORS




- 1. Electronic control unit
- 2. Four stage pressure switch
- 3. Vehicle speed signal (from ABS)
- 4. Brake and clutch pedal switches
- 5. Flow meter
- 6. Rpm sensor
- 7. Accelerator pedal potentiometer
- 8. Coolant temperature sensor
- 9. Coolant overheating warning light
- 10. Battery
- 11. Ignition switch
- 12. Detonation sensors
- 13. Timing sensor
- 14. Cruise control system
- 15. Automatic transmission
- 16. Electric fuel pump
- 17. Electric fuel pump relay
- 18. System failure signal at Infocenter

- 19. Diagnostic socket
- 20. Phase transformer solenoid valve
- 21. Fuel vapour solenoid valve
- 22. Lambda sensor
- 23. Butterfly casing actuator
- 24. Rev counter signal
- 25. Variable geometry inlet manifold solenoid valve
- 26. Injectors
- 27. Climate control compressor and radiator fan high/low speed relays control unit
- 28. Climate control system
- 29. Radiator fan
- 30. Coils
- 31. Spark plugs
- 32. Lancia CODE control unit
- 33. Water temperature gauge

P3U09GX01

DIAGRAM SHOWING FUEL SUPPLY CIRCUIT



P3U10GX01

- 1. Fuel supply manifold
- 2. Fuel supply pipe to the injectors
- 3. Fuel filler

- 4. Electric fuel pump with filter and pressure regulator
- 5. Tank
- 6. Injectors

The fuel supply system takes place by means of an electric pump immersed in the tank which draws in the fuel and sends it to the filter and then to the injectors.

The fuel system is the returnless type, i.e. there is only one pipe between the fuel tank and the engine.

This system makes it possible to:


- keep the risk of fire, in the case of an accident, to a mimimum;
- reduce fuel vapour emissions into the atmosphere.

The electric fuel pump is enclosed in a casing which also incorporates the fuel pressure regulator, the fuel gauge and the fuel filter.

The system is also fitted with an inertia switch which, if the vehicle is involved in an impact, cuts off the electric fuel pump supply.

98 range

DIAGRAM SHOWING FUEL ANTI-EVAPORATION CIRCUIT



11

- 1. Injection/ignition control unit
- 2. Charcoal filter
- 3. Fuel vapour cut out solenoid valve
- 4. Multi-purpose valve

reaching excessive levels.

- 5. Filler cap with safety and ventilation valve
- 6. Fuel vapour separator
- 7. Tank

The anti-evaporation system is designed to prevent the fuel vapours, consisting of the lightest fractions of hydrocarbons which basically form in the tank, from being discharged into the atmosphere.

The system works, above all, when the outside temperature is high, when the temperature of the fuel increases and consequently the tendency for evaporation is higher; under these circumstances there is an increase in the pressure inside the tank (7).

In particular, even when the tank (7) is full and the vehicle is stationary, the multi-purpose valves (4) remain open as they are located in a higher position than the breather pipe and therefore they allow the vapours to reach the separator (6), from where they condense and mainly return to the tank (7). If, on the other hand, the fuel is splashing around during driving or the vehicle overturns, the valves (4)

close preventing the fuel from escaping.

Then the pressure inside the tank reaches about 30-40 mbar, the multi-purpose valves (4) open and the fuel vapours reach the charcoal filter (2). The valves (4) also allow an intake of air into the tank through the charcoal filter, for example, after the level of the fuel has decreased with the consequent vacuum created inside the tank.

With the engine running, the control unit (1) operates the fuel vapour cut out solenoid valve (3), which allows the intake of vapours by the engine and the consequent washing of the charcoal filter (2). If, as a result of the malfunction of one of the components, the pressure inside the tank increases to dangerous levels, the safety valve (5), located near the cap, allows the pressure to be discharged outwards. If necessary, this valve can open in the opposite direction to ventilate the tankand prevent the vacuum

Copyright by Fiat Auto

SYSTEM FOR RECIRCULATING GASES COMING FROM THE ENGINE CRANKCASE (BLOW-BY)

The system controls the emission, from the cylinder block/crankcase, of the exhaust gases composed of air/petrol mixtures and the burnt gases which escape through the piston seals, in addition to the lubricant oil vapours and recirculates them to the inlet.

The breather gases, directed by special partitions, rise by the engine oil filler and then pass through the coils (7), under the tappet cover, where they lose part of the oil which they contain which returns to the camshafts, via the pipe (6) in the form of droplets.

The pipe (6) is an appropriate siphon shape to prevent the breather gases from escaping and only allows the recirculation of the drops of oil.


With the butterfly open, the gases comes out of the intake (5) and are sent, via the connector (4) on the air hose, upstream of the butterfly valve, to be drawn into the manifold.

With the butterfly closed, the vacuum in the inlet manifold draws in the gases through the intake (1) and, through the pipe (2) they reach the connector (3) on the inlet manifold where a PCV valve (8) (Positive Crank Ventilation) which shutters the inlet is fitted.

The PCV valve can be modulated and the quantity of gas which passes through is proportional to the vacuum in the inlet manifold.

When the butterfly valve is completely open (condition A), the vacuum inside the inlet manifold is minimal, the spring (10) is completely extended and the PCV valve allows the maximum flow of breather gases.


Conversely, with the butterfly completely closed (condition B), the vacuum inside the manifold is maximum which causes the movement of the piston (9) which shutters the section through which the breather gases flow inside the PCV valve thereby restricting the intake of actual gases into the manifold.



P31112GX0

98 range

ENGINE EXHAUST ASSEMBLY DIAGRAM



P3U13GX01

- 1. Exhaust manifold
- 2. Lambda sensor

- 3. Catalytic silencer
- 4. Silencers

The closed-loop type control of the mixture strength is activated by the Lambda sensor which measures the oxygen content of the exhaust gases upstream of the catalytic silencer.

The Lambda sensor measurements allow the electronic control unit to continuously correct the quantity of petrol injected, thereby keeping the air/fuel ratio constant.

This means that the harmful exhaust emissions are kept in check, a function completed by the three way catalytic converter (catalytic silencer).

The efficient operation of the catalytic silencer and consequently containing the toxicity of the exhaust gases, depends on the air/fuel ratio which the engine receives.

The three-way type catalytic converter makes it possible to simultaneously keep down the levels of the three pollutant gases present in the exhaust: unburnt hydrocarbons (HC), carbon monoxide (CO), nitrogen oxides (NOx).

Two types of chemical reaction take place inside the converter:

- oxidation of the CO and the HC, converted into carbon dioxide (CO2) and water (H2O);
- reduction of the NOx, converted into Nitrogen (N2).


The following would rapidly put the catalytic converter out of action and make it irreparable:

- the presence of lead in the petrol which lowers the degree of conversion to such levels that it makes the presence of the catalytic converter in the system useless;
- the presence of unburnt petol in the converter: in effect, a flow of petrol for 30s in an ambient of 800 °C (temperature inside the silencer) is sufficient to cause the catalyzer to melt and break.


It is vital for the injection/ignition system to be in perfect working order, therefore the spark plug leads should not, under any circumstances, be disconnected with the engine running and, if tests are carried out, the catalytic converter should be replaced with a suitable length of pipe.

13 Copyright by Fiat Auto

INJECTION/IGNITION SYSTEM WIRING DIAGRAM



Connection between control unit/ignition coils and injectors



Key:


- 1. Clutch pedal switch
- 2. Infocenter
- 3. Rev counter signal
- 4. Automatic transmission
- 5. Diagnostic socket
- 6. Lancia CODE control unit
- 7. Butterfly casing actuator
- 8. Vehicle speed signal (from ABS system)
- 9. Rpm and TDC sensor
- 10. Detonation sensor 1
- 11. Detonation sensor 2
- 12. Engine coolant temperature gauge
- 13. Coolant temperature sensor
- 14. Timing sensor
- 15. Brake pedal switch
- 16. Four stage pressure switch
- 17. Climate control engagement
- 18. Coolant overheating warning light
- Air conditioning compressor and radiator high/low speed fans relay control unit
- 20. Air conditioning compressor
- 21. Radiator fans
- 22. Cruise control warning light
- 23. Cruise control system
- 24. Flow meter
- 25. Ignition switch
- 26. Injection/ignition system relay feed
- 27. Variable geometry manifold solenoid valve
- 28. Timing variator solenoid valve
- 29. Fuel vapour solenoid valve
- 30. Accelerator pedal potentiometer
- 31. Battery
- 32. Electric fuel pump relay
- 33. Inertia switch
- 34. Electric fuel pump
- 35. Lambda sensor

36-40. Injectors N° 1 to 5

41-45. Ignition coils for cylinders N° 1 to 5

P3U15GX01

LOCATION OF INJECTION/IGNITION SYSTEM COMPONENTS



P3U16GX01

Key

- 1. Detonation sensors
- 2. Diagnostic socket
- 3. Injection/ignition control unit
- 4. Rpm and TDC sensor
- 5. Injectors
- 6. Coolant temperature sensor
- 7. Fuel vapour solenoid valve

- 8. Butterfly casing actuator
- 9. Phase transformer solenoid valve
- 10. Charcoal filter
- 11. Timing sensor
- 12. Single coils
- 13. Air flow meter

Engine Fuel system

10.

INJECTION - IGNITION SYSTEM COMPONENTS

The injection-ignition system consists mainly of a wiring system, an electronic control unit (I.E. control unit) and the following sensors and actuators:

Sensors

- RPM and TDC sensor
- Knock sensors
- Engine coolant temperature sensor
- Timing sensor
- Throttle position sensor (built into the throttle body acuator)
- Intake air temperature sensor
- Intake air flow and temperature sensor (debimeter)
- Lambda probe
- Potentiometer on accelerator pedal
- Brake pedal switch
- Clutch pedal switch

Actuators

- Throttle body actuator
- Variable valve timing control solenoid
- Fuel vapour cut-off solenoid
- Variable geometry manifold control solenoid
- Fuel pump (including filter and pressure regulator)
- Injectors
- Ignition coils
- Spark plugs

INJECTION - IGNITION SYSTEM WIRING

The various system components are connected by two different wiring systems.

Engine side wiring (connector M) connects components fitted to the engine to the injection control unit. The vehicle side wiring (connector F) connects the other components to the control unit and acts as an interface with other vehicle wiring systems.


The two connectors (M and F) are the same and both are 64-pin. Special insertion keys prevent wires being misconnected to the wrong control unit connectors.

ELECTRONIC INJECTION-IGNITION CONTROL UNIT

The injection-ignition electronic control unit is located in the engine bay, secured to a braket beside the intake manifold.

The control unit processes signals from the various sensors by applying software algorithms and controls the actuators accordingly (particularly the injectors and pressure regulator) to achieve the best possible engine service conditions.

The control unit is "flash E.P.R.O.M." type, i.e. it can be reprogrammed from outside without andy need to adjust the hardware.



CONNECTOR F

- 1 Excessive engine coolant temperature warning light
- 2. Cruise control light
- 3. Lancia CODE control unit
- 4. Not connected
- 5. Not connected
- Climate control system compressor activation request
- 7. Accelerator pedal potentiometer 1 activation
- 8. Accelerator pedal 1 potentiometer signal
- 9. Low radiator fan speed activation request
- Cruise control
- 11. Drive selection (automatic transmission)
- 12. Not connected
- Climate control system compressor activation control
- 14. Not connected
- 15. Power supply from battery
- 16. Power supply from relay
- 17. Not connected
- 18. Not connected
- 19. Accelerator position (automatic transmission)
- 20. Not connected
- 21. Not connected
- 22. Not connected
- 23. Not connected

CONNECTOR M

- 1 Throttle body motor (-)
- 2. Not connected
- 3. Cylinder 4 injector
- 4. Variable geometry manifold actuator
- 5. Fuel vapour cut-off solenoid
- 6. Knock sensor 2 reference earth
- 7. Not connected
- 8. Not connected
- 9. Not connected
- 10. Engine rpm sensor
- 11. Not connected
- 12. Not connected
- Not connected
- Cylinder 3 ignition coil
- 15. Cylinder 4 ignition coil
- 16. Cylinder 1 ignition coil
- 17. Throttle body motor (+)
- 18. Not connected
- 19. Cylinder 1 injector
- 20. Cylinder 3 injector
- 21. Not connected
- 22. Knock sensor 1 signal
- 23. Lambda probe signal


3N19HJ01

CONNECTOR F


- 24. Accelerator pedal potentiometer 1 earth
- 25. Accelerator pedal potentiometer 2 earth and air flow meter
- 26. Brake pedal switch for cruise control
- 27. Brake pedal switch
- 28. Gear change signal (automatic transmission)
- 29. Not connected
- 30. Electric fuel pump relay
- 31. Fuel system relay go ahead32. Supply from relay
- 33. Coolant temperature (automatic transmission)
- 34. Not connected
- 35. Rev counter signal
- 36. Not connected
- 37. Not connected
- 38. Not connected
- 39. Not connected
- 40. Accelerator pedal potentiometer 2 signal
- 41. Request to engage radiator fan high speed
- 42. Cruise control
- 43. Cruise control
- 44. Vehicle speed signal (from ABS)
- 45. Not connected
- 46. Injection system failure
- 47. Supply from ignition switch
- 48. Supply from relay
- 49. Not connected
- 50. Go ahead to engage radiator fan low speed
- 51. Not connected
- 52. Not connected
- 53. Diagnostic socket, line K
- 54. Intake air temperature signal
- 55. Not connected
- 56. Accelerator pedal potentiometer 1 supply
- 57. Intake air quantity signal
- 58. Cruise control
- 59. Clutch pedal switch
- 60. Not connected
- 61. Not connected
- 62. Go ahead to engage radiator fan high speed
- 63. Reference voltage for flow meter
- 64. Not connected

CONNECTOR M


- 24. Butterfly casing potentiometer 1 signal
- 25. Coolant temperature
- 26. Reference earth for butterfly casing potentiometers 1 and 2, coolant temperature sensor and timing sensor
- 27. Not connected
- 28. Not connected
- 29. Not connected
- 30. Not connected
- 31. Ignition coil for cylinder 5
- 32. Ignition coil for cylinder 2
- 33. Butterfly casing motor (-)
- 34. Earth for Lambda sensor
- 35. Injector for cylinder 2
- 36. Timing variator solenoid valve
- 37. Not connected
- 38. Detonation sensor 2 signal
- 39. Not connected
- 40. Buttefly casing potentiometer 2 signal
- 41. Not connected
- 42. Timing sensor signal
- 43. Not connected
- 44. Not connected
- 45. Not connected
- 46. Not connected
- 47. Not connected
- 48. Not connected
- 49. Butterfly casing motor (+)
- 50. Not connected
- 51. Reference voltage for timing sensor
- 52. Injector for cylinder 5
- 53. Not connected
- 54. Reference earth for detonation sensor 1
- 55. Reference earth for Lambda sensor
- 56. Not connected
- 57. Not connected
- 58. Supply for butterfly casing potentiometers 1 and 2
- 59. Engine rpm sensor
- 60. Not connected
- 61. Not connected
- Not connected 63. Not connected
- 64. Not connected



P3U20GX01



P3U20GX02



P3U20GX03

IGNITION COILS (0.221.504.014)

The ignition is the static advance electronic type with one coil for each spark plug (SIN-GLE-COIL); this solution eliminates the high tension circuit, improving reliability and safety and reducing the risk of interference due to high tension leads and connections.

It involves a normal coil which increases the tension of the impulse sent to the spark plugs: each individual coil, located on the cylinder head, supplies a spark plug directly without intermediary cables.

Checking coil primary winding circuit resistance

The resistance is checked by connecting an ohmmeter to the outside pins (1 and 3) of the connector:

Primary resistance: 0.73 ohm

Electrical specifications


| Primary winding | inductance | 2,5 | m | Н |
|-------------------|------------|-----|---|---|
| Primary winding | resistance | 0,7 | 3 | Ω |
| Anti-interference | resistance | 1 | Κ | O |

Electrical connections wiring diagram

- 1. Supply through ignition switch
- 2. Supply through battery
- 3. Relay
- 4. Single coil
- 5. Spark plug
- 6. Electronic control unit

Wiring connector

The numbers in the boxes, connected to pin 1, indicate the corresponding control unit pins arranged in the order of the cylinder numbers.



TIMING SENSOR (0.232.101.026)

The Bosch Motronic ME 3.1 system is a sequential, phased type, i.e. the injection of the fuel takes place in sequence for each cylinder during the inlet stroke.


To achieve this, in addition to the rpm and TDC signal, the electronic control unit also uses a timing signal to determine the point of injection.

The signal sent to the control unit is produced by a Hall effect sensor fitted by the exhaust side camshaft drive pulley.

Operating principle

A semi-conductor layer, through which the current passes, immersed in a normal magnetic field (lines of force perpendicular to the direction of the current) produces a difference in power, known as "HALL" voltage.

If the intensity of the current remains constant, the voltage produced only depends on the intensity of the magnetic field; it is sufficient therefore to simply alter the intensity of the magnetic field periodically to produce a modulated electrical signal whose frequency is proportional to the speed at which the magnetic field changes. To achieve this change a metal ring (internal part of the pulley) with an opening is made to pass through the sensor. As it moves the metal part of the ring covers the sensor blocking the magnetic field with a resulting low output signal; conversely, corresponding to the opening and the magnetic field, the sensor produces a high signal.




- 1. Deflector (pulley seal)
- 2. Magnetic material

As a result the high signal alternates with the low signal once every two engine revolutions, namely when cylinder N°1 is 78° before TDC.

This signal, together with the rpm and TDC signal, allows the control unit to recognize the cylinders and determine the point of injection. For each engine revolution the control unit checks that there is a timing signal; if this signal is missing for two consecutive revolutions, the control unit signals the failure (warning light in the instrument panel comes on) and does not allow the engine to be started up.

Wiring connector

The numbers indicate the corresponding control unit pins



P3U21GX03


Removing-refitting

This operation involves the removal of the toothed belt from the camshaft and the exhaust side camshaft toothed pulley.


Once these operations have been carried out, it is necessary to:

- disconnect the electrical connector;
- undo the fixing bolts and remove the sensor. When refitting, carry out the procedure in the reverse order, following the instructions for refitting and tensioning the toothed belt.


NOTE The sensor does not require any sort of adjustment.



- 1. Rpm sensor
- 2. Toothed pulley
- 3. Engine flywheel



P3U22GX02



RPM AND TDC SENSOR (0.261.210.160)

This sensor which measures the rpm and TDC is the inductive type, in other words it operates by varying the magnetic field produced when the teeth on a toothed pulley (flywheel) located inside the cylinder block/crankcase and fixed to the crankshaft rear counter-weight pass by. In this way the sensor is fixed to the cylinder block/crankcase and the gap and the angular position no longer need to be checked and adjusted.

The teeth which pass in front of the sensor alter the gap between the pulley and the sensor; the flow, which varies as a result, produces an alternating voltage whose frequency depends on the number of revs.

The flywheel consists of 58 teeth plus a space equivalent to the two missing teeth.

The reference defined by the space of the two missing teeth constitutes the basis for measuring the point of synchronism (TDC).

Removing-refitting

Position the vehicle on a lift then, working from the lower part of the vehicle.

- Disconnect the electrical connector:
- undo the bolt fixing the sensor and remove it from its housing.

Wiring connector

The sensor is connected to the electronic control unit (pins M10 and M59) by means of twisted cables covered by an anti-interference outer casing.

NOTE The numbers indicate the corresponding control unit pins


Checking the resistance

The sensor resistance can be measured by disconnecting the connector and connecting an ohmmeter to the sensor.

Resistance: 774-946 ohm at 20°C

98 range

10.






When measuring the distance, it is necessary to be at right angles with the flywheel and by a tooth and not a gap.



Checking the gap

The rpm and TDC sensor is fixed directly to the cylinder block/crankcase and therefore the gap and the angular position no longer need to be adjusted. If a fault is suspected, the gap can be checked, proceeding as follows:

- remove the rpm and TDC sensor;
- check that the distance between the surface of the sensor and the flywheel tooth corresponds to the sum of the length of the sensor (34.5 mm) and the gap (0.8 1.5 mm).



P3U23GX02


DETONATION SENSORS (0.261.231.095)

The detonation sensors are located in the monoblock under the inlet manifolds between cylinders 1-2 and 4-5, respectively.

These sensors have a bush to prevent inappropriate torque tightening. If they are replaced, do not place shims or washers between the cylinder block/crankcase and sensor contact surfaces.

When the engine is knocking (detonation), vibrations of a certain frequency are produced in the cylinder block/crankcase.

This phenomenon creates mechanical repercussions on a piezoelectric crystal which sends a signal to the control which, on the strength of this signal, reduces the ignition advance (from 3° up to a maximum of 9.7°) until the phenomenon disappears. Later, the advance is gradually restored to the basic value.




P3U23GX03

Wiring connector

The sensors are connected to the electronic control unit (Pins M22/M54 and M38/M6) by means of twisted cables covered by an anti-interference outer casing.

NOTE the numbers in the boxes indicate the corresponding control unit pins.




ELECTRIC FUEL PUMP (0.580.313.011)

The electric fuel pump is located inside the fuel tank housed in a casing which also incorporates:

- the fuel pressure regulator;
- the fuel gauge;
- the fuel filter.

- 1. electric fuel pump;
- 2. fuel filter;
- 3. level gauge with float;
- 4. diaphragm pressure regulator;
- 5. gauze pre-filter;



The electric fuel pump has a permanent magnet electric motor (1) which drives the pump (2) impeller and a support cover (3) which contains the electrical and hydraulic connections

The electric pump is the single stage peripheral flow type giving high performance in low voltage and temperature conditions.

The advantages compared with electric pumps which operate on the volumetric principle are as follows:

- lighter:
- smaller

FUEL SUPPLY MANIFOLD

The fuel manifold is fixed to the inside of the inlet manifold and its task is to send the fuel to the injectors. The fuel manifold is produced by aluminium die-casting and incorporates the seats for the injectors. The fuel intake takes place through the fixing of a conical seal bolt.


INJECTORS (0.280.155.770)

The twin jet type injectors are fitted on the inlet manifolds, immediately before the inlet valves. These injectors are specific for engines with 4 valves per cylinder, making it possible to direct the jets towards the two inlet valves.

The jets of fuel which come out of the injectors at a pressure of 3 bar are instantly atomized forming two cones of about 10° each.

The operation of the injectors is the «sequential phased» type, i.e. the five injectors are operated in accordance with the engine cylinder intake sequence, whilst the supply can already start for each cylinder during the expansion stroke up to when the inlet stroke has already begun.

The injectors are fixed by the fuel manifold which presses them into their housings in the inlet manifolds. In addition, they are secured to the fuel manifold by means of «safety clips». Two rubber seals (10) and (11) ensure the seal on the inlet manifold and the fuel manifold.




- 1. Injector body
- 2. Needle
- 3. Magnetic core
- 4. Coil spring

- 5. Winding
- 6. Injector nose
- 7. Adjustable spring
- 8. Fuel filter

- P3U25GX01
- Electrical connection socket
 Fuel seal
- 11. Vacuum seal

Wiring connector

NOTE The numbers indicate the corresponding control unit pins arranged in the order of the cylinder numbers.




P3U25GX02


Checking the resistance

The injector resistance can be measured by disconnecting the connector and connecting an ohmmeter as shown in the diagram.


Resistance value 16.2 ohm



P3U25GX03



P3U26GX01



P3U26GX02



The position of the accelerator pedal is transformed into an electrical voltage signal and is sent to the injection control unit from the potentiometer connected to the pedal.


The accelerator pedal position signal is then processed, together with the information relating to the number of revs, in order to determine the injection timing and pressure.

The sensor consists of a casing (1) fixed to the pedals assembly by means of a flange, which contains a shaft (2), in an axial position, connected to the two potentiometers (3): one main one and one safety one.

There is one coil spring on the shaft which guarantees the correct resistance to pressure, whilst a second spring ensures the return.

WIRING CONNECTOR

The numbers indicate the corresponding control unit pins



P3U26GX03

BRAKE PEDAL SWITCH

There is a switch (1) on brake pedal which operates the brake lights; this switch also sends a signal to pin F27 of the injection control unit.


The "brake pedal pressed" signal is used by the control unit to:

- understand that there is a deceleration situation:
- check the plausibility of the signal coming from the accelerator potentiometer.

CLUTCH PEDAL SWITCH

There is a switch (2) on the clutch pedal connected to pin F59 of the injection control unit.

The "clutch pedal operated" signal is used by the injection control unit to distinguish between gear engaged and gear change conditions.



AIR FLOW METER (0.281.002.199)

The flow meter is on the air inlet hose and is the hot film type.

The flow meter contains the intake air temperature sensor.


The operation is based on a heated diaphragm located in a measuring duct through which the intake air entering the engine flows.

The hot film diaphragm is kept at a constant temperature (about 120 °C above the temperature of the intake air) by the heating resistance.

The mass of air passing through the measuring duct tends to remove heat from the diaphragm therefore, in order to keep the latter at a constant temperature, a certain current must pass through the resistance. This current, being proportional to the mass of air flowing to the engine, is measured by a suitable Wheatstone bridge and the signal obtained is sent to the injection control unit.

- 1. Covers
- 2. Electronic card
- 3. Sensor
- 4. Support plate
- 5. Support
- 6. Seal (O-Ring)
- 7. Temperature sensor

NOTA Questo debimetro misura direttamente la massa d'aria (e non il volume) eliminando così i problemi di temperatura, altitudine, pressione ecc.



Descrizione del funzionamento

The Wheatstone bridge (made of resistors R1,R2,R3,R4) is balanced when R3 is about 120 °C higher than the temperature of the air.

The air that passes through the diaphragm removes heat from R3, therefore the bridge is unbalanced.

This situation is detected by the circuit at IC1 which

This situation is detected by the circuit at IC1 which operates the transistor T1, in a manner proportional to the bridge imbalance and the transistor causes more current to pass through Rh to heat R3 and restore the equilibrium of the bridge.


Circuit IC2 measures the current passing through Rh.

This current makes it possible to maintain the equilibrium of the bridge and is therefore proportional to the mass of air passing through the air flow meter.

1. Air temperature signal

- 2. Battery voltage
- 3. Earth

- 4. Reference voltage (5V)
- 5. Air flow rate signal



Wiring connector

The numbers indicate the corresponding control unit pins.

P3U28GX02

BUTTERFLY CASING ACTUATOR

The actuator is fixed to the inlet chamber and regulates the quantity of air drawn in by the engine.


Depending on the signal coming from the accelerator pedal potentiometer, the injection control unit controls the opening of the butterfly through a direct current motor integrated in the butterfly casing actuator.

The butterfly casing actuator is equipped with two integrated potentiometers connected in parallel so that one controls the other and viceversa.

If there is a fault with the two potentiometers or there is no supply, the control unit reduces the engine torque, according to the position of the accelerator pedal.


If the butterfly casing actuator or the injection control unit is replaced, the following "self-learning" procedure must be carried out:

- Place the ignition key in the ON position and keep it in this position for 30 secs.
- Turn the ignition key to the OFF position for 5 secs.
- Return the key to the ON position and start up the engine.




Wiring connector

The numbers indicate the corresponding control unit pins.



P3U29GX01

- 1. Connecting cable
- 2. Protective sleeve
- 3. Sensor element
- 4. Ceramic support pipe
- 5. Sensor housing
- 6. Ceramic seal
- 7. Protective pipe



P3U29GX02

- a. Rich mixture (shortage of air)
- b. Lean mixture (excess air)

1 2 3 4 M55 +12V M34

LAMBDA SENSOR

The Lambda sensor is the "planar" type, fitted on the front section of exhaust pipe and informs the injection control unit of the progress of the combustion (stoichiometric ratio).

To obtain an optimum mixture the quantity of air drawn in by the engine must be equal to the theoretical amount required to burn the entire amount of fuel injected.

In this case the Lambda factor (I) ratio between the quantity of intake air and the quantity of theoretical air (required to burn all the fuel injected) is equal to 1.

Therefore:

 λ =1 ideal mixture

 $\lambda > 1$ lean mixture

 λ <1 rich mixture

The Lambda sensor, in contact with the exhaust gases, produces an electrical signal, whose voltage value depends on the concentration of oxygen present in the actual gases.

This voltage varies sharply when the composition of the mixture shifts away from the value $\xi\gamma\alpha$

The heating of the Lambda sensor is managed by the injection control unit in a manner proportional to the temperature of the exhaust gases.

This avoids thermal shocks to the ceramic casing due to the contact of the condensation water present in the exhaust gases when the engine is cold.

The measuring cell and the heater are integrated in the "planar" (stratified) ceramic element with the advantage that the cell heats up rapidly allowing a closed-loop check within a few seconds of the engine being started up.

Wiring connector

The numbers indicate the corresponding control unit pins.

Engine


Fuel system




10.



The Lambda sensor can be rapidly put out of action by the presence of even slight amounts of lead in the fuel.





The resistance of the heater and the sensor can be measured by disconnecting the connector and connecting an ohmmeter as shown in the diagram.

Resistance = 500-1000 ohm at 20°C

PHASE TRANSFORMER

In order to achieve a good compromise between high performance in terms of power at high speeds and good torque at low speeds, a phase transformer (electronically controlled and hydraulically operated) has been adopted for the inlet camshaft.

This device makes it possible to vary the timing diagram (inlet stroke) according to the engine load conditions; this parameter is processed by the MOTRONIC control unit on the basis of the electrical signals received by the air flow meter and the rpm sensor and is sent as a command to the phase transformer solenoid.

The construction of the device involves a main assembly on the inlet camshaft which is designed to alter the angular position of the shaft in relation to the drive pulley.

There is also a valve, operated by a solenoid, both of which are found on the inlet manifold and are hydraulically connected to the main assembly by means of suitable ducts.

The operating principle is as follows:

- with the temperature of the coolant below 40 °C and when the engine is idling or the speed exceeds 4800 rpm, the solenoid (1) is de-energized, therefore the valve body (2), thrust by the opposing spring (3), remains raised not allowing the oil, arriving from the duct (A), to reach the transformer. In this case, the inlet valve timing remains unaltered.

With the coolant temperature above 40 °C and the engine speed above idling and below 4800 rpm with the butterfly angle greater than about 8°, the solenoid (1) is energized, thereby pushing the valve body (2) downwards. In this position the oil, coming from the duct (A), enters the piston chamber (B) and from there, via a special port, reaches duct (C) inside the latter.



10

The oil can only flow out of the above mentioned duct through the upper port (in contact with duct (D) supplying oil to the transformed pecause, as the valve body (2) is lowered, the lower port is not in contact with the drainage duct (E).

The oil reaches chamber (G), through ducts (D) and (F), moving the piston (4) axially towards the engine; as this piston has helical teeth on the outside, as a result of this axial movement, it is forced to rotate in a clockwise direction (as seen from the timing side).

Its rotation is transmitted, by means of a straight toothed splined profile, to the pinion (5) which, bolted onto the threaded end of the camshaft (6), transmits the rotation to the shaft, thereby altering the inlet valve timing by an advance of 9°.

When the solenoid is de-energized, the valve body (2) returns to the original position, interrupting the flow of oil under pressure to the chamber (G), but allowing the return of the oil to the drainage, thanks to the thrust of the opposing spring (7).

An additional duct guarantees the lubrication of the camshaft bearing even when the device is not activated.


The oil which reaches chamber (H) of the solenoid as a result of seepage, is discharged via the drainage duct (E).

Recovery

If the solenoid valve is faulty, the control unit final stage (driver) is deactivated.

Copyright by Fiat Auto


Phase transformer operating diagram




P3U32GX01

- 1. Solenoid valve
- 2. Valve body
- 3. Valve body spring
- 4. Piston
- 5. Pinion
- 6. Camshaft element

- 7. Piston spring
- 8. Battery
- 9. Injection/ignition system relay
- 10. Injection/ignition control unit
- 11. Ignition switch





INJECTION NTC

NTC STRUMENTO

Ω


512÷602 184÷208

 $76 \div 88$

| °C | Ω | °C | Ω | °C |
|---|---|---|--|-----------------|
| -20 -10 0 10 20 25 30 | 15970 9620 5975 3816 2500 2044 1679 | 40 50 60 70 80 90 100 | 1150 807 576 418 309 231 176 | 60 90 120 |

Wiring connector

The numbers indicate the respective control unit pins.



P3U33GX03

COOLANT TEMPERATURE SENSOR

This sensor is fitted on the themostat casing; it consists of a brass casing which affords protection for the actual resistive elements comprising two NTC (Negative Temperature Coefficient) thermistors, whose electrical resistance decreases as the temperature increases.

The two NTC sensors are distinct and provide information concerning the temperature for the special indicator in the instrument panel and for the injection/ignition control unit.

The reference voltage for the NTC element for the injection system is 5 Volt; since the control unit inlet circuit is designed as a voltage divider, this voltage is shared between a resistance in the control unit and NTC resistance for the sensor. As a result, the control unit is capable of making evaluations through the changes in voltage and thereby gaining information concerning the temperature.

- 1. NTC for injection system
- 2. NTC for indicator in the instrument panel

Recovery

The last value measured is used or, if the temperature of the intake air is above a certain value, then the fixed value of 80 °C is used.

The self-adjustment of the mixture strength is inhibited.

The radiator fan is activated.

The self-adjustment of the idle is inhibited.

Checking the resistance

The table at the side contains the resistance values which the NTC elements can assume according to the temperature. These figures can be measured by disconnecting the connector and connecting an ohmmeter to the sensor pins.

Removing-refitting


Disconnect the electrical connection and remove the sensor.



Tightening torque 2.2 da Nm.

Copyright by Fiat Auto

^{*} Connection to the coolant temperature gauge in the instrument panel.



INERTIA SAFETY SWITCH

In order to improve the safety of the occupants of the vehicle in the case of impacts the vehicle is equipped with an inertia switch located inside the passenger compartment, under the driver's seat on the right hand side.


This sensor reduces the risk of fire (as a result of fuel escaping) by de-activating the electric pump supplying the injection circuit.

The inertia switch consists of a steel ball in a (conical shaped) housing which is kept in place by the attraction force of a permanent magnet. If the vehicle is invovled in a violent crash, the ball is released from the magnetic clip and opens the normally closed (NC) electrical circuit, interrupting the connection to earth of the electric pump and consequently the supply to the injection system.

To restore the connection to earth for the electric pump, the seat has to be moved backwards and the switch pressed until a click is heard.



Even after an apparently slight impact, if there is a smell of fuel or leaks are noticed from the fuel system, do not turn the inertia switch back on, but first search for the cause of the problem and correct it to prevent the risk of fire.



P3U34GX01

Inertia switch components

- 1. Complete inertia sensor
- 2. Outer casing
- 3. Button
- 4. Upper side
- 5. Engagement side
- 6. Permanent magnet
- 7. Permanent magnet housing
- 8. Steel ball
- C. Common terminal
- N.C. Normally closed contact
- N.A. Normally open contact

Multi-purpose valve

This valve is used to carry out different functions, namely:


- to prevent the flow of liquid fuel if the tank is too full or in the case of an accident where the vehicle
- to allow the breathing of petrol vapours to the active charcoal filter;
- to allow the ventilation of the tank if there is a vacuum inside it.

The valve consists of a float casing (2), a heavy ball (3), a plate (4) thrust against the valve body (5) and a shim (8) thrust against the plate (4) by a spring (9). The operation of the multi-purpose valve can be summarized in the following cases, depending on how full the fuel tank is:


a. if the tank is full, the float (2) shutters the port (1) preventing the liquid fuel from reaching the active


charcoal filter preventing it from being damaged;

b. if the level of the fuel in the tank decreases, the float (2) moves down and rests on the ball (3) opening the port (1); when the pressure exerted by the petrol vapours on the plate (4) exceeds the spring (5) loading, a ring section opens between the actual plate and the valve body, which allows the petrol vapours to come out of the duct (6) and reach the active charcoal filter.




- c. if the level of the fuel in the tank decreases to such an extent that a vacuum is created inside the tank, this acts on the shim (8) and, overcoming the spring (9) loading, recalls it downwards allowing the ventilation of the tank through the port (7);
- d. if the vehicle overturns, irrrespective of how full the tank is, the ball (3), weighing down on the float (2), pushes it against the port (1) preventing the dangerous flow of petrol to the inlet manifold and the consequent risk of fire.









P3U36GX02

- 1. Pipe connecting the fuel vapour separator to the active charcoal filter
- 2. Multi-purpose valve
- 3. Fuel vapour separator
- 4. Pipe connecting the vapour separator to the fuel tank

Safety and ventilation valve

This valve is located in the fuel filler cap and, depending on the pressure in tank, performs the following functions:

- discharging the excess pressure which forms inside the tank outwards (safety function); the pressure acts on the plate (2) and, overcoming the spring (1) loading, allows the excess vapours to be discharged outwards.
- allowing the flow of outside air into the tank when, as a result of fuel consumption, the vacuum which forms inside the tank is excessive (ventilation function). In this case, when the vacuum exceeds the spring (4) loading, it moves the valve (3) allowing the intake of air.

Fuel vapour separator (expansion tank)


The fuel vapours coming from the tank reach the vapour separator (3), located to the side of the fuel filler, through the pipe (4).

Some of the vapours condense and return to the tank via the same pipe (4), whilst the remaining vapours leave the separator through the multi-purpose valve (2) and are directed to the active charcoal filter via the pipe (1).


CHARCOAL FILTER AND FUEL VAPOUR CUT OUT SOLENOID VALVE

Questi componenti fanno parte del sistema antievaporazione e recupero vapori carburante. Il filtro a carboni è ubicato nel vano passaruota destro e per accedervi è necessario rimuovere la parte anteriore del rivestimento del vano passaruota anteriore destro.

L'elettrovalvola inetrcettatrice è posta nel vano motore sotto il collettore di aspirazione.



P3U37GX01



P3U37GX02

- 1. Inlet connector
- 2. One-way valve
- 3. Spring
- 4. Shutter
- 5. Outlet port
- 6. Solenoid valve
- 7. Outlet connector

Filtro a carboni

È costituito da granuli di carbone (4) che trattengono i vapori di benzina che entrano dalla presa (5).

L'aria di lavaggio che entra dalla presa (1), attraverso il filtro di carta (3), lambisce i granuli di carbone asportando i vapori di benzina per convogliarli verso l'uscita (2) e da questa verso la valvola intercettatrice.

L'aria, entrata dalla presa (5), può anche essere richiamata dalla depressione nel serbatoio provvedendo alla ventilazione dello stesso. La divisione (6) assicura che l'aria di lavaggio aspirata lambisca tutti i granuli di carbone favorendo ilrilascio dei vapori di benzina verso il collettore di aspirazione.

Sono inoltre presenti due molle (7) che consentono una dilatazione della massa dei granuli quando la pressione aumenta.

Vapour cut out solenoid valve (0.280.142.340)


The function of this valve is to control the quantity of petrol vapours drawn in by the active charcoal filter and directed to the inlet manifold which is done by the electronic control unit. If this valve is not supplied, it is in the open position; when the ignition is switched ON, it closes preparing for operation. In effect, if energized, the solenoid valve (6) attracts the shutter (4) which, overcoming the spring (3) loading, closes the port (5) preventing the flow of petrol

The operation is controlled from the electronic control unit in the following way:

- during starting the solenoid valve remains closed, preventing the petrol vapours from excessively enriching the mixture;
- with the engine started up, the electronic control unit sends the solenoid valve a signal which modulates the opening.

In this way the control unit controls the quantity of petrol vapours sent to the inlet, preventing considerable variations in the mixture strength (especially during idling).


NOTE The solenoid valve must be fitted in the corrct position: the arrow on the casing should be pointing towards the vacuum intake on the inlet manifold.



Checking the resistance

The resistance of the solenoid valve can be measured by disconnecting the connector and connecting an ohmmeter as shown in the diagram.

Resistance: 17.5-23.5 ohm at 20 °C



Wiring connector

NOTE The numbers indicate the corresponding control unit pins

CHECKS - ADJUSTMENTS AND REPAIR OPERATIONS ON THE BOSCH MOTRONIC ME 3.1 INJECTION/IGNITION SYSTEM IN ADDITION TO THE FAULT DIAGNOSIS



WHEN WORKING ON A VEHICLE EQUIPPED WITH A MOTRONIC INJECTION/IGNITION SYSTEM THE FOLLOWING PRECAUTIONS MUST BE OBSERVED:

- do not start up the engine when the electrical connections are not properly connected or slack at the battery terminals;
- do not use a rapid battery charger to start up the engine;
- never disconnect the battery with the engine running;
- when recharging the battery, disconnect it first from the network;
- if the vehicle is going in a drying oven after painting, at temperatures in excess of 80 °C, the injection/ignition electronic control unit must be removed;
- do not connect or disconnect the electronic control unit multiple connector with the ignition switch in the ON position;
- always disconnect the negative battery lead before carrying out electrical welding on the vehicle.

It should be remembered that this system has a memory which is permanently supplied (stand-by memory) where the self-adjustment values are stored. If the settlery is disconnected then this information is lost and can only be acquired again after a certain length of time so this operation should be carried out as infrequently as possible.

CHECKING ENGINE IDLE SPEED

If the engine idle speed is not 750 ± 50 rpm and the injection-ignition control unit is the self-adjusting type then it is not possible to carry out an adjustment, therefore it is necessary to check that the accelerator linkage is correctly adjusted and the fault should be looked by carrying out a complete fault diagnosis using the Examiner/SDC

CHECKING CONCENTRATION OF POLLUTANT EMISSIONS


Through the self-adjustment of the system, the Motronic ME 3.1 system ensures a continuous check on the idle speed and the CO percentage thereby making any other external adjustment operation superfluous (there are no longer any adjustment screws). However, a check on the contents of the exhaust gases downstream of the catalyzer can provide precious information concerning the injection/ignition system operating conditions, the engine parameters or the catalyzer.

Checking the exhaust concentration of CO and HC


The exhaust concentration of carbon monoxide (CO) and unburnt hydrocarbons (HC) is measured by inserting a suitably calibrated CO tester probe at least 30 cm into the end of the exhaust pipe as shown in the diagram.

If the shape of the end section of the exhaust pipe does not allow the sensor to be fully introduced then a special extension pipe must be added which guarantees the seal in the join area.


- 1. Check that the idle CO and HC concentrations are correct.
- 2. If the value of the HCs differs from the recommended limit, proceed with tuning the engine checking the following in particular: the ignition advance angle the valve clearances the valve gear timing the engine compression. If the engine parameters are correct then the cause of the problem should be sought in the decreased efficiency of the catalyzer.




P3U40GX01








P3U21GJ03




P3U21GJ04




P3U21GJ02


REMOVING - REFITTING ACCELERATOR PEDAL POTENTIOMETER


- Disable the alarm (if fitted) housed in the luggage compartment, right side and disconnect the negative battery lead.
- 1. Undo the two buttons and the fixing nut and remove the floor carpet on the driver's side.
- 2. Undo the fixing bolts and remove the protection for the fuse box.
- 3. Disconnect the electrical connection for the pedals courtesy light.
- 4. Cut the band and remove the plastic shield for the clutch pump.
- 5. Undo the outlet connector for the clutch pump taking care to ensure that no fluid escapes.



P3U21GJ05











- 1. Remove the band and remove the clutch pump fluid inlet pipe.
- 2. Remove the seal and remove the pin which connects the clutch pump to the pedal.
- 3. Undo the fixing nuts and remove the clutch pump.
- 4. Undo the bolts fixing the pedals assembly to the brake servo.
- 5. Disconnect the electrical connector for the accelerator potentiometer.







P3U22GJ05

LANCIA K 1998 20v 2446 20v


10.







P3U23GJ02



P3U23GJ03



- 1. Remove the pedals assembly from the mounting bracket and disconnect the electrical connector for the brake pedal switch and the clutch pedal switch.
- 2. At the bench, remove the potentiometer idler rod.
- 3. Undo the fixing bolts and remove the accelerator potentiometer.

Refitting


Fit the potentiometer in its housing, tighten the fixing bolts (1) and connect the linkage.

Rest the assembly on a reference plane as illustrated in the diagram and measure 208.4 millimetres from the plane to the rivet connecting the pedal to the lever.


With the pedal in this position, tighten the fixing bolts (1) for the accelerator potentiometer. Refit the pedals assembly reversing the order of the operations carried out for the removal.



Bleed the system



ADJUSTING ACCELERATOR PEDAL END OF TRAVEL



Connect the diagnostic equipment to the socket inside the vehicle.

With the pedal in the end of travel position, check that the voltage readings on the instrument correspond to the figures in the table.


Accelerator position in minimum position

| V | V% | |
|-----------|--------|--|
| 0,5 ± 0,1 | 10 ± 2 | |

Accelerator position in maximum position

| V | V% |
|----------------------|-------------------|
| 4,4 ⁺ 0,2 | 88 ^{+ 4} |
| - 0,1 | - 2 |

The voltage figures are only valid with a supply voltage of 5V; as this voltage varies, the percentage readings on the diagnostic equipment must be considered.



celerator in the maximum position, regulate the adjustment device and repeat the procedure using the diagnostic equipment.

1. To correct the voltage values with the ac-

P3U24GJ01

EngineFuel system

LANCIA K 1998 | 20v 20v 98 range

10.

DIAGNOSTICS

The complete fault diagnosis of the system can be carried out by means of an active dialogue with the diagnostic equipment (Examiner SDC).

If a fault is detected with the sensors, the electronic control unit replaces the information coming from the faulty sensor with pre-memorized (recovery) information to allow the engine to run. The detection of a fault involves it being permanently memorized and the sensor excluded from the system until the signal is once again compatible.

The same procedure is applied if the fault invovles an actuator or control flap. The detection of a fault and the replacement with recovery data means that the fault is signalled by the special warning light in the instrument panel coming on.

The following parameters can, in the case of a fault, be managed by the control unit: flow meter, idle adjustment actuator, coolant temperature sensor, butterfly valve position sensor, Lambda sensor, air temperature sensor, battery voltage and detonation sensors. In the case of faults with the control unit, the timing sensor or the injectors, the system does not identify the fault and the vehicle breaks down. Irregularities can be read, by an operator, on the control unit using the Fiat/Lancia Tester.

Detecting faults

This is carried out during the basic function which manages the sensor/actuator.

Memorizing the error and the structure of the errors memory

The errors are memorized in the control unit in the order in which they arrive in the RAMs. The location and the type of error is recorded for each of them and 2 environmental conditions (specific for each type of fault) measured the moment the fault is detected plus a frequency counter.

Classification of the defect

If a defect is recognized for the first time and the error state persists for a time t > 0.5s, then the defect is memorized as "permanent". If this defect later disappears, it is memorized as "intermittent" and "not present". If it then reappears, it remains memorized as "intermittent", but becomes "present".

The classification of a fault as "permanent" activates the recovery function; when the fault disappears the normal reading or implementation function is restored.

Several types of fault are classified as "important", i.e. significant in terms of pollution control regulations. The presence of these faults is signalled by the warning light in the instrument panel coming on.

Frequency counter

Each error is allocated a frequency counter, which is used to determine the moment a fault which is no longer present was recorded. The first time a fault is detected the counter is set at 10. If the fault disappears then the counter remains at the current value. If it reappears then it is increased by 1 (with a maximum upper limit of 50).

The counter is decreased is time the vehicle is started up and the fault has not reappeared. If the counter reaches zero, then the fault is automatically cancelled from the memory.

If after the counter has decreased the fault should reappear the counter is returned to a value of 10 (if it is at a figure of more than 10 then it is not altered).

Signalling a fault

The failure warning light comes on when there is a defect memorized as "present" and "important". The delay time between the detection of the fault and the warning light coming on is 0.1 seconds; the delay time between the disappearance of the fault from the memory and the warning light going out is 4 seconds.

The warning light comes on each time the ignition key is turned to the ON position. If there are "important" faults already present, then the warning light goes out after 4 seconds.

Cancelling the error

When the frequency counter reaches 0, the fault is and the associated parameters are cancelled.

The immediate cancellation of the entire errors memory occurs in the following cases:

- by means of the "cancel errors memory" command sent by the tester;
- by interrupting the electronic control unit supply (disconnecting the battery or the control unit connector).

Fault diagnosis with Examiner/SDC

The exchange of data between the injection/ignition control unit and the diagnostic equipment (Examiner/SDC) takes place by means of a two-way serial line (line K) using the standard Bosch communication protocol.

The diagnostic equipment can provide the following information:

- display of the errors;
- display of the engine parameters;
- active diagnosis

List of errors

| Description | Nature of the errors |
|------------------------------|---|
| Rpm sensor | Loss of signals |
| Butterfly potentiometer | C.C. |
| Air temperature sensor | C.C. |
| Coolant temperature sensor | C.A-C.C. |
| Battery | Supply> 16.01V. |
| | Supply < 10V. |
| Lambda sensor | C.A-C.C Incorrect CO value |
| Injector | C.C |
| Idle speed actuator | C.C. |
| Petrol vapour solenoid valve | C.C. |
| Relays actuators | C.C. |
| Control unit | Faults in the operation of the microprocessor or the control unit memories are signalled. |
| Flow meter | C.C. |
| Timing sensor | Signal absent or not plausible |
| Detonation sensor | Signal absent or not plausible |
| Vehicle speed signal | Signal absent or not plausible |
| Phase transformer | C.C. |
| Electric fuel pump | C.C. |
| Lancia CODE | Code not recognized or not received |

Copyright by Fiat Auto 45

EngineFuel system



10.

Parameters displayed

Engine rpm
Injection time
Advance
Intake air temperature
Coolant temperature
Butterfly valve opening angle
Battery voltage
Lambda sensor
Self-adjustment
Flow meter
Engine knock (detonation)
Vehicle speed
Petrol vapour cut out solenoid valve
Lancia CODE
Mileage covered

Active diagnosis

The following active tests can be carried out using the diagnostic equipment:

- Phase transformer
- Injector
- Failure warning light
- Petrol vapour solenoid valve
- Air conditioning
- Idle speed actuator
- Cancelling errors.

Recovery

If the sensors are faulty, the control unit replaces the value sent by the sensor with a Recovery value which, according to the different faults is either stored in the control unit memory or specially constructed using other available information in order to allow the vehicle to reach a service centre.

This value is also transmitted to the diagnostic equipment, therefore, during the fault diagnosis it is worth bearing in mind that if there are problems the error for the sensor concerned will be signalled and the Recovery value will appear on the display.

Permanent memory

The control unit has a «permanent» type memory (EEPROM), in other words it keeps a record of the error even in the cause of the problem has disppeared and the ignition has been switched OFF; it also has a «volatile» type memory (RAM) which, on the other hand, loses the information concerning the error as soon as the cause disppears.

This also makes it possible to identify errors of an occasional nature more efficiently.

Before ending the fault diagnosis, the contents of the «permanent» memory must be cancelled using the Examiner/SDC in Active diagnosis.


If this is not the case, when the diagnostic equipment is reconnected the errors already examined will be signalled.

The contents of the «permanent" errors memory can be cancelled in the following ways:

- 1 Using the Examiner/SDC in active diagnosis.
- 2 If the cause of the error is no longer present and the engine has been started up 5 times (running for at least 20 minutes) with an interval of at least 2 minutes between each time the engine is started up.



Disconnecting the control unit from the system, even for very long periods, does not cancel the contents of the «permanent» memory.



| page | | , p | age |
|--|------|--|------|
| BOSCH ME 2.1 INTEGRATED INJECTION/IGNITION SYSTEM | 1 | FUEL SUPPLY CIRCUIT | 31 |
| - BOSCH ME 2.1 Injection/ignition | | - Fuel circuit diagram | 31 |
| system functional diagram | 2 | - Fuel drip tray assembly | 32 |
| - Location of BOSCH ME 2.1 injec- | | - Fuel manifold | 33 |
| tion/ignition system components in | | - Injectors | 33 |
| the engine compartment | 3 | - Inertia safety switch | 34 |
| SYSTEM MANAGEMENT | | | |
| STRATEGIES | 4 | EMISSION CONTROL DEVICES | 35 |
| - Operating principle | 4 | - Exhaust system diagram | 35 |
| - Management of signals | 5 | - Lambda sensor | 36 |
| - Injection management | 6 | - Catalytic silencer | 37 |
| - Ignition management | 8 . | Anti-evaporation circuit diagram | 38 |
| - Motorized butterfly casing operation | 9 | - Anti-evaporation system | 20 |
| - Management of engine idle speed | 9 | components | 38 |
| - Active charcoal filter valve | 9 | - System for recirculating gases com- | 41 |
| - Self-adjustment | 10 | ing from the crankcase (blow-by) | 41 |
| - Management of anti-theft function | | | |
| (Lancia CODE) | 10 | CHECKS, ADJUSTMENTS AND RE- | |
| - Complementary functions | 11 | PAIR OPERATIONS TO THE BOSCH | |
| - Diagnostics | 13 | ME 2.1 SYSTEM | 42 |
| ELECTRICAL/ELECTRONIC | | - Checking the emission | |
| CIRCUIT | 13 | concentration | 42 |
| | | - Checking the engine idle speed | 43 |
| - Engine control unit | 13 ' | - Engine control unit | 44 |
| - BOSCH ME 2.1 system wiring | | - Carrying out the self-learning proce- | |
| diagram | 16 | dure for the engine control unit | 44 |
| - Diagram showing information arriv- | | - Air flow meter | 45 |
| ing at/leaving the BOSCH ME 2.1 | | - Butterfly casing integrated with D.V.L. | . 45 |
| injection/ignition system control | 19 | - Coolant temperature sensor | 46 |
| unit and sensors/actuators | 10 | - Fuel manifold complete with | |
| BOSCH ME 2.1 system control unit pin out | 20 | injectors | 46 |
| - Engine rpm and TDC sensor | 22 | Engine speed sensor | 47 |
| - Engine timing sensor | 23 | - Lambda sensor | 48 |
| - Coolant temperature sensor | 24 | - Catalytic silencer | 49 |
| - Accelerator pedal potentiometer | 25 | Engine timing sensor | 49 |
| - Brake pedal switch | | Left cylinder head ignition coils | 49 |
| - Clutch pedal switch | 25 | Right cylinder head ignition coils | 50 |
| - Ignition coils | 26 | - Multi-purpose valve | 51 |
| - Detonation sensor | 27 | - Active charcoal filter | 52 |
| | | - Active charcoal filter valve | 52 |
| INLET CIRCUIT | 28 | | |
| - Inlet circuit diagram | 28 | | |
| - Air flow meter | 29 | | |
| - Butterfly casing actuator | 30 | | |

COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.



1

BOSCH ME 2.1 INTEGRATED INJECTION/IGNITION SYSTEM

Introduction

The BOSCH ME 2.1 system fitted on the 3000 V6 - 24v engine belongs to the category of systems which integrate a static advance, digital, electronic ignition system with a phased, multiple, intermittent type indirect electronic fuel injection system.

The system can be divided into the following sub-systems;

ELECTRICAL/ELECTRONIC CIRCUIT INLET CIRCUIT FUEL SUPPLY CIRCUIT EMISSION CONTROL DEVICES

The system is capable of acquiring the following parameters:

- the engine rotation speed;
- the correct sequence for TDC in the cylinder explosion stroke (injection timing);
- the intake air flow rate and temperature;
- the accelerator pedal position;
- the temperature of the engine coolant;
- the effective mixture strength;
- the presence of any detonation;
- the speed of the vehicle;
- the possible operation of the brake or clutch pedals;
- the battery voltage;
- the possible switching on of the air conditioning;
- the signals coming from the other control systems connected (via the CAN line).

This information, if it is in analogue form, is converted into digital signals by the analogue/digital converters (A/D) to allow it them to be used by the control unit.

The management programme (software) inside the control unit memory consists of a series of strategies, each of which manages a precise system control function.


By using the information (input) listed previously, each strategy processes a series of parameters based on maps of data stored in special areas of the control unit memory and then controls the system actuators (output) which consist of devices which allow the operation of the engine, namely:

- injectors;
- ignition coils;
- relays;
- implementation actuators and solenoid valves;
- interface with the vehicle;
- interface with other control systems connected.

NOTE The BOSCH ME 2.1 engine control system does not require any adjustments as it is the self-adjusting type.

NOTE The connectors described in the text are seen from the side opposite the cable inlet. The numbers indicate the corresponding engine control unit pins.

BOSCH ME 2.1 INJECTION/IGNITION SYSTEM FUNCTIONAL DIAGRAM




P3U02FX01

- 1. Engine control unit
- 2. Battery
- 3. Ignition switch
- 4. Electric fuel pump relay
- 5. Engine control system relay
- 6. Rev counter
- 7. System failure light
- 8. Speedometer
- 9. CAN connection line (communication with ABS / ASR / automatic transmission control units)
- 10. Climate control connection
- 11. LANCIA CODE connection
- 12. Diagnostic equipment connection
- 13. Cruise control connection
- 14. Accelerator pedal position sensor
- 15. Brake pedal switch
- 16. Clutch pedal switch

- Air flow meter with air temperature sensor
- 18. Butterfly casing integrated with D.V.L.
- 19. Radiator fan relays/fuses
- 20. Radiator fan
- 21. Engine rpm and TDC sensor
- 22. Coolant temperature sensor
- 23. Detonation sensor
- 24. Ignition coil (one per cylinder)
- 25. Injector (one per cylinder)
- 26. Engine timing sensor
- 27. Charcoal filter solenoid valve
- 28. Charcoal filter
- 29. Electric fuel pump
- 30. Lambda sensor
- 31. Inertia switch
- 32. Catalizer

LOCATION OF BOSCH ME 2.1 INJECTION/IGNITION SYSTEM COMPONENTS IN THE ENGINE COMPARTMENT



P3U03FX01

- 1. Ignition coils (left cylinder head)
- 2. Detonation sensors
- 3. Engine rpm and TDC sensor
- 4. Air flow meter
- 5. Coolant temperature sensor

- 6. Butterfly casing integrated with D.V.L.
- 7. Engine timing sensor
- 8. Lambda sensor
- 9. Fuel manifold complete with injectors

Engine Fuel system



10.

SYSTEM MANAGEMENT STRATEGIES

Operating principle

Any engine operating point is identified by two parameters:

- rotation speed;
- engine load.

If these parameters are known by processing, it is possible to calculate and then implement the injection (quantity of fuel supplied and timing with TDC in explosion stroke), the ignition (correct ignition advance) and other possible functions for each engine operating point.

In the BOSCH ME 2.1 system, the rotation speed is measured directly by means of the sensor, whilst the engine load is determined indirectly, on the basis of the air flow rate and the temperature (both measured via the flow meter).

Special maps are produced, during experiments on the engine and the vehicle, for the injection and the ignition, where the injection time/phase and ignition advance (for a certain number of pairs of speed/load parameters, required for the correct operation of the engine are stored.

For any engine operating point not exactly between those values stored in the memory the values are determined by mathematical interpolation.

The injection time values calculated are also correctly according to the signal coming from the Lambda sensor which, on the basis of suitable operating strategies, ensures that the mixture strength constantly fluctuates around the stoichiometric value.

All special operating situations which require special adjustments of the basic injection time/phase and ignition advance values are managed by the engine control unit by means of suitable strategies on the basis of the signals coming from the various system sensors.

The injection/ignition system basically carries out the following functions:

- management of the signals
- management of the injection
- management of the ignition
- motorized butterfly casing operation
- check on the engine idle speed
- check on the charcoal filter solenoid valve
- self-adjustment
- immobilizer connection (Lancia CODE)
- auxiliary functions (radiator fans, climate control, cruise control, antispin, automatic transmission).


MANAGEMENT OF THE SIGNALS

NOTE The "signals" refer to the collection of signals coming from the sensor on the crankshaft and the one on the camshaft which, having a precise reciprocal position, provide the control unit with a synchronized sequence of signals which the control unit is capable of recognizing.

During starting, the control unit recognizes the timing of the injection and the ignition, which are fundamental for the subsequent operation of all the strategies.


This recognition is implemented on the basis of the interpretation of the future signal coming from the flywheel sensor on the crankshaft and the engine timing sensor on the camshaft.

There are sixty teeth on the flywheel, two of which have been removed to create a discontinuity: the angle between the two consecutive teeth is therefore 6°: The signal is the sinusoid type.



- 1. Engine rpm and TDC sensor (solenoid)
- 2. Flywheel 60-2 teeth (crankshaft) 3. Flywheel
- signal (engine speed sensor)

The signal coming from the timing sensor consists of a square wave corresponding to the passing of the single tooth on the wheel in front of the sensor.



- 4. Engine timing sensor (Hall effect)
- 5. Flywheel 1 tooth (camshaft) 6. Flywheel
- signal (engine timing sensor)

Engine Fuel system



10.

INJECTION MANAGEMENT

Calculation of injection time/phase and operation of injectors

The "basic" injection time is calculated by a mathematical interpolation of the speed/load map: the values contained in the map, obtained experimentally, also depend on the characteristics of the injector. The "final" injection time is determined by means of a calculation algorhythm in which the "basic" injection time is corrected by a series of coefficients which take into account the different engine operating conditions which are hightlighted by the various sensors present in the system.

The operation of the injectors is the phased sequential type. The timing of the injectors can vary according to the engine speed.

Checking the mixture strength

The injection time is continuously corrected according to the signal coming from the Lambda sensor so that the mixture strength constantly fluctuates around the stoichiometric value at a frequency which is not noticeable whilst driving.

The control unit also manages the supply of the Lambda sensor heater. In effect, according to the engine load and speed conditions, it processes a forecast of the exhaust gas temperature and controls the heater supply current, limiting it to actual heating requirements.

Starting and operation when cold

During cold starting the injection is managed simultaneously (full group, i.e. not phased until the recognition of the injection phase, after which the management becomes phased.

The injection time whilst the starter motor is turning the engine is determined by a special map depending on the temperature of the coolant: after starting the normal map is then used for the calculation.

During operation when cold, since there is a natural weakening of the mixture as a result of the reduced evaporation and the strong condensation on the internal walls of the fuel inlet manifold, the "basic" injection time is increased by a multiplication coefficient which depends on the temperature and speed of the engine.

Operation during acceleration and deceleration

Acceleration and deceleration are interpreted by the system as transition stages between two conditions, starting and arriving: this transition can be positive (acceleration) or negative (deceleration). The transition management strategy is very complex as it has to take a large number of factors into account.

The extent of the correction basically depends on the variation in the engine load, measured by the flow meter and indirectly determined by the position of the accelerator pedal: however, other factors such as the speed of movement of the accelerator pedal, the engine speed and the temperature of the engine coolant also play a part.

In general, the "basic" injection time is increased for positive transitions and decreased for negative transitions.

In particular, if the increase in the injection time is noticeable at an injector which has just closed, the control unit reopens the injector (extra pulse), to compensate the mixture strength extremely quickly: the subsequent injections are already increased on the basis of the coefficients mentioned previously.

Operation in full load conditions

This strategy is enabled when the butterfly exceeds a certain level which, in turn, depends on the engine speed.

The injection time in this situation is determined by a special map according to the engine load and speed conditions.

Rotation speed restriction

This strategy limits the maximum speed which can be reached by the engine enabling the cut-off when 6800 rpm is reached (7000 rpm can be reached) for a maximum period of 5 seconds. The operation of the injectors is restored at 6600 rpm.

Operation in cut off conditions

The control unit enables the cut-off strategies when the temperature of the engine exceeds a certain level.

The cut-off strategy is enabled when:

- the idle condition is recognized;
- the number of revs is beyond a certain level, which varies inversely to the ratio of the gear engaged (the cut-off operation speed is high in short gears and gradually lower in long gears).

Before the idle condition is reached the dynamics of the number of revs decrease is checked: if it is higher than a given value, the fuel injection is partly activated on the basis of a logic which involves the "soft accompaniment" of the engine at idle speed.

When the idle speed condition is reached, normaly functions are resumed.

The fuel cut off is also enabled in the case of partial deceleration, identified by particular engine speed or load conditions, on condition that this situation exists for a pre-set time.

Operation of electric fuel pump

The electric fuel pump is operated by the engine control unit via a relay.

The pump cuts out:

- if the engine speed goes below 50 rpm
- after a certain period (about 5 seconds) with the ignition key in the MAR position without the engine being started up (timed go ahead);
- if the inertia switch has intervened.

Copyright by Fiat Auto 7

gamma 98

10.

IGNITION MANAGEMENT

The management of the ignition basically consists of determining the desired ignition advance according to the engine operating conditions and its implementation through the operation of the power transistors, located inside the control unit.

The "basic" advance value, calculated on the basis of the engine load and speed, is then corrected according to the different engine operating conditions.

The primary winding of each coil is supplied by the battery voltage via the relayand is connected to the power transistors incorporated in the engine control unit, whose transmitter is earthed, whilst the base receives the operating voltage from the control unit.

According to the engine rotation speed and the ignition advance to be implemented, the engine control unit establishes the moment for the start of conduction in the primary winding so that the desired current intensity (saturation) is reached in the primary winding just before the current is interrupted.

Thei angle of this moment obviously varies in relation to TDC for the explosion stroke of each cylinder and the greater the engine rotation speed, the greater the advance since the time required to saturate the current in the coil primary winding is virtually constant: it is determined using suitable coefficients stored in the memory (dwell management).

The moment of the start of conduction is also corrected on the basis of the battery voltage. The engine control unit determines the moment the current in the primary winding is interrupted, transforming the advance degrees into the time required by the engine to pass through this angle: this time constitutes the advance in relation to TDC for the explosion stroke with which the current at the base of the transistor is interrupted. The moment the current is interrupted at the base of the power transistors, the connection to earth for the primary winding is interrupted and, consequently, the high tension discharge takes place in the secondary winding.


Starting

During starting it is not possible to implement the normal management of the advance because considerable fluctuations in the rotation speed do not allow the correct calculation of the dwell and the advance.

The control unit implements a fixed advance for the entire time the engine is driven by the starter motor.

Operation in cut-off conditions

The injection advance is reduced on entry into cut-off: from the moment the supply of fuel is restored, the advance gradually returns to the "basic" vaue.



P3U08FX01

- $\triangle \alpha$ correction of ignition advance when idling
- $^{+}\triangle\,$ RPM: the speed during idling exceeds the nominal one
- △ RPM: the speed during idling is lower than the nonimal one

Operation with engine idling

When the engine is idling, the management of the advance is implemented independenly of the "basic" advance.

The advance value during whilst idling is correctly in a manner which is inversely proportional to the variation of the speed in relation to the pre-set speed which, in turn, depends on the temperature of the coolant.

In particular, the advance is increased if the speed decreases and is decreased if the speed increases to guarantee the stability of the actual speed.

Control of the detonation

This strategy has the task of detecting the presence of detonation, by processing the signal coming from the appropriate sensor. The strategy constantly compares the signal coming from the sensor with a level which is, in turn, constantly updated to take into account background noise and the ageing of the engine.

If the system recognizes the presence of detonation, the strategy reduces the ignition advance, in steps of 3° up to a maximum of 9° until the phenomenon disappears. Latern on, the advance is gradually restored to the basic value or until the onset on the phenomenon.

The strategy is also equipped with a self-adjustment function which memorizes the reductions in the advance which are continuously repeated to adjust the advance to the different conditions the engine finds itself in (for example the use of a low octane rating fuel). The strategy is capable of restoring the advance to the map value if the conditions which have caused the reduction disappear.

OPERATION OF MOTORIZED BUTTERFLY CASING

The engine control unit controls the position of the butterfly through the operation of a direct current motor integrated in the butterfly casing.

The operating strategy determines the position of the butterfly mainly on the basis of the position of the accelerator pedal and the engine speed.

The transition stages are managed to improve the response of the engine according to the operation of the pedal by the driver and the engine operating conditions.

The control unit also sets the position of the butterfly according to the specific requirements connected to the different vehicle systems (antispin, cruise control, automatic transmission, etc.).

ENGINE IDLE SPEED MANAGEMENT

The general purpose of this strategy is to keep the engine speed around the value memorized (engine warm: 700 rpm), the position of the actuator depending on the engine speed and load conditions and the vehicle speed.

- Starting.

When the key is inserted, the position assumed by the actuator depends on the engine temperature (open-loop position).

- Engine idle speed.

The engine speed varies according to the temperature of the engine is constantly kept close to this value by modifying the position of the butterfly to compensate for any fluctuations in the speed: this particularly takes place when external loads are switched on (power assisted steering, heated rear windscreen, etc.).

If the fans and the air conditioning is switched on, both managed by the control unit, the strategy manages the actuator in advance of the engagement of the load; the same takes place on automatic versions with the vehicle stationary and the gearbox in drive.

- Deceleration.

In deceleration conditions outside of idling, the control unit controls the position of the actuator through a special flow rate curve (dash-pot curve), in other words slowing down the return of the butterfly to the closed position thereby achieving a reduction in the engine braking effect.

In addition, if the vehicle is decelerating, the information concerning its speed correlated to the engine speed, allows the optimum management of the dash-pot effect, adjusting it to the gear engaged.

CONTROL OF CHARCOAL FILTER SOLENOID VALVE

This strategy controls the position of the charcoal filter solenoid valve as follows:

- with the engine warm, the control unit operates the solenoid valve in duty-cycle to control the quantity of fuel vapours sent to the inlet (scavenging of the charcoal filter) according to the engine speed and load conditions. In particular, the system alternates periods of scavenging with periods free from scavenging: during the latter, the self-adjustment strategy is enabled; it is disabled during scavenging;
- in cut-off conditions the solenoid valve remains closed.
- after warm starting the solenoid valve remains closed for several moments, then it starts to be controlled in conjunction with the activation of the control of the mixture strength via the Lambda sensor;
- after cold starting, the solenoid valve remains closed for the entire time that the engine is warming up.

EngineFuel system

LANCIA K 1999) 24v 98 range

10.

SELF-ADJUSTMENT

Self-adjustment of the system

The control unit is equipped with a self-adjustment function which has the task of recognizing the changes which take place in the engine due to the processes of bedding in over a period of time and the ageing of both the components and the engine itself.

These changes are memorized in the form of modifications to the basic map and are designed to adapt the operation of the system to the gradual alterations in the engine and the components in relation to the specifications when new.

This adjustment function also makes it possible to compensate for any inevitable differences (due to production tolerances) with components which may be replaced. This means that all vehicles can give maximum results without special adjustment and control operations.

Self-learning:

In the following conditions:

- removing, refitting or replacing the injection control unit

- removing, refitting or replacing the butterfly casing integrated with D.V.L.

the control unit, if commanded by the diagnostic equipment, implements the self-learning logic. The values stored in the control unit memory are not cancelled even if the battery is disconnected.

MANAGEMENT OF THE ANTI-THEFT FUNCTION (LANCIA CODE)

To improve protection against theft attempts, the vehicle is equipped with an engine immobilizer system (Lancia CODE) which only allows the activation of the injection/ignition control unit by means of an electronic code.

Each time the key is turned to the OFF position, the Lancia CODE system completely deactivates the injection/ignition control unit.

If the key is turned from OFF to ON, the following operations take place, in order:

- 1. The injection/ignition control unit sends the Lancia CODE control unit a request for the secret code in order to deactivate the immobilization of the functions.
- 2. The Lancia CODE control unit responds by only sending the secret code after having, in turn, received the recognition code transmitted by the ignition key, which contains a special transponder.
- 3. The recognition of the secret code allows the de-activation of the immobilization of the functions and the injection/ignition control unit can activate the normal system management programme.

A special two-way serial line allows the exchange of data between the injection/ignition control unit and the Lancia CODE control unit.

If there is a failure with the Lancia CODE system, the vehicle can be started up using special emergency procedures.



Given the presence of the Lancia CODE system DO NOT, during the diagnostic stage and/or operational checks, carry out tests using another injection/ignition control unit. In such a case the Lancia CODE control unit would transfer the (unrecognized) code to the test control unit which could then no longer be used on any other vehicles.

COMPLEMENTARY FUNCTIONS Management of radiator fans

NOTE Since the coolant temperature is measured by the sensor there is no longer a thermal contact on the radiator.


The engine control unit controls the engagement of the radiator fans according to the coolant temperature and activation of the climate control.

There are two operating speeds for the fans, managed according to two different logics, completely independent of one another.

- a) According to the temperature of the coolant:
- low speed: the fan is switched on when the temperature of the coolant reaches the lower level (T1);
- high speed: the fan is switched on when the temperature of the coolant reaches the upper level (T2).

The fan is switched off with a hysteresis of around 3 °C.

- b) According to the condition of the four stage pressure switch:
- low speed: the fan is switched on when the pressure switch 2nd stage is reached;
- high speed: the fan is switched on when the pressure switch 3rd stage is reached.



P3U11FX01

T1 =lower level

T2 =upper level

level activated ON:

OFF: level de-activated 1. Fan state: 0 = off

1 = low speed

2 = high speed

- 2. The level of the four stage pressure switch
- 3. The level of the four stage pressure switch
- 4. Coolant temperature progress

Engine

Fuel system

LANCIA K 1299 24v 98 range

10.

Climate control system connection

The injection/ignition control unit is functionally connected to the climate control system as follows:

- 1. it receives the request to switch on the compressor and operate the various interventions (additional air);
- 2. it gives the go ahead to switch on the compressor, then the strategy conditions are verified;
- 3. it receives information on the stage of the four stage pressure switch and operates the various interventions (operation of the radiator fan).

As far as point 1 is concerned, if the engine is idling, the control unit increases the air flow rate, modifying the position of the butterfly in advance of the compressor being switched on and conversely it returns the butterfly to the normal position after the compressor is switched off.

As far as point 2 is concerned, the control unit automatically operates the switching off of the compressor;

- for several seconds after starting;
- when the temperature of the engine coolant exceeds a certain level (engine overheated).

Control of cruise control system (where fitted)

According to the position of the cruise control lever the control unit directly operates the motorized butterfly to control and maintain the motorized speed.

The cruise control is temporarily disabled:

- by operating the brake
- by operating the clutch

the "recall" button is used to return to the speed memorized. The cruise control is not disabled if there is a request for acceleration (e.g. overtaking) and the vehicle returns automatically to speed set as soon as the accelerator is released.

The ASR function (antispin) has priority over the cruise control for safety reasons.

Connection with the ABS/ASR control unit (where fitted)

The dialogue between the engine control unit and the ABS/ASR control unit takes place via the CAN line available at the two control units.

If the wheels are slipping (signalled by the ABS/ASR control unit), the injection control unit reduces the engine torque by:

- reducing the ignition advances
- reducing the butterfly opening angle.

Connection with the automatic transmission control unit (where fitted)

The dialogue between the engine control unit and CAE automatic transmission control unit takes place via the CAN line available at the two control units.

If the wheels are slipping (signalled by the CAE control unit) the injection control unit reduces the engine torque by:

- reducing the ignition advances
- reducing the butterfly opening angle.

DIAGNOSTICS

The system is equipped with an autodiagnostic function designed to check for any irregularities in the following components:

Actuators

injectors
coils
charcoal filter solenoid valve
motorized butterfly casing
electric fuel pump relay
climate control relay
fan relays

Sensors

engine speed sensor
engine timing sensor
Lambda sensor
accelerator pedal position sensor
coolant temperature sensor
detonation sensor
brake-clutch pedal switches
air flow meter

The control unit autodiagnostic system checks the signals coming from the sensors and compares them with the permissible limit figures:

signalling of faults during starting

- warning light on for 4 seconds indicates test stage

- warning light off after 4 seconds indicates no failure in components which can alter the pollution control figures
- warning light on after 4 seconds indicates failure

signalling of faults during operation

- warning light on indicates failure
- warning light off indicates no failure in components which can alter the pollution control values

Recovery strategy

If a fault is detected with the sensors/actuators, the control unit, where possible, replaces the missing data, reconstrucing it using the software (recovery) to allow the operation of the engine.

Using the diagnostic equipment it is possible to carry out a complete fault diagnosis of the system which, in three stages, allows the:

- display of a series of functional parameters (with the engine switched off orrunning);
- display of the errors and their cancellation;
- activation of certain actuators (active diagnosis).

ELECTRICAL/ELECTRONIC CIRCUIT

ENGINE CONTROL UNIT

The control unit uses a "FLASH EPROM".

This new technology allows a development of the calibrations (for example, to improve driving comfort) without having to remove the control unit or replace the EPROM.

The operation consists of loading the new programme in the control unit memory, via the diagnostic connector, using the diagnostic equipment, afterhaving checked the normal operation of the system elements (no defects).

Copyright by Fiat Auto 13

Engine Fuel system



Operation

The engine control unit M10 controls and regulates the entire ignition system and electronic injection. The direct supply of the control unit reaches the battery, from the maxifuse line of CENTR B5, at pin 4 of connector B of M10 via the line protected by fuse F20 of the junction unit B1.

The main injection relay J10 controls the entire system: it is supplied directly by the battery via the maxi-fuse line B80; it is energized by a signal controlled by the ignition (INT/A) from the line protected by fuse F16 of the junction unit B1; as a result, the main relay J10 sends the supply:

- to pin 2 of connector A of the actual control unit M10;
- to the injectors N70:
- to the coils A30;
- to the timing sensor K47, via the line protected by fuse B40;
- to the air flow meter K41, via the line protected by fuse B40;
- to the vapour recovery solenoid valve L10, via the line protected by fuse B40;
- to the Lambda sensor heater K40, via the line protected by fuse B40;

the supply controlled by ignition (INT/A) also supplies the petrol pump relay J15 which is enrigized by an (earth) signal coming from pin 29 of connector C of the control unit M10.

It provides the supply - via fuse F3 of the junction unit B1 - for the electric fuel pump N40, which is connected to earth through the inertia switch I50, which, in the case of an impact, interrupts the circuit and prevents dangerous supplies of fuel.

Pins 3, 7, 8 of connector A of the control unit M10 are earthed and act as a reference, the first two for the ignition and the third for the injectors.

Pin 8 of connector F is also earthed.

The engine control unit M10 receives signals from the different sensors, thereby keeping all the engine operating parameters under control.

The timing sensor K47 receives a reference earth from pin 39 of connector E of the control unit M10 and sends a signal whose frequency corresponds to the timing at pin 40 of the same connector.

The engine temperature sender unit K36 receives a reference earth from pin 28 of connector E of the control unit M10 and supplies a signal proportional to the temperature of the engine coolant to pin 29 of connector E of the same control unit. The same sender unit provides information for theengine temperature gauge and overheating warning light.

The heated Lambda sensor K40 provides the control unit M10 with information surrouding the correct composition of the air/fuel mixture: the signal is sent to pin 32 of connector C of the control unit, whilst pin 31 provides the reference earth. The sensor K40 is heated by a resisatnce to ensure correct operation, even when cold; the resistance is supplied by relay J10 and receives the heating signal from pin 5 of connector A of M10.

The detonation sensors K50 and K51 allow, via the unaltered frequency signals from pins 42 and 44 of connector E of the control unit, respectively, information to be received concerning detonation conditions. The earth is sent by pins 41 and 43, respectively, of connector E of the control unit M10.

The air flow meter K41 (supplied by the relay J10) receives the reference voltage from pin 46 of connector E for the control unit and sends pin 47 of the same connector a signal proportional to the air flow rate. There is an air temperature sensor inside K41: the reference earth for the sensor is supplied from pin 48 of connector E of M10, whilst pin 45 of connector E receives the air temperature signal.

The accelerator pedal K55 is fitted with two integrated potentiometers (one main one and one safety one). The first receives a supply and earth from pins 22 and 23 of connector C of M10, respectively and sends the signal to pin 25.

Engine Fuel system

10.

Pin 14 for connector C of M10 receives the signal coming from the brake lights switch I30, with the supply "controlled by the ignition" (INT/A) with the line protected by fuse F1 of the junction unit B1. Pin 19 for connector D of control unit M10 receives an earth signal coming from the clutch pedal switch I31.

Injectors N70 receive a go ahead supply for the opening from the main relay J10.

The engine control unit sends the commands to the injectors from pins 25, 13, 1, 26, 14 and 2 of the connector for cylinders 1, 2, 3, 4, 5 and 6, respectively.

Control unit M10 also controls the coils A30 via the signals for the primary coil windings, whilst the secondary winding sends the impulse to the spark plugs: pins 20, 6, 17, 13, 19 and 5 for connector F operate ignition coils 1, 2, 3, 4, 5 and 6, respectively. The primary coils A30 receive the go ahead supply for opening from the main relay J10.

The butterfly casing actuator N75 is fitted with two integrated potentiometers connected in parallel: it controls the opening of the butterfly by means of a stepping motor.

The motor receives a supply from pins 1 and 2 of connector F of M10. Pin 33 of connector E sends a supply to the two potentiometers, pin 32 of connector E provides the earth signal for them, whilst pins 31 and 34 of the same connector receive signals which arrive from the butterfly casing actuator N75. The fuel vapour recovery solenoid valve L10 allows the flow of fuel vapours to the engine inlet where they are added to the mixture which enters the combustion chamber. Valve L10, supplied by the main relay J10 (through fuse B40), is opened by the control unit when the engine is operated by a duty cycle type signal from pin 21 of connector C for the control unit M10.

Control unit M10 is connected with the Lancia CODE control unit M20 through the special serial line from pin 39 of connector C; in this way, if the LANCIA CODE does not detect a correct code it does not give the go ahead and the engine is not started up.

The control unit is equipped with an autodiagnostic system, which can be used by connecting it to connector R10: it receives all the signals indirectly from the control unit M10 through the M20 CODE control unit serial line (pin 39 of connector C).

The autodiagnostic system also produces a signal - from pin 21 of connector F - for the "injection failure" warning light, in the instrument panel E50, which comes out of the control unit M10, whilst pin 15 of connector A for E50 provides a supply controlled by the ignition (INT/A) from the line protected by fuse F1 of the junction unit B1. The speedometer signal (vehicle speed) reaches pin 13 of connector D for the control unit M10; the signal is produced by the ABS control unit M50.

The control unit M10 sends - pin 38 of connettore C - the instrument a signal proportional to the engine speed.

The control unit M10 is connected to the air conditioning system via pins 4 and 21 of connector E. This makes it possible to adjust the engine idle speed to the increase in the load each time the compressor is switched on or to switch it off in the case of high engine speed or load conditions.

The control unit also controls the engine cooling system: pin 6 of connector A, pin 3 of connector D and pins 15, 17 of connector E control the engagement of the relevant fan. The control unit M10 is connected to the electronic automatic transmission (CAE) via pins 5, 17 of connector D.

Pins 11 and 12 of connector D for the control unit M10 involve the connection with the ABS/ASR control unit, a connection made through the CAN line.


Pins 20, 21, 22, 23, 24 of connector D and pin 10 of connector E of control unit M10 are connected with the Cruise Control.


On some versions there is an additional connector R51 for connection with the control unit, located in the engine compartment; this connection is only used by the production plant and should not, under any circumstances, be used in a service situation.

Copyright by Fiat Auto

10.

BOSCH ME 2.1 SYSTEM WIRING DIAGRAM





LANCIA K 1999) 24v 98 range

10.

BOSCH ME 2.1 wiring diagram key

| A30 A5 B1 B40 B5 B80 C21 C30 C40 D23 D4 D5 D80 E50 I30 I31 I50 J10 J15 K36 | Ignition coil Junction board Junction unit Injection services fuse MAXI FUSE box I.E. fuse (MAXI FUSE) Dashboard earth on Air Bag bracket Left rear earth Earth on engine Dashboard/i.e. coupling Engine front coupling ABS coupling plus antispin Injector coil coupling Instrument panel Switch on brake pedal Switch on clutch pedal Inertia switch Main injection relay Fuel pump relay Coolant temperature sensor/sender |
|---|---|
| K40 | Lambda sensor |
| K41 | Air flow meter |
| K46 | Rpm sensor |
| K47 K50 | Cam angle sensor Detonation sensor |
| K50 | Detonation sensor 2 |
| K55 | Accelerator pedal potentiometer |
| L10 | Fuel vapour recovery solenoid valve |
| L15 | Variable geometry solenoid valve |
| M10 | Engine control unit |
| M11 | Main injection relay diode |
| M20 | CODE control unit |
| M50 | ABS control unit |
| N40 | Electric fuel pump and gauge |
| N70 | Injector |
| N75 | Integrated butterfly casing actuator |
| D10 | Multiple dispusantia a acceliu a |


Multiple diagnostic coupling

I.E. control unit additional socket

- 1 Automatic transmission
- 2 CAN line
- 3 On board instruments
- 4 Cruise Control
- 5 Accelerator pedal
- 6 Air conditioning switch
- 7 Engine cooling fan
- 8 Brake lights
- 9 Engine control unit
- 10 ABS control unit
- 11 Horn
- 12 Supply from battery

R10 R51

DIAGRAM SHOWING INFORMATION ARRIVING AT/LEAVING THE CONTROL **UNIT AND SENSORS/ACTUATORS**




P3U19FX01

- 1. Electric fuel pump
- 2. Air conditioning compressor
- 3. Radiator fan
- 4. N.c.
- 5. Cruise control
- 6. Four stage pressure switch
- 7. Brake-clutch pedal switches
- 8. Timing sensor
- 9. Speedometer
- 10 Lambda sensor
- 11. Coolant temperature sensor
- 12. Detonation sensors13. Engine speed sensor
- 14. Accelerator pedal position sensor

- 15. Air flow meter with air temperature sensor
- 16. Battery
- 17. Butterfly casing integrated with D.V.L.
- 18. CAN line (communication with ABS / ASR / automatic transmission control units)
- 19. LANCIA CODE
- 20. Diagnostic equipment socket
- 21. Charcoal filter solenoid valve 22. Ignition coil (one per cylinder)
- 23. System failure light24. Rev counter
- 25. Injector (one per cylinder)

BOSCH ME 2.1 SYSTEM CONTROL UNIT PIN OUT



P3U20FX01

32

- A-1 N.c.
- A-2 Supply
- A-3 Earth for ignition
- A-4 N.c.
- A-5 Lambda sensor heater
- A-6 Fan 1st speed relay
- A-7 Earth for ignition
- A-8 Sensor earth
- B-1 N.c.
- B-2 N.c.
- **B-3** Programming
- B-4 Battery
- C-1 N.c.
- C-2 N.c.
- C-3 N.c.
- C-4 N.c.
- C-5 N.c.
- C-6 N.c.
- C-7 N.c. C-8 N.c.
- C-9 N.c.
- C-10 N.c.
- C-11 N.c.
- C-12 N.c.
- C-13 N.c.
- C-14 N.c.
- C-15 N.c. C-16 N.c.
- C-17 N.c.
- C-18 N.c.
- C-19 N.c.


- C-20 N.c.
- C-21 Charcoal filter solenoid valve
- Accelerator pedal potentiometer 1 supply
- ccelerator pedal potentiometer 1 earth C-23
- C-24 Accelerator pedal potentiometer 1 signal
- C-25 Accelerator pedal potentiometer 2 signal
- C-26 Accelerator pedal potentiometer 2 earth C-27 Accelerator pedal potentiometer 2 supply C-28 N.c.
- C-29 Fuel pump relay
- C-30 N.c.
- C-31 Lambda sensor earth
- C-32 Lambda sensor signal
- C-33 N.c.
- C-34 N.c.
- C-35 N.c.
- C-36 N.c.
- C-37 N.c.
- C-38 Rpm signal
- C-39 Diagnostic connection (line K)
- C-40 N.c.
- D-1 N.c.
- D-2 N.c.
- Cooling fan 2nd speed relay
- N.c.
- D-5 CAE gear selector switch
- D-6 N.c.
- D-7 N.c.
- D-8 N.c.


Engine Fuel system


98 range


10.

| D-9 | N.c. | F-29 | Coolant temperature sensor signal |
|------|--|------------|--|
| D-10 | | E-30 | |
| | "High" CAN line | | Butterfly casing potentiometer 1 |
| D-11 | "Low" CAN line | | Butterfly casing potentiometer earth |
| | | | |
| | Speedometer signal | | Butterfly casing potentiometer supply |
| | Brake lights switch | | Butterfly casing potentiometer 2 |
| D-15 | | E.35 | |
| D-16 | | E-36 | |
| | CAE recognition | E-37 | Engine rpm sensor (-) |
| D-18 | N.c. | E-38 | Engine rpm sensor (+) |
| D-19 | Clutch pedal switch | E-39 | Timing sensor earth |
| | Cruise control set + | E-40 | Timing sensor signal |
| | Cruise control set - | | Earth for detonation sensor 1 (cylinders |
| | Cruise control recall | | 1-4-5) |
| | Brake switch | F 12 | Detonation sensor 1 signal |
| | Deactivation of cruise control | | Earth for detonation sensor 2 (cylinders |
| | Operation of injector for cylinder n° 3 | E-43 | |
| | | - 44 | 2-3-6) |
| | Operation of injector for cylinder n° 6 | | Detonation sensor 1 signal |
| | N.c. | | Air temperature sensor |
| E-4 | , | | Flow meter - reference voltage 5V |
| | pressor relay | | Flow meter signal |
| | | E-48 | Flow meter earth |
| | N.c. | F-1 | Butterfly casing motor integrated with |
| E-7 | N.c. | | D.V.L. (-) |
| E-8 | N.c. | F-2 | Butterfly casing motor integrated with |
| E-9 | N.c. | . – | D.V.L. (+) |
| E-10 | Cruise control on warning light | F-3 | N.c. |
| E-11 | N.c. | F-4 | N.c. |
| E-12 | N.c. | F-5 | Operation of ignition coil for cylinder n° 6 |
| | Operation of injector for cylinder n° 2 | F-6 | Operation of ignition coil for cylinder n° 2 |
| | Operation of injector for cylinder n° 5 | F-7 | N.c. |
| | Air conditioning pressure switch 1st stage | F-8 | Earth |
| E-16 | N.c. | г-о F-9 | N.c. |
| | Air conditioning pressure switch 2nd stage | | |
| | | F-10 | |
| E-18 | N.c. | F-11 | |
| E-19 | | F-12 | |
| E-20 | N.c. | | Operation of ignition coil for cylinder n° 4 |
| | Air conditioning switch | F-14 | |
| E-22 | | F-15 | N.c. |
| | N.c. | F-16 | N.c. |
| E-24 | | F-17 | Operation of ignition coil for cylinder n° 3 |
| E-25 | Operation of injector for cylinder n° 1 | F-18 | • |
| E-26 | Operation of injector for cylinder n° 4 | | Operation of ignition coil for cylinder n° 5 |
| E-27 | N.c. | | Operation of ignition coil for cylinder n° 1 |
| E-28 | Engine coolant temperature sensor | | Operation of injection warning light |
| | earth | , _ 1 | - p |
| | | | |









ENGINE RPM AND TDC SENSOR

The engine rpm and TDC sensos is fixed to the cylinder block/crankcase facing the flywheel on the crankshaft pulley.

Operating principle

The sensor consists of a tubular casing which houses a permanent magnet (2) and an electrical winding (4). The magnetic flow created as a result of the flywheel teeth pasing is subject to fluctuations resulting from the variation in the gap.


These fluctuations produce an electro-motive force in the winding where there is an alternately positive and negative voltage. The peak sensor output voltage depends, all things being equal, on the distance between the sensor and the tooth (gap).


- 1, Brass metal bushing
- 2, Permanent magnet
- 3, Plastic sensor casing
- 4, Coil winding
- 5, Polar core
- 6, Ring gear or flywheel
- 7, Electrical cable

Wiring connector

The sensor resistance can be measured by disconnecting the connector and connecting an ohmmeter to the sensor.


Resistance: 860+10% ohm at 20 °C





P3U23FX02

Wiring connector



ENGINE TIMING SENSOR

The engine timing signal, together with the engine rpm and TDC signal, allows the control unit to recognize the order of the cylinders to implement the phased injection. This signal is produced by a Hall effect sensor, fitted by the exhaust camshaft drive pulley.

NOTE The sensor angular position cannot be adjusted in any way.


Operating principle


- 1, Camshaft disc
- 2, Timing sensor
- 3. Dowel

A semi-conductor layer through which the current passes, immersed in a normal magnetic field (lines of force perpendicular to the direction of the current) produces a difference in power, known as Hall voltage. If the intensity of the current remains con-

If the intensity of the current remains constant, the voltage created only depends on the intensity of the magnetic field. Simply varying the intensity of the field periodically therefore produces a modulated electrical signal.

The rotation of the disc (1) when the dowel (3) passes the sensor (2) locks the magnetic field with a consequent "low" output signal. Conversely, when after the dowel (3) the sensor (2) reading produces a "high" signal. As a result the high signal alternates with the low signal once every two revolutions of the engine (see paragraph on "signal management").





P3U24FX02


INJECTION NTC

INSTRUMENT NTC

| °C | Ω | °C | Ω |
|-----|-------|-----|------|
| -20 | 15970 | 40 | 1150 |
| -10 | 9620 | 50 | 807 |
| 0 | 5975 | 60 | 576 |
| 10 | 3816 | 70 | 418 |
| 20 | 2500 | 80 | 309 |
| 25 | 2044 | 90 | 231 |
| 30 | 1679 | 100 | 176 |

| °C | Ω |
|-----------------|------------------|
| 60 90 120 | 76/88 512/602 |

Wiring connector



P3U24FX03

COOLANT TEMPERATURE SENSOR

This sensor is fitted on the themostat casing; it is made up of a brass casing which affords protection to the actual resistive elements consisting of two NTC thermistors (Negative Temperature Coefficient, the electrical resistance of the sensor decreases as the temperature increases).


The two NTC elements are distinctive and provide information on the temperature for the specific gauge in the instrument and for the injection/ignition control unit.


The reference voltage for the NTC element for the injection system is 5 Volt; since the control unit intake circuit is designed as a voltage divider, this voltage is shared between a resistance in the control unit and the sensor NTC resistance. As a result the control unit is capable of carrying out evaluations through the changes in voltage and thereby obtain information on the temperature.

A. NTC for instrument panel B. NTC for injection system

Checking the resistance

The table at the side contains the resistance values which the NTC elements can assume according to the temperature. These figures can be measured by disconnecting the connector and connecting an ohmmeter to the sensor pins.





ACCELERATOR PEDAL POTENTIOMETER


The position of the accelerator pedal is tranformed into an electrical voltage signal and is sent to the injection control unit by the potentiometer connected to the pedal.

The accelerator pedal position signal is processed together with the information relating to the engine speed to obtain the injection times and pressures.

The sensor consists of a casing (1) fixed to the pedals by means of a flange, which contains a shaft (2), in an axial position, connected to the two potentiometers (3): one main one and one safety one.

A coil spring on the shaft guarantees the correct resistance to pressure, whilst a second spring ensures the return on release.

Wiring connector



BRAKE PEDAL SWITCH

There is a switch (1) on the brake pedal which operates the brake lights; the same switch sends a signal for the injection control unit.

The "brake pedal pressed" signal is used by the control units for:


- understanding a deceleration situation;
 - checking the plausibility of the signal coming from the accelerator potentiometer.

CLUTCH PEDAL SWITCH

There is a switch (2) on the clutch pedal connected to the injection control unit.

The "clutch pedal operated" signal is used by the injection control unit for distinguishing gear engaged and gear change conditions.

Copyright by Fiat Auto 25






Diagram showing electrical connections


The ignition is the static advance type, with a single coil for each spark plug (SINGLE COIL); this solution dispenses with the high tension circuit, improving reliability and safety and decreasing the risk of interference due to high tension connections and leads. It involves a normal coil which increases the tension of the impulse sent to the spark plugs: each single coil, located in the cylinder head, directly supplies a spark plug without

- 1. Supply through ignition switch
- 2. Battery
- 3. Relay
- 4. Coil
- 5. Spark plug


IGNITION COILS

intermediary cables.

6. Electronic control unit



P3U26FX02




P3U26FX03


Checking coil primary winding resistance

The resistance is checked by connecting an ohmmeter to the outer pins (pins 1 and 3) of the connector:

Primary resistance: 0,48 ohm


Wiring connector






P3U27FX02

P3U27FX04





DETONATION SENSOR

The detonation sensors are located in the monobloc under the inlet manifolds.

These sensors have a bush to prevent incorrect torque tightening. If they are replaced, do not place washers or shims between the crankcase and sensor contact surfaces.

This sensor makes it possible to detect detonation, vibrations due to the irregular combustion of the mixture in the combustion chamber.

If this phenomenon is repeated it can destroy the mechanical parts as a result of the irregular increase in the temperature of the walls.

When the engine is detonating, vibrations of a particular frequency are produced in the cylinder block which are transformed by the sensor into a voltage signal proportional to their intensity.

A: combustion without detonation The curve (h) shows the pressure in the cylinder without detonation.

The sensor produces a signal (i) corresponding to the curve (h).

B: combustion with detonation

The curve (h) shows the pressure in the cylinder with detonation: it can be seen that the pressure is more irregular. The sensor signal (i) detects the onset of particularly intense vibrations.


Wiring connector

INLET CIRCUIT

The inlet circuit consists of the following components;

- air filter with hoses;
- air flow meter;
- acoustic resonator fitted in parallel to the inlet hose;
- motorized butterfly casing;
- inlet chamber on which the inlet manifolds and the motorized butterfly casing are fitted.


DIAGRAM SHOWING INLET CIRCUIT




P3U28FX01

- Inlet vent
 Air filter
- 3. Air flow meter
- 4. Motorized butterfly casing
- 5. Resonator
- 6. Inlet chamber
- 7. Inlet manifolds





P3U29FX01



- Air temperature signal
- 2. Battery voltage
- Earth
- 4. Reference voltage (5V)

P3U29FX02

Air flow rate signal

AIR FLOW METER

The flow meter is located on the air inlet hose and is the hot film type.

The intake air temperature sensor is integrated inside the flow meter.

The operation is based on a heated diaphragm in a measuring duct through which the air entering the engine flows.

The hot film diaphragm is kept at a constant temperature (about 120 °C higher than the temperature of the entering air) by the heating resistance.

The mass of air passing through the measuring duct tends to remove heat from the diaphragm therefore, in order to keep the latter at a constant temperature, a certain current must flow through the resistance.

This current, being proportional to the mass of air flowing through the engine, is measured by a Wheatstone bridge and the signal obtained is sent to the injection control unit.

- 1. Covers
- 2. Electronic card
- 3. Sensor
- 4. Support plate
- 5. Support
- 6. O-Ring
- 7. Temperature sensor

NOTE This flow meter measures the mass of air (and not the volume) directly, thereby eliminating problems of temperature, altitude, pressure, etc.


Description of the operation

The Wheatstone bridge (made up of resistances R1, R2, R3, R4) is balanced when R3 is about 120 °C higher than the temperature of the air.


The air that passes through the diaphragm removes heat from R3, consequently the bridge is not balanced.

This situation is detected by the circuit at IC1, which controls transistor T1, in a manner proportional to the imbalance of the bridge, as a result of which more current passes through Rh to heat R3 and therefore restore the balance of the bridge. The circuit IC2 measures the current passing through Rh.


This current allows the bridge to be kept balanced and is therefore proportional to the mass of air passing through the air flow meter.



P3U30FX01



P3U30FX02



P3U30FX03

Wiring connector

BUTTERFLY CASING ACTUATOR

The actuator is fixed to the inlet chamber and regulates the quantity of air drawn in by the engine.

Depending on the signal coming from the accelerator pedal potentiometer, the injection control unit opens the butterfly by means of a direct current motor integrated in the butterfly casing actuator.

The butterfly casing actuator is equipped with two integrated potentiometers connected in parallel so that they control each other. In the case of a fault with the two potentiometers or if there is no supply, the control unit reduces the engine torque, according to the position of the accelerator pedal. The replacement of the butterfly casing actuator or the injection control unit means that the "self-learning" procedure has to be carried out (see chapter on CHECKS, ADJUST-MENTS AND REPAIR OPERATIONS).

Wiring connector




FUEL SUPPLY CIRCUIT

This circuit consists of the following components:

- Fuel tank
- Drip tray complete with pump, filter, pressure regulator and gauge
- Supply pipe
- Returnless type fuel manifold complete with injectors


DIAGRAM SHOWING FUEL CIRCUIT




P3U31FX01

- 1 Fuel tank
- 2 Drip tray complete with pump, filter, pressure regulator and gauge
- 3 Fuel filler
- 4 Returnless type fuel manifold
- 5 Injector
- 6 Supply pipe

31 Copyright by Fiat Auto



- 1. Electric fuel pump
- 2. Fuel filter
- 3. Gauge with float
- 4. Pressure regulator
- 5. Gauze pre-filter



FUEL DRIP TRAY ASSEMBLY

Electric fuel pump

The pump is housed inside the fuel tank in a special tray which also supports the gauge and is equipped with a filter on the pump inlet.

The pressure regulator is fitted on the pump supply.

The pump is the single stage peripheral flow type and is adapted to run on unleaded fuel. The rotor is driven by a c.c. electrical motor supplied by a relay, operated by the control unit to ensure:

- that the pump cuts out if the speed goes below a minimum level
- the timed operation (about 5 seconds) each time the ignition switch is turned to the ON position without the engine being started up;
- the operation with the engine started up.

The pump is equipped with an excess pressure valve which short circuit the supply with the inlet if the pressure in the supply circuit exceeds about 5 bar to prevent the electric motor from overheating.

In addition, a one-way valve in the supply, prevents the entire fuel circuit from being drained when the pump is not working.


Fuel filter


The fuel filter is housed in the casing surrounding the pump and does not require periodic replacement.


Fuel pressure regulator

This is a differential diaphgragm type device, regulated during manufcature to a pressure of 3.50 ± 0.05 bar and located in the top part of the drip tray assembly.


The fuel under pressure (1), coming from the pump, exerts a force on the flow valve (3) opposed by the calibrated spring (2). As the calibration pressure is exceeded, the flow valve opens and the excess fuel (4) returns to the tank, thereby stabilizing the pressure in the circuit.







P3U33FX03



FUEL MANIFOLD

The fuel manifold, which has the task of distributing the fuel to the injectors, is produced by aluminium die-casting and incorporates the seats for the injectors and the air bleed valve.

The fuel intake is achieved by means of a rapid attachment. Since the system is the returnless type, there is no recirculation pipe.

- 1. Fuel manifold
- 2. Injectors
- 3. Fuel supply connector
- 4. Bleed valve

INJECTORS

The injector has the task of supplying the amount of fuel required for the operation of the engine: the fuel is injected into the inlet manifold, immediately upstream of the inlet valves.

A single jet, top-feed type of injector basically consists of a nozzle operated by a solenoid valve and a return spring.

In the rest position, the needle (2), which is in one piece with the core (3), is thrust by the spring onto the nose of the injector (6), closing the opening and guaranteeing the seal to prevent the unwanted escape of fuel.


As soon as the winding (5) is energized, the core is attracted, it compresses the spring opening the nozzle port and allowing the fuel to come out.

- 1. Injector body
- 2. Needle
- 3. Magnetic core
- 4. Coil spring
- 5. Winding
- 6. Injector nose
- Adjustable spring
- 8. Filter
- 9. Electrical connection
- 10. Seal


Wiring connector

The injector resistance can be measured by disconnecting the connector and connecting an ohmmeter as shown in the diagram.

Resistance value: 14.5±5% ohm at 20 °C



P3U34FX01



INERTIA SAFETY SWITCH

The inertia switch has the task of interrupting the electrical supply of the electric fuel pump if the vehicle is subject to violent deceleration (impact) to prevent fuel from escaping and creating a fire risk if the fuel manifold or the supply pipe are damaged.

The switch consists of a steel ball fitted in a conical shaped housing and kept in position by the attraction force of a permanent magnet.

Below the action of acceleration due to inertia forces, the ball can be released from the magnetic clip and gradually come out of the tapered housing in an upwards movement which depends on the angle of the cone.

There is a rapid mechanism above the ball which forms a normally closed (NC) circuit. When the ball is struck, the mechanism changes position into a normally open (NA) circuit thereby interrupting the electrical supply to the electric pump and causing it to cut out.

The calibration of the switch causes intervention at acceleration above 1.2 g (about 11.7 m/s 2 , corresponding to an impact at a speed of around 25 kph).

To restore the connection to earth for the auxiliary electric pump, the seat must be moved backwards and the switch pressed until it can be heard to click.



After an apparently slight impact, if there is a smell of fuel or there are leaks from the fuel system, do not turn the switch back on, but search for the cause of the problem and remedy it to prevent the risk of fire.


If this is not the case and there are no leaks, the vehicle can be restrated by pressing the button to reactivate the electric pump.

EMISSION CONTROL DEVICES

The devices adopted for this purpose have two objectives:

- to keep down the levels of pollutant substances present at the exhaust, by means of the Lambda sensor and the catalytic silencer;
- to eliminate the outwards dispersion of unburnt hydrocarbons, by means of the (fuel) anti-evaporation system and the (lubricant) oil vapour recirculation system.

DIAGRAM SHOWING EXHAUST SYSTEM




P3U35FX01


- 1. Exhaust manifold
- 2. First section of exhaust
- 3. Catalytic silencer
- 4. Flexible element
- 5. Silencers
- 6. Lambda sensor

Copyright by Fiat Auto


35



- 1. Connecting cable
- 2. Protective sleeve
- 3. Planar sensor element
- 4. Ceramic support pipe
- 5. Sensor housing
- Ceramic seal
- 7. Protective tube



Wiring connector



P3U36FX03

LAMBDA SENSOR

The Lambda sensor measures the oxygen content of the exhaust gases: it is fitted on the exhaust pipe, upstream of the catalytic silencer.

The sensor output signal is sent to the control unit for the correction (feed-back) of the mixture strength.

When the sensor provides a low signal (voltage below 200 mV), the control unit recognizes a weak mixture and increases the injection time; later on, when the sensor signal is high (voltage above 800 mV), the control unit recognizes a rich mixture and decreases the injection time. This sequence is repeated with a frequency in the order of tens of Hertz. so that the engine is constantly operating at a mixture strength fluctuating around the stojchiometric value. The measuring cell and the heater are integrated in the "planar" (stratified) ceramic element with the advantage of the cell heating up rapidly to allow the closed loop control within 10 seconds of the engine being started up.


At temperatures below 300°C, the ceramic material is not activated, therefore the sensor does not send signals which can be understood: to ensure that it heats up rapidly during starting and the temperature is maintained during idling, the sensor is equipped with a heater with an electrical resistance controlled by the control unit.



The sensor can be rapidly put out of action by the presence of even slight amounts of lead in the fuel

The sensor heater resistance can be measured by disconnecting the connector and connecting an ohmmeter as shown in the diagram.

Resistance: 0.5/1 KΩ at 20°C



P3U36FX04

Fuel system

10.

CATALYTIC SILENCER

The catalytic silencer is a device which makes it possible to simultaneously keep down the levels of the three main pollutants present in the exhaust: unburnt hydrocarbons (HC), carbon monoxide (CO) and nitrogen oxides (NOx).


Two types of chemical reaction take place inside the catalyzer:

- oxidation of the CO and the HC, converted into carbon dioxide (CO₂) and water (H₂O);
- dissolving of the NOx, converted into nitrogen (N).

These reactions can take place in an extremely short space of time thanks to the presence, inside the structure (cermamic support) of the catalyzer, of a layer of active substances (platinum and rhodium) which greatly accelerate the conversion speed of the harmful substances.

The efficiency of this conversion process is therefore conditioned by the fact that the mixture strength on which the engine is running is constantly fluctuating around the stoichiometric value, which is achieved thanks to the feed-back control carried out by the control unit on the basis of the Lambda sensor signals.

Lastly, the conversion processes are activated at temperatures above 300° - 350°C; it is therefore essential that the catalyzer reaches this temperature as quickly as possible in order to work properly.



P3U37FX01

- 1. Ceramic monolith
- 2. Metal support
- 3. Steel outer casing



When operations have to be carried out near the catalytic silencer, the vehicle should be left for a while because the (internal) operating temperature of the catalyzer is between 500 and 850 °C.




There are basically two things which can ruin the inside of the catalyzer, namely:

- the presence of lead in the fuel which lowers the degree of conversion to practially nil ("lead poisoning") and irreparably damages the Lambda sensor as well;
- the presence of totally unburnt fuel in the exhaust gases, due to failed ignition, which causes an increase in temperature which leads to the melting of the ceramic support. As a result, the coil connectors should not be disconnected with the engine running for any reason whatsoever: in the case of tests, the silencer should be replaced with an equivalent length of pipe.

Copyright by Fiat Auto 37


DIAGRAM SHOWING ANTI-EVAPORATION CIRCUIT



P3U38FX01

- 1. Multi-purpose valve
- 2. Separator
- 3. Vapour supply to the charcoal filter
- 4. Charcoal filter
- 5. Charcoal filter solenoid valve

ANTI-EVAPORATION SYSTEM COMPONENTS



P3U38FX02

Active charcoal filter

The vapours coming from the tank are sent to the separator (2) through the two multi-purpose valves (1).

The vapours which condense in the separator return to the tank.

The vapours which do not condense are sent, via the pipe (3), to the canister (4) where they are absorbed and stored by the activated charcoal.

The vapours are directed to the inlet manifold by means of the solenoid valve (5) operated by the injection control unit.

- 1. From the multi-purpose valve
- 2. To the solenoid valve
- 3. Single-acting valve

Multi-purpose valve

The functions of the two multi-purpose valves are:

- pressurizing the tank
- retaining
- sealing in case of overturning.


Pressurizing the tank

The tank pressure is maintained between 30 and 45 mbar using a fluro-silicon rubber valve resting on a seal.

The valvel is supported by a stainless steel plate and opposed by a spring.

When the pressure in the tank exceeds the recommended value, it overcomes the resistance of the spring and allows the valve to raise, thereby allowing the flow of vapours towards the canister.

When the pressure returns to within the recommended limits, the valve closes.



P3U39FX01

Retaining

In certain operating conditions a vacuum can form in the tank as a result of:

- thermal variations
- fuel consumption.

The function of the valve, in this case, is to restore the pressure in the tank through the intake of air.

Any faults with this function can cause irregular operation or the breakdown of the vehicle through problems with the electric pump supply.

This function is carried out by the valve fitted directly on the fluoro-silicon rubber mounting.


Sealing in the case of overturning (rollover)

The rollover function is to prevent the escape of fuel from the tank if the vehicle overturns or if it is on a steep incline.

During normal operation of the vehicle (bends, acceleration, braking, etc.) the fuel may spill over into the canister.

The high rollover sensitivity prevents this. The rolling closing angle is less than 33°.

- 1. Pressurizing valve
- 2. Shim
- 3. Spring
- 4. Ball
- 5. Float




Charcoal filter solenoid valve

The function of this valve is to control the quantity of vapours drawn in by the active charcoal filter and directed to the inlet manifold by means of the injection/ignition electronic control unit.

If the valve is not supplied it is closed to prevent the fuel vapours from escaping.

A from the charcoal filter B to the inlet manifol



P3U40FX02

Wiring connector

SYSTEM FOR RECIRCULATING GASES COMING FROM THE ENGINE CRANKCASE (BLOW-BY)

This system controls the emission, from the crankcase, of the breather gases consisting of air/petrol mixtures and burnt gases which escape from the piston seals, in addition to the lubricant oil vapours, recirculating them to the inlet.

The emission of oil vapours is controlled by means of a separator (1) which directs the vapours released from the cylinder heads to the pipe (2).

The difference in temperature between the separator and the oil vapours causes partial condensation. The condensed vapours are sent to the cylinder head via the pipe (3).


With the butterfly open, the gases are sent, via the hose (5), upstream of the butterfly valve (7) to be drawn into the manifold.

With the butterfly closed the vacuum in the inlet manifold (6) draws in the gases through the pipe (4) via a PCV valve (8) (Positive Crank Ventilation) which shutters the inlet.

The PCV valve, in effect, is modulated and the quantity of gases passing through is proportional to the vacuum in the inlet manifold.

When the butterfly valve is completely open (condition A), the vacuum inside the inlet manifold is minimal, the spring (10) is completely extended and the PCV valve allows the maximum flow of breather gases.

Conversely, with the butterfly completely closed (condition B), the vacuum inside the manifold is maximum which causes the movement of the piston (9) which shutters the section through which the breather gases flow inside the PCV valve thereby liminting the intake of the actual gases.



P3U41FX01

Copyright by Fiat Auto 41

CHECKS, ADJUSTMENT AND REPAIR OPERATIONS ON THE BOSCH ME 2.1 SYSTEM



When working on a vehicle fitted with the Bosch ME2.1 system, observe the following precautions:

- do not start up the engine when the terminals for the electrical connections are not properly connected or slack at the battery poles;
- do not use a rapid battery charger for starting the engine;
- never disconnect the battery from the electrical equipment with the engine running;
- in order to charge the battery, disconnect it first from the electrica system;
- if the vehicle goes in a drying oven after painting at temperatures in excess of 80°C, the engine control unit must be removed from the vehicle first;
- do not connect/disconnect the control unit multiple connectors with the ignition switch in the ON position;
- always disconnect the negative battery lead before carrying out electrical welding on the vehicle.

The system has a memory which is directly supplied by the battery, even with the ignition switched off, where the self-adjustment values are stored. Disconnecting the battery will result in this information being lost and it can only be acquired again after a certain amount of time: this operation should therefore be limited as far as possible.

CHECKING THE CONCENTRATION OF THE EMISSIONS


The system manages the advance, the carbon monoxide (CO) content and the idle air flow rate, without the possibility of any manual adjustments. However, a check on the content of the exhaust gases, upstream and downstream of the catalyzer can provide precious indications on the operating conditions of the injection/ignition system, the engine parameters and the catalyzer.

Checking idle concentration of CO and HC upstream of the catalytic silencer

To check the concentration of carbon monoxide (CO) and unburnt hydrocarbons (HC) upstream of the catalyzer, proceed as follows:

- 1. Undo the cap located on the exhaust pipe, upstream of the catalyzer, and tighten the tool in its place.
- 2. Connect a suitably calibrated CO-tester probe to the tool.
- 3. Start up the engine and let it reach operating temperature.
- 4. Check that the engine speed corresponds to the recommended figure.
- 5. Check that the idle concentration of CO is within the recommended values (see table); if this is not the case, it is necessary to check:
- that the Lambda sensor is working properly, using the diagnostic equipment;
- for the presence of air penetration in the area surrounding the Lambda sensor housing;
- the injection and ignition system (in particular, the wear of the spark plugs).
- 6. In the same conditions, check that the concentration of HC is below 500 p.p.m.
- 7. If these figures are not found, proceed with tuning the engine, checking in particular:
- the valve gear timing;
- the engine compression.

98 range



P3U43FX01

43

Table summarizing the pollutant emission tolerance figures

| | CO (%) | HC (p.p.m.) | CO2 (%) |
|-----------------------------|---------|-------------|---------|
| Upstream of the catalyzer | 0,4 ÷ 1 | -500 | -12 |
| Downstream of the catalyzer | -0,35 | 90 | -13 |

Checking concentration of CO and HC at the exhaust


The exhaust concentration of carbon monoxide (CO) and unburnt hydrocarbons (HC) is measured by inserting a suitably calibrated tester probe at least 30 cm into the end of the exhaust pipe.

- 1. Check that the idle CO and HC concentrations correspond to the recommended figures (see table).
- 2. If the value of the HC is outside of the recommended limit, whilst that measured previously upstream of the catalyzer was correct, the engine parameters are correct and therefore the cause of the problem should be sought in the decreased efficiency of the catalyzer.

CHECKING THE ENGINE IDLE SPEED

If the engine idle speed does not correspond to the recommended figure and the system is the self-adjusting type, then it is not possible to carry out any adjustments. Therefore it is necessary to check that the accelerator linkage is correctly adjusted and the cause of the problem should be sought by carrying out a complete fault diagnosis using the diagnostic equipment.

Copyright by Fiat Auto



ENGINE CONTROL UNIT

Removing

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- disconnect the battery terminal (-);
- remove the control unit shield;
- disconnect the electrical connections D, E,
 F, C, B, A from the control unit following the order given above;
- undo the nuts and remove the control unit (2).

Refitting

P3U44FX01

Proceed as follows:

- fit the control unit and fix it using the nuts;
- connect and attach the electrical connection to the control unit following the order A, B, C, D, E, F;
- fit the shield and connect the battery terminal (-);
- carry out the control unit self-learning procedure.

CARRYING OUT THE SELF-LEARNING PROCEDURE FOR THE ENGINE CONTROL UNIT

NOTE During this procedure, from the moment the control panel is supplied to the end of the procedure, never press the accelerator pedal, the brake pedal or the clutch pedal.


Make sure that the ignition switch is in the OFF position;

Proceed as follows:


- connect the switch MPX 97 (1806365000) to the diagnostic socket;
- place the knob in position 3;
- connect the Examiner diagnostic equipment:
- turn the ignition switch to the ON position;
- wait for 60 seconds, the time required for the control unit to check the spring inside the butterfly casing and the butterfly minimum/maximum angular positions;
- place the ignition switch in the OFF position;
- wait for 15 seconds, the time required for the control unit to record the values learnt in the Eprom;
- using the Examiner, check that the idle self-learning procedure has been successfully completed.

NOTE If the self-learning procedure is not correct, turn the ignition switch to the OFF position and repeat the procedure described above.

If the problem persists, check that the diagnostic cable is correctly connected and check the operation of the instrument.







P3U45FX02

AIR FLOW METER

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- disconnect the battery terminal (-);
- proceed with removing the left front and left rear engine compartment side covers and the resonator;
- disconnect the electrical connection (1) from the butterfly casing;
- undo the nuts (2a);
- remove the brackets (2b) and the air flow meter (2c).

Proceed with the refitting, reversing the order of the operations carried out for the removal.

BUTTERFLY CASING INTEGRATED WITH D.V.L.

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.


Proceed as follows:


- disconnect the battery terminal (-);
- proceed with removing the left front and left rear engine compartment side covers and the hose between the resonator and the butterfly casing;
- disconnect the electrical connection (1) from the butterfly casing;
- undo the bolts (2a);
- remove the butterfly casing (2b) complete with seal.

Proceed with the refitting, reversing the order of the operations carried out for the removal.

NOTE When refitting, the butterfly casing learning procedure must be repeated.

45





COOLANT TEMPERATURE SENSOR

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF positino.

Proceed as follows:

- disconnect the battery terminal (-);
- proceed with removing the left front and left rear engine compartment side covers and the resonator;
- disconnect the electrical connection (1) from the coolant temperature sensor (2);
- undo and remove the sensor.

Proceed with the refitting, reversing the order of the operations carried out for the removal.

FUEL MANIFOLD COMPLETE WITH INJECTORS


Removing-refitting


NOTE Make sure that the ignition switch is in the OFF position.


Proceed as follows:

- disconnect the battery terminal (-);
- proceed with the removal of the inlet ducts;
- discharge the fuel pressure, acting on the breather valve (4);
- disconnect the fuel supply pipe (1) from the fuel manifold (3b);
- disconnect the electrical connections (2) from the injectors;
- undo the bolts (3a) and remove the fuel manifold complete with injectors (3c).

Proceed with the refitting, reversing the order of the operations carried out for the removal.







ENGINE SPEED SENSOR

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- position the vehicle on a lift;
- disconnect the battery terminal (-);
- raise the lift, then remove the protection/shield under the engine and the left exhaust pipe from the exhaust manifold;
- undo the bolts (arrow) and remove the lower engine flywheel protection (2);
- undo the bolts (1a) and remove the sensor
 (1b) from its housing;
- release the electrical wiring for the sensor from the fixings;
- disconnect the electrical connection (3) for the sensor, then remove it.

Proceed with the refitting, reversing the order of the operations carried out for the removal.


Checking the gap


If you wish to check the gap between the sensor and the flywheel, follow the instructions given below:

- measure the distance between the end of the sensor and the lower part of the sensor bracket (distance "a");
- measure the distance between the fitting dowel on the cylinder block/crankcase and the upper part of the tooth (distance "b"), repeating the measurement for at least two opposite teeth;
- The gap (t = b-a) should be between 0.8 and 1.5 mm.


The gap cannot be adjusted, therefore if the value measured is outside of the tolerance, check the condition of the sensor and the flywheel.

- 1. Sensor
- 2. Fitting dowel
- 3. Flywheel tooth





P3U48FX02



LAMBDA SENSOR

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- position the vehicle on a lift;
- disconnect the battery terminal (-);
- raise the lift, then disconnect the electrical connection (4) for the Lambda sensor and release the electrical wiring from the fixings;
- remove the protection under the engine;
- undo the bolts (1) fixing the catalytic converter to the exhaust pipes;
- release the catalytic converter (2) from the support seals:
- remove the protection (3a);
- undo the Lambda sensor (3b) and remove it.

Proceed with the refitting, reversing the order of the operations carried out for the removal.

CATALYTIC SILENCER


Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.


Proceed as follows:

- position the vehicle on a lift;
- disconnect the battery terminal (-);
- raise the lift, then remove the Lambda sen-
- sor following the instructions given above; undo the bolts (1a) fixing the catalytic converter (1b) to the intermediate exhaust silencer and remove it;
- then remove the gaskets.


Proceed with the refitting, reversing the order of the operations carried out for the removal.



P3U49FX01



P3U49FX02



P3U49FX03

ENGINE TIMING SENSOR

Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- disconnect the battery terminal (-);
- proceed with removing the left front and left rear engien compartment side covers and the hose between the resonator and the butterfly casing;
- disconnect the electrical connection (1) from the engine timing sensor and release the wiring from the fixing bands;
- undo the bolt (2a) and remove the sensor (2b).

Proceed with the refitting, reversing the order of the operations carried out for the removal.

LEFT CYLINDER HEAD IGNITION COILS

Removing-refitting


NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:


- disconnect the battery terminal (-);
- remove the left cylinder head ignition coil cover;
- disconnect the electrical connections (1) from the ignition coils;
- undo the bolts and remove the brackets (2) fixing the electrical wiring;
- undo the remaining fixing bolts (1a) and remove the ignition coils (1b).

Proceed with the refitting, reversing the order of the operations carried out for the removal.

49



P3U50FX01



RIGHT CYLINDER HEAD IGNITION COILS


Removing-refitting

NOTE Make sure that the ignition switch is in the OFF position.

Proceed as follows:

- disconnect the battery terminal (-);
- remove the sleeve between the resonator and the butterfly casing;
- remove the air chamber;
- disconnect the electrical connections (1) from the ignition coils;
- undo the bolts (2a) and remove the brackets (2b) fixing the electrical wiring;
- undo the remaining fixing bolts (1a) and remove the ignition coils (1b).

Proceed with the refitting, reversing the order of the operations carried out for the removal.




MULTI-PURPOSE VALVE

Removing-refitting


Proceed as follows:

- position the vehicle on a lift;
- remove the right rear wheel;
- raise the lift, then undo the bolts and remove the rear section of the right rear wheel arch liner;
- undo the bolts (1) fixing the fuel filler pipe to the bodyshell;



- remove the fuel filler cap (3);


- remove the spring (2) fixing the fuel filler
- release the latter from the housing, pressing inwards;




- disconnect the fuel vapour recirculation pipe (4) from the multi-purpose valve (5); remove the multi-purpose valve from the

fuel vapour separator.

Proceed with the refitting, reversing the order of the operations carried out for the removal.





ACTIVE CHARCOAL FILTER

Removing

Proceed as follows:

- position the vehicle on a lift:
- remove the right front wheel;
- raise the lift, then remove the right front additional wheel arch liner;
- disconnect the fuel vapour inlet and outlet pipes (1) for the active charcoal filter (2b);
- undo the bolt (2a) and remove the active charcoal filter after having released it from the solenoid valve.

Proceed with the refitting, reversing the order of the operations carried out for the removal.

CHARCOAL FILTER VALVE

Removing-refitting

Proceed as follows:

- position the vehicle on a lift;
- raise the lift, then proceed with removing the active charcoal filter as described previously;
- disconnect the electrical connection (1) from the solenoid valve;
- disconnect the pipes (2) and remove the solenoid valve.

Proceed with the refitting, reversing the order of the operations carried out for the removal.

Engine Index 10.

| pac | 0 |
|-----|---|
| | |

| | | | | | | 3,545,000 |
|-----|-------|-------|--------|-------|------|-----------|
| ODE | D A T | A A A | ~ ^ B! | 6 5 2 | 1116 | • I F |
| UPE | KAI | LUN | S ON | VE | THE | عالم |

| - Removing-refitting injectors | 1 |
|---|----|
| - Removing-refitting distribution manifold | 4 |
| - Removing-refitting heater plugs | 7 |
| - Removing-refitting pressure pump | 9 |
| - Checking supercharging pressure | 19 |
| - Removing-refitting accelerator ped- al potentiometer | 21 |
| - Adjusting accelerator pedal end of | 24 |


COPYRIGHT FIAT AUTO

The reproduction, even partial, of the text and illustrations is prohibited.

The information contained in this publication is purely indicative and could be out of date following modifications made by the Manufacturer, at any time, for technical or commercial reasons or in order to conform to legal requirements in the various countries.




Fiat Auto S.p.A. D.M.C. - M.P.S. Servizi Post Vendita - Tecnologie Assistenziali Largo Senatore G.Agnelli, 5 - 10040 Volvera - To (Italia) Publication no. 506.475/26 - Marzo 1999 - 400 Printed by Satiz S.p.A. - Turin (Italy) order no. 60446664




REMOVING-REFITTING INJECTORS

- Disable the alarm (if fitted), in the luggage compartment on the right side, and disconnect the negative battery lead.

1. Remove the upper engine protective cover.



2. Undo the two bolts shown in the diagram and move the rigid pipe between the E.G.R. valve and the solenoid valve aside.



3. Disconnect the fuel return pipe from the injectors working on the spring.


P3U01GJ04


Engine

Operations on vehicle


LANCIA K 198 range

10.











P3U02GJ03




- 1. Disconnect the electrical connections from the injectors and move the wiring aside undoing the two bolts as illustrated.
- 2. Undo the fixing nuts and position the oil filter at theside.
- 3. Disconnect the electrical connector from the excess pressure sensor.
- 4. Move the fuel return manifold aside.
- 5. Undo the injector side connectors for the pipes between the distribution manifold and the injectors.







P3U02GJ05



1. Move the oil vapour separator aside undoing the three fixing nuts.




2. Undo the manifold side connectors for the pipes between the distribution manifold and the injectors and remove them.




3. Undo the fixing nuts and carefully remove the injector bracket.


Use 1870739000 to remove the injectors.

NOTE When refitting carry out the operations described above in the reverse order, replacing the washers under the injectors and tighten the connectors for the pipes between the distribution manifold and the injectors to the recommended torque of 2 daNm.





P3U01GJ02




REMOVING - REFITTING DISTRIBUTION MANIFOLD




- Disable the alarm (if fitted), in the luggage compartment, right side, and disconnect the negative battery lead.
- 1. Remove the upper engine protective cover.







P3U02GJ03

- 2. Undo the two bolts shown in the diagram and move the rigid pipe between the E.G.R. valve and the solenoid valve aside.
- 3. Undo the fixing nuts and position the diesel filter at the side.
- 4. Disconnect the electrical connector from the excess pressure sensor.





P3U02GJ05







1. Move the return manifold aside.




2. Undo the injector side connectors for the pipes between the distribution manifold and the injectors.







4. Undo the manifold side connectors for the pipes between the distribution manifold and the injectors and remove them.



1. Remove the fuel supply pipe between the pressure pump and the distribution manifold.




2. Disconnect the electrical connection from the fuel pressure sensor.





3. Undo the remaining fixing nut illustrated in the diagram and carefully remove the distribution manifold.

NOTE To refit, reverse the order of the operations described above, tightening the connectors for the pipes between the distribution manifold and the injectors and the fuel supply pipe from the pressure pump to the recommended torque of 2 daNm.











P3U02GJ02




REMOVING-REFITTING HEATER PLUGS

- Disable the alarm (if fitted), in the luggage compartment, right side, and disconnect the negative battery lead.
- 1. Remove the upper engine protective cover.
- 2. Undo the two bolts shown in the diagram and move the rigid pipe between the E.G.R. valve and the solenoid valve aside.
- 3. Undo the fixing nuts and position the diesel filter to the side.








P3U02GJ03



1. Move the return manifold aside.









3. Disconnect the electrical connection, undo the fixing nut and remove the heater plugs using a suitable spanner.

NOTE To refit, carry out the operations described above in the reverse order.




REMOVING-REFITTING PRESSURE PUMP

- Disable the alarm (if fitted), in the luggage compartment, right side, and disconnect the negative battery lead.
- 1. Remove the upper engine protective cover.




2. Position the vehicle on a lift and remove the right front wheel.



P3U09GJ01


3. Remove the right side wheel arch liner.





iew of auxiliary shaft belt itted on vehicle:


- 1. Alternator
- 2. Power assisted steering pump
- 3. Fixed pulley
- 4. Air conditioning compressor pulley
- 5. Moving pulley
- 6. Crankshaft pulley
- 7. Automatic tensioning device






P3U10GJ04

- 1. Loosen the belt tensioner rotating the automatic tensioner nut (1) in an anti-clockwise direction.
- 2. Rotate the tensioner until the reference opning (3) in the actual tensioner corresponds with the opening (2) in the bracket; then insert tool 1870645000 to lock the tensioner in this position.
- 3. Loosen the tension of the moving pulley acting on the fixing bolt; then remove the auxiliary shaft drive belt.







P3U10GJ02




P3U10GJ03








P3U11GJ02



P3U11GJ03




1




After having removed the auxiliary shaft drive belt, proceed as follows:

- 1. Remove the lower engine shield and lock the flywheel using tool 1860898000.
- 2. Remove the auxiliary shaft drive pulley on the crankshaft (damper flywheel).
- 3. Remove the fixed idler pulley for the auxiliary shaft belt, to allow the subsequent removal of the timing belt lower shield.
- 4. Remove the lower shield for the timing drive belt and remove the flywheel lock.






1. Remove the oil pump fixing bolt; position the the pin for tool 1860905000 for deterimining T.D.C. in place of the bolt.






2. Position tool 1860905000 on the crankshaft drive gear and on the pin (3) fitted previously; rotate the crankshaft using small movements until the centering dowel (2) is aligned with the opening (4) in the tool. In this position cylinder n° 1 is correctly aligned at T.D.C.









3. Fix the tool 1860905000 to the crankshaft drive gear using the bolt shown.









P3U13GJ02




P3U13GJ03




- 1. Remove the reaction rod and the support, acting on the fixings shown in the diagram, to allow the subsequent removal of the timing belt upper shield.
- 2. Remove the upper timing belt shield.
- 3. Remove tool 1860905000 then loosen the timing belt tension acting on the nut shown in the diagram and remove the actual belt.
- 4. Lock the pressure pump pulley inserting two service bolts with an M6 thread in the openings and tightening the bolts on the pump mounting.







P3U14GJ02




P3U14GJ03



1. Undo the nut fixing the pressure pump pulley.

Remove the two bolts used for locking the pressure pump pulley.


2. Remove the pulley using tool 1860854000.




the fuel temperature sensor.

3. Disconnect the electrical connection from

4. Disconnect the electrical connection from the fuel pressure regulator on the pressure pump.






P3U02GJ04




- 1. Disconnect the following items from the fuel return manifold:
 - 1. the fuel return pipe from the injectors


 - 2. the return pipe from the pressure pump3. the fuel return pipe from the filter



- 3. Disconnect the fuel inlet pipe from the pressure pump.
- 4. Remove the fuel supply pipe from the pressure pump to the distribution manifold.
- 5. Remove the pressure pump.




P3U15GJ03



5

P3U15GJ02




Refitting

Reverse the order of the operations described above until the refitting of the pressure pump pulley. Then proceed with the refitting and tensioning of the timing belt and the auxiliary shaft drive belt.



The timing belt should always be replaced each time it is removed. Tighten the nut securing the pressure pump to a torque of 2.5 daNm and the connectors securing the fuel supply pipe between the pressure pumpand the distribution manifold to a torque of 2 daNm.




凹

Fitting and tensioning timing drive belt


- 1. Remove the bolt (1) fixing the oil pump; position the pin for tool 1860905000 for deteriming T.D.C. in place of the bolt.
- 2. Fit the timing drive belt on the crankshaft drive gear only. Position tool 1860905000 on the crankshaft drive gear and on the pin (3) fitted previously; rotate the crankshaft, using small movements, until the centering dowel (2) is aligned with the opening (4) in the tool. In this position cylinder n° 1 is exactly at T.D.C.






P3U12GJ04


3. Fix the tool 1860905000 to the crankshaft drive gear using the bolt shown and complete the refitting of the upper section of the belt.



Using a screwdriver, apply force to the automatic tensioner so that the tensioner is in the maximum tension position, then tighten the nut fixing the tensioner to the mounting. Release the crankshaft from tool 1860905000 and rotate it through two revolutions in its normal direction of rotation.



2 Loosen the nut fixing the tensioner (3) and, using a screwdriver for leverage in order not to completely discharge the tensioner, ensure that the moving reference (1) on the tensioner coincides with the fixed reference (2), then tighten the tensioner (3) fixing nut to a torque of 2.5 daNm.




Refitting and tensioning the auxiliary shaft belt

2. Fit the belt suitably reversing the order of the operations described for the removal. The tensioning is carried out by positioning tools 1860826000 and 1860825000 on the (not locked) moving pulley by the special openings; rotate the lever obtained in this way in an anti-clockwise direction until it is possible to easily remove pin 1860830000. Lock the bolt (3) fixing the moving tensioner in this position. The automatic tensioner pre-loaded spring will ensure that the belt is correctly tensioned.

P3U17GJ03

Timing belt fitting order




 \bigwedge

The position for the two timing references on the crankshaft pulley and the tappet cover is illustrated.

The belt should be fitted observing the following order:

- crankshaft drive gear (1);
- fixed pulley (2);
- camshaft pulley (3);
- injection pump pulley (4);
- automatic tensioner pulley (5);
- water pump pulley (6).


NOTE The belt should be fitted taking care to ensure there is no bending or sharp angles which would adversely affect the structure of the actual belt.



CHECKING SUPERCHARGING PRESSURE


1. Fit tool 1870737000 between the air hose and the inlet manifold.





2. Wire the pressure transducer as illustrated in the diagram.





3. Connect the pressure transducer to tool 1870737000

Place the Examiner diagnostic equipment in the passenger compartment and connect it to the pressure transducer.


P3U19GJ03

Engine

Operations on vehicle


10.

- Select "pressure gauge" on the Examiner/SDC and prepare it for the acquisition of data in the "intake pressure" mode with an end of scale of 2000 mmHg and time setting of 10 seconds
- Road test the vehicle (adhering to the speed limits in force) as follows:
- With motorway conditions available, let the vehicle reach 2500 rpm in 4th gear.
- Start the graphic acquisition by pressing "start" on the diagnostic equipment and after about 2 seconds fully depress the accelerator pedal until 3500 rpm is reached.
- Having reached this speed, completely release the accelerator pedal.
- 1. Display the resulting graph and in the pressure section (1), excluding the initial peak, the reading should be 1900 2800 mbar (1444 1581 mmHg) corresponding to a supercharging pressure of 900 1080 mbar.




P3U20GJ01


- During an extra-urban journey at various speeds, let the vehicle reach 2500 rpm in 3rd gear.
- Start the graphic acquisition by pressing "start" on the diagnostic equipment and after about 2 seconds fully depress the accelerator pedal until 3500 rpm is reached.
- Having reached this speed, completely release the accelerator pedal.
- 2. Display the resulting graph and, in the pressure section (2), excluding the initial peak, the reading should be 1900 2080 mbar (1444 1581 mmHg) corresponding to a supercharging pressure of 900 1080 mbar.




P3U20GJ02








P3U21GJ03




P3U21GJ04



REMOVING - REFITTING ACCELERATOR PEDAL POTENTIOMETER

- Disable the alarm (if fitted) housed in the luggage compartment, right side and disconnect the negative battery lead.
- 1. Undo the two buttons and the fixing nut and remove the driver's side floor mat.
- 2. Undo the fixing bolts and remove the protection for the fuse box.
- 3. Disconnect the electrical connection for the pedals courtesy light.
- 4. Cut the band and remove the plastic shield for the clutch pump.
- 5. Undo the clutch pump outlet connector taking care to prevent any fluid from escaping.




P3U21GJ05


Engine


Operations on vehicle

LANCIA K 1990 JTD 98 range

10.













- 1. Remove the band and remove the clutch pump fluid inlet pipe.
- 2. Remove the circlip and remove the pin connecting the clutch pump to the pedal.
- 3. Undo the fixing nuts and remove the clutch pump.
- 4. Undo the bolts fixing the pedals assembly to the brake servo.
- 5. Disconnect the electrical connector for the accelerator potentiometer.










P3U23GJ02





- 1. Remove the pedals assembly from the mounting bracket and disconnect the electrical connector for the brake pedal switch and for the clutch pedal switch.
- 2. At the bench, remove the potentiometer idler rod.
- 3. Undo the fixing bolts and remove the accelerator potentiometer.



Refitting

Fit the potentiometer in its housing, tighten the fixing bolts (1) and connect the linkage.


Rest the assembly on a reference plane as illustrated in the diagram and measure 208.4 millimetres from the plane to the rivet connecting the pedal to the lever.

With the pedal in this position, tighten the bolt (1) fixing the accelerator potentiometer.

Reattach the pedals assembly, reversing the order of the operations described for the removal.



Bleed the system




P3U23GJ04

98 range

10.

ADJUSTING ACCELERATOR PEDAL END OF TRAVEL



Connect the diagnostic equipment to the socket inside the vehicle.

With the pedal in the end of travel position, check that the voltage readings on the instrument correspond to the figures in the table.


Accelerator position in minimum position

| v | V% |
|------------|---------|
| 0,4 ± 0,05 | 8 ± 1 % |

Accelerator position in maximum position

| V | V% |
|-------------|-------------|
| 3,9 +0/-0,2 | 78 + 0%/-4% |

The voltage readings are only valid with a supply voltage of 5V, as this voltage varies the percentage readings on the diagnostic equipment should be considered.



1. To correct the voltage values with the accelerator in the maximum position, requlate the adjustment device and repeat the procedure using the diagnostic equipment.

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|--------------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| | | | |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |



| 2 | 1 |
|---|---|
| ດ | 7 |

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|-----------------------------|--|-----------------------------|
| | | | |
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| | | | |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|-----------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | СССССС | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|-----------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |



| \mathbf{a} | \sim |
|--------------|--------|
| •, | •, |
| | - 5 |
| | |
| • | |

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|--------------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | СССТСН | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT | ELECTRICAL | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| ELECTRIQUE | EQUIPMENT | ANDAGE | ELETTRICO |



| 41 |
|----|
| |

| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|-----------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |



| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|--------------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | CLUTCH | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |



| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|--------------------------------|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | СССТСН | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |

LANCIA k

98 range

Auxiliary units Index

50.

page

| AUTOMATIC CLIMATE CONTROL SYSTEM | |
|--|--|
| INTRODUCTION | 1 |
| GENERAL DESCRIPTION OF CLI- MATE CONTROL SYSTEM COMPO- NENTS | 3 |
| Drier filter Four stage pressure switch Expansion valve Evaporator Condenser Inside air temperature sensor Outside air temperature sensor Mixed air temperature sensor Solar ray sensor Compressor Evaporator/heater unit Combination filter element | 3 3 4 5 5 6 6 7 7 7 8 8 |
| CLIMATE CONTROL SYSTEM CONTROLS | 9 |
| CLIMA button TEMP buttons AUTO button OFF button RECIRCULATION button ECON function ECON button FAN speed buttons VENT, BILEV, FLOOR air distribution buttons WINDSCREEN demisting button Air flow rate Engaging compressor HI condition LO condition | 99 99 10 10 13 13 14 16 16 17 |
| OUTSIDE TEMPERATURE CALCULATION | 17 |
| - Speedometer signal | 17 |
| AIR DISTRIBUTION DIAGRAM | 19 |



For anything not dealt with, refer to section 50 Auxiliary Units in the previous edition (Print no. 506.475/01).

COPYRIGHT by Fiat Auto S.p.A.

Total or partial reproduction of the text or illustrations is forbidden.

The information in this publication is intended as a guide and could be superseded as a result of modifications adopted by the Manufacturer at any time due to technical and commercial reasons and in accordance with local regulations.

Fiat Auto S.p.A.

D.M.C. – M.D.S.
Servizi la Cliente – Post vendita
Largo Senatore G. Agnelli, 5 – 10040 Volvera – To – (Italia)
Print no. 506.475/25 – Marzo 1999 – 400
Printed by Satiz S.p.A. – Turin (Italy)
order n° *604.46.450*


INTRODUCTION

The automatic climate control system can, ideally, be divided into two parts.

The first part consists of a closed circuit system (shown in the diagram below) which produces cold air and mainly uses the following components:

- a compressor;
- a condenser, which is fitted in front of the engine coolant radiator;
- an evaporator, which is located in the evaporator/heater unit;
- a drier filter.

The second part of the system consists of a closed circuit, which uses the engine coolant to produce hot air.




P3U01BH01

Climate control system diagram

- 1. Compressor
- 2. Condenser
- 3. Drier filter
- 4. Expansion valve
- 5. Evaporator fan
- 6. Evaporator

- 7. Evaporator heater
- 8. Condenser fan
- 9. 4 stage pressure switch
- A. Water inlet
- B. Water outlet

50.




P3U02BH01

Diagram showing climate control system in the vehicle


- 1. Compressor
- 2. Condenser
- 3. Drier filter
- 4. Expansion valve
- 5. Evaporator
- 6. Solar ray sensor
- 7. Passenger comp. interior air temp. sensor
- 8. Passenger comp. exterior air temp. sensor
- 9. Mixed air temperature sensor
- 10. Pressurizing valve
- 11. Exhaust valve
- 12. 4 stage pressure switch
- 13. Combination filter element

GENERAL DESCRIPTION OF THE CLIMATE CONTROL SYSTEM COMPONENTS



P3U03BH01

- 1. Filter body
- 2. Filter
- Drier pack
 Outlet union



P3U03BH02

DRIER FILTER

The drier filter, fitted between the condenser and the expansion valve, performs three basic functions:

- it acts as an accumulator for the coolant fluid
- it acts as a filter element
- it acts as a drier element.

The filter accumulates a large part of the coolant (in a liquid state) and acts as a separator between the coolant in a liquid state and a gaseous state.

Humidity in the system can be extremely damaging because, if it comes into contact with the coolant fluid, it produces hydrochloric and fluorochloric acid which corrodes the components which then deteriorate.

Humidity can also result in the formation of ice in the system expansion valve.

There are special substances (SILICAGEL and activated aluminium) inside the drier filter which retain the humidity present in the coolant fluid.

For this reason the drier filters must be kept in a dry environment and sealed until the moment of fitting.

4 STAGE PRESSURE SWITCH

The four stage pressure switch has the task of separately operating the two speed levels of the radiator and condenser cooling fans when the vehicle is stationary or travelling at low speeds and the flow of air produced by the movement of the vehicle starts to fail.


The condensation of the coolant must be activated through forced ventilation.

In addition, it has the task of disconnecting the compressor pulley electro-magnet coupling, when the pressure of the fluid (high pressure side) reaches dangerous limits (28 \pm 2 bar), in spite of the action of the radiator and condenser cooling fan.

When the pressure is below 2.45 bar and the outside temperature is below 5°C, the thermal pressurizing conditions are insufficient to cause the evaporation of the coolant.

Calibration values (bar)

| Level | Opens | Closes | Differential |
|-------|-------------|----------|--------------|
| 1° | 2,45 ± 0,35 | 3,5 max | |
| 2° | | 15 ± 1 | 4 ± 1 |
| 3° | | 20 ± 1,2 | 4 ± 1 |
| 4° | 28 ± 2 | | 6 ± 2 |



P3U04BH01

- 1. Evaporator outlet fluid duct
- 2. Thermo-sensitive element
- 3. To the compressor inlet connector
- 4. Fluid under pressure
- 5. Opposing spring
- 6. Ball and calibrated port
- 7. Expanded fluid (to the evaporator inlet connector)
- 8. Expansion valve body
- 9. Rod
- C. To the compressor
- F. To the drier filter
- Ei. Evaporator inlet
- Eu. Evaporator outlet

EXPANSION VALVE

The expansion valve controls the flow of fluid to the evaporator so that the power of the coolant in the system is maximum, adjusting the flow rate and the pressure of the coolant according to the different compressor rotation speeds.

This type of valve has two different areas through which the coolant flows:

- one lower one, from the drier filter 4 to the evaporator 7, contains the overheating spring 5 and the modulating element which, in this case, is the ball 6 housed in the calibrated duct.
- one upper one, from the evaporator 1 to the compressor 3, containing the thermostatic sensor 2 which is connected to the upper part of the diaphragm and the ball 6.

This valve carries out three different functions in the system:

- controlling the coolant flow rate
- stabilizing the evaporation temperature;
- controlling overheating.

The flow rate control function is carried out through the movement of the ball 6, connected via the rod 9 to the thermostatic sensor 2. The action of the ball is opposed by the spring 5.


The position of the ball 6 depends on the difference in pressure acting the diaphragm inside the sensor 2; this, in turn, depends on the temperature of the coolant coming out of the evaporator.

High evaporator 1 outlet temperatures (corresponding to conditions where large quantities of heat are dissipated) cause an increase in the pressure inside the thermostatic sensor 2; this leads to the movement of the rod 9 and the ball 6 connected to it, which increases the size of the area through which it flows and consequently the system flow rate.

A low evaporator 1 outlet temperature (corresponding to conditions where the heat dissipitation is low) create a restricted area for the calibrated port 6 reducing the system flow rate.

The calibrated port also "atomizes" the fluid in a liquid state, to facilitate subsequent evaporation. The function of stabilizing the evaporation pressure, according to the difference in temperature, between the evaporator inlet and outlet, is carried out as follows: the lower part of the diaphgram is sensitive to the temperature of the coolant at the evaporator inlet, thanks to a duct which joins it to the valve outlet, Downstream of the calibrated port whilst the upper part is sensitive to the temperature at the evaporator outlet. The variations in pressure between the evaporator inlet and outlet, lead to variations in temperature which act in the opposite direction to the rod 9 and the ball 6 connected to it (contributing to damping the oscillations).

The control of the overheating is ensured by the spring 5, which is suitably calibrated to allow smooth operation when there is a rise in the pre-set temperature. This rise in temperature (overheating) ensures that the fluid at the evaporator is in a vapour state, without the presence of any fluid which, if drawn in by the compressor, could damage the valves.



P3U05BH01

EVAPORATOR


The evaporator is fitted inside the passenger compartment in the evaporator/heater assembly.

The expansion stage takes place inside the evaporator with the consequent evaporation of the fluid, which causes a rapid decrease in temperature.

The evaporator is therefore a heat exchanger with the function of cooling the air which comes into contact with it.

The ambient air to be conditioned for the passenger compartment is forced to pass through the heat pack by means of an electric fan; it is therefore cooled and dehumidified because the vapour condenses on the surface of the coils and is then discharged outwards through a pipe.

The system is designed to run with the windows of the vehicle closed.



CONDENSER

The condenser, fitted in front of the engine radiator, is designed to give off a certain amount of heat with the consequent change of the R134A coolant from a gaseous state to a liquid state (temperature of 60 °C).

It consists of an aluminium radiator with a high thermal efficiency level, cooled by the air from the dynamic ventilation produced through the electric fan and the movement of the vehicle.

An insufficient heat exchange in the condenser, in addition to producing an increase in the pressure in the system, results in the incomplete condensation of the R134A, therefore fluid still in a gaseous state will reach the expansion valve, considerably reducing the cooling capacity of the system.


P3U05BH02

In certain driving conditions (traffic jams or uphill) and at high outside temperatures, the coolant fluid may not manage to liquefy completely; therefore, in addition to the existing engine cooling radiator switch, there is a pressure switch designed to engage the electric fan, independently of the engine coolant temperature command.


Auxiliary unitsAutomatic climate control system

98 range

50.



P3U06BH01



INSIDE AIR TEMPERATURE SENSOR

This sensor is located between the steering column and the INFOCENTER control unit. It is fitted on an inlet so that the temperature reading for the air inside the passenger compartment is as reliable as possible.

It is an "NTC" type sensor with a resistance of 2.2 kOhm at 25°C; its operating temperarture ranges from a minimum of -30°C to a maximum of +85°C.


| Temperature (C°) | Resistance (Ohm) | | | |
|------------------|------------------|--|--|--|
| -15 | 15982 | | | |
| -10 | 12154 | | | |
| 0 | 7200 | | | |
| +10 | 4393 | | | |
| +20 | 2753 | | | |
| +30 | 1768 | | | |
| +40 | 1161 | | | |

OUTSIDE AIR TEMPERATURE SENSOR (D)

This sensor is fitted below the left external rear view mirror, as shown in the diagram. It is an "NTC" type sensor with a nominal value of 10 kOhm at 25°C.

| Temperature (C°) | Resistance (Ohm) | | | | |
|------------------|------------------|--|--|--|--|
| -20 | 100000 | | | | |
| -10 | 55000 | | | | |
| 0 | 32650 | | | | |
| +10 | 20000 12500 | | | | |
| +20 | | | | | |
| +30 | 8000 | | | | |
| +40 | 5000 | | | | |

- A. Overturned
- B. Vertical
- C. Horizontal
- D. Outside temperature sensor
- E. Defrosting





MIXED AIR TEMPERATURE SENSORS

In order to ensure an optimum temperature reading, two sensors have been used whose only difference is their colour.

Sensor (1) gives a reading for the air directed to the lower vents, whilst sensor (2) gives a reading for the air directed to the upper vents. If an air distribution is selected which includes both solutions, the INFOCENTER takes an average of the temperature readings for the two sensors.

The sensors in question are the "NTC" type with a resistance of 10 KOhm at 25°C; their operating temperatures range from a minimum of -20°C to a maximum of +90°C.

| Temperature (C°) | Resistance (Ohm) |
|------------------|------------------|
| -5 | 42326 |
| 0 | 32650 |
| +10 | 19899 |
| +20 | 12492 |
| +30 | 8057 |

SOLAR RAY SENSOR

The solar ray sensor is located in the dashboard, near the windscreen. It is the photodiode type.



There are two types of compressor used in this climate control system, namely:

- NIPPONDENSO 7SB
- SANDEN SD 7 V 16.

P3U07BH02

98 range

50.


EVAPORATOR/HEATER UNIT

The system should automatically regulate the following parameters and functions: air temperature at the vents, fan speed, air distribution, recirculation, engagement of the compressor.

There is provision in the system for the manual adjustment of the following parameters and functions: fan speed in 5 positions, air distribution in 4 positions (5 in automatic), recirculation, engagement of the compressor.

The manual manoeuvres take priority over the automatic operation and are memorized until the user cancels the command and restores the automatic operation of the function.

By manually varying one of the parameters, the other remain controlled automatically. The temperature of the air at the vents is always controlled automatically to ensure that the temp. inside the passenger compartment corresponds to the one indicated on the display (except if the system is switched off). As described previously, the climate control system is integrated with the INFOCENTER system which is analyzed, in detail, in Section 55 - Electrical equipment.



P3U08BH01


- 1. Mixture actuator
- 2. Recirculation actuator
- 3. Distribution actuator

COMBINATION FILTER ELEMENT


The air introduced in the passenger compartment from the outside passes through a combination filter, composed of two layers:

the first "particle" layer is designed to trap the small particles of fine dust and pollen. the second "activated charcoal" layer retains several pollutant agents (odours) present in the atmosphere.


CLIMATE CONTROL SYSTEM CONTROLS



PRIMARH



P3U09BH02



The controls which allow the use of the automatic climate control system are located in the INFOCENTER system which is in the centre of the dashboard.

CLIMA DATE button

This is for gaining access in the INFOCENTER system to the climate control function.

TEMP buttons

By using the TEMP buttons the user can select the temperature for the passenger compartment in a 15 °C range (from 18 °C to 32 °C). The temperature reading appears on the display, however long the buttons are pressed for.

If the user sets a temperature above 32 °C (90 °F), the HI condition occurs (see HI button), accompanied by the disappearance of the words FULL AUTO and the appearance of the word AUTO. This condition involves the following situations:

- mixture flap stuck in maximum hot position:

 FLOOR distribution (unless the user makes a different selection or there is a different period of time between starting up the engine and the optimum temperature being reached, also known as starting transition)

 compressor managed by the system logic, unless the user makes a different selection;

 air flow rate equal to 300 m/h, unless the user makes a different selection, or a setting of 80 m/h for the starting transition;

- recirculation switched off.

The exit from this situation only takes place by altering the requested temperature.


AUTO button

By pressing the AUTO button the system automatically checks the temperature, the distribution, the fan speed and the engagement of the recirculation.


When the system is in this situation the words FULL AUTO appear on the display.

Automatic climate control system


50.



P3U10BH01



P3U10BH02



P3U10BH03

Passenger compartment air exchange logic (only with treated temperature above 3°C)

OFF button

When the OFF button is pressed the system switches off (if it is on) or switches on (if it is off). When this button is operated the messages on the display relating to the operation of the climate control should go out, with only the recirculation remaining on.

RECIRCULATION button ()

Pressing the recirculation button switches on that function and the appropriate symbol appears on the display. If there are no manual operations, the recirculation is controlled automatically (through a special actuator). This takes place according to the outside temperature when it is above 26 °C and also the treated (or mixed) temperature.


Under these circumstances, a special automatic cycle is activated for the management of the recirculation. It consists of switching on the recirculation function for 7 minutes (complete exclusion of flow of air from the outside) during which the recirculation symbol appears on the display. When the above mentioned period has elapsed, the system opens the recirculation flap for 32 seconds to allow the exchange of air inside the vehicle. During this operation the symbol disappears from the display. When the 32 seconds have elapsed, the recirculation flap closes for another 7 minutes and the symbol reappears on the display and the cycle is repeated below 26 °C or the recirculation button is pressed manually.

NOTE With the engine running (immediately after starting), if the outside temperature conditions are equal to or above 26 °C (condition for the recirculation to be automatically switched on), this function is not enabled until the inside temperature


value set by the user stabilizes.


Auxiliary units Automatic climate control system

50.




P3U11BH01






P3U11BH02


If the recirculation button is pressed when the recirculation is switched on, the words FULL AUTO disappear from the display and the recirculation symbol appears. The recirculation function remains on permanently.




P3U11BH03

If the recirculation button is pressed again the symbol disappears from the display and the recirculation function remains off permanently.





P3U12BH02




P3U12BH03

If the recirculation button is pressed for a third time, the initial automatic recirculation control function is returned to. The words FULL AUTO reappear on the display and the cyclical operation of 7 mins and 32 secs is restored.


There are other possible situations with the temperature below 26 °C:

- 1. During the phase when the INFOCENTER control unit is working in FULL AUTO conditions and the RECIRCULATION function is engaged, if the button () is pressed, the air vents open and will no longer be controlled by the control unit. The word AUTO will appear on the display and the recirculation symbol will disappear.
- 2. In the the phase in which the control unit is working in FULL AUTO conditions, but not in the RECIRCULATION stage (i.e. with the outside air vents open), if the button () is pressed, the words FULL AUTO will disappear and the word AUTO will appear together with the recirculation symbol.




P3U12BH04


98 range



P3U13BH01



P3U13BH02



P3U13BH03

Behaviour of the recirculation with the ECON button switched on

When the system is working in ECON conditions, the RECIRCULATION function can only be switched on manually.

When the ECON button is pressed, the climate control is in the position with the timed opening of the outside air intake vents and hte moment they are opened, the symbol disappears from the display.

If the button is pressed for a second time, this function is eliminated and the control unit takes control of the climate control system.

ECON button

When the ECON button is pressed the compressor is excluded and the words AUTO ECON appear on the display.

Once the button is pressed, the function is memorized for an indefinite period, even after the vehicle stops, like other manual commands.

If the button is pressed again, it cancels the function and the control of both the compressor and the other parameters linked to the ECON returns to automatic.


The movement the ECON button is pressed, the system checks whether the outside temperature is higher than or lower than the requested temperature.

There are two possible situations:

- **A.** If the outside temperature is below the requested temperature, then the system works normally and is capable of meeting the requirements without switching on the compressor.
- **B.** If the outside temperature is higher than the inside temperature, then the system is not capable of decreasing the temperature in the passenger compartment.

This situation is shown on the INFOCENTER display by the flashing of the word ECON, for about 10 seconds.

This flashing situation is memorized and each time the car is started up or the inside temperature is altered to be lower than or equal to the outside temperature or the AUTO condition is reached it will appear on the display. If the TEMP button is pressed, the user can increase or decrease the temperature by 1 °C. Taking the outside temperature as greater than that requested, the word ECON will appear on the display, flashing and later constantly.



P3U14BH01

FAN speed buttons


Pressing the AIR buttons changes the air flow rate which is shown by a bar-graph (consisting of 5 bars) and the word AUTO will appear on the display. If there is no manual intervention, the speed is controlled by the logic and the words FULL AUTO appear on the display.

It is possible to operate the AIR button manually to increase (right button) or decrease (left button) the flow rate; in the latter case, with the compressor switched on, the fan is always activated (minimum one bar), whilst the ECON button remains off.


VENT (∜), BILEV (∜), FLOOR (∜) air distribution buttons

Pressing the VENT, BILEV, FLOOR buttons alters the distribution of the air and the symbols plus the word AUTO will appear on the display

A. If the VENT button is pressed, the symbol will appear on the display and the air will be directed to the centre of the dashboard.





P3U14BH02



P3U14BH03


B. If the BILEV button is pressed, the symbol (*/) comes on in the display and the air is directed to the lower-central part of the dashboard.






P3U15BH02

C. If the FLOOR button is pressed, the symbol (v/) comes on in the display and the air is directed to the lower part of the dashboard.







P3U15BH04

During the winter temperature increase stage, until the treated air at the vents reaches a temperature above 21 °C, the system operates with the fan at the first speed.


Copyright by Fiat Auto 15



P3U16BH01



P3U16BH02



P3U16BH03

Button for demisting the windscreen (viii)

This function is only switched on automatically during the temperarture increase stage until the temperature of the air at the vents is above 21 °C.

In all other cases the function can only be switched on manually and is accompanied by the appearance of the symbol and the word AUTO.

Air flow rate

If the AIR buttons are operated the change in the air flow rate should be displayed through the bar-graph and the appearance of the word AUTO.

If there is no manual intevention, the speed will be controlled continuously by the INFO-CENTER logic and the words FULL AUTO will appear on the display.

With the compressor switched on, the minimum speed which can be set manually will correspond to one bar lit up in order to prevent the compressor from freezing.

Switching on the compressor

The INFOCENTER sends a signal to the Bosch MOTRONIC electronic control unit to activate the compressor. The engagement of the compressor, apart from the 4 stage pressure switch, depends on the outside temperature (A) in accordance with the law illustrated.




With outside temperatures between 5 and 7 °C, the logic should switch on the compressor, on condition that the OFF and ECON buttons are not switched on.


If the recirculation has been switched on manually, the compressor will remain switched on until the outside temperature reaches -5 °C.

Auxiliary units


Automatic climate control system



P3U17BH01



P3U17BH02



HI condition

If the user sets a temperature above 32 °C (90 °F), the HI condition ensues, i.e. maximum heating. This will appear on the display accompanied by the word AUTO.

This situation leads to the following consequences:

- mixture flap stuck in "completely hot" po-
- distribution flap in FLOOR position, unless the user makes a different selection or the distribution setting is at DEF;
- compressor managed by the logic, unless the user has made a different selection;
- air flow rate equal to 300 m³/h, unless there is a different selection or a setting of 80 m³/h:
- recirculation switched off.

The exit from this state only takes place by decreasing the temperature.

LO condition

If the user sets a temperature below 18 °C (64) °F) then the LO condition ensues, i.e. maximum cooling. This word appears on the display accompanied by AUTO. This situation leads to the following consequences:

- mixture flap stuck in the maximum cold position;
- distribution positioned at VENT, unless the user has made a different selection;
- air flow rate equal to 400 m³/h, unless the user has made a different selection:
- compressor managed by the logic, unless the user has made a different selection;
- recirculation on without reopening.

The exit from this state can only take place by increasing the requested temperature.

CALCULATION OF THE OUTSIDE **TEMPERATURE**

Speedometer signal

This signal arrives from the multiple instrument and is a signal processed by the INFO-CENTER for calculating the temperature according to the speed of the vehicle.



The impulse generator is based on a HALL effect sensor, with 4 impulses/ revolution (equal to 4 impulses/metre) operating at ambient temperature, 14V and 3000 rpm.

The value of the outside temperature at which the system operates is selected each second from the value memorized and the value detected, according to the forward speed and the time, in accordance with a logic in the control unit.


In other words, with the ignition switched on, the control unit takes into account the outside temperature value which the sensor measures and compares it with the last temperature memorized before the ignition was switched OFF.

If the outside temperature is below the figure memorized previously, the control unit replaces the latter value with the one in its memory; if it is higher, it is not updated.

With the vehicle moving, the outside temperature value is updated also using the signal from the instrument panel speedometer; this signal is considered according to a threshold figure of 30 km/h.

If the vehicle speed does not exceed 30 km/h, the value of the outside air temperature is only updated if it decreases in relation to the value memorized previously the moment the ignition was switched ON.

If the vehicle exceeds 30 km/h for at least one minute, then the value of the outside air temperature is replaced by the one memorized previously, both if it has increased or decreased.




P3U18BH01

| CONNECTOR | SIGNAL ARRIVING | | |
|-----------|---------------------|--|--|
| A | Earths and supplies | | |
| В | Faules and wear | | |
| С | Faults | | |
| D | Climate control | | |
| E | Various signals | | |
| F | Fault diagnosis | | |

AIR DISTRIBUTION DIAGRAM

The air is drawn in by the electric fan (2) through the air intakes according to the position of the recirculation flap (1); (B) indicates an air flow from the outside and (A) an air flow from the interior of the vehicle.


The air passes through the evaporator (3) and reaches the mixing area where the mixture flap (4), depending on the position it is in, directs the air directly to either the distribution or the heater radiator (5). Lastly, the mixed air is directed, according to the position of the distribution flatp (6), either to the demisting (C) or the ventilation (D) or the floor (E).



P3U19BH01

- 1. Recirculation flap
- 2. Electric fan
- 3. Evaporator
- 4. Mixture flap
- 5. Heater radiator
- 6. Distribution flap
- 7. Combination filter (not prevent on versions with heaters)
- A. Passenger compartment interior air flow (recirculation
- B. Outside air flow
- C. Windscreen air flow
- D. Centre, front, side vents air flow
- E. Lower and rear vents air flow

Copyright by Fiat Auto



| GENERALITES CARACTERISTIQUES TECHNIQUES | INTRODUCTION TECHNICAL DATA | ALLGEMEINES TECHNISCHE DATEN | GENERALITÀ DATI TECNICI |
|---|---|--|--|
| MOTEUR | ENGINE | MOTOR | MOTORE |
| EMBRAYAGE | ССССССССССССССССССССССССССССССССССССССС | KUPPLUNG | FRIZIONE |
| BOITE DE VITESSES DIFFERENTIEL | GEARBOX DIFFERENTIAL | SCHALTGETRIEBE AUS- GLEICHGETRIEBE | CAMBIO DI VELOCITÀ DIFFERENZIALE |
| ARBRE DE TRANSMISSION | PROPELLER SHAFT | GELENKWELLE | ALBERO DI TRASMISSIONE |
| DIFFERENTIEL ARRIERE | REAR DIFFERENTIAL | HINTERES AUS- GLEICHGETRIEBE | DIFFERENZIALE POSTERIORE |
| FREINS | BRAKING SYSTEM | BREMSEN | FRENI |
| DIRECTION | STEERING | LENKUNG | STERZO |
| SUSPENSIONS ET ROUES | SUSPENSION AND WHEELS | AUFHÄNGUNGEN UND RÄDER | SOSPENSIONI E RUOTE |
| ORGANES SUBSIDIAIRES | AUXILIARY UNITS | ZUSATZ- EINRICHTUNGEN | ORGANI SUSSIDIARI |
| EQUIPEMENT ELECTRIQUE | ELECTRICAL EQUIPMENT | ELEKTRISCHE ANLAGE | IMPIANTO ELETTRICO |
| CARROSSERIE | BODYWORK | CAROSSERIE | CARROZZERIA |





Electrical equipment

Index

55.

page

Removing-refitting alternator

COPYRIGHT by Fiat Auto S.p.A.

Any reproduction of the text or illustrations is prohibited.


The information contained in this publication is supplied as a guide and may no longer be up to date as a result of modifications made by the Manufacturer, at any time, for reasons of a technical or commercial nature in addition to meet legal requirements in different countries.



Direzione Qualità
Assistenza Tecnica
Largo Senatore G. Agnelli, 5 – 10040 Volvera – To – (Italia)
Print n° 506.475/30 – V 2000 – 400
Printed by Satiz S.p.A. – Turin (Italy)
order n° *604.47.413*


Recharging

REMOVING - REFITTING ALTERNATOR






- Disable the alarm (if fitted) and disconnect the negative battery lead.
- 1. Position the vehicle on a lift and remove the right front wheel.




- 2. Undo the bolts and remove the complete right wheel arch liner (1a).
- 3. Working on the automatic tensioner (1a), remove the auxiliary shaft drive belt (1b) from the alternator pulley.
- 4. Undo the fixing bolt (1a) and remove the fixed tensioner (1b).





3U001QL02




3U001QL04

Electrical equipment

Recharging


LANCIA K 99 update

55.





- Remove the shield under the engine.
- Position a suitable container for collecting the oil.
- 1. Use tool 1860758000 to remove the oil filter (1a).




2. Open the plastic protection (1a) for the alternator electrical connections.


Configuration A: vehicles up to chassis n° 2108250

Configuration B: vehicles up to chassis n^* 2108251

3. Undo the fixing nuts (1a) and disconnect the cables (1b) and (1c), for alternator terminals B+ and D+, respectively.




3U002QL03





- 1. Undo the bolts (1a) fixing the alternator to the mounting brakeet (1b).
- Release the alternator from its housing and remove it.




Refitting

- 2. Position the bushes (1a) and (1b) in line with the alternator fixing tabs (1c).
- Fit the alternator and tighten the fixing bolts to the mounting bracket.



Alternator fixing bolts: 2.5 daNm

3. Connect the cables (1a) and (1b) to the alternator terminals B+ and D+, respectively so that the terminal (1c) for cable (1a), connected to terminal B+, is positioned vertically on the alternator cover, towards terminal D+ for configuration A; and is facing downwards for configuration B, as illustrated in the diagram. Then secure the cable terminals using the nuts (1d).



3U003QL03


Electrical equipment

Recharging

LANCIA K 99 update

55.

1. Fit the protective cover (1a) for terminal B+, for configuration A, and he cover for both terminals B+ and D+, for configuration B. Make sure that the protection is correctly closed and that the alternator cables are in the correct position, shown in the diagram.



- Fit a new oil filter; lubricate the gasket, tighten by hand to a torque of 1.5 daNm (i.e. tighten by a further \(^3\) of a turn).
- Fit the shield under the engine.
- Fit the fixed tensioner and tighten the fixing bolt
- Fit the engine components drive belt (services belt).
- Fit the complete wheel arch and secure it using the bolts.
- Fit the right front wheel and tighten the bolts to a torque of 9.8 daNm.
- Remove the vehicle from the lift and check/top up the engine oil level.
- Reset the alarm (if fitted).
- Connect the negative battery lead.

LANCIA k 98 update

Electrical equipment

Wiring diagrams

55.

45

| | | | | page |
|--------------------|----|------|-----|------|
| Electrical symbols | | | | 1 |
| Explanation of how | to | read | the | |
| wiring diagrams | | | | 4 |
| Wiring diagrams | | | | - 5 |

Components key



For anything not deal with, see the 98 range wiring diagrams in the 4th volume manual

COPYRIGHT by Fiat Auto S.p.A.

Total or partial reproduction of the text or illustrations is forbidden.

The information in this publication is intended as a guide and could be superseded as a result of modifications adopted by the Manufacturer at any time due to technical and commercial reasons and in accordance with local regulations.

Fiat Auto S.p.A.

D.M.C. – M.D.S.
Servizi la Cliente – Post vendita
Largo Senatore G. Agnelli, 5 – 10040 Volvera – To – (Italia)
Print no. 506.475/25 – Marzo 1999 – 400
Printed by Satiz S.p.A. – Turin (Italy)
order n° *604.46.450*


Electrical equipment Wiring diagrams

55.

| DECORIDETOR | SALOON/SW COUPÉ | | | |
|--|-----------------|------|-------|------|
| DESCRIPTION | | 2446 | 2959 | 2387 |
| Version with air conditioning Engine cooling — Engine coolant temperature gauge and overheating warning light | 5 | 5 | 27 | |
| Version without air conditioner Engine cooling — Engine coolant temperature gauge and overheating warning light | 7 | 7 | | |
| LANCIA-CODE | 9 | 9 | 29 | |
| Automatic heating | 11 | 11 | | |
| Side lights and warning light — Dipped headlamps — Main beam headlamps and warning light — Parking lights — Number plate lights | 13 | 13 | | |
| Fuel gauge and reserve warning light — Handbrake warning light — Insufficient brake fluid warning light — Seat belts not fastened warning light — Speedometer — Milometer/trip meter and zeroing button — Rev counter — Current socket — Voltmeter | 15 | 15 | | |
| Starting — Electronic injection and ignition — Recharging and warning light — Insufficient engine oil pressure warning light — Injection system failure warning light — Rev counter — Speedometer | 178 | 17 | 37 | |
| Automatic climate control system | 19 | 19 | 39 | |
| Alarm and activation warning light | 21 | 21 | 21 | |
| Complete infocenter | 23 | 23 | 23 | |
| Instrument panel connections | 25 | 25 | 41 | |
| Anti-lock brakes (A.B.S.) and failure warning light | | | 35 | |
| Cruise Control | 31 | 31 | 33 | |
| Automatic transmission (ZF) | | | 43 | |
| Version with automatic transmission Starting — Electronic injection and ignition — Recharging and warning light — Insufficient engine oil pressure warning light — Injection system failure warning light — Rev counter — Speedometer | 44/1 | 44/1 | | |
| Automatic transmission (AISIN) | 44/2 | 44/2 | ····· | |
| Version with automatic transmission | | | | |
| Direction indicators and warning light — Hazard warning lights and warning light — Brake lights — Reversing lights | 44/3 | 44/3 | | |
| Version with air conditioning Engine cooling — Engine coolant temperature gauge and overheating warning light | | | | 44/4 |
| Starting — Diesel injection pressure pump electronic control unit — Recharging and warning light — Insufficient engine oil pressure warning light — Injection system failure warning light — Heater plugs control unit and warning light | | | | 44/6 |
| Instrument panel connections | | | | 44/8 |




Electrical symbols



Electrical equipment

55.


Electrical symbols



98 update

55.

Electrical symbols




P3U03PL01

Electrical equipment Wiring diagrams

55.

Explanation of how to read wiring diagrams




Reference key

- A Component number
- B Connection number
- C Identification of connector at component
- D Connecting pin number
- E Ultrasound welding taped in cable loom

3U04PL


LANCIA K im 20v im 20v

Versions with air conditioning



Copyright by Fiat Auto

55



Versions with climate control

Engine cooling - Water temperature gauge and overheating warning light

Components key

- 3 Left front earth7 Battery
- 8 Main connector block 9 Earth on bodyshell 17 1st Engine cooling fan
- 18 Fan speed resistance
- 31 Peripheral control unit (engine compartment)
 E6 Engine cooling fan high speed relay feed
 E7 Engine cooling fan low speed relay feed
- 328 Connection between dashboard and left engine compartment cables 35 Front/electronic injection cable coupling 73 Secondary connector block


- 738 60A protective fuse for LG E, control unit / junction unit 73C 30A fuse protecting ignition switch / alarm device 75 Junction unit (dashboard) 78 instrument panel W Water temperature gauge

W1 Engine coolant overheating warning light

- 105 ignition switch131 Earth on steering column support503 Water temperature sensor

N.D. Ultrasound welding taped in cable foom

3U07PL




JUSSPL

101680AEd

Versions without air conditioning

55.

Location of components



Copyright by Fiat Auto

N.D. Ultrasound welding taped in cable loom

105 Ignition switch
131 Earth on steering column support
503 Water temperature sensor

W Water temperature gauge
W1 Engine coolant overheating warning light

31 Peripheral control unit (engine compartment)
328 Connection between dashboard and left engine compartment cables
35 Connection between engine compartment / electronic injection cable
73 Secondary connector block

Connection between engine compartment / electronic injection cables


1st Engine cooling fan
Penpheral control unit (engine compartment)

Earth on bodyshell Main connector block

738 60A protective fuse for I.G.E. control unit / junction unit 73C 30A fuse protecting ignition switch / alarm device 75 Junction unit (dashboard) 78 Instrument panel

Electrical equipment

55. Interconnections



AV 31A BN 31A HV 31A AN 12


RN 72A HN 69 VB 5


AV 104A BN 104D HV n.d. AN n.d.


HN 78C VB 85B W 78D C 103 GR 103 GR 78A Z 105

503

73C










P3U11PL01

■R 73B ₹7.d.

78A Instrument panel








Engine cooling - Water temperature gauge and overheating warning light

Versions without climate control

Components key

3 Left front earth 7 Battery





3U12PL

LANCIA K issa 20v issa 20v

Location of components


Lancia CODE - (See key at end of wiring diagrams)





Interconnections

55



■HN 108

- CN 85B

RN n.d.

GR 72A

SB 72A

L 26A AB 341

BC 340

RV 72A

BC 85B

CN 72A

RN 342

BR 72A

SB 75F

RV n.d.

AB 75F

L 84

AN 108


Engine cooling · Water temperature gauge and overheating warning light

Components key

- Main connector block

- 9 Earth on bodysheli
 33 Dashboard cable / right engine compartment rable
 35 Connection between engine compartment / electronic injection cables
 44 Power earth
 72 A Fuel injection control unit
 73 Secondary connector block
 73 B 60A protective fuse for I.G.E. control unit / junction unit
 73C 30A fuse protecting signition switch / alarm device
 75 Junction unit (dashboard)
 78 Instrument panel
- X1 Lancia CODE failure warning light

- 105 Ignition switch 106 Lancia CODE aerial 108 Lancia CODE control unit 488 150 A maxifuse 502 7 5 A fuse for immobilizer
- N.D. Ultrasound welding taped in cable loom



The cables in the wiring diagram are marked

0

LANCIA K im zov im zov

98 update

Automatic heater - (See key at end of wiring diagrams)

1090

9

E 1400


488 450A

R [H]

3U18PL

P3U18PL01

55.



88

 $\stackrel{\circ}{\sim}$

#(\$)_z

730

[806]-

ധ

73 Secondary connector block
738 60A protective fluse for I G.E. control unit / junction unit
73C 30A lise protecting ignition switch / anti-theft device
75 Junction unit (dashboard)
E1 ignition discharge relay
80 Power earth on dashboard
81 Climate control fan (Brushless)
82 Air recreculation motor
85 Infocenter control unit
88 Diagnostic socket
89 Left rear view mirror
90 Connection between dashboard / left front door cables
96 Earth on carrier

105 Ignition switch
109D Distribution / mixture motor
109M Distribution / mixture motor
488 150 A maxifuse


N.D. Ultrasound welding taped in cable loom

Automatic heater Components key


8 Main connector block 9 Earth on bodyshell


Electrical equipment Interconnections

55.




89





P3U19PL01



The cables in the wiring diagram are marked


3UZOPL

12

P3U20PL01


98 update

Side lights and warning light - Dipped headlamps and warning light - Main beam headlamps and warning light - Parking lights - Headlamp flasher - Number plate lights - (See key at end of wiring diagrams)



Electrical equipment Interconnections

55.



Connection between left longitudinal and tailgate cables

GN n.d A 78D

Z 343 BV 72A GR n.d. C n.d. V 503

RN 72A HN 69 VB 5

LR 78A

■ LR 31A

AV 31A BN 31A HV 31A AN 12

GN 72A A 72A

Components key Side lights and warning light - Dipped headlamps and warning light - Main beam headlamps and warning light - Parking lights - Headlamp flasher - Number plate lights

175

Connection between left longitudinal and tailgate cables

(Only for Station Wagon versions)

HR 177 Z 176A AB 176A

G 76E ZB 422 HR 76E

> H 76E S 75C

N 178

A 181

■ GV 76E

 Main connector block
 Barth on bodyshell
 Right front earth
 Right front light cluster
 Right front light cluster
 Peripheral control unit (engine compartment) Battery Left front earth

1 Left front light cluster

ment cables Connection between dashboard / left engine compart-£4 Main beam headlamps relay feed E1 Dipped headlamps relay feed

32B

- 73 Secondary connector block
 738 60 A fuse protecting I.G.E. control unit / junction unit
 730 30 A fuse protecting ignition switch / anti-theff device
 75 Junction unit (dashboard)
 76 I.G.E. control unit
 78 Instrument panel
- 178 Left rear earth 179 Left rear light cluster on fixed section 488 150 A maxifuse

F Side lights warning light G Dipped headlamps warning light H Main beam headlamps warning light

B Side lights / number plate lights control switch C Dipped headlamps / main beam headlamps control switch E Ideogram lights control switch D Parking lights control switch 104 Steering column switch unit 102 Exterior lights control unit

■ GV 76E

RV n.d. AN 76E


■ GV 175S

RV 433

RN 171 CN 433 CB 424

œ

- E Main beam headlamps flasher button D Direction indicators / parking lights control switch
- F Main beam headlamps control switch 105 Ignition switch
 131 Earth on steering column support
 172 Right rear light cluster on fixed section
 174 Right rear light cluster on movable section
- 175D Right no. plate light 177 Left rear light cluster on movable section 175S Left no. plate light 175 Connection between left longitudinal / tailgate cables



P3U24PL01

N.D. Ultrasound welding taped in cable loom

3U24PL

LANCIA K im 200 im 200

98 update

Fuel gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer/trip meter and zeroing button - Rev counter - Current socket. Voltmeter - (See key at end of wiring diagrams)

\$ \$ \$ \$ P3U25PL01 .D. 1. GX 6.53 89 88 89 88 D 68 HG Ė...... 8 - (a) 5 m) É.,,,,, L@ 5 S #8 1190 (11) (8) - g - g 328 (******* 0 o Ž 0.Z 2 13 1 2 м. Э. æ 1198 (15A) = - 118 -- HB 11980----8 5111 S. 301 92 88 [(0021)- 3-8 o Z © 0 430 See ideogram lights wiring diagram 482 100 N.D. £ [1408) **⊕**+ ≅ 2 105 £ (AU) ₹ 22 14 14 14 14 14 14 (**G**) N.0.

100

Connection between dashboard and left longitudinal cables

CN 296

MG 78D

■ MG 482

C 164

HG n.d. GR n.d.


AG 78D

AG 482

MB 78C

Zn.d.

C 296 HG 90 GR 90



P3U27PL01

N 107A

N 107A

V n.d. GN n.d.

H 199

R n.d.

SB n.d.

B 199

G 150 NZ n.d. AN 169

AB 199

M 199

HV n.d.

RN 171

GN 150 HV 150

VN 150

A 169

CN 164

AB n.d. G n.d. NZ 90 AN 296 A 296


M 75F

Fuel gauge and reserve warning light - Handbrake warning light - Insufficient brake fluid level warning light - Seat belt unfastened warning light - Speedometer - Milometer/trip meter display and zeroing button - Rev counter - Current socket - Voltmeter

Components key

8 Main connector block 9 Earth on bodyshell 12 Insufficient brake fluid level sensor 12 Insufficient brake fluid level sensor 13 Secondary connector block 13 Secondary connector block 13 Secondary connector block 14 SoA flue protecting services 18 60A divestmenture flue for 14 El control unit / junction unit 19 Capa flue protecting ignition switch/alam device 15 G. El control unit 16 Instrument panel 15 Saan heits on I sterned warning light 15 Saan heits on I sterned warning light Seat beits not fastened warning light N. Handbrake / I.G.E. control unit warning light





The cables in the wiring diagram are marked

3U27PL

88 Diagnostic socket
96 Earth on carrier
97 Earth on floor
100 Cigar lighter
100 Connection between dashboard and left longitudinal cables


V Fuel gauge
V1 Fuel reserve warning light
X Milometer (rip meter
Y Electronic fachometer
7 Trip computer zeroing button


O Insufficient brake fluid level warning light

Electronic revicounter

P3U2BPL01

Starting - Electronic injection and ignition - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - (See key at end of wiring diagrams)






Starting - Electronic injection and ignition - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light

Components key

Left front earth Sattery








Ultrasound welding taped in cable loom

P3U3ZPL01

LANCIA K ima 200 ima 200 and 200 graph 200 gra



3035PL

55.

8281 112 113 109M 97 32A 32B 75 110

P3U3SPL01

Automatic climate control

Components key

- 8 Main connector block
 9 Earth on bodyshell
 11 Compressor coupling for air conditioning
 17 1st Engine cooling fan
 18 Engine cooling fan
 18 Engine cooling fan spead resistance
 26 A four stage pressure switch
 27 Aight front earth
 27 Aight front earth
 31 Peripheal control unit (engine compartment)

Compressor coupling relay feed

- 66 Engine cooling fan high speed relay feed ET Engine cooling fan high speed relay feed ET Engine cooling fan low speed relay feed as Connection briving dash & left engine comp cables 324 Connection briving dash & left engine comp cables 35 Connection briving dash & right engine comp cables 35 Connection briving dash & right engine comp cables 69 Engine services dable connection 74. Fuel higheriton control unit 70 Sectorday connection block 73 800 potective fuse for 10 E. control unit 7 Junction unit 73 C30A fuse protecting graphion switch/anti-theft device 75 Junction unit (dashpaper) 51 Inchion confrict fuser calls.

E1 Ignition discharge relay

W1 Engine coolant overheating warning light W Water temperature gauge

N.D. Ultrasound welding taped in cable foom

90 Connection between dashboard and left f
96 Earth on carrier
97 Earth on floor
105 Ignition switch
109D Distribution / mixture motor
1100 Distribution / mixture motor
110 Vehicle interior at temperature sensor
111 Mixed air sensor 1
112 Mixed air sensor 1
113 Solar homperature sensor
131 Earth on steering column support
488 150 A maxifuse
503 Water temperature sensor 80 Power earth on dashboard 81 Climate control fan (Brushless) 82 Air recirculation motor 85 Infocenter control unit 88 Diagnostic socket 89 Left rear view mirror A Motor for folding left rear view mirror

B Motor for vertical adjustment of left rear view mirror


C Motor for horizontal adjustment of left rear view mirror D Left rear view mirror heating resistance Connection between dashboard and left front door cables

33A RV n.d. GR 108 HN 108 **AN 108** SB 75F And HR 298D BG n.d. GN n.d. HV n.d. RG 119B RG 119B BV n.d. HG 100 HN 298D S n.d. AG n.d. Connection between dashboard and right engine compartment cables Connection between dashboard and left front door cables AB 75F BR n.d. **CN 85B** RN n.d. BC 85B I SN 89C CB 92 V 89A RV 92 H 89A L 89A VB 89D HB 92 Vn.d. H 115 L 115 VB 115 LR n.d. LN n.d. C 298A SN 85A S 85A BN n.d. VG 298A AB 298A NZ 100 Z 97 LN 89B BN 91 Z 92 -CN 72A RN 342 **GR 72A BR 72A** HN 35 A 502 B n.d. AG 95 AR 92 VN 92 NZ 92 HN 94 SB 72A AB 341 AN n.d. **RV 72A** BC 340 L 26A

The cables in the wiring diagram are marked

P3U36PL01

Alarm device - (See key at end of wiring diagrams)



21

55

120

Connection between dashboard and right front door cables


AR 298D

BG n.d.

Z 97

VN 298B

NZ n.d.



Alarm device

Components key

- Left front light cluster
 Left front earth
 Left side direction indicator
 Sattery
- Main connector block

- Diagnostic socket
- Connection between dashboard and left front door cables

- 98. Earth on Carrier
 97. Earth on floor
 100 Commercian between dashboard and laft longitudinal cables
 105. Ignition switch
 107. Alarm control unit
 108. LANCIA.-CODE control unit
 1188. Commercian tervisee floashboard and right front door cables
 120. Connection between dashboard and right front door cables

Jesson

- E2. Intermittent device for direction indicators / hazard warning lights

- Left from central locking geared motor and signalling of left from door open and alarm on

- 900

- 9 Earth on bodyshell
 10 Button on bonnet for engaging alarm
 27 Right front light cluster
 32 A Right front light cluster
 33 A Connection between dash & left engine compartment cables
 34 Power earth
 74 Power earth
 75 Secondary connector block
 75 BOA protective fuse for 16 E control unit
 76 30 A large protecting injunition switch/alarm device
 75 Junction unit (dashboard)
 75 Interiminant charics for clienting indicating in hazard diagraphs

- A Luggage compartment coursey light and alam on switch 141 Connection between right longitudinal and right rear door cables 146 Right rear door central looking geared motor and signalling of right rear door open and alarm on

126 Right front central locking geared motor and signalling of right front door open, and alarm on 131 Earth on steering column support 137 Tailgale lock assembly

- 50 Connection between left longitudinal and left rear door cables 155 Left rear door central locking geared motor and signalling of left rear door open and alarm on

- 172 Aight rear latting to the section 173 Aight rear earth 175 Connection between left tongrudinal and tailgate cables 176 Callegate cables connection 177. Left rear light cluster on movable section 177. Left rear light cluster on movable section 178. Left rear light cluster on movable section 179. Left rear light cluster on tixed section 199. Alarm sizer 179. Left rear light cluster on tixed section 199. Alarm sizer 179. Left rear light cluster on tixed section 199. Alarm sizer 179. Left rear light cluster on tixed section 199. Alarm sizer 179. Left rear light cluster on tixed and receiver cables 267. Volumetric sensors for alarm device 269. Connection between dashboard and left longitudinal cables 189. Left Refix to describe the control unit 189. Left rear light cluster 189. Left Refix to describe the control unit 189
- N.D. Ultrasound welding taped in cable from

P3U39PL01 BN n.d. **AN 298D** CB 298B **RB 437** AG n.d. Nn.d. GN n.d. SN n.d. NL 437 HV n.d. Gn.d. 8 n.d.

V n.d.

LN n.d. LR n.d.

VG 115 LB 115 HB 115

Z 123

422 Connection between dashboard and left longitudinal cables

SB 1210

NL 438

HN 125 RB 438 AG 126

R 124

SN 438

VB 121D

L 121B H 1218 V 121A

B n.d.

N 126 G 123 BV 126 HV 126

CB 123


LN 121B LR 121B

NZ 438

BG 126 HR 125

VN 123

GN 126




The cables in the wiring diagram are marked

3U40PL

P3U40PL01







3041PL

3U43PL

55.



150 Connection between left longitudinal and left rear door cables P3U43PL01



73C 73B

96 119B

126 78

146

175

178

176A 176 137

Complete Infocenter

Components key

5 Left front brake pad wear sensor
7 Battery 9 Earth on bodysheil 8 Main connector block

105 Iganion switch
1198 Connection between dashboard and right longitudinal cables
120 Connection between dashboard and right front door cables
120 Connection between dashboard and right front door cables
126 Right front central locking general motor and signalling of right

131 Earth on steering column support

front door open and anti-theft device on

21 Minimum engine ou level sensor
32A Connection between dash & left engine compartment cables
32B Connection between dash & left engine compartment cables
33A Connection between dash & right engine compartment cables
53E Engine services table connection
72A Fuel migration control unit
73 Secondary connector block
73 Secondary connector block
73B Secondary connector block
73C 33A fuels protecting engine on which anti-theft device
75 Junction unit (dashboard)

Intermittent device for direction indicators / hazard warning lights

76 (S.t. Lucino)
78 Instrument panel
1 Check summary warning light
Command revicounter

U Electronic revicounter
Y Electronic tachometer

173 Right lear earth
175 Connection between left longitudinal and tailgate cables
176 Tailgate sables connection
178 Left rear earth
200 Controlled damping suspension electronic control unit (S.C.S.
340 Right front bake pad wear sensor
340 Asyntremelay
421 Connection between dashboard and left longitudinal cables
428 Connection between dashboard and left longitudinal cables
428 Connection between dashboard and left longitudinal cables

Controlled damping suspension electronic control unit (S.C.S.)

Connection between dashboard and left longitudinal cables 150 A maxifuse

150 Connection between left longitudinal and left rear door cables 155 Left rear door central looking geared motor and signalling of left rear door open and anti-theft device on

141 Connection between right longitudinal and right rear door cables 146 Right rear door central looking geared motor and signalling of right

rear door open and anti-theft device on

A Luggage compartment courtesy light switch and anti-theft de

Z Electronic automatic transmission gear selection display 85 infocenter control unit 88 Diagnostic socket 90 Connection between dashboard and left front door cables 95 Left front central locking geared motor and signalling of left front door open and arti-theft device on 96 Earth on carrier 97 Earth on toop open between dashboard and left longitudinal cables 101 Light dimmer

N.D. Ultrasound welding taped in cable loom


The cables in the wiring diagram are marked

Print no 506.475/25

P3U44PL07

24

Instrument panel connections - (See key at end of wiring diagrams)



Copyright by Fiat Auto

3U45PL

76 I.G.E control unit 78 instrument panel 85 Infocenter control unit

intermittent device for direction indicators / hazard warning lights

32A

32B

117

127

73C 344-35 73

#

I 482

55. Electrical equipment Interconnections 32B BN 104A BN 104D HV n.d. HN 78C VB 85B W 78D C 103 GR 103 BV 78A Connection between dashboard and left engine compartment cables

184 183



GN n.d.I

■ V 503


RN 72A HN 69 VB 5

Z 343 -BV 72A -GR n.d. C n.d.

GN 72A A 72A **■**LR 31A


LR 78A

AV 31A BN 31A HV 31A AN 12




119C Connection between dashboard and right longitudinal cables

P3U47PL01



119D Connection between dashboard and right longitudinal cables



The cables in the wiring diagram are marked

LANCIA K | 201 | 201 | 201 | 201 98 update

26

Components key

Instrument panel connections

- 3 Left front earth Battery
- 8 Marn connector brock 9 Earth on bodyshell

- E6 Engine cooling fan high speed diely keed
 E7 Engine cooling fan low speed reley fead
 E7 Engine compartment cables
 328 Connection between dash and gift sing oo compartment cables
 E3A Connection between dash and gift sing one compartment cables
 E3A Connection between engine comp in out (A B S)
 E3 Connection between engine comp in extraordic injection cables
 E60 Connection for services cables in engine
 E7A Feel injection control unit
 E73 Secondary connector block
 E73L Secondary connector block
 E73L OAA histe protecting inguino winch/arti-theft device
 E73L Direction unit (dashboard)
 E73L Direction unit (dashboard)
- St Dipped headlamps relay feed E4 Main beam headlamps relay feed
- 12 insulficient brake fluid level sensor
 20 Alternator
 22 Engine coolant temperature sender unit
 23 Sonsor signalling minimum engine oil pressure
 26 Er four stage pressure switch
 31 Peripheral control unit (engine compartment)

- 38 Diagnostic socket
 56 Earth on carrier
 97 Earth on floor
 100 Connection between dashboard and left longitudinal cables
 101 Light dimmer
 103 Ignition switch
 108 Lanua CODE control unit
 117 Switch signalling handbiake applied
- 117 Switch signalling handbrake applied
 119C Connection between dashboard and right fongitudinal cables
 119D Connection between dashboard and right front door cables
 127 Switch signalling seat belts not fastened
 131 Earth on steering column support


- 133 Relay for driver's seat heater pad
 184 Relay for passenger seat heater pad
 196 Taligate locking unlocking relay.
 186 Servotronic device electronic control unit (S.C.S.)
 200 Controlled damping suspecsion electronic control unit (S.C.S.)
 274 Connection between dashboard and AIR-BAG cables.
 275 AIR-BAG control unit.
 344 Connection between abash and anti-lock brakes cables (A.B.S.)
 430 Connecting diode for handbrake applied/insufficient brake fluid
- level system
- 482 Electric fuel pump / fuel gauge 488 150 A maxifuse 503 Water temperature sensor

N.D. Ultrasound welding taped in cable foom


P3U48PL01

Version with air conditioning





Location of components



エ



8 HG 78C GR 108 **AV 78D** MN 78A V 33A CN 85 Connection between dashboard and injection cables RN 271 HV 78D ■ BV 78A RV n.d. HB 503 M 72E

Instrument panel

H 505 HN 505 VN 72D HN 72D G 72E A 72D H 72D

503

105

VN 505

A 505

S n.d.

A n.d.

RN 72D

R 72D

CN 72F

BR 72C AB 72C V 72E 736

HG 72D

RG n.d.

Paustetol

Engine cooling - Water temperature gauge and overheating warning light

Version with air conditioning

Components key

HV n.d. GN 768 CB 768 AN n.d. N n.d. N n.d. RV 858 A n.d. G n.d.

MN 68 CN 76B BV 68 HN 119B VN 108B NZ 101 Z 85E MB n.d.

AN n.d. LN 344 LB n.d.

35 Connection between engine compartment and electronic injection cab
73 Secondary connector block
738 60A protective fuse for LG E, control unit / junction unit
73C 30A fuse protecting ignition switch / alarm device
74 80A fuse protecting peripheral control unit (engine compartment)
68 Connection between dashboard and electronic injection cables
72 Electronic injection control unit
75 Junction unit (dashboard)
78 Instrument panel

18 Engine cooling far speed resistance
27 Right front earth
27 Right front earth
31 Petipheral control unit (engine compartment)
32 Compressor coupling relay feed
33 Compressor coupling speed relay feed
35 Engine cooling fan high speed relay feed
35 Connection between engine compartment and electronic injection cables

78**D**

instrument panel

BR 76B MG 100 AG 100 MV 68

R 1190

17 1st Engine cooling fan Main connector block
 Earth on bodyshell

Compressor coupling for air conditioning

105 Ignition switch
31 Earth on steering column support
503 Duel engine coolant sender unit
506 15A fuse protecting electronic injection control unit
N D. Ultrasound welding taped in cable foom

W. Water temperature gauge.
W1. Engine coolant overheating warning light.

AB 274 S 119D M 68 AR 119D

SN 119D GN 344 AV 68

The cables in the wiring diagram are marked

3U52PL

28


P3USZPLO1


Print no. 506,475/25

LANCIA-CODE device and failure warning light - (See key at end of wiring diagrams)

Location of components

55.





Copyright by Fiat Auto

3U54PL

88 Diagnostic socket
97 Earth on floor
105 Ignition switch
106 Lancia CODE aertal
108 Lancia CODE control unit
502 7.5A fuse protecting Flat-CODE

X1 Lancia CODE failure warning light

7B

A n.d.

Z 32B

68 Connection between dashboard and electronic injection cables 72 Fuel injection control unit 73 Secondary connector block 738 60A protective fuse for LG E. control unit / junction unit 73C 30A fuse protecting ignition switch / alarm device 75 Junction unit (dashboard) 78 Instrument panel 78 Instrument panel


8 Main connector block 9 Earth on bodyshell

N.D. Ultrasound welding taped in cable loom

Electrical equipment Interconnections

LANCIA K 1 24v 98 update

55.



90 105)


106


75





P3USSPL01

LANCIA-CODE device Components key










3U56PL

30

P3U56PL01

Cruise Control - (See key at end of wiring diagrams)



N.D. Ultrasound welding taped in cable loom

Cruise Control operation
Potentiometer on accelerator pedal
Switch on clutch

150A maxi fuse

A1 Cruise control warning light Ignition switch Earth on driver's side support Brake lights switch

32A Connection betwe 32B Connection betwe 32 Connection betwe 72 Fuel injection cont 73 Secondary connect 73C 30A fuse protection 75 Junction unit (das 78 Instrument panel A1 Connection 75 Junction unit (das 78 Instrument panel A1 Connection 75 Junction unit (das 78 Instrument panel A1 Connection 75 Junction unit (das 78 Instrument panel A1 Connection 75 Junction Units Connection 75 Junction Units Connection 75 Junction Units Connection 75 Junction Units Connection Panel Connec

Fuel injection control unit Secondary connector block

Connection between dashboard and left engine compartment cables Connection between dashboard and left engine compartment cables Connection between dashboard and right engine compartment cables

30A fuse protecting ignition switch/alarm device Junction unit (dashboard)

69

HN 23


GR 21 RN 15

HR 21 **B** 20 Cruise Control

3 Left front earth
7 Battery
8 Main connector block
9 Earth on bodyshell


Interconnections Electrical equipment

55.





73B 33A

105



P3U59PL01






The cables in the wiring diagram are marked

3060PL


Location of components




Interconnections Electrical equipment

LANCIA K 100) 24v 98 update

55.



73B 68




Cruise Control

Components key

8 Main connector block9 Earth on bodyshell

3 Left front earth7 Battery

Battery



105 Ignition switch
131 Earth on steering column support
505 Cruise Control operation
512 Potentiometer on accelerator pedal
514 Switch on clutch
N.D. Ultrasound welding taped in cable loom

68 72 73 73C 75 78

Secondary connector block

30A fuse protecting ignition switch / alarm device Junction unit (dashboard)

A1 Cruise control warning light

instrument panel

Connection between dashboard and electronic injection cables Electronic injection control unit

The cables in the wiring diagram are marked

306421

Location of components

넴

[409]

190E)

S.

Anti-lock brakes (A.B.S.) and failure warning light - (See key at end of wiring diagrams)

78 H SERVICE SERVIC SERVICE II


FINAL TERRITORIST

GENERAL TERRITORIST

GENERAL TERRITORIST

FINAL TERRITORIS \circ

 $\mathbf{\omega}$




I


c) Z


P3U65PL01 194A **-®**+ 5 * See automatic transmission wiring diagram € 1601h S 105 193A

Copyright by Fiat Auto

3066PL








8 Main connector block 9 Earth on bodyshell

Connection between dashboard and anti-lock brakes cables (A.B.S.)



The cables in the wiring diagram are marked

GN 34 ■ LN 34 73 Secondary connector block
73C 30A fuse protecting ignition switch / anti-theft device
75 Junction unit (dashboard)
77 10A fuse protecting anti-lock brakes (A.B.S.)
78 Instrument panel
P. Anti-lock braking system failure warning light (A.B.S.)
P. Anti-lock braking system failure warning light (A.B.S.) 47A Connection for A.B.S. cable with sensor on right front wheel for anti-lock brakes (A.B.S.) 19A Connection for A.B.S. cable with sensor on left front wheel for anti-lock brakes (A.B.S.) Anti-lock brakes (A.B.S.) and failure warning light 9A. Earth on side panel for anti-lock brakes (A.B.S.).
19. Sensor on left front wheel for anti-lock brakes (A.B.S.). 34 Anti-lock brakes electronic control unit (A.B.S.) 47 Sensor on right front wheel for anti-lock brakes i 3A Left front earth for anti-lock brakes (A.B.S)
7 Battery Sensor on right front wheel for anti-lock brakes (A.B.S. 600 A 315 78 75 194 Sensor on right rear wheel for anti-lock brakes (A.B.S.) 194A Connection for A.B.S. cable with sensor on right rear wheel for anti-lock brakes (A.B.S.) 105 Ignition switch
193 Sensor on left rear wheel for anti-lock brakes (A.B.S.)
193A Connection for A.B.S. cable with sensor on left rear 374 Diagnostic socket for anti-lock braking system (A.B.S.) 488 150A maxifuse 315 Electronic automatic transmission gear-selector control unit 503. Connection between A.B.S. and automatic transmission. 271 Brake lights switch 344 Connection between dashboard and anti-lock brakes wheel for anti-lock brakes (A.B.S.) cables (A.B.S.) P3U67PL01 344 78A 75H Junction unit (dashboard) 78D Instrument panel Instrument panel SN 119D GN 344 CN 76B HN 119B VN 108B NZ 101 Z 85E MB n.d. BN 76B AV 119C AG 119C LG 75E AN n.d.* BR 76B MG 100 AG 100 BV 32B V 32B R 1190

47

N.D. Ultrasound welding taped in cable loom

■ RV 34

O Insufficient brake fluid level warning light Y Electronic tachometer


36

306820

P3U08PL01


98 update

Starting - Electronic injection and ignition - Recharging and warning light - Insufficient engine oil pressure warning light - Warning light signalling injection system failure - Rev counter - -Speedometer - (See key at end of wiring diagrams)



55. Interconnections

> LANCIA K B 24v 98 update



Starting - Electronic injection and ignition - Recharging and warning light - Insufficient engine oil pressure warning light - Warning light signalling injection system failure - Rev counter - Speedometer Components key

738-60A protective fuse for LG E control unit / junction unit 732-30A fuse protecting ignition switch / alarm device 732-60A fuse protecting peripheral control unit (engine compartment) 75 Junction unit (dashbaard) E1 lignition discharge relay

78 instrument panel


K Battery recharging warning light
M insufficient engine oil pressure warning light
U Electronic text counter
Y Electronic texthometer
Infocenter control unit


- 11 Compressor coupling for air conditioning
 15 Starter motor
 16 Soak plus
 20 Alternator
 23 Sensor signating minimum engine of pressure
 23 Sensor signating minimum engine of pressure
 25 Air temperature sensor
 26 A Four stage pressure switch
 31 Peripheal countof unit (engine compartment)
 27 Conceiton between dash and left engine compartment cables
 38 Compressor coupling relay feed
 39 Connection between dash and left engine compartment cables
 36 Compressor occuping relay feed
 39 Connection between dash and left engine compartment cables
 30 Connection between dash and left engine compartment cables
 30 Connection between dash and left engine compartment cables
 31 Connection between dash and left engine compartment cables
 32 Connection between dash and left engine compartment cables
 33 Connection between dash and left engine coult
 40 Edit of section in inject cables
 41 Perior lavapour cut out solenoid valve
 42 Perior lavapour cut out solenoid valve
 43 Connection coult
 44 Connection coult
 55 Ignition coult
 56 Ignition coult
 57 Ignition coult
 58 Ignition coult
 58 Ignition coult
 59 Ignition coult
 59 Ignition coult 8 Main connector block 9 Earth on bodyshell 11 Compressor coupling I 3 Left front earth
 7 Battery
- 85 Information territorial ter
- N.D. Uttrasound welding taped in cable loom

Injectors

1st Deronation sensor

2 nd Detonation sensor
Electronic injection engine coolant temperature sensor
Spin sensor
Portenioneter on butterfly valve
Timing sensor
Connection between dashboard and electronic ejection cables
Field injection control unit






The cables in the wiring diagram are marked

P3U7ZPL01

Automatic climate control - (See key at end of wiring diagrams)



39

Automatic climate control

Components key

- 18 Engine cooling fan speed resistance 26A Four stage pressure switch 27 Right front earth 31 Peripheral control unit (engine compartment)
- ES Compressor coupling relay feed
 E6 Engine cooling Ian high speed relay feed
 E7 Engine cooling Ian high speed relay feed
 E7 Engine cooling Ian high speed relay feed
 E8 Connection between dash and right engine compartment cables
 E8 Connection between engine comp & electronic injection cables
 E8 Connection between adeshboard and electronic injection cables
 E8 Sensor for engine coolant temperature
 E9 Evel injection control unit
 E9 Secondary connector block
 E9 Evel injection control unit
 E9 Evel injection control unit
 E9 Evel injection control unit
 E9 EVEL EVEL EVEL EVEL EVEL EVEL EVEL
 E9 EVEL EVEL
 E9 EVEL EVEL
 E9 EVE

- 78 Instrument banel
 W Water temperature gauge
 W Engine coolant overheating warning light
 80 Power earth on dashboard
 81 Climate control fan (Brushless)
- 82 Air recirculation motor
- 85 Infocenter control unit 84 Single stage pressure switch (3000 i.e.)
- 88 Diagnostic socket 89 Left rear view mirror

- A Motor for folding left rear view mirror

 B Motor for folding left rear view mirror
 C Motor for wertical adjustment of left rear view mirror
 C Motor for horizontal adjustment of left rear view mirror
 D Left rear view mirror hearing resistance
 90 Connection between dashboard and left front door cables
 96 Earth on floor
 105 Ignition switch
 105 Distribution / mixture motor
 109M Distribution / mixture motor
 110 Vehicle interior air temperature sensor
 111 Mixed air sensor 2
 112 Mixed air sensor
 113 Solar temperature sensor
 114 Mixed air sensor
 115 Solar temperature sensor
 116 Solar temperature sensor
 117 Mixed air sensor 2
 118 Solar temperature sensor
 119 Mixed air sensor 2
 110 Solar temperature sensor
- N.D. Ultrasound welding taped in cable from

Electrical equipment Interconnections


LANCIA K 1001 24V 98 update

55.

90 ■ L 84 33A Connection between dashboard and right engine compartment cables AB 75F ■ V 68 *GL n.d. HG 100 HN 298D *HN 298B *ZB 97 BG n.d. GN n.d. RG 119B BV n.d. Nn.d. G n.d. B n.d. Connection between dashboard and left front door cables BG n.d. BR 85B RN n.d. * MR 4502 BN 91 * MN 4502 LN 898 LN 898 SN 898 * CB 923 SN 898 * CB 923 SN 898 N 998 RV n.d. V n.d. H 115 L 115 VB 115 RN 342 BR 340 N 26 **B** 26 RG 95 AB 449 * AR 92 VN 92 VN 451 * L 26A V 26A AB 341


The cables in the wiring diagram are marked

P3U76PL01



41

<u>5</u>5



P3U79PL01

Components key Instrument panel connections


3 Left front earth 7 Battery


- Main connector block
 Sarth on bodyshell
- 12 Insufficient brake fluid level sensor
- 20 Alternator
 23 Sensor signalling minimum engine oil pressure
 31 Peripheral control unit (engine compartment)
- E1 Dipped headlamps relay feed
- £4 Main beam headlamps relay feed
 £6 Engine cooling fan high speed relay feed
- 27 Engine Cooling fan low Speed relay feed
 32 Connection between dashboard and leit engine compartment cables
 34 Anni-logk brake selector-hydraulic coprole unit (A B S)
 35 Connection between engine compartment and injection cables
 66 Connection between dashboard and electronic injection cables
 69 Connection for services ables in engine
 72 Fuel injection control unit
 73 Seconday connection block
 735 Seconday connection block
 736 30A truse protecting ignition switch/shift-field cevice
 74 BoA luse protecting ignition switch/shift-field cevice
 75 Board services fuel for fine control unit (engine compartment)
 76 Dunction unit (dashboard)
- £2 Intermittent device for direction indicators / hazard warning lights
- 76 I.G.E. control unit 78 Instrument panel (See key at the end of the wiring diagrams)
- 85 infocenter control unit 88 Diagnostic socket 96 Earth on carrier 97 Earth on floor

100 Connection between dashboard and left longitudinal cables 101 Light dimmer 105 Ignition switch 108 Lands CODE control unit 117 Switch signalling handbrake applied 119 Connection between dashboard and right longitudinal cables 1190 Connection between dashboard and right longitudinal cables 1190 Connection between dashboard and right longitudinal cables 1190 Connection between dashboard and right front door cables 127 Switch signalling saat belts not it assened 131 Earth on sitering column support 131 Earth on sitering column support 138 Relay for draver's seat heater pad 148 Relay for draver's seat heater pad 180 Falley locking/unlocking relay feed 190 Tailgate locking/unlocking relay feed 190 Controlled damping suspension electronic control unit 200 Controlled damping suspension electronic control cables 274 Connection between dashboard and AIR-SAG cables 275 AIR-BAG control unit 320 Tinm on electronic automatic transmission gear selector lever 340 Connection between dashboard and arti-lock brakes cables (A 8 S) 430 Connection glodde for handbrake applied/insufficient brake fluid

- 482 Electric fuel pump / fuel gauge
- N.D. Ultrasound welding taped in cable foom

119B Connection between dashboard and right longitudinal cables **B 170 ■ HN 190 HR 196 GR 196 CN 180 VN 141 RN 198 N 136D LR n.d. H 196 GN n.d. A 136E HV n.d. LR n.d. R n.d. HG 198 AR 190 G n.d. RV 487* RV 166A BL 444** RG 136E * *BN n.d. **BL n.d. ■ HG 78C RV 295 AR 87A *8 n.d. LR n.d. Rn.d. RG 90 G n.d. L 134 LR 90 N 97 A 90 GN 195 * * HV 195 * * VN n.d. H 76C HR 76C GR 76C **CN 76C** RN 134 HN 78A GN n.d.







The cables in the wiring diagram are marked

LANCIA K 120 24v 98 update

Sportronic automatic transmission - (See key at end of wiring diagrams)





P3U83PL01

Automatic transmission (Sportronic)

Components key


- 8 Main connector block 9 Earth on bodyshell 13 Reversing lights switch 15 Starter motor
- 32 Connection between dashboard and left engine compartment cable 61 Engine coolant temperature sensor 88 Connection between dashboard and electronic injection cables 89 Engine services cable control of 89 Engine services cable control of 72 Euel injection control block 73 Secondary connector block 73 Secondary connector block 73 Sacondary connector block Connection between dashboard and left engine compartment cables
- 74-80A tuse protecting beripheral control unit (engine compartment)
 75 Junction unit (dashboard)
 E1 ignation discharge relay
- U Slectronic revicounter
 Y Electronic tachometer Instrument panel

- Electronic automatic transmission geal selection display
 Sindicenter control unit
 Connection between dashboard and left front door cables
 Left front central locking geared motor and signalling of left front
- door open and alarm on 96 Earth on carrier

3UB3P

- tion cables
- 501 Connection for sensor cables for automatic transmission 514 Switch on clutch
- N.D. Ultrasound welding taped in cable loom

- 135 Ignition switch
 31 Earth on steering column support
 175 Connection between left longitudinal and tailgate cables
 902 Switch control unit
 915 Electronic automatic transmission gear selector control unit (ZF)
 916 Diagnostic socket for electronic automatic transmission
 917 Connection between automatic transmission and electronic injec-
- 318 Connection between electronic auto trans and dash, cables 320 Tirm on electronic automatic transmission gear selector lever 343 40A stater eriely 432 20A protective fuse ignition switch relay feed



The cables in the wiring diagram are marked ELG 320

EN n.d.
EN N 75F

HN 75F

RV n.d.
EAB n.d. BBC 315 BR AR n.d. BAR n.d. HR 501 HR 501

P3U84PL01


LANCIA K TO 200 TO 200

'99 update

Electrical equipment Wiring diagrams

55.


Version with automatic transmission Starting - Electronic ignition and fuel injection - Recharging and low engine oil warning light - Fuel injection fault warning light - Rev Counter - Speedometer - (See key at end of wiring diagrams)



Publication no. 506.475/29








'99 update

Electrical equipment

Wiring diagrams

55.

Version with automatic transmission Direction indicators and warning light - Hazard warning lights and warning light - Brake lights - Reversing lights -(See key at end of wiring diagrams)



VII.99.- Update.

55.

Key to components

- 171 Additional stop lights warning light
 174 Right rear light cluster on moving part
 174 Connection between left longitudinal cable and tailgate cable
 177 Left rear light cluster on moving part
 178 Left rear earth
- 307 Automatic transmission horn control
- 318 Connection between electronic automatic transmission cable and dashboard cable switch
- 401 Electronic automatic transmission gear selection control unit
 413 Connection to solenoids assembly
 415 Gear position selector
 416 Gear position selector

- Engine rpm sensor Vehicle speed sensor Gearbox oil temperature sensor

Components not present in the complete key

LANCIA K

99 update


Electrical equipment


Wiring diagrams


Component location 55


TD version with air conditioning Engine cooling – Engine coolant temperature gauge and overheating warning light – (See key at end of wiring dia grams)























Interconnections

55



Connection between dashboard and left engine compartment cables





35

Connection between engine compartment and electronic injection cables

GR 85B HR 85B

N 107A RNnd HB 78D

HR 69

GR 69 CN 10-

B 69

B 78C

■ HB 35

RN 31A

H 751

BR 31A

GR 72 -

■AR 72A, ~

HN 477 NZ 72 NZ 72A

H 49

■ HB 22

AR 72

■BR72A(⊤

Version with air conditioning

Engine cooling — Engine coolant temperature gauge and overheating warning light


Component key

- Main connector block Earth on bodyshell 1 stengine cooling fan

- 17A 2nd engine cooling fan
 18 Engine cooling fan resistance
 22 Engine coolant temperature sender unit
 27 Right front earth
 31 Peripheral control unit (engine compa
- Peripheral control unit (engine compart
- ment)
 E6 Engine cooling fan high speed relay
 E7 Engine cooling fan low speed relay
 32A Connection between dashboard and left
- engine compartment cables
 35 Connection between engine compartment and electronic injection cables

72A Fuel pump electronic control unit

- 105 131 488 Ignition switch
 Earth on steering column support
 150A maxifuse
 - 73C 30A fuse protecting ignition switch 74 80A fuse protecting peripheral control 73 Secondary connector block
 73B 60A fuse protecting I G E control unit / 75 78 Instrument panel
 W Engine coolant temperature gauge
 W1 Engine coolant overheating warning unit (engine compartment) Junction unit (dashboard) Junction unit



The cables in the wiring diagram are marked by a square


V 2000 - Update

99 update

Electrical equipment


Wiring diagrams


Starting – Diesel injection pressure pump electronic control unit – Recharging and warning light – Insufficient engine oil pressure warning light – Injection system failure warning light – Heater plugs control unit and warning light





Interconnections Electrical equipment

55









2387 JTD version

Starting – Diesel injection pressure pump electronic control unit – Recharging and warning light – Insufficient engine oil pressure warning light – Injection system failure warning light – Heater plugs control unit and warning light

Component key

- 328 32A 3 Left front earth
 7 Battery
 7 Batter
 8 Main connector block
 8 Main connector block
 9 Earth on bodyshall
 2 Insufficient brake fluid level sensor
 6 Alternator Three stage pressure switch four stage pressure switch everytheral control unit (engine compartment) of 1 felay feed (Alan beam headiamps relay feed 4 Main beam headiamps relay feed 5 Engine cooling fan high speed relay feed 5 Engine cooling fan high speed relay feed connection between dashboard and left engine compart chales Minimum engine oil pressure sender unit Minimum engine oil pressure sensor
- between dashboard and left engine com-
- partment cables

 33A Connection between dashboard and right engine

35

- 68 compartment cables
 Connection between engine compartment and electronic injection cables
 Connection between dashboard housing and electronic injection cables
 Geographic services and the services cables
 Geographic services cables
 Geographic services and the services cables
 Geographic services
 Geographic services
- tic socket

- 96 100 Earth on carrier Earth on floor Connection between dashboard and right longitudinal ca
- (gnition switch
 LANCIA CODE control unit
 Switch signalling handbrake applied
 Connection between dashboard and right longitudinal ca Light diminer

1005

- 119D bles Connection between dashboard and right longitudinal ca Switch signalling seat belts not fastened
- 127 131 183 198 200 274 275 302 Earth on steering column support Relay for driver is side heater pad Relay for driver is side heater pad Servotronik electronic control unit Controlled damping suspension electronic control unit Connection between dashboard and air bag cables Air Bag control unit
- unit
 Connection between electronic automatic transmis
 soin and dashboard cables
 Timn on electronic automatic transmission gear selec
 for lever
 Connection between dashboard and anti-lock brakes Switch control unit
 Electronic automatic transmission gear selector control

318


nnection between dashboard and anti-lock brakes


344 320


401

- unit Diode connecting handbrake system/insufficient brake fluid level Electronic automatic transmission gear selector control
- 430 Fuel pump/Fuel gauge 150A maxifuse
- Ultrasound welding taped in cable foom

NZ n d HN 78C VB 85B V 78D C 103 GR 103 BV 78D 32B AV 104A BN 104D HV n d AN n d Connection between dashboard and left engine compartment cables BL 78C AR 78C LR 78A EV 22 GR n d C n d BR 31A AR 31A LR 31A AV 31A BN 31A HV 31A AN 12 VB 5







The cables in the wiring diagram are marked by a square


V 2000 - Update

44/8

LANCIA K 99 update


Wiring diagrams Electrical equipment


55



Electrical equipment

55






CN 76C

HR 76C GR 76C


H 76C


119C Connection between dashboard and right longitudinal cables



■ AG 183

RG 200B NG 200B





119D

■ The cables in the wiring diagram are marked by a square

Instrument panel connections Diesel version

23-

g 275

32A 100 101 328 430

N 136D LR n d h u AH

Gnd

N 97

VNnd RN 134

HN 78A

GN n d

RV 166A RV 487*

RG 136E

*B n d

LR 90

73C 344 73B

A 200

198

184

=()

Y-482

127

Component key

328 33A 40 440 442 446 460 58 61 61 62 63 7269 7269 738 32A Main connector block

Early for the connector block

Early feed

Ea Left front earth Battery

73C 30A fuse protecting ugnition switch
75 Junction unit (dashboard)
E1 Switch discharge relay
78 Instrument pamel
K Batter recharging warning light
K Batter recharging warning light
S Heater plugs warning light
S Heater plugs warning light
U Electronic rev counter
Y Electronic speedometer
W Electronic speedometer
S binfocenter control unit
88 Diagnostic socket
97 Earth on floor

of Allam control unit golden control unit 4.40 A starter plugs control unit 59 Heater plugs control unit 59 Heater plugs control unit 64 Potentionneter on accelerator pedal 64 Potentionneter on accelerator pedal 64 Potentionneter on accelerator pedal 68 The tase disease hiter reastance (PT C) 82 Heater disease hiter resistance (PT C) 84 Heater disease hiter resistance (PT C) 85 Heater disease hiter resistance (PT C) 86 Heater disease hiter resistance (PT C) 87 Fuel pumps respulsator 1980 Heater pedal 1980 Pedal

AR 200B

S 200B

SN 200A

MN 200A

MG 200A

2

Ultrasound welding taped in cable loom

tion cables
Engine services cables connection
Fuel pump electronic control unit
Secondary connector block
60A fuse protecting I G E control unit/junction unit

Timing sensor
Connection between dashboard and electronic injec

Electronic injection engine coolant temperature sensor

/ 5A fuse protecting electronic injection Electronic injectino system relay feed

V 2000 - Update

Print n 506 475/30

99 update

Electrical equipment

55

Component key

- 171 Additional brake lights warning light
- 174 Right rear light cluster on moving section
- 177 Left rear light cluster on moving section
- 178 Left rear earth
- 307 Automatic transmission acoustic warning cotnrol switch
- 318 Connection between electronc automatic transmission and dashboard cables
- 401 Electronic automatic transmission gear selector control unit
- 413 Connection to the solenoid valve unit
- 415 Gear selector position
- 416 Gear selector position
- 417 Engine rpm sensor
- 418 Vehicle speed sensor
- 420 Transmission fluid temperature sensor

Components not present in complete key



LANCIA k 98 update

Electrical equipment Components key

55.

3U96PL



55.

Components key

- Left front light cluster
- Left front earth
- Left front earth for anti-lock brakes (A.B.S.)
 - Left front brake pad wear sensor
- Left side direction indicator 9 ~
 - Battery
 - Main connector block
 - Earth on bodyshell
- Earth on side panel for anti-lock brakes (A.B.S.) 98
 - Button on bonnet lid for engaging an
 - ti-theft device
- 11 Compressor coupling for air conditioning 12 Insufficient brake fluid level sensor

- 13 Reversing lights switch 15 Starter motor 16 Spark plugs 17 1st Engine cooling fan 18 Engine cooling fan speed resistance
- Sensor on left front wheel for anti-lock brakes (A.B.S.) 9
- brake Connection between anti-lock 19A
- (A.B.S.) cable and sensor on left wheel
- 20 Alternator 21 Minimum engine oil level sensor
- Engine coolant temperature sender unit 22
- Sensor signalling minimum engine oil pressure 23
- Four stage pressure switch 26A
 - Right front earth 27 30 31
- Peripheral control unit (engine comp.) Dipped headlamps relay feed Right front light cluster
 - Horn relay feed E2
- Main beam headlamps relay feed Compressor coupling relay feed
- Engine cooling fan high speed relay feed Fog lights relay
- E7 Engine cooling fan low speed relay
- 32A Connection between dashboard and left Connection between dashboard and left engine compartment cables 32B
- engine compartment cables Connection between dashboard and right engine compartment cables 33A

- Anti-lock brakes electro-hydraulic control
 - Connection between engine compartment and electronic injection cables
- Heated Lambda sensor
- Earth for electronic injection
- Petrol vapour cut out solenoid valve Power earth
- Sensor on right front wheel for anti-lock Air flow meter 36 38 44 44 45 47
- (A.B.S.) cable and sensor on right wheel Connection between anti-lock brakes brakes (A.B.S.) 17A
- Electric fuel pump and heated Lambda sensor relay feed 49
 - Ignition coil
 - Ignition coil 52 53 55 56 57 58 59 59 50 60
- Ignition coil
- Ignition coil Ignition coil
 - anition coil

 - niectors

- 1st Detonation sensor
- 2nd Detonation sensor
- Engine coolant temperature sensor for
- electronic injection
 - Rpm sensor
 - Timing sensor
- Connection between dashboard and elec-Electronic injection cables connection 62 66 67 68
 - tronic injection cables
 - Engine services cable connection
 - Secondary connector block Fuel injection control unit 69 72 73 73A 73B
- 60A protective fuse for I.G.E. control unit / 80A fuse protecting rear services
- 73C 30A fuse protecting ignition switch / anjunction unit
- 74 80A fuse protecting peripheral control unit ti-theft device
 - (engine compartment)
 - Ignition discharge relay Junction unit (dashboard) E1 = 2 75
- Intermittent device for direction indicators / hazard warning lights
 - Timer for headlamp washer E3 Timer for head I.G.E. control unit
- 10A fuse protecting anti-lock brakes (A.B.S.) 76
- A Trailer direction indicator warning light Instrument panel
- Driver's side heated seat warning light

- Passenger's side heated seat warning B3
- Heated rear windscreen warning light Fog lights warning light

Rear fog lamps warning light Side lights warning light Instrument panel light bulbs

longitudinal cables Light dimmer

Connection between dashboard and left

Earth on carrier Earth on floor

96

- Exterior lights control unit 101
- ber plate lights C Control switch for dipped beam

B Control switch for side lights / num

- headlamps / main beam headlamps
- D Parking lights control switch
 E Ideogram lights control switch
 Steering column switch unit
 D Switch for direction indicators / park-

104

M Insufficient engine oil pressure warning N Handbrake/I.G.E. control unit warning O Insufficient brake fluid level warning P Anti-lock braking system failure warn-

light light

Battery recharging warning light Check summary warning light

Seat belts not fastened warning light

Main beam headlamps warning light

Dipped headlamps warning light

- E Main beam headlamps flasher button F Main beam headlamps control switch ing lights
 - - 104G Switch for rearscreen wash/wipe 105 Ignition switch 106 Immobilizer aerial 107 Anti-theft control unit 108 Immobilizer control unit 108D Distribution / mixture motor 109M Distribution / mixture motor 110 Vehicle interior air temperature sensor 111 Mixed air sensor 112 Mixed air sensor 2 113 Solar temperature sensor 113 Solar temperature sensor 117 Switch signalling handbrake applied

ing light (A.B.S.

T Voltmeter

- Vehicle interior air temperature sensor

U Electronic rev counter
V Fuel gauge
V1 Fuel reserve warning light
X Milometer/trip meter
X1 LANCIA-CODE failure warning light
Y Electronic tachometer

- Switch signalling handbrake applied
- 119A Connection between dashboard and right longitudinal cables

warning

Engine coolant overheating

Y1 S.C.S. switch unit W Water temperature gauge

Electronic automatic transmission gear

selection display Trip computer zeroing button

- 119B Connection between dashboard and right longitudinal cables
- 119C Connection between dashboard and
 - right longitudinal cables
- 119D Connection between dashboard and
- 120 Connection between dashboard and right front door cables
- right front door cables
- and signalling of right front door open and anti-theft device on Right front central locking geared motor
- Switch signalling seat belts not fastened 127

Motor for vertical adjustment of left rear C Motor for horizontal adjustment of left

view mirror

ω

A Motor for folding left rear view mirror

Left rear view mirror

Diagnostic socket

Single stage pressure switch (3000 i.e.)

Infocenter control unit Air recirculation motor

Climate control fan (Brushless) Power earth on dashboard

- Electrically operated sun roof end of trav-Timer for front courtesy light 128 1
 - Electrically op. sun roof control button el switch
 - Earth on steering column support Tailgate lock assembly

95 Left front central locking geared motor and

front door cables

signalling of left front door open and an-

90 Connection between dashboard and left

D Left rear view mirror heating resistance

rear view mirror

Tailgate locking/unlocking motor



|)) | transmission | | Phase transformer injector |
|------------|---|-----|--|
| 317 | between electronic auto. | 514 | Switch on clutch |
| | trans, and electronic injection cables | | Diode for signal inversion |
| 318 | Connection between electronic automatic | | Side Bag control unit |
| | transmission and dashboard cables | | Driver's Side Air Bag |
| 320 | selector lever with anti-lock brakes cable | | nassenger side Air bag Driver's satellite |
| | | | Passenger satellite |
| 334 | Connection between electronic injection | | Rain gutter connection with engine com- |
| 6 | | | partment cable |
| 040 | night from brake pag wear sensor | 2 | |
| 341 | Right side direction indicator 40A starter relay | Z. | Weiging taped in cable toom |
| 344 | | | |
| · • | ti-lock brakes cables (A.B.S.) | | |
| 345 | Right front earth | | |
| 3/4 | Diagnostic socket for anti-lock braking | | |
| 377 | | | |
| 422 | _ | | |
| | | | |
| 430 | - | | |
| | | | |
| 431 | | | |
| 432 | are locked 20A protective fuse janition switch relay | | |
|] } | feed | | |
| 434 | | | |
| 435 | Current socket relay | | |
| 436 | | | |
| 482 | | | |
| 488 | | | |
| 499 | | | |
| 200 | | | |
| 200 | | | |
| 502 | Sign sensors 7.5 fuse protecting Fiat-CODE | | |
| 503 | _ | | |
| | cable and automatic t | | |
| 504 | | | |
| L! | control unit | | |
| 202 | | | |
| | system | | |
| 507 | | | |
| 208 208 | Motorized actuator on butterfly casing 15A fuse protecting electronic injection | | |
| | system | | |
| 510 | 30A relay for infocenter control unit/ | | |
| 511 | | | |
| | | | |
| | | | |

Orange-Light blue Orange-White Orange-Black Yellow-Black Yellow-Blue Yellow-Red

Grey-Yellow

Grey-Black Grey-Red Grey-Green Blue-White Blue-Yellow Blue-Green Blue-Green Brown-White Brown-Black Black-Violet Red-White Red-Yellow Red-Sellow

Green-White Green-Black Green-Red Violet-White

3U99PL

Pink-Black

Violet Light blue-White Light blue-Yellow Light blue-Black Light blue-Violet White-Yellow White-Blue White-Black White-Black White-Red White-Red White-Coreen White-Coreen

Cable colour code

Light blue White Orange Yellow

Grey Blue Brown Black Red

Green

309891