

F I A T F I O R I N O / Q U B O



S O U N D S Y S T E M

# CONTENTS

INTRODUCTION .....	3	Balance adjustment .....	12
Advice .....	3	FADER adjustment .....	13
- Road safety .....	3	LOUDNESS function .....	13
- Reception conditions .....	3	Protection against theft .....	13
- Care and maintenance .....	4		
- Compact Disc .....	4	RADIO (Tuner) .....	14
Technical data .....	5	Introduction .....	14
		Selecting the frequency band .....	14
QUICK REFERENCE GUIDE .....	6	Presetting buttons .....	14
Steering wheel controls .....	9	Storing the last station heard .....	14
General .....	10	Automatic tuning .....	15
- Radio section .....	10	Manual tuning .....	15
- Compact Disc section .....	10	AUTOSTORE function .....	15
- MP3 CD section .....	10	Emergency alarm reception .....	16
- Audio section .....	10	EON function .....	16
		Stereophonic stations .....	16
FUNCTIONS AND ADJUSTMENTS .....	11	Menu .....	16
Turning the sound system on .....	11	- MENU button functions .....	16
Turning the sound system off .....	11	- AF SWITCHING function .....	17
Selecting Radio function.....	11	- TRAFFIC INFO function .....	17
Selecting CD function.....	11	- REGIONAL MODE function .....	18
Audio source memory function .....	11	- MP3 DISPLAY function .....	18
Volume adjustment .....	11	- SPEED VOLUME function.....	18
SPEED VOLUME function .....	11	- EXTERNAL AUDIO VOL function .....	19
MUTE/PAUSE function .....	12	- RADIO OFF function .....	19
Audio adjustments .....	12	- RESTORE DEFAULT function .....	19
Bass/Treble adjustment .....	12		

COMPACT DISC PLAYER .....	20
Introduction .....	20
Selecting the CD player .....	20
Loading/ejecting CD .....	20
Possible error messages .....	21
Display information .....	21
Select track .....	21
Fast forward/backward .....	21
Pause function .....	21
Protection against theft .....	22
- Entering the secret code .....	22
- Code Card .....	22
 MP3 CD PLAYER .....	 23
Introduction .....	23
MP3 mode .....	23
Display information .....	24
- ID3-TAG info display .....	24
Select next/previous directory .....	24
Protection against theft .....	24
 TROUBLESHOOTING .....	 25

# INTRODUCTION

The vehicle sound system, fitted with CD player (radio with Compact Disc player) or MP3 CD player (radio with MP3 CD player) has been designed in accordance with the special features of the passenger compartment, with a personalised design that blends with the style of the dashboard. The sound system cannot be adapted to other vehicles and for this reason it cannot be removed.

The radio is installed in a user-friendly position for the driver and passenger and the graphics on the front panel make location of the controls quick, facilitating use.

## ADVICE

### Road safety

You are advised to learn how to use the various radio functions (e.g.: storing stations) before starting to drive.

### Reception conditions

Reception conditions change constantly when driving. Reception may be disturbed by the presence of mountains, buildings or bridges particularly when far away from the station being listened to.

**IMPORTANT** When receiving traffic information, the volume may be higher than normal.



## WARNING

*Too high a volume when driving can put the driver's life at risk and that of other people. Therefore the volume should always be adjusted in such a way that it is always possible to hear the noises of the surrounding environment (e.g.: horns, ambulance, police sirens, etc.).*

## Care and maintenance

The radio structure ensures long operation with no need for particular maintenance. In the event of a fault, contact a Fiat Dealership.

To clean the front panel only use a soft, antistatic cloth. Cleaning and polishing products might spoil the surface.

### Compact Disc

Remember that dirt, marks or distortion on Compact Disc can cause skipping. To obtain optimum playing conditions we give the following advice:

- ❑ Only use Compact Discs which have the following brand:



- ❑ Carefully clean all Compact Discs of fingerprints and dust using a soft cloth. Support Compact Discs from the outer circumference and clean from the centre outwards;
- ❑ Never use chemical products for cleaning (e.g.: spray cans, antistatic or thinners) as they might damage the surface of Compact Discs;
- ❑ After use, put Compact Discs back in their container, to avoid marks or scratches that may cause skipping when playing;
- ❑ Do not expose Compact Discs to direct sunlight, high temperatures or damp for prolonged lengths of time to prevent them from bending;
- ❑ Do not stick labels or write on the recorded surface of Compact Discs.

To remove a Compact Disc from its container, press the centre and raise the disc carefully, holding it by the outer circumference.

Always hold Compact Discs by the outer circumference. Never touch the surface.

To remove fingerprints and dust, use a soft cloth starting from the centre of the Compact Disc outwards.

Do not use highly scratched, cracked, or distorted discs, etc. The use of these discs will involve malfunctioning or damage to the player.

For optimal playing use original CDs only. Regular operation is not guaranteed if using R/RW CDs not properly mastered and/or CDs with max. capacity higher than 650 MB.

**IMPORTANT** Do not use the protective sheets for CD in commerce or discs with stabilisers, etc. as they might get stuck in the internal mechanism and damage the disc.

**IMPORTANT** Should copy-protected CDs be used, then, few seconds may be required for playing them. Moreover, due to the proliferation of always new and different protection methods, it is not guaranteed that the CD player can play whatever protected disc. Copy protection is often indicated on the CD cover in small letters or hard to read characters. Usually it is indicated by writings like: "COPY CONTROL", "COPY PROTECTED", "THIS CD CANNOT BE PLAYED ON A PC/MAC", or it is identified by symbols like:



Protected discs (and their cover) very often are not marked with the audio CD identification symbol:



**IMPORTANT** The CD player can read most of the compression systems currently on sale (e.g.: LAME, BLADE, XING, FRAUNHOFER) however, due to the evolution of these systems, reading of all compression formats is not guaranteed.

**IMPORTANT** When loading a multi-session CD, only the first session will be played.

## TECHNICAL DATA

☐ Power: 4 x 30 W


### Front speakers

- ☐ n°2 tweeters located on rear mirror rim
- ☐ n°2 mid-woofers Ø130 mm located on the door

### Rear speakers (where provided)

- ☐ n°2 full-range speakers Ø100 mm located on rear shelf
- ☐ Anti-theft protection system
- ☐ Aerial

# QUICK GUIDE



F0T0016m

## AUDIO SECTION

- ☐ Loudness function
- ☐ Standard equalization
- ☐ Personal equalization
- ☐ Automatic volume changing according to car speed (SPEED VOLUME)
- ☐ MUTE function

## RADIO SECTION

- ☐ Traffic information reception (TA)
- ☐ Automatic storage of 6 stations in the dedicated FM band - FMT (AS – Auto-store)


## CD / MP3 SECTION




- ☐ Play / Pause
- ☐ Previous / next track selection
- ☐ FF / FR
- ☐ Previous / next directory selection

Button	GENERAL FUNCTIONS	Mode
<b>ON / OFF</b>	On	Brief knob pressing
	Off	Long knob pressing
	Volume adjustment	Knob rotation LH/RH


Button	GENERAL FUNCTIONS	Mode
<b>FM AS</b>	Radio band selection FM1, FM2, FM Autostore	Brief cyclic button pressing
<b>AM</b>	Radio band selection MW, LW	Brief cyclic button pressing
<b>CD</b>	Audio source selection (radio/CD)	Brief cyclic button pressing
<b>MUTE</b>	Volume on/off (MUTE / PAUSE)	Brief button pressing
<b>AUDIO</b>	Audio settings: bass (BASS), treble (TREBLE), right/left sound adjustment (BALANCE), front/rear sound adjustment (FADER)	Menu activation: brief button pressing Adjustment selection: press button ▲ or ▼ Value adjustment: press button ◀ or ▶
<b>MENU</b>	Advanced functions adjustment	Menu activation: brief button pressing Adjustment selection: press button ▲ or ▼ Value adjustment: press button ◀ or ▶



Button	RADIO FUNCTIONS	Mode
	Radio station tuning: • Automatic tuning • Manual tuning	Automatic tuning: press button ◀ or ▶ (long pressing for fast forward) Manual tuning: press button ▲ or ▼ (long pressing for fast forward)
1 2 3 4 5 6	Current radio station storage	Long button pressing respectively for preset/memories from 1 to 6
	Stored station recall	Brief button pressing respectively for preset/memories from 1 to 6

Button	CD FUNCTIONS	Mode
	CD ejection	Brief button pressing
	Previous/next track playback	Brief pressing on buttons ◀ or ▶
	CD track fast forward/backward	Long pressing on buttons ◀ or ▶
	Previous/next directory playback (for MP3 CD)	Brief pressing on buttons ▲ or ▼

**STEERING WHEEL CONTROLS**  
(where provided)



F0T0297m

Button	FUNCTION	Mode
	AudioMute on/off (with sound system on)	Brief button pressing
<b>+</b>	Volume up	Press button
<b>-</b>	Volume down	Press button
<b>SRC</b>	Radio frequency (FM1, FM2, FMT, MW, LW) and audio source (Radio - CD - MP3 - CD Changer) selection button	Press button
<b>Δ</b>	Radio: recall preset stations (1 to 6) CD player: select next track CD Changer: select next track	Press button
<b>▽</b>	Radio: recall preset stations (6 to 1) CD player: select previous track CD Changer: select previous track	Press button

## GENERAL

The sound system possesses the following functions:

### Radio section

- ☐ PLL tuning with FM/AM/MW/LW frequency bands;
- ☐ RDS (Radio Data System) with TA (traffic announcements) - TP (Program Type) - EON (Enhanced Other Network) - REG (Regional programmes);
- ☐ AF: alternative frequency search selection in RDS mode;
- ☐ emergency alarm presetting;
- ☐ automatic/manual station tuning;
- ☐ FM Multipath detector;
- ☐ manual storage of 30 stations: 18 in the FM band (6 in FM1, 6 in FM2, 6 in FMT), 6 in the MW band and 6 in the LW band;
- ☐ automatic storage (AUTOSTORE function) of 6 stations in FM band;
- ☐ SPEED VOLUME function: automatic volume adjustment with car speed;
- ☐ automatic Stereo/Mono switching.

## CD section

- ☐ Direct disc selection;
- ☐ Track selection (forward/backward);
- ☐ Fast forward/backward;
- ☐ CD Display function: displaying CD name/time elapsed from start of track;
- ☐ Playing audio CDs and R/RW CDs.



***On multimedia CDs in addition to sound tracks also data tracks are recorded. Playing one of these CDs may cause rustling and such a volume as to compromise road safety, as well as causing damage to the final stages and speakers.***

## CD MP3 section

- ☐ MP3-Info function (ID3-TAG);
- ☐ Directory selection (previous/next);
- ☐ Track selection (forward/backward);
- ☐ Fast forward/backward;
- ☐ MP3 CD data display: directory name, ID3-TAG info, time elapsed from start of track, file name);
- ☐ Playing audio CDs and R/RW CDs.

## Audio section

- ☐ Mute/Pause function;
- ☐ Soft Mute function;
- ☐ Loudness function;
- ☐ 7 band graphic equalizer;
- ☐ Separate bass/treble adjustment;
- ☐ Right/left channel balancing.

# FUNCTIONS AND ADJUSTMENTS

## TURNING THE SOUND SYSTEM ON

The set is switched on pressing briefly the button/knob ON/OFF.

When turning the sound system on, the volume level will be brought to 20 if it was set to over.

If the radio is turned on with the ignition key at STOP, it will turn off automatically after about 20 minutes. It is however possible to turn the radio on again for other 20 minutes by pressing the button/knob ON/OFF.

## TURNING THE SOUND SYSTEM OFF

Keep button/knob ON/OFF pressed.

## SELECTING RADIO FUNCTION

Pressing briefly and repeatedly button FM-AS it is possible to select the following functions in sequence:

☐ TUNER ("FM1", "FM2", "FMT");

Pressing briefly and repeatedly button AM it is possible to select the following functions in sequence:

☐ TUNER ("MW", "LW").

## SELECTING CD FUNCTION

Pressing briefly and repeatedly button CD it is possible to select the CD audio source (only if the Compact Disc is inserted);

## AUDIO SOURCE MEMORY FUNCTION

If while listening to a CD another function is selected (e.g.: the radio), playing is stopped and when the CD mode is resumed, it starts again from the point in which it was stopped.

If while listening to the radio another function is selected, when the Radio mode is resumed, it is tuned to the last station selected.

## VOLUME ADJUSTMENT

Adjust volume through button/knob ON/OFF.

If the volume level is changed during the broadcast of a traffic bulletin, the new setting is maintained only until the end of the bulletin.

## SPEED VOLUME FUNCTION

The SVC function makes it possible to automatically adapt the volume level to the speed of the car, increasing it as the speed increases to maintain the ratio with the noise level inside the passenger compartment.

See section MENU for activating/deactivating this function.

## MUTE /PAUSE FUNCTION (turning off the volume completely)

To switch on the Mute function, briefly press the button MUTE. Volume will gradually lower and the display will show the word "MUTE" (when in radio mode) or "PAUSE" (when in CD or CD-Changer mode).

To switch off the Mute function, press the button MUTE again. Volume will gradually become louder returning to the value set before switching on the Mute function.

Changing volume will deactivate the Mute function and the volume will be set to the new level selected.

With the Mute function on:

- ☐ if an emergency alarm or a traffic bulletin arrives with the TA function on, the message ignores the Mute function. The Mute function will be resumed at the end of the traffic announcement.

## AUDIO ADJUSTMENTS

The options proposed by the audio menu differ according to the audio source selected: AM/FM/CD/CDC.

To change Audio functions, press briefly button AUDIO. The display will show "BASS".

To scroll the Menu options, use buttons ▲ or ▼. To change the setting of the option selected, press buttons ◀ or ▶.

The display will show the current status of the function selected.

The functions controlled by the menu are the following:

- ☐ BASS (bass adjustment);
- ☐ TREBLE (treble adjustment);
- ☐ BALANCE (right/left balance);
- ☐ FADER (front/rear balance);
- ☐ LOUDNESS (LOUDNESS on/off);
- ☐ EQUALIZER (standard equalization activation and selection);
- ☐ USER EQUALISER (personal equalization setting).

## TONE ADJUSTMENT (bass/treble)

Proceed as follows:

- ☐ Use button ▲ or ▼ to select "BASS" or "TREBLE" in the AUDIO menu;
- ☐ press button ◀ or ▶ to increase/decrease the basses or trebles.

Pressing the buttons briefly the change is gradual by steps. Pressing longer, changing is faster.

## BALANCE ADJUSTMENT

Proceed as follows:

- ☐ Use button ▲ or ▼ to select "BALANCE" in the AUDIO menu;
- ☐ press button ◀ to increase the sound from the right speakers or button ▶ to increase the sound from the left speakers.

Pressing the buttons briefly the change is gradual by steps. Pressing longer, changing is faster.

Select "◀ 0 ▶" to set the same value for both right and left speakers.

## FADER ADJUSTMENT

Proceed as follows:

- ☐ Use button ▲ or ▼ to select “FADER” in the AUDIO menu;
- ☐ press button ◀ to increase the sound from the rear speakers or button ▶ to increase the sound from the front speakers.

Pressing the buttons briefly the change is gradual by steps. Pressing longer, changing is faster.

Select “◀ 0 ▶” to set the same value for both front and rear speakers.

## LOUDNESS FUNCTION

The Loudness function improves the sound volume when listening at low level, increasing the basses and trebles.

To switch the function on/off, use button ▲ or ▼ to select “LOUDNESS” in the AUDIO menu. The function condition (on or off) is shown on the display for few seconds by “LOUDNESS ON” or “LOUDNESS OFF”.

## PRESET/USER\*/CLASSIC/ROCK/JAZZ functions (equalizer on/off)

The integrated equalizer can be turned on or off. With the equalizer off, it is possible to change the sound settings only adjusting the bass (“BASS”) and treble tones (“TREBLE”), while activating the function makes it possible to adjust the sound curves.

To turn the equalizer off, select “PRESET” by means of button ◀ or ▶.

To turn the equalizer on, use button ◀ or ▶ to select one of the following options:

- ☐ “USER” (adjustment of the 7 equalizer bands that can be changed by the user);
- ☐ “CLASSIC” (predefined equalizer adjustment for best playing of classic music);
- ☐ “ROCK” (predefined equalizer adjustment for best playing of rock and pop music);
- ☐ “JAZZ” (predefined equalizer adjustment for best playing of jazz music).

When one of the equalizer settings is on, the display shows “EQ”.

## \*USER EQ SETTINGS function (only if the USER equalizer setting has been selected)

To set a personal equalizer adjustment, use button ▲ or ▼ to select USER and then press button ▼ for long.

The display shows a graph with 7 bars, where each bar represents a frequency. Choose the bar to be adjusted using button ◀ or ▶; the bar chosen starts to flash and it is possible to adjust it using button ▲ or ▼.

To store the new settings, press button AUDIO again. The display still shows “USER EQ SETTINGS”.

## ANTITHEFT PROTECTION

Refer to section “CD PLAYER”.

# RADIO (Tuner)

## INTRODUCTION

When the set is turned on the last function selected before turning off is played (Radio or CD).

To select the Tuner source while listening to another audio source, press briefly buttons FM or AM, according to the required frequency band.

When Tuner is on, the display will show the selected station name (RDS stations only) (or frequency), the frequency band (e.g.: FM1) and the preselection button number (e.g.: PI).

## SELECTING THE FREQUENCY BAND

If in the Tuner mode, briefly and repeatedly press button FM or AM to select the required frequency band.

Every time the button is pressed the following bands are selected in sequence:

- ☐ Pressing button FM: "FM1", "FM2", "FMT";
- ☐ Pressing button AM: , "MW" and "LW".

Each band is shown by the respective wording on the display.

The last station selected in the respective frequency band will be tuned.

The FM band is divided into sections: FM1, FM2 and FMT. The FMT reception band is reserved to the stations stored automatically with the AutoStore function.

## PRESETTING BUTTONS

The buttons with symbols from 1 to 6 make it possible to set the following pre-settings:

- ☐ 18 in the FM band (6 in FM1, 6 in FM2, 6 in FMT);
- ☐ 6 in the MW band;
- ☐ 6 in the LW band;

To call a preset station, choose the required frequency band and then press briefly the corresponding preset button (from 1 to 6).

Pressing the respective preset button for longer than 2 seconds will store the tuned station. Storing is confirmed by a beep.

## STORING THE LAST STATION HEARD

The radio automatically keeps in storage the last station heard for each reception band, which is then tuned when the radio is turned on or the reception band is changed.

## AUTOMATIC TUNING

Briefly press button ◀ or ▶ to start automatically searching the tuning for the next station that it is possible to receive in the direction chosen.

If button ◀ or ▶ is pressed for longer, quick searching takes place. When the button is released, the tuner stops on the next receivable station.

If the TA function is on (traffic information), the tuner only searches stations which broadcast traffic bulletins.

## MANUAL TUNING

This allows manual station searching in the chosen band.

Select the required frequency band and then press briefly and repeatedly button ▲ or ▼ to start searching in the chosen band. Pressing one of the buttons ▲ or ▼ longer obtains fast forward searching, which is stopped when the button is released.

## AUTOSTORE FUNCTION (automatic station storage)

To switch on the AutoStore function, keep button FM-AS pressed until receiving the confirmation beep. With this function the radio automatically stores the six stations with the strongest signal in decreasing order of intensity of the FMT frequency band.

**IMPORTANT** Activating the AutoStore function cancels the stations stored previously in the FMT band.

If the TA function is on (traffic information), only the stations that send traffic information will be stored.

During automatic storage the display shows “FM AST”.

To interrupt AutoStore press button FM-AS again: the radio will automatically tune to the station heard before activation of the AutoStore function.

At the end of the AutoStore function the radio automatically tunes on the first preset station in the FMT band stored on preset button 1.

On buttons numbered from 1 to 6, the stations are automatically stored that give a strong signal in that moment in the preset band.

Activating the AutoStore function in MW or LW bands will automatically select the FMT band where the function is then run.

**IMPORTANT** Sometimes the AutoStore function is unable to find 6 stations with a strong signal. In this case the previous stations will be stored on the free preset buttons.



## EMERGENCY ALARM RECEPTION

In the RDS mode the radio is set to receive emergency announcements in the case of exceptional circumstances or events that may cause general danger (earthquakes, floods, etc.), if they are broadcast by the station tuned.

This function is activated automatically and cannot be deactivated.

During emergency announcement the display will show the message "ALARM". During this announcement the volume will change as described for traffic announcements (see paragraph "TA FUNCTION").

## EON FUNCTION (Enhanced Other Network)

Certain countries have circuits which group together several stations enabled to broadcast traffic information. In this case the programme of the station being heard will be interrupted temporarily:

- ☐ to receive traffic information (only with TA function on);
- ☐ to listen to regional programmes every time these bulletins are given by one of the stations of the same circuits.

## STEREOPHONIC STATIONS

If the signal received is weak, the device switches automatically from Stereo to Mono.

## MENU

### MENU button functions

To activate the menu function, briefly press button MENU. The display shows the word "MENU".

To scroll the menu functions use button ▲ or ▼. To change the setting of the selected function use button ◀ or ▶.

The display will show the current status of the function selected.

The functions controlled by the menu are the following:

- ☐ AF SWITCHING (ON/OFF)
- ☐ TRAFFIC INFO (ON/OFF)
- ☐ REGIONAL MODE regional programmes (ON/OFF);
- ☐ MP3 DISPLAY (MP3 CD data display);
- ☐ SPEED VOLUME (automatic volume control in relation to speed);
- ☐ EXTERNAL AUDIO VOL (external audio sources control)
- ☐ RADIO OFF (System power off mode).
- ☐ RESTORE DEFAULT

To exit the menu function, press button MENU again.

## AF SWITCHING function (alternative frequency search)

Within the RDS system the radio can work in two different modes:

- ☐ “AF ON”: alternative frequency search on (the display shows “AF”);
- ☐ “AF OFF”: alternative frequency search off.

With “AF ON”, the radio is automatically tuned to the station with the strongest signal that is broadcasting the same programme. During the journey it will thus be possible to continue listening to the station chosen without having to change the frequency when changing area.

Of course, the station being listened to must be receivable in the area the car is crossing.

To turn the AF function on/off press button MENU, select “AF SWITCHING” and then ON/OFF. If the AF function has been turned on the display shows “AF”.

If the radio is working in the AM band, when the AF function is activated, it passes to the FM1 band on the last station selected.

## TRAFFIC INFO function (traffic information)

Certain stations in the FM band (FM1, FM2 and FMT) are enabled to also broadcast information about traffic conditions. In this case the display shows “TP”.

To turn the TA (traffic information) function on/off, briefly press button MENU, select “TRAFFIC INFO” and then ON/OFF.

**IMPORTANT** If the TA function (traffic information) is on, with CD, Telephone or Mute/Pause active: automatic station tuning will start.

With the TA function it is possible:

- ☐ to search only RDS stations that transmit in the FM band, enabled to broadcast traffic information;
- ☐ to receive traffic information although CD player are being used;
- ☐ to receive traffic information at a pre-defined minimum volume even with the radio volume off.

**IMPORTANT** In certain countries radio stations exist which, even if the TP function is on (the display shows “TP”), do not transmit traffic information.

If the radio is working in the AM band, when TA is activated, it passes to the FM1 band on the last station heard.

The volume with which the traffic bulletin is transmitted varies depending on the listening volume:

- ☐ listening volume below 20: traffic bulletin volume = 20 (fixed value);
- ☐ listening volume above 20: traffic bulletin volume = listening volume + 1.

If the volume is changed during a traffic bulletin the value is not shown on the display and the new value is kept only for the bulletin in progress.

When receiving traffic information the display will show message “TRAFFIC INFORMATION”.

The TA function is interrupted by pressing any sound system button.

## REGIONAL MODE function (regional broadcast reception)

Certain national broadcasters, at determine times of the day, transmit regional programmes which differ from region to region. This function makes it possible to tune in only on local stations (regional) (see paragraph "EON function").

Activate this function if you want to tune automatically to regional stations broadcasting in the selected band.

To turn the function on/off use button ◀ or ▶.

The display will show the current status of the function:

- ☐ "REGIONAL MODE: ON": function on.
- ☐ "REGIONAL MODE: OFF": function off.

If the function is off and a regional programme is tuned that works in a determine area and the car enters a different area, the regional station of the new area is received.

**IMPORTANT** If AF and REG are both active, when passing from one region to another the radio could not tune properly to a valid alternative frequency.

## MP3 CD DISPLAY (MP3 CD data display)

With this function it is possible to choose the information shown on the display, when listening to a MP3 CD.

This function can be selected only if a MP3 CD is loaded: in this event the display shows "MP3 DISPLAY".

To change the function use buttons ◀ or ▶.

The display shows the setting among the six possible:

- ☐ TITLE (track title, if ID3-TAG available)
- ☐ AUTHOR (track author, if ID3-TAG available)
- ☐ ALBUM (album title, if ID3-TAG available)
- ☐ DIR (directory name);
- ☐ FILENAME (MP3 file name);
- ☐ TIME (time elapsed from start of track).

## SPEED VOLUME function (volume changing with speed)

This function makes it possible to automatically adapt the volume level to the speed of the car, increasing it as the speed increases to maintain the ratio with the noise level inside the passenger compartment.

To turn the function on/off use button ◀ or ▶. The display will show the current status of the function:

- ☐ OFF: function off
- ☐ LOW: function on (low sensitivity)
- ☐ HIGH: function on (high sensitivity).

## EXTERNAL AUDIO VOL function

With this function it is possible to adjust (setting from 0 to 40) or exclude (OFF) external audio sources.

To turn this function on/off, use button ◀ or ▶.

The display will show the current status of the function:

- ☐ “EXTERN FUNCTION OFF”: function off.
- ☐ “EXTERN VOLUME: 23”: function on with volume level 23.

## RADIO OFF function (system power on/off mode)

This function enables to switch off the sound system according to two different modes. To turn the function on use button ◀ or ▶.

The display will show the selected mode:

- ☐ “00 MIN ”: deactivation dependent on ignition key. Sound system will switch off automatically when turning the ignition key to STOP;
- ☐ “20 MIN ”: deactivation independent of ignition key. After having turned the ignition key to STOP the sound system will stay on for 20 minutes max.

**IMPORTANT** When the sound system is switched off automatically after turning the ignition key to STOP (for both immediate or 20-minute delayed power off), it will switch on automatically turning the ignition key to MAR. If the sound system has been switched off pressing the button ON/OFF, when turning the key to MAR it will stay off.

## RESTORE DEFAULT function

This function enables to restore default settings. Options available are the following:

- ☐ NO: no restore;
- ☐ YES: restore default settings. During this operation the display will show the message “RESTORING”. At the end of this operation, the audio source will not be changed and the previous situation is displayed.

# COMPACT DISC PLAYER

INTRODUCTION

QUICK  
GUIDE

FUNCTIONS AND  
ADJUSTMENTS

RADIO

COMPACT  
DISC PLAYER

MP3 CD  
PLAYER

## INTRODUCTION

This section only describes CD player operation variants: as concerns sound system operation, refer to section “FUNCTIONS AND ADJUSTMENTS”.

## SELECTING THE COMPACT DISC PLAYER

To turn on the Compact Disc player integrated in the set, proceed as follows:

☐ insert a CD with the set on: the first track will be played;

or

☐ if a CD is already inserted, turn the set on and press briefly button CD to select “CD”: the last heard track will be played.

For optimal playing use only original CDs. When using R/RW CDs, use top quality CDs mastered at the as low as possible speed.

## INSERTING/EJECTING A CD

To insert the CD set it gently in place to activate the powered loading system, which will position it correctly.

Press button ▲, with the device on, to operate the powered CD eject system. After ejection, the source heard before playing the CD will return.

If CD is not ejected, the device will reload it automatically after about 20 seconds and then will set to Tuner (Radio).

CD cannot be ejected if the device is off.

Inserting the ejected CD without fully removing it from the slot, the tuner will not change the source to CD.

## POSSIBLE ERROR MESSAGES

If the CD inserted is illegible (e.g.: CD-ROM inserted, CD not inserted properly or reading error), the display will show the message “CD ERROR” for about 2 seconds.

The CD is then ejected and the previous source before CD was selected returns.

## DISPLAY INFORMATION

When the CD player is working, the display shows the following information which means:

“T05”: shows the number of the track on the CD;

“03:42”: shows the time elapsed since the start of the track (if the corresponding Menu function is on);

## SELECT TRACK (forward/backward)

Briefly press button ◀ to play the previous track and button ▶ to play the next one. Tracks are played in sequence: after the last track, the first one will be played and vice versa.

If playing the track started more than 3 seconds ago, pressing briefly button ◀ the track is played again from the start. In this case if wanting to play the previous track, press the button twice consecutively.

## FAST FORWARD/BACKWARD

Keep button ▶ pressed to move the track selected forward at high speed and keep button ◀ pressed to move it quickly backward. Fast forward/backward is stopped once the button is released.

## PAUSE FUNCTION

To pause the CD player, press button MUTE. The display will show “PAUSE”.

To resume playing the track, press button MUTE again.

The pause function is deactivated changing the sound source.

## ANTITHEFT PROTECTION

The radio is fitted with an antitheft protection system based on the exchange of information between the radio and the electronic control unit (Body Computer) installed on the car.

This system warrants the highest level of security and prevents entry of the secret code every time the radio supply is disconnected.

If the result of the check is positive, the set starts working, whereas if the comparison codes are not the same or if the electronic control unit (Body Computer) is replaced, the device informs the user of the need to enter the secret code according to the procedure described in the following paragraph.

## Entering the secret code

When turning the sound system on (in the event of code request), the display will show the word "CODE" for about 2 seconds, followed by four dashes "----".

The secret code comprises four figures from 1 to 6, each corresponding to one of the dashes.

To enter the first digit of the code, press the corresponding key of the preset stations (from 1 to 6). Enter the other code digits in the same way.

If the four figures are not entered within 20 seconds, the display shows the word "CODE" for 2 seconds and then four dashes "----". This is not to be considered as an incorrect code entry.

After entering the fourth digit (within 20 seconds), the radio starts working.

If a wrong code is entered, the radio sounds a beep, the display shows the word "CODE" for 2 seconds and then four dashes "----" to warn the user that it is necessary to enter the correct code.

Every time the user enters a wrong code, the waiting time increases gradually (1 min, 2 min, 4 min, 8 min, 16 min, 30 min, 1 h, 2 h, 4 h, 8 h, 16 h, 24 h) until reaching a maximum of 24 hours. The waiting time will be shown on the display with the word "WAIT". When this goes off it is possible to start the new code entry procedure.

## Code Card

This is the document that certifies possession of the radio. The Code Card contains the radio model, serial number and secret code.

**IMPORTANT** Keep the Code Card carefully to be able to give the related data to the competent authorities in the event of theft.

# MP3 CD PLAYER

## INTRODUCTION

This section only describes MP3 CD player operation variants: as concerns sound system operation, refer to section "FUNCTIONS AND ADJUSTMENTS".

NOTE MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson multimedia.

## MP3 MODE

In addition to standard audio CDs, the sound system can also play audio files in MP3 format. Sound system will operate as described in the previous section ("Sound system with Compact Disc player") when inserting a conventional audio CD.

For optimal playing use only top quality CDs mastered at a speed as low as possible.

MP3 CD files are structured by directories, with sequential lists of all directories containing MP3 tracks (directories and sub-directories are all brought to the same level), directories not containing MP3 tracks cannot be selected.

Technical data and operating conditions for MP3 files are as follows:

- ☐ adopted CD-ROM shall be mastered according to ISO9660 Standard;
- ☐ music files shall be renamed as ".mp3" otherwise they cannot be played;
- ☐ sampling frequencies are: 44.1 kHz, stereo (96 to 320 kbit/s) - 22.05 kHz, mono or stereo (32 to 80 kbit/s);
- ☐ it is possible to play variable bit-rate tracks (files).

**IMPORTANT** Characters: blank, ' (apostrophe), ( and ) (open and closed brackets) are not admitted in MP3 track names. When sampling MP3 CD you must not use these characters to name files otherwise the sound system will not be able to play it.



## DISPLAY INFORMATION

### ID3-TAG info display

In addition to time elapsed, directory name and file name, also ID3-TAG info relevant to track Title, Artist, Author (see section "MP3 DISPLAY FUNCTION") are displayed.

The MP3 directory name shown on the display corresponds to the name with which the directory is stored on the CD, followed by an asterisk.

Example of full MP3 directory name: BEST OF \*.

If you want to display one ID3-TAG info (Title, Artist, Album) and the track being played has no ID3-TAG info then, the file name will be displayed.

## SELECT NEXT/PREVIOUS DIRECTORY

Press button ▲ to select the next directory or press button ▼ to select the previous one. The name of the new selected directory will be shown on the display.

Directories are selected in cyclic sequence: after the last directory the first one is selected and vice versa.

If no other directory/track is selected in the following 2 seconds, the first track in the new directory will be played.

If the last track in the currently selected directory is played, the next will then be played.

## PROTECTION AGAINST THEFT

Refer to section "COMPACT DISC PLAYER".

# TROUBLESHOOTING

## OVERVIEW

### Low volume

The Fader function shall only be set to “F” (front), to prevent sound system output power reduction and volume muting if the Fader level set is = R+9.

### Required source cannot be selected

No CD loaded. Load the CD or the MP3 CD you want to play.

## COMPACT DISC PLAYER

### CD not played

Loaded CD is dirty. Clean the CD.  
Loaded CD is scratched. Try to play another CD.

### Required CD cannot be loaded

Another CD is already loaded. Press button ▲ and remove the CD.

## MP3 FILE READING

### Skipping when reading MP3 files

Loaded CD is scratched or dirty. Clean the CD as described in paragraph “CD” in section “INTRODUCTION”.

### MP3 track length not displayed correctly

In certain cases (due to recording) MP3 track length can be displayed incorrectly.

[illegible]





The data contained in this publication is intended merely as a guide. FIAT reserves the right to modify the models and versions described in this booklet at any time for technical and commercial reasons.

If you have any further questions please consult your FIAT dealer.

Printed in recycled paper without chlorine.